



HMS Industrial Networks AB
Web: www.anybus.com
Tel: +46 35 172900
E-mail: info@hms.se



SP1324, rev 2.01, Mar 2012. AB9001.



www.anybus.com

Module Front

USB port:
Connect a PC to the USB port for firmware upgrades.

PROFIBUS Connector (DB9F):

Pin no	Description
1	Shield
3	B-Line
4	RTS
5	GND bus
6	+5 V bus out
8	A-Line
2, 7, 9	Not connected
Housing	PE



LEDs: X-gateway and Modbus-TCP Network

No	Name	Indication	Meaning
1	(GW) Gateway Status	Off Alternating red/green Flashing green Green Running Flashing red Red	Power off Missing configuration Idle Running Invalid configuration Fatal error
5	(SD) SD Card Status	Green Flashing red	Accessing SD card Failure
6	(MTCP) Modbus-TCP Status	Off Green Flashing red Red	No Modbus-TCP network communication Communicating with Modbus-TCP network Transaction error or timeout Fatal error
7	(LA1, LA2) Ethernet Link 1 & 2	Off Flashing green	No link Receiving/transmitting Ethernet packets at 100 Mbit
8		Flashing yellow	Receiving/transmitting Ethernet packets at 10 Mbit

LEDs: PROFIBUS Network

No	Name	Indication	Meaning
2	Not used	-	-
3	(OP) Network Status	Off Flashing green Green Flashing red (1 flash) Flashing red (2 flashes)	Not online Online, clear Online, data exchange Parameterization error Configuration error
4	(ST) Module Status	Off Green Red	Not initialized Initialized Fatal error


Installation and Startup Summary

- Attach the X-gateway to the DIN-rail.
- Connect the module to the PROFIBUS network.
- Connect the module to the Modbus-TCP network.
- Turn on the module (+24 V DC).
- Download IPconfig from www.anybus.com to a PC.
- Connect the PC to the module via one of the Modbus-TCP connectors (Ethernet crossover cable not necessary). Use IPconfig to identify the IP address of the module on the network using its Modbus-TCP MAC address (found at the bottom of the module).
- Start a web browser (IE 7.0 or 8.0), enter the IP address and connect to the X-gateway's web interface.
- Configure the module using the web configuration pages.
- Include the Anybus X-gateway GSD file in the PROFIBUS configuration tool (download the GSD file from www.anybus.com).
- Configure and start the PROFIBUS network.

Top View



Power:
(+) +24 V DC
(-) GND
(⊕) PE

SD card slot:



Bottom View

Modbus-TCP Connector:



Pin no	Description
1	TX+
2	TX-
3	RX+
6	RX-
4, 5, 7, 8	Termination

Technical Details

- Power supply:
24 V DC (-15% to +20%).
- Power consumption:
Maximum power consumption is 300 mA @ 24 V DC.
Typical power consumption: 150 mA @ 24 V DC.
- Surrounding temperature
70 degrees C @ 225 mA @ 24 V DC.
- Protective Earth (PE):
Internal connection to PE via DIN-rail or, if the DIN-rail can not be used, via the power connector.
Note: Make sure the DIN-rail is properly connected to PE.

For maintenance and support, contact the HMS support department. Contact information is available at the support pages on www.anybus.com.

Further information and documents about this product can be found at the product pages on www.anybus.com.

