



**ASSEMBLY INSTRUCTIONS:**

- A) Layout plinth (item 1) on floor, square plinth, mark and drill 5/16" (8.0mm) dia. hole for 3/8 LAG bolts (4) - not supplied.
- B) LAG assembled plinth to floor. Assure that plinth is square and accurate.
- C) Align pedestal (item 2) over top opening in plinth unit. Side edges of pedestal and plinth are to be flush.
- D) Front and rear holes in pedestal bottom are to be aligned with mounting holes on plinth top.
- E) Once the pedestal is seated properly on the plinth remove cover plates on plinth.
- F) Assemble using 3/8-16 x .75 hex head bolt and 3/8 nuts and lock washers (item 3, 4, & 5) provided. Torque bolts and nuts to 180 in/lbs

**Note:** When assembling total modular system build from the floor up for assembly ease. Plinth > Pedestal > Terminal

PARTS LIST		
ITEM No.	DESCRIPTION	QTY
1	PLINTH	1
2	BASE UNIT	1
3	3/8-16 X 3/4 HEX CAP SCREW	4
4	3/8-16 LOCK WASHER	4
5	3/8-16 HEX NUT	4

