

DEVICE LIST 1/20/2010

Total Manufacturers 164

Total Devices 24506

ACT	ACTRANS	ADVANCE_GROUP	ALI(Acer)
ALL 24 SERIES(ISP)	AMI SEMICONDUCTOR	ALLIANCE	ALTERA
AMD	AMPLUS_FLASH	ARTSCHIP	AMIC
ANACHIP	ASI	ASP	ASAHI KASEI(AKM)
ASD	ATMEL W&M	ATMEL-CUSTOMER	ATC
ATMEL	BENCHMARO	BRIGHT	AUSTIN
BELLING-SYSTRON	CERAMATE	CHINA CORE	CATALYST
CELESTICA	CHIPSWINNER	CORERIVER	CHINGIS
CHIPCON	CYPRESS	DALLAS	CWI
CYGNAL	EFST	ELECTRONIC ARRAYS	DENSE-PAC
DEUTRON	EMTC	EON	ESMT
EM	EXEL	FAIRCHILD	
EXCELSEMI		FAIRCHILD	
FORCE TECHNOLOGIES		FUJITSU	GENCORE
Fremont Micro Devices		GIGADEVICE	GOAL
GENERAL(GI)	GENERIC	HARRIS	HITACHI
GREENWICH	HAIER	HYNIX	HYUNDAI
HOLTEK	HONGKONG	ICSI	ICT
ICE	IMT	INTEL	INTELSIL
IDT	K-LINE	LATTICE	LG Semicon
ISSI	MACRONIX	MAXIM	MAXWELL
LINKSMART	MICON	MICROCHIP	MICRON
MEGAWIN	MITSUBISHI	MOSEL-VITELIC	MOSTEK
MICRONAS	NANTRONICS	NEC	NEXFLASH
MOTOROLA	NSC	NTE	NUMONYX
NJRC	NXP	OKI	ON Semiconductor
NUVOTON	PHILIPS	PJ	PMC
PFLASH(MSTAR)	PTC	QIXIN	Quick Pulse
PSS	RATO	RAYDIUM	RENESAS
RAMTRON	ROCKWELL	ROHM	SAIFUN
RICOH	SANYO	SEEQ	SEIKO
SAMSUNG	SHARP	SIEMENS	SIGNETICS
SGS-THOMSON		SIMTEK	SMOS
Silicon Laboratories	SPACE ELECTRONICS[Sei]	ST	SPANSION
SONY	SST	SYNCMOS	STC
SSSC	SUNPLUS	TEKMOS	SYNERTEK
SUMMIT	TECHCODE	TI	TEMIC
SYNTEK		TURBO IC	TMC
Terra Semiconductor	TOSHIBA	WELTREND	UMC
TOPRO	VLSI	WINBOND	
UTRON	WHITE ELECTRONIC DESIGNS	XILINX	WSI
XELTEK	XICOR	ZILOG	XILINX-CUSTOMER
YMC	YSS		ZMD

ACT**E(E) PROM/FRAM/NVRAM**

93LC46(08bit)	93LC46(08bit)@SOIC8	[(SA602A)]
93LC46(16bit)	93LC46(16bit)@SOIC8	[(SA602A)]
93LC56(08bit)	93LC56(08bit)@SOIC8	[(SA602A)]
93LC56(16bit)	93LC56(16bit)@SOIC8	[(SA602A)]
93LC66(08bit)	93LC66(08bit)@SOIC8	[(SA602A)]
93LC66(16bit)	93LC66(16bit)@SOIC8	[(SA602A)]
93LC86(08bit)	93LC86(08bit)@SOIC8	[(SA602A)]
93LC86(16bit)	93LC86(16bit)@SOIC8	[(SA602A)]

ACTRANS**E(E) PROM/FRAM/NVRAM**

AC25010@SOIC8 [(SA602A)]	AC25512@SOIC8 [(SA602A)]
AC25LC010@SOIC8 [(SA602A)]	AC25LC512@SOIC8 [(SA602A)]
AC39LV010@PLCC32 [(SA015A1T)]	AC39LV010@VSOP32 [(SA620)]
AC39LV020@PLCC32 [(SA015A1T)]	AC39LV020@VSOP32 [(SA620)]
AC39LV040@PLCC32 [(SA015A1T)]	AC39LV040@VSOP32 [(SA620)]
AC39LV080@TSOP40 [(SA409T)]	AC39LV088@TSOP48 [(SA247-B005)]
AC39LV512@PLCC32 [(SA015A1T)]	AC39LV512@VSOP32 [(SA620)]
AC39VF800@TSOP48 [(SA247-B005)]	

ADVANCE GROUP

E(E) PROM/FRAM/NVRAM

AF24BC01	AF24BC01@SOIC8 [(SA602A)]
AF24BC01@TSOP8 [(SA026)]	AF24BC02
AF24BC02@SOIC8 [(SA602A)]	AF24BC02@TSOP8 [(SA026)]
AF24BC04	AF24BC04@SOIC8 [(SA602A)]
AF24BC04@TSOP8 [(SA026)]	AF24BC08
AF24BC08@SOIC8 [(SA602A)]	AF24BC08@TSOP8 [(SA026)]
AF24BC16	AF24BC16@SOIC8 [(SA602A)]
AF24BC16@TSOP8 [(SA026)]	AF24C128
AF24C128@SOIC8 [(SA602A)]	AF24C128@TSOP8 [(SA026)]
AF24C256	AF24C256@SOIC8 [(SA602A)]
AF24C256@TSOP8 [(SA026)]	AF24C32
AF24C32@SOIC8 [(SA602A)]	AF24C32@TSOP8 [(SA026)]
AF24C64	AF24C64@SOIC8 [(SA602A)]
AF24C64@TSOP8 [(SA026)]	AF93C46(08bit)
AF93C46(08bit)@SOIC8 [(SA602A)]	AF93C46(08bit)@TSOP8 [(SA026)]
AF93C46(16bit)	AF93C46(16bit)@SOIC8 [(SA602A)]
AF93C46(16bit)@TSOP8 [(SA026)]	AF93C56(08bit)
AF93C56(08bit)@SOIC8 [(SA602A)]	AF93C56(08bit)@TSOP8 [(SA026)]
AF93C56(16bit)	AF93C56(16bit)@SOIC8 [(SA602A)]
AF93C56(16bit)@TSOP8 [(SA026)]	AF93C66(08bit)
AF93C66(08bit)@SOIC8 [(SA602A)]	AF93C66(08bit)@TSOP8 [(SA026)]
AF93C66(16bit)	AF93C66(16bit)@SOIC8 [(SA602A)]
AF93C66(16bit)@TSOP8 [(SA026)]	AF93C86(08bit)
AF93C86(08bit)@SOIC8 [(SA602A)]	AF93C86(08bit)@TSOP8 [(SA026)]
AF93C86(16bit)	AF93C86(16bit)@SOIC8 [(SA602A)]
AF93C86(16bit)@TSOP8 [(SA026)]	

MICROCONTROLLER

A1000A2	A1000A2@PLCC44 [(SA244)]
A1000A2@PQFP44 [(SA245A)]	A1000A3
A1000A3@PLCC44 [(SA244)]	A1000A3@PQFP44 [(SA245A)]
AG1001@SDIP42 [(SA028)]	AG89F516
AG89F516@PLCC44 [(SA244)]	AG89F516@PQFP44 [(SA245A)]
AG89F54	AG89F54@PLCC44 [(SA244)]
AG89F54@PQFP44 [(SA245A)]	AG89P51
AG89P51@PLCC44 [(SA244)]	AG89P51@PQFP44 [(SA675)]
AG89P516	AG89P516@PLCC44 [(SA244)]
AG89P516@PQFP44 [(SA675)]	AG89P51A
AG89P51A@PLCC44 [(SA244)]	AG89P51A@PQFP44 [(SA675)]
AG89P52	AG89P52@PLCC44 [(SA244)]
AG89P52@PQFP44 [(SA675)]	

ALI(Acer)

E(E) PROM/FRAM/NVRAM

M8720	M8720@PLCC32 [(SA015A1T)]
-------	---------------------------

MICROCONTROLLER

M6759	M6759@PLCC44 [(SA244)]
M6759@TQFP44 [(SA245A)]	

ALL 24 SERIES(ISP)

E (E) PROM/FRAM/NVRAM

24C01(ISP) [ISP-HEADER01]	24C02(ISP) [ISP-HEADER01]
24C04(ISP) [ISP-HEADER01]	24C08(ISP) [ISP-HEADER01]
24C128(ISP) [ISP-HEADER01]	24C16(ISP) [ISP-HEADER01]
24C256(ISP) [ISP-HEADER01]	24C32(ISP) [ISP-HEADER01]
24C64(ISP) [ISP-HEADER01]	

ALLIANCE**E (E) PROM/FRAM/NVRAM**

AS29F200@PSOP44 [(SA638-B006)]	AS29F200@TSOP48 [(SA247-B005)]
AS29F200B@PSOP44 [(SA638-B006)]	AS29F200B@TSOP48 [(SA247-B005)]
AS29F200T@PSOP44 [(SA638-B006)]	AS29F200T@TSOP48 [(SA247-B005)]

ALTERA**E (E) PROM/FRAM/NVRAM**

EPC1(LC)@PLCC20 [(SA001A)]	EPC1(LI)@PLCC20 [(SA001A)]
EPC1(PC)	EPC1(PI)
EPC1064(LC)@PLCC20 [ordering number is marked above]	EPC1064(LI)@PLCC20 [ordering number is marked above]
EPC1064(LI)@PLCC20 [ordering number is marked above]	EPC1064(PI)
EPC1064(PC)	EPC1064(PI)
EPC1213(LC)@PLCC20 [ordering number is marked above]	EPC1213(LI)@PLCC20 [ordering number is marked above]
EPC1213(LI)@PLCC20 [ordering number is marked above]	EPC1213(PI)
EPC1213(PC)	EPC1213(PI)
EPC1441(LC)@PLCC20 [(SA001A)]	EPC1441(LI)@PLCC20 [(SA001A)]
EPC1441(PC)	EPC1441(PI)
EPC1441(TC)@TQFP32 [(SA663)]	EPC1441(TI)@TQFP32 [(SA663)]
EPC2(LC)@PLCC20 [(SA001A)]	EPC2(LI)@PLCC20 [(SA001A)]
EPC2(TC)@TQFP32 [(SA663)]	EPC2(TI)@TQFP32 [(SA663)]
EPCS16SI16@SOIC16 [(SA404)]	EPCS16SI8N@SOIC8 [(SA602A)]
EPCS1SI8@SOIC8 [(SA602A)]	EPCS4SI8@SOIC8 [(SA602A)]
EPCS64SI16@SOIC16 [(SA404)]	

PLD

EP310	EP310@PLCC20 [(SA001A)]
EP320	EP320@PLCC20 [(SA001A)]
EP330	EP330@PLCC20 [(SA001A)]
EP600	EP600@PLCC28 [(SA008A)]
EP600@SOIC24 [(SA404)]	EP600I
EP600I@PLCC28 [(SA008A)]	EP600I@SOIC24 [(SA404)]
EP610	EP610@PLCC28 [(SA008A)]
EP610@SOIC24 [(SA404)]	EP610A
EP610A@PLCC28 [(SA008A)]	EP610A@SOIC24 [(SA404)]
EP610I	EP610I@PLCC28 [(SA008A)]
EP610I@SOIC24 [(SA404)]	EP610T
EP610T@PLCC28 [(SA008A)]	EP610T@SOIC24 [(SA404)]
EP630	EP630@PLCC28 [(SA008A)]
EP630@SOIC24 [(SA404)]	EP900
EP900@PLCC44 [(SA244)]	EP900I
EP900I@PLC44 [(SA244)]	EP910
EP910@PLCC44 [(SA244)]	EP910A
EP910A@PLCC44 [(SA244)]	EP910I
EP910I@PLCC44 [(SA244)]	EP910T
EP910T@PLCC44 [(SA244)]	

AMD**E (E) PROM/FRAM/NVRAM**

1736	1736@SOIC8 [(SA602A)]
1765	1765@SOIC8 [(SA602A)]
AM25FL005D@SOIC8 [(SA602A)]	AM25FL005D@USON8 [(SA683)]
AM25FL010D@SOIC8 [(SA602A)]	AM25FL010D@USON8 [(SA683)]
AM25FL016A@SOIC16 [(SA404)]	
AM25FL016A@SOIC16(ISP) [ISP-HEADER01]	

```

AM25FL016A@WSON8 [(SA684)]
AM25FL016A@WSON8(ISP) [ISP-HEADER01]
AM25FL020D@SOIC8 [(SA602A)] AM25FL020D@USON8 [(SA683)]
AM25FL032A@SOIC16 [(SA404)]
AM25FL032A@SOIC16(ISP) [ISP-HEADER01]
AM25FL032A@WSON8 [(SA684)]
AM25FL032A@WSON8(ISP) [ISP-HEADER01]
AM25FL040D@SOIC8 [(SA602A)] AM25FL040D@USON8 [(SA683)]
AM25FL080D@SOIC8 [(SA602A)] AM25FL080D@USON8 [(SA683)]
AM27128 AM27128(DC)
AM27128(DC)@PLCC32 [(SA015A1T)] AM27128@PLCC32 [(SA015A1T)]
AM27128A AM27128A(F)
AM27128A(F)@PLCC32 [(SA015A1T)] AM27128A(PC)
AM27128A(PC)@PLCC32 [(SA015A1T)] AM27128A@PLCC32 [(SA015A1T)]
AM2716 AM2716B
AM27256 AM27256@PLCC32 [(SA015A1T)]
AM27256AP AM27256AP@PLCC32 [(SA015A1T)]
AM27256F AM27256F@PLCC32 [(SA015A1T)]
AM27256PC AM27256PC@PLCC32 [(SA015A1T)]
AM2732 AM2732A
AM2732B AM27512
AM27512@PLCC32 [(SA015A1T)] AM27512DC
AM27512DC@PLCC32 [(SA015A1T)] AM27512F
AM27512F@PLCC32 [(SA015A1T)] AM27512PC
AM27512PC@PLCC32 [(SA015A1T)] AM27513
AM2764 AM2764@PLCC32 [(SA015A1T)]
AM2764A AM2764A(DC)
AM2764A(DC)@PLCC32 [(SA015A1T)] AM2764A(DCB)
AM2764A(DI) AM2764A(DIB)
AM2764A(F) AM2764A(F)@PLCC32 [(SA015A1T)]
AM2764A(JC) AM2764A(LC)
AM2764A(LCB) AM2764A(LE)
AM2764A(LEB) AM2764A(PC)
AM2764A(PC)@PLCC32 [(SA015A1T)] AM2764A@PLCC32 [(SA015A1T)]
AM27C010 AM27C010@PLCC32 [(SA015A1T)]
AM27C020@PLCC32 [(SA015A1T)] AM27C020
AM27C040 AM27C020@TSOP32 [(SA410T)]
AM27C040@TSOP32 [(SA410T)] AM27C040@PLCC32 [(SA015A1T)]
AM27C080@PLCC32 [(SA015A1T)] AM27C080
AM27C100 AM27C080@TSOP32 [(SA410T)]
AM27C100@TSOP32 [(SA410T)] AM27C100@PLCC32 [(SA015A1T)]
AM27C1024 AM27C1024
AM27C128 AM27C128
AM27C128@PLCC32 [(SA015A1T)] AM27C2048
AM27C2048@PLCC44 [(SA244)] AM27C2048@TSOP40 [(SA409T)]
AM27C256 AM27C256(F)
AM27C256(F)@PLCC32 [(SA015A1T)] AM27C256(PC)
AM27C256(PC)@PLCC32 [(SA015A1T)] AM27C256@PLCC32 [(SA015A1T)]
AM27C400 AM27C400@PLCC44 [(SA244)]
AM27C4096 AM27C4096@PLCC44 [(SA244)]
AM27C512 AM27C512(P)
AM27C512(P)@PLCC32 [(SA015A1T)] AM27C512@PLCC32 [(SA015A1T)]
AM27C64 AM27C64@PLCC32 [(SA015A1T)]
AM27H010 AM27H010@PLCC32 [(SA015A1T)]
AM27H010@TSOP32 [(SA410T)] AM27H256
AM27H256@PLCC32 [(SA015A1T)] AM27HB010
AM27HB010@PLCC32 [(SA015A1T)] AM27HB010@TSOP32 [(SA410T)]
AM27LV010 AM27LV010@PLCC32 [(SA015A1T)]
AM27LV010@TSOP32 [(SA410T)] AM27LV010B
AM27LV010B@PLCC32 [(SA015A1T)] AM27LV010B@TSOP32 [(SA410T)]
AM27LV020 AM27LV020@PLCC32 [(SA015A1T)]
AM27LV020@TSOP32 [(SA410T)] AM27LV020B
AM27LV020B@PLCC32 [(SA015A1T)] AM27LV020B@TSOP32 [(SA410T)]
AM2816A AM2817A
AM2817A@PLCC32 [(SA015A1T)] AM2817A@SOIC28 [(SA404)]
AM2864A AM2864A(E)
AM2864A(E)@PLCC32 [(SA015A1T)] AM2864A@PLCC32 [(SA015A1T)]
AM2864B AM2864B(E)
AM2864B(E)@PLCC32 [(SA015A1T)] AM2864B@PLCC32 [(SA015A1T)]
AM28F001 AM28F001@PLCC32 [(SA015A1T)]
AM28F001@TSOP32 [(SA410T)] AM28F010
AM28F010@PLCC32 [(SA015A1T)] AM28F010@TSOP32 [(SA410T)]
AM28F010A AM28F010A@PLCC32 [(SA015A1T)]
AM28F010A@TSOP32 [(SA410T)] AM28F020
AM28F020@PLCC32 [(SA015A1T)] AM28F020@TSOP32 [(SA410T)]
AM28F020A AM28F020A@PLCC32 [(SA015A1T)]
AM28F020A@TSOP32 [(SA410T)] AM28F256
AM28F256@PLCC32 [(SA015A1T)] AM28F256@TSOP32 [(SA410T)]
AM28F256A AM28F256A@PLCC32 [(SA015A1T)]
AM28F256A@TSOP32 [(SA410T)] AM28F512
AM28F512(F) AM28F512(F)@PLCC32 [(SA015A1T)]

```

AM28F512(F)@TSOP32 [(SA410T)]	AM28F512@PLCC32 [(SA015A1T)]
AM28F512@TSOP32 [(SA410T)]	AM28F512A
AM28F512A(F)	AM28F512A(F)@PLCC32 [(SA015A1T)]
AM28F512A(F)@TSOP32 [(SA410T)]	AM28F512A@PLCC32 [(SA015A1T)]
AM28F512A@TSOP32 [(SA410T)]	
AM29DL400BB@PSOP44 [(SA638-B006)]	
AM29DL400BB@TSOP48 [(SA247-B005)]	
AM29DL400BT@PLCC44 [(SA638-B006)]	
AM29DL400BT@TSOP48 [(SA247-B005)]	
AM29DL800B@PSOP44 [(SA638-B006)]	AM29DL800B@TSOP48 [(SA247-B005)]
AM29DL800BB@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29DL800BB@PSOP44 [(SA638)]	
AM29DL800BB@TSOP48 [(SA247-B005)]	
AM29DL800BT@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29DL800BT@PSOP44 [(SA638)]	
AM29DL800BT@TSOP48 [(SA247-B005)]	
AM29DL800T@PSOP44 [(SA638-B006)]	AM29DL800T@TSOP48 [(SA247-B005)]
AM29F002B	AM29F002B@PLCC32 [(SA015A1T)]
AM29F002B@TSOP32 [(SA410T)]	AM29F002BB
AM29F002BB@PLCC32 [(SA015A1T)]	AM29F002BB@TSOP32 [(SA410T)]
AM29F002BT	AM29F002BT@PLCC32 [(SA015A1T)]
AM29F002BT@TSOP32 [(SA410T)]	AM29F002NB
AM29F002NB@PLCC32 [(SA015A1T)]	AM29F002NB@TSOP32 [(SA410T)]
AM29F002NBB	AM29F002NBB@PLCC32 [(SA015A1T)]
AM29F002NBB@TSOP32 [(SA410T)]	AM29F002NBT
AM29F002NBT@PLCC32 [(SA015A1T)]	AM29F002NBT@TSOP32 [(SA410T)]
AM29F002NT	AM29F002NT@PLCC32 [(SA015A1T)]
AM29F002NT@TSOP32 [(SA410T)]	AM29F002T
AM29F002T@PLCC32 [(SA015A1T)]	AM29F002T@TSOP32 [(SA410T)]
AM29F004BB@PLCC32 [(SA015A1T)]	AM29F004BB@TSOP32 [(SA410T)]
AM29F004BT@PLCC32 [(SA015A1T)]	AM29F004BT@TSOP32 [(SA410T)]
AM29F010	AM29F010@PLCC32 [(SA015A1T)]
AM29F010@TSOP32 [(SA410T)]	AM29F010A
AM29F010A@PLCC32 [(SA015A1T)]	AM29F010A@TSOP32 [(SA410T)]
AM29F010B	AM29F010B@PLCC32 [(SA015A1T)]
AM29F010B@TSOP32 [(SA410T)]	AM29F016@PSOP44 [(SA638)]
AM29F016@TSOP40 [(SA409T)]	AM29F016@TSOP48 [(SA247-B005)]
AM29F016B(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016B@PSOP44 [(SA638)]	AM29F016B@TSOP40 [(SA409T)]
AM29F016B@TSOP48 [(SA247-B005)]	
AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016D@PSOP44 [(SA638)]	AM29F016D@TSOP40 [(SA409T)]
AM29F016D@TSOP48 [(SA247-B005)]	AM29F017B@TSOP48 [(SA247-B005)]
AM29F017D@TSOP40 [(SA409T)]	AM29F017D@TSOP48 [(SA247-B005)]
AM29F032B@PSOP44 [(SA638)]	AM29F032B@TSOP40 [(SA409T)]
AM29F040	AM29F040@PLCC32 [(SA015A1T)]
AM29F040@TSOP32 [(SA410T)]	AM29F040A
AM29F040A@PLCC32 [(SA015A1T)]	AM29F040A@TSOP32 [(SA410T)]
AM29F040B	
AM29F040B(Reverse)@TSOP32 [(SA410T)]	
AM29F040B@PLCC32 [(SA015A1T)]	AM29F040B@TSOP32 [(SA410T)]
AM29F080@PSOP44 [(SA638)]	AM29F080@TSOP40 [(SA409T)]
AM29F080B@PSOP44 [(SA638)]	AM29F080B@TSOP40 [(SA409T)]
AM29F100BE@PSOP44 [(SA638-B006)]	AM29F100BE@TSOP48 [(SA247-B005)]
AM29F100BS@PSOP44 [(SA638-B006)]	AM29F100BS@TSOP48 [(SA247-B005)]
AM29F100TE@PSOP44 [(SA638-B006)]	AM29F100TE@TSOP48 [(SA247-B005)]
AM29F100TS@PSOP44 [(SA638-B006)]	AM29F100TS@TSOP48 [(SA247-B005)]
AM29F160DB@TSOP48 [(SA247-B005)]	AM29F160DT@TSOP48 [(SA247-B005)]
AM29F200AB@PSOP44 [(SA638-B006)]	AM29F200AB@TSOP48 [(SA247-B005)]
AM29F200AT@PSOP44 [(SA638-B006)]	AM29F200AT@TSOP48 [(SA247-B005)]
AM29F200BB@PSOP44 [(SA638-B006)]	AM29F200BB@TSOP48 [(SA247-B005)]
AM29F200BE@PSOP44 [(SA638-B006)]	AM29F200BE@TSOP48 [(SA247-B005)]
AM29F200BS@PSOP44 [(SA638-B006)]	AM29F200BS@TSOP48 [(SA247-B005)]
AM29F200BT@PSOP44 [(SA638-B006)]	AM29F200BT@TSOP48 [(SA247-B005)]
AM29F200TE@PSOP44 [(SA638-B006)]	AM29F200TE@TSOP48 [(SA247-B005)]
AM29F200TS@PSOP44 [(SA638-B006)]	AM29F200TS@TSOP48 [(SA247-B005)]
AM29F400AB@PSOP44 [(SA638-B006)]	AM29F400AB@TSOP48 [(SA247-B005)]
AM29F400AT@PSOP44 [(SA638-B006)]	AM29F400AT@TSOP48 [(SA247-B005)]
AM29F400BB@PSOP44 [(SA638-B006)]	AM29F400BB@TSOP48 [(SA247-B005)]
AM29F400BBE@PSOP44 [(SA638-B006)]	
AM29F400BBE@TSOP48 [(SA247-B005)]	
AM29F400BBF@PSOP44 [(SA638-B006)]	
AM29F400BBF@TSOP48 [(SA247-B005)]	
AM29F400BBS@PSOP44 [(SA638-B006)]	
AM29F400BBS@TSOP48 [(SA247-B005)]	
AM29F400BE@PSOP44 [(SA638-B006)]	AM29F400BE@TSOP48 [(SA247-B005)]
AM29F400BF@PSOP44 [(SA638-B006)]	AM29F400BF@TSOP48 [(SA247-B005)]
AM29F400BS@PSOP44 [(SA638-B006)]	AM29F400BS@TSOP48 [(SA247-B005)]
AM29F400BT@PSOP44 [(SA638-B006)]	AM29F400BT@TSOP48 [(SA247-B005)]
AM29F400BTE@PSOP44 [(SA638-B006)]	
AM29F400BTE@TSOP48 [(SA247-B005)]	

```

AM29F400BTF@PSOP44 [(SA638-B006)]
AM29F400BTF@TSOP48 [(SA247-B005)]
AM29F400BTS@PSOP44 [(SA638-B006)]
AM29F400BTS@TSOP48 [(SA247-B005)]
AM29F800B@PSOP44 [(SA638-B006)]
AM29F800BB@PSOP44 [(SA638-B006)]
AM29F800BBF@PSOP44 [(SA638-B006)]
AM29F800BBF@TSOP48 [(SA247-B005)]
AM29F800BF@PSOP44 [(SA638-B006)]
AM29F800BT@PSOP44 [(SA638-B006)]
AM29F800BTF@PSOP44 [(SA638-B006)]
AM29F800BTF@TSOP48 [(SA247-B005)]
AM29F800T@PSOP44 [(SA638-B006)]
AM29F800TB@PSOP44 [(SA638-B006)]
AM29F800TF@PSOP44 [(SA638-B006)]
AM29LL800B@TSOP48 [(SA247-B005)]
AM29LL800BB@TSOP48 [(SA247-B005)]
AM29LL800BT@TSOP48 [(SA247-B005)]
AM29LL800T@TSOP48 [(SA247-B005)]
AM29LV001BB@TSOP32 [(SA410T)]
AM29LV001BT@TSOP32 [(SA410T)]
AM29LV002B@TSOP40 [(SA409T)]
AM29LV002BT@TSOP40 [(SA409T)]
AM29LV004B@TSOP40 [(SA409T)]
AM29LV004BT@TSOP40 [(SA409T)]
AM29LV004T@TSOP40 [(SA409T)]
AM29LV008B@TSOP40 [(SA409T)]
AM29LV008BT@TSOP40 [(SA409T)]
AM29LV010B@TSOP32 [(SA410T)]
AM29LV020B@PLCC32 [(SA015A1T)]
AM29LV033C@TSOP40 [(SA409T)]
AM29LV040B@PLCC32 [(SA015A1T)]
AM29LV040E@PLCC32 [(SA015A1T)]
AM29LV040J@PLCC32 [(SA015A1T)]
AM29LV081@TSOP40 [(SA409T)]
AM29LV116BB@TSOP40 [(SA409T)]
AM29LV116DB@TSOP40 [(SA409T)]
AM29LV200B@PSOP44 [(SA638-B006)]
AM29LV200BB@PSOP44 [(SA638-B006)]
AM29LV200BB@TSOP48 [(SA247-B005)]
AM29LV200BE@PSOP44 [(SA638-B006)]
AM29LV200BE@TSOP48 [(SA247-B005)]
AM29LV200BF@PSOP44 [(SA638-B006)]
AM29LV200BF@TSOP48 [(SA247-B005)]
AM29LV200BS@PSOP44 [(SA638-B006)]
AM29LV200BS@TSOP48 [(SA247-B005)]
AM29LV200BT@PSOP44 [(SA638-B006)]
AM29LV200BT@TSOP48 [(SA247-B005)]
AM29LV200T@PSOP44 [(SA638-B006)]
AM29LV200TE@PSOP44 [(SA638-B006)]
AM29LV200TE@TSOP48 [(SA247-B005)]
AM29LV200TF@PSOP44 [(SA638-B006)]
AM29LV200TF@TSOP48 [(SA247-B005)]
AM29LV200TS@PSOP44 [(SA638-B006)]
AM29LV200TS@TSOP48 [(SA247-B005)]
AM29LV400B@PSOP44 [(SA638-B006)]
AM29LV400BB@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29LV400BB@PSOP44 [(SA638-B006)]
AM29LV400BB@TSOP48 [(SA247-B005)]
AM29LV400BT@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29LV400BT@PSOP44 [(SA638-B006)]
AM29LV400BT@TSOP48 [(SA247-B005)]
AM29LV400T@PSOP44 [(SA638-B006)]
AM29LV800B@PSOP44 [(SA638-B006)]
AM29LV800BB@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800BB@PSOP44 [(SA638-B006)]
AM29LV800BB@TSOP48 [(SA247-B005)]
AM29LV800BT@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800BT@PSOP44 [(SA638-B006)]
AM29LV800BT@TSOP48 [(SA247-B005)]
AM29LV800DB(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800DB(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29LV800DB@PSOP44 [(SA638)]
AM29LV800DB@TSOP48 [(SA247-B005)]
AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29LV800DT@PSOP44 [(SA638)]
AM29LV800DT@TSOP48 [(SA247-B005)]
AM29LV800T@PSOP44 [(SA638-B006)]
AM9716
AM29F800B@TSOP48 [(SA247-B005)]
AM29F800BB@TSOP48 [(SA247-B005)]
AM29F800BF@TSOP48 [(SA247-B005)]
AM29F800BT@TSOP48 [(SA247-B005)]
AM29F800T@TSOP48 [(SA247-B005)]
AM29F800TB@TSOP48 [(SA247-B005)]
AM29F800TF@TSOP48 [(SA247-B005)]
AM29LV001BB@PLCC32 [(SA015A1T)]
AM29LV001BT@PLCC32 [(SA015A1T)]
AM29LV002@TSOP40 [(SA409T)]
AM29LV002BB@TSOP40 [(SA409T)]
AM29LV004B@PSOP44 [(SA638)]
AM29LV004BB@TSOP40 [(SA409T)]
AM29LV004T@PSOP44 [(SA638)]
AM29LV008B@PSOP44 [(SA638)]
AM29LV008BB@TSOP40 [(SA409T)]
AM29LV008T@PSOP44 [(SA638)]
AM29LV010B@PLCC32 [(SA015A1T)]
AM29LV017B@TSOP40 [(SA409T)]
AM29LV020B@TSOP32 [(SA410T)]
AM29LV033MU@TSOP40 [(SA409T)]
AM29LV040B@TSOP32 [(SA410T)]
AM29LV040E@TSOP32 [(SA410T)]
AM29LV040J@TSOP32 [(SA410T)]
AM29LV081B@TSOP40 [(SA409T)]
AM29LV116BT@TSOP40 [(SA409T)]
AM29LV116DT@TSOP40 [(SA409T)]
AM29LV200B@TSOP48 [(SA247-B005)]
AM29LV400B@TSOP48 [(SA247-B005)]
AM29LV400T@TSOP48 [(SA247-B005)]
AM29LV800B@TSOP48 [(SA247-B005)]
AM29LV800T@TSOP48 [(SA247-B005)]
AM9732

```

AM9732A
AM9764@PLCC32 [(SA015A1T)]

AM9764

PLD

PALC16L8Q	PALC16L8Q@PLCC20 [(SA001A)]
PALC16L8Z	PALC16L8Z@PLCC20 [(SA001A)]
PALC16R4Q	PALC16R4Q@PLCC20 [(SA001A)]
PALC16R4Z	PALC16R4Z@PLCC20 [(SA001A)]
PALC16R6Q	PALC16R6Q@PLCC20 [(SA001A)]
PALC16R6Z	PALC16R6Z@PLCC20 [(SA001A)]
PALC16R8Q	PALC16R8Q@PLCC20 [(SA001A)]
PALC16R8Z	PALC16R8Z@PLCC20 [(SA001A)]
PALCE16V8H	PALCE16V8H@PLCC20 [(SA001A)]
PALCE16V8H@SOIC20 [(SA404)]	PALCE16V8Q
PALCE16V8Q@PLCC20 [(SA001A)]	PALCE16V8Q@SOIC20 [(SA404)]
PALCE16V8Z	PALCE16V8Z@PLCC20 [(SA001A)]
PALCE16V8Z@SOIC20 [(SA404)]	PALCE20V8H
PALCE20V8H@PLCC28 [(SA008A)]	PALCE20V8H@SOIC24 [(SA404)]
PALCE20V8Q	PALCE20V8Q@PLCC28 [(SA008A)]
PALCE20V8Q@SOIC24 [(SA404)]	PALLV16V8
PALLV16V8@PLCC20 [(SA001A)]	PALLV16V8@SOIC20 [(SA404)]
PALLV16V8Z	PALLV16V8Z@PLCC20 [(SA001A)]
PALLV16V8Z@SOIC20 [(SA404)]	

MICROCONTROLLER

AM87C51	AM87C51@PLCC44 [(SA244)]
AM87C51@TQFP44 [(SA245A)]	AM87C521
AM87C521@PLCC44 [(SA244)]	AM87C521@TQFP44 [(SA245A)]
AM87C541	AM87C541@PLCC44 [(SA244)]
AM87C541@TQFP44 [(SA245A)]	

AMI SEMICONDUCTOR

E(E) PROM/FRAM/NVRAM

N256S0818HDA	N256S0818HDA@SOIC8 [(SA602A)]
N256S0818HDA@TSSOP8 [(SA026)]	N256S0830HDA
N256S0830HDA@SOIC8 [(SA602A)]	N256S0830HDA@TSSOP8 [(SA026)]
N64S0818HDA	N64S0818HDA@SOIC8 [(SA602A)]
N64S0818HDA@TSSOP8 [(SA026)]	N64S0830HDA
N64S0830HDA@SOIC8 [(SA602A)]	N64S0830HDA@TSSOP8 [(SA026)]

AMIC

E(E) PROM/FRAM/NVRAM

A25L010	A25L010[150mil]@SOP8 [(SA602A)]
A25L010[209mil]@SOP8 [(SA605A)]	A25L016
A25L016@SOP8 [(SA023A)]	A25L020
A25L020[150mil]@SOP8 [(SA602A)]	A25L020[209mil]@SOP8 [(SA605A)]
A25L032	A25L032@SOP8 [(SA023A)]
A25L040	A25L040@QFN8 [(SA683)]
A25L040@SOP16 [(SA404)]	A25L040@SOP8 [(SA602A)]
A25L05P(Bottom)	A25L05P(Bottom)@QFN8 [(SA683)]
A25L05P(Bottom)[150mil]@SOP8 [(SA602A)]	
A25L05P(Bottom)[209mil]@SOP8 [(SA605A)]	A25L05P(Top)@QFN8 [(SA683)]
A25L05P(Top)	
A25L05P(Top)[150mil]@SOP8 [(SA602A)]	
A25L05P(Top)[209mil]@SOP8 [(SA605A)]	A25L080@QFN8 [(SA683)]
A25L080	A25L080@SOP8 [(SA023A)]
A25L080@SOP16 [(SA404)]	A25L10P(Bottom)@QFN8 [(SA683)]
A25L10P(Bottom)	
A25L10P(Bottom)[150mil]@SOP8 [(SA602A)]	
A25L10P(Bottom)[209mil]@SOP8 [(SA605A)]	A25L10P(Top)@QFN8 [(SA683)]
A25L10P(Top)	
A25L10P(Top)[150mil]@SOP8 [(SA602A)]	
A25L10P(Top)[209mil]@SOP8 [(SA605A)]	
A25L16P(Bottom)@QFN8 [(SA683)]	
A25L16P(Bottom)@QFN8(ISP) [ISP-HEADER01]	
A25L16P(Bottom)@SOP16 [(SA404)]	

```

A25L16P(Bottom)@SOP16(ISP) [ISP-HEADER01]
A25L16P(Bottom)@SOP8 [(SA023A)]
A25L16P(Bottom)@SOP8(ISP) [ISP-HEADER01]
A25L16P(Top)@QFN8 [(SA683)]
A25L16P(Top)@QFN8(ISP) [ISP-HEADER01]
A25L16P(Top)@SOP16 [(SA404)]
A25L16P(Top)@SOP16(ISP) [ISP-HEADER01]
A25L16P(Top)@SOP8 [(SA023A)]
A25L16P(Top)@SOP8(ISP) [ISP-HEADER01]
A25L20P(Bottom)
A25L20P(Bottom)[150mil]@SOP8 [(SA602A)]
A25L20P(Bottom)[209mil]@SOP8 [(SA605A)]
A25L20P(Top)
A25L20P(Top)[150mil]@SOP8 [(SA602A)]
A25L20P(Top)[209mil]@SOP8 [(SA605A)]
A25L40P(Bottom Boot)
A25L40P(Bottom Boot)@QFN8 [(SA683)]
A25L40P(Bottom Boot)@SOP16 [(SA404)]
A25L40P(Bottom Boot)@SOP8 [(SA602A)]
A25L40P(Top Boot)
A25L40P(Top Boot)@QFN8 [(SA683)]
A25L40P(Top Boot)@SOP16 [(SA404)]
A25L40P(Top Boot)@SOP8 [(SA602A)]
A25L42P(Bottom Boot)
A25L42P(Bottom Boot)@QFN8 [(SA683)]
A25L42P(Bottom Boot)@SOP16 [(SA404)]
A25L42P(Bottom Boot)@SOP8 [(SA602A)]
A25L42P(Top Boot)
A25L42P(Top Boot)@QFN8 [(SA683)]
A25L42P(Top Boot)@SOP16 [(SA404)]
A25L42P(Top Boot)@SOP8 [(SA602A)]
A25L512
A25L512[150mil]@SOP8 [(SA602A)]
A25L512[209mil]@SOP8 [(SA605A)]
A25L80P
A25L80P@QFN8 [(SA683)]
A25L80P@SOP16 [(SA404)]
A25L80P@SOP8 [(SA023A)]
A25L82P(Bottom Boot)
A25L82P(Bottom Boot)@QFN8 [(SA683)]
A25L82P(Bottom Boot)@SOP16 [(SA404)]
A25L82P(Bottom Boot)@SOP8 [(SA023A)]
A25L82P(Top Boot)
A25L82P(Top Boot)@QFN8 [(SA683)]
A25L82P(Top Boot)@SOP16 [(SA404)]
A25L82P(Top Boot)@SOP8 [(SA023A)]
A25LS080
A25LS080@QFN8 [(SA683)]
A25LS080@SOP16 [(SA404)]
A25LS080@SOP8 [(SA023A)]
A27020
A27020@PLCC32 [(SA015A1T)]
A27020L
A27020L@TSOP32 [(SA410T)]
A27020L@PLCC32 [(SA015A1T)]
A275308
A275308@PLCC32 [(SA015A1T)]
A276308
A276308(E)@PLCC32 [(SA015A1T)]
A276308(E)@SOIC28 [(SA404)]
A276308@PLCC32 [(SA015A1T)]
A276308@SOIC28 [(SA404)]
A276308A
A276308A(L)@PLCC32 [(SA015A1T)]
A276308A(L)@SOIC28 [(SA404)]
A276308A@PLCC32 [(SA015A1T)]
A276308A@SOIC28 [(SA404)]
A277308
A277308@PLCC32 [(SA015A1T)]
A277308A
A277308A@PLCC32 [(SA015A1T)]
A278308
A278308@PLCC32 [(SA015A1T)]
A278308A
A278308A(L)@PLCC32 [(SA015A1T)]
A278308A@SOIC28 [(SA015A1T)]
A279308
A279308@PLCC32 [(SA015A1T)]
A290011T
A290011T@PLCC32 [(SA015A1T)]
A290011U
A290011U@TSOP32 [(SA410T)]
A290011U@PLCC32 [(SA015A1T)]
A290011U@PLCC32 [(SA015A1T)]
A29001T
A29001T@PLCC32 [(SA015A1T)]
A29001U
A29001U@TSOP32 [(SA410T)]
A29001U@PLCC32 [(SA015A1T)]
A290021T
A290021T@PLCC32 [(SA015A1T)]
A290021U
A290021U@TSOP32 [(SA410T)]
A290021U@PLCC32 [(SA015A1T)]
A29002T
A29002T@PLCC32 [(SA015A1T)]
A29002U
A29002U@TSOP32 [(SA410T)]
A29002U@PLCC32 [(SA015A1T)]
A29010
A29010@PLCC32 [(SA015A1T)]
A29010@TSOP32 [(SA410T)]
A29040
A29040@PLCC32 [(SA015A1T)]
A29040A
A29040A@PLCC32 [(SA015A1T)]
A29040B
A29040B@TSOP32 [(SA410T)]
A29040B@PLCC32 [(SA015A1T)]
A29400TM@PSOP44 [(SA638)]
A29400TM@PSOP44 [(SA638)]
A29400UM@PSOP44 [(SA638)]
A29400UM@PSOP44 [(SA638)]
A29400UV@TSOP48 [(SA247-B005)]
A29400UV@TSOP48 [(SA247-B005)]
A29512
A29512@PLCC32 [(SA015A1T)]
A29512A
A29512A@TSOP32 [(SA410T)]
A29512A@PLCC32 [(SA015A1T)]
A29800TM@PSOP44 [(SA638)]
A29800TM@PSOP44 [(SA638)]
A29800TV@TSOP48 [(SA247-B005)]
A29800TV@TSOP48 [(SA247-B005)]

```


A29800UM@PSOP44 [(SA638)]	A29800UV@TSOP48 [(SA247-B005)]
A29L004ATL@PLCC32 [(SA015A1T)]	A29L004ATV@TSOP32 [(SA410T)]
A29L004ATW@TSOP40 [(SA409T)]	A29L004ATY@VSOP32 [(SA620)]
A29L004AUL@PLCC32 [(SA015A1T)]	A29L004AUV@TSOP32 [(SA410T)]
A29L004AUW@TSOP40 [(SA409T)]	A29L004AUY@VSOP32 [(SA620)]
A29L004T@PLCC32 [(SA015A1T)]	A29L004T@TSOP32 [(SA410T)]
A29L004T@TSOP40 [(SA409T)]	A29L004T@VSOP32 [(SA620)]
A29L004U@PLCC32 [(SA015A1T)]	A29L004U@TSOP32 [(SA410T)]
A29L004U@TSOP40 [(SA409T)]	A29L004U@VSOP32 [(SA620)]
A29L008ATV@TSOP40 [(SA409T)]	A29L008AUV@TSOP40 [(SA409T)]
A29L008T@TSOP40 [(SA409T)]	A29L008U@TSOP40 [(SA409T)]
A29L040	A29L040@PLCC32 [(SA015A1T)]
A29L040@TSOP32 [(SA410T)]	A29L040@VSOP32 [(SA620)]
A49LF004@PLCC32 [(SA015A1T)]	A49LF004@VSOP32 [(SA620)]
A49LF004M@PLCC32 [(SA015A1T)]	A49LF004M@VSOP32 [(SA620)]
A49LF040ATL@PLCC32 [(SA015A1T)]	A49LF040ATX@VSOP32 [(SA620)]
A49LF040ATY@VSOP32 [(SA620)]	A49LF040TL@PLCC32 [(SA015A1T)]
A49LF040TX@VSOP32 [(SA620)]	A50FW040@PLCC32 [(SA015A1T)]
A50FW040@VSOP32 [(SA620)]	A50FW040M@PLCC32 [(SA015A1T)]
A50FW040M@VSOP32 [(SA620)]	A50LPW040@PLCC32 [(SA015A1T)]
A50LPW040@TSOP32 [(SA410T)]	A617308
A617308@TSOP32 [(SA410T)]	A61L5308
A61L5308@TSOP28 [(SA430T)]	A623308(M)
A623308(R)@TSOP28 [(SA430T)]	A623308(V)@TSOP28 [(SA430T)]
A625308(M)	A625308(R)@TSOP28 [(SA430T)]
A625308(V)@TSOP28 [(SA430T)]	A62L256
A62L256(M)	A62L256(R)@TSOP28 [(SA430T)]
A62L256(V)@TSOP28 [(SA430T)]	A62S6308(M)
A62S6308(X)@TSOP32 [(SA410T)]	A62S7308A(M)
A62S7308A(X)@TSOP32 [(SA410T)]	A62S8308A(M)
A62S8308A(X)@TSOP32 [(SA410T)]	A62W5308(M)
A62W5308(R)@TSOP28 [(SA430T)]	A62W5308(V)@TSOP28 [(SA430T)]

ANACHIP

E(E) PROM/FRAM/NVRAM

27CX010	27CX010@PLCC32 [(SA015A1T)]
27CX010@TSOP32 [(SA410T)]	27CX161
27CX162	27CX256
27CX321	27CX322
27CX641	27CX642
93C46	93C46@SOIC8 [(SA602A)]
93C46A	93C46A@SOIC8 [(SA602A)]
93C56A	93C56A@SOIC8 [(SA602A)]
93C66A	93C66A@SOIC8 [(SA602A)]
93CX46	93CX46@SOIC8 [(SA602A)]
93CX56	93CX56@SOIC8 [(SA602A)]
93CX66	93CX66@SOIC8 [(SA602A)]
AM24LC02	AM24LC02@SOIC8 [(SA602A)]
AM24LC02@TSSOP8 [(SA026)]	AM24LC04
AM24LC04@SOIC8 [(SA602A)]	AM24LC04@TSSOP8 [(SA026)]
AM24LC08	AM24LC08@SOIC8 [(SA602A)]
AM24LC08@TSSOP8 [(SA026)]	AM24LC16
AM24LC16@SOIC8 [(SA602A)]	AM24LC16@TSSOP8 [(SA026)]
AM24LC21	AM24LC21@SOIC8 [(SA602A)]
AM24LC21@TSSOP8 [(SA026)]	AM24LC21B
AM24LC21B@SOIC8 [(SA602A)]	AM24LC21B@TSSOP8 [(SA026)]
AM93LC46(08bit)	AM93LC46(08bit)@SOIC8 [(SA602A)]
AM93LC46(08bit)@TSOP8 [(SA026)]	AM93LC46(16bit)
AM93LC46(16bit)@SOIC8 [(SA602A)]	AM93LC46(16bit)@TSOP8 [(SA026)]
AM93LC56(08bit)	AM93LC56(08bit)@SOIC8 [(SA602A)]
AM93LC56(08bit)@TSOP8 [(SA026)]	AM93LC56(16bit)
AM93LC56(16bit)@SOIC8 [(SA602A)]	AM93LC56(16bit)@TSOP8 [(SA026)]
AM93LC66(08bit)	AM93LC66(08bit)@SOIC8 [(SA602A)]
AM93LC66(08bit)@TSOP8 [(SA026)]	AM93LC66(16bit)
AM93LC66(16bit)@SOIC8 [(SA602A)]	AM93LC66(16bit)@TSOP8 [(SA026)]
AM93LC86(08bit)	AM93LC86(08bit)@SOIC8 [(SA602A)]
AM93LC86(08bit)@TSOP8 [(SA026)]	AM93LC86(16bit)
AM93LC86(16bit)@SOIC8 [(SA602A)]	AM93LC86(16bit)@TSOP8 [(SA026)]

PLD

PEEL18CV8Z	PEEL18CV8Z@PLCC20 [(SA001A)]
PEEL18CV8Z@SOIC20 [(SA404)]	PEEL18CV8Z@TSOP20 [(SA026)]
PEEL18LV8Z	PEEL18LV8Z@PLCC20 [(SA001A)]

```

PEEL18LV8Z@SOIC20 [(SA404)]
PEEL22CV10A
PEEL22CV10A@SOIC24 [(SA404)]
PEEL22CV10A+
PEEL22CV10A+@SOIC24 [(SA404)]
PEEL22CV10A++
PEEL22CV10A++@SOIC24 [(SA404)]
PEEL22CV10AZ
PEEL22CV10AZ@SOIC24 [(SA404)]
PEEL22CV10AZ+
PEEL22CV10AZ+@SOIC24 [(SA404)]
PEEL22CV10AZ++
PEEL22CV10AZ++@SOIC24 [(SA404)]
PEEL22LV10AZ
PEEL22LV10AZ@SOIC24 [(SA404)]
PEEL22LV10AZ+
PEEL22LV10AZ+@SOIC24 [(SA404)]
PEEL22LV10AZ++
PEEL22LV10AZ++@SOIC24 [(SA404)]

PEEL18LV8Z@TSOP20 [(SA026)]
PEEL22CV10A@PLCC28 [(SA008A)]
PEEL22CV10A@TSOP24 [(SA026)]
PEEL22CV10A+@PLCC28 [(SA008A)]
PEEL22CV10A+@TSOP24 [(SA026)]
PEEL22CV10A++@PLCC28 [(SA008A)]
PEEL22CV10A++@TSOP24 [(SA026)]
PEEL22CV10AZ@PLCC28 [(SA008A)]
PEEL22CV10AZ@TSOP24 [(SA026)]
PEEL22CV10AZ+@PLCC28 [(SA008A)]
PEEL22CV10AZ+@TSOP24 [(SA026)]
PEEL22CV10AZ++@PLCC28 [(SA008A)]
PEEL22CV10AZ++@TSOP24 [(SA026)]
PEEL22LV10AZ@PLCC28 [(SA008A)]
PEEL22LV10AZ@TSOP24 [(SA026)]
PEEL22LV10AZ+@PLCC28 [(SA008A)]
PEEL22LV10AZ+@TSOP24 [(SA026)]
PEEL22LV10AZ++@PLCC28 [(SA008A)]
PEEL22LV10AZ++@TSOP24 [(SA026)]

```

APLUS FLASH

E (E) PROM / FRAM / NVRAM

```

AF24BC01
AF24BC01@TSSOP8 [(SA026)]
AF24BC02@SOIC8 [(SA602A)]
AF24BC04
AF24BC04@TSSOP8 [(SA026)]
AF24BC08@SOIC8 [(SA602A)]
AF24BC128
AF24BC128@TSOP8 [(SA026)]
AF24BC16@SOIC8 [(SA602A)]
AF24BC256
AF24BC256@TSOP8 [(SA026)]
AF24BC32@SOIC8 [(SA602A)]
AF24BC64
AF24BC64@TSOP8 [(SA026)]
AF24C128@SOIC8 [(SA602A)]
AF24C256
AF24C256@TSOP8 [(SA026)]
AF24C32@SOIC8 [(SA602A)]
AF24C64
AF24C64@TSOP8 [(SA026)]
AF25BC128@SOIC8 [(SA602A)]
AF25BC256
AF25BC256@TSOP8 [(SA026)]
AF93BC46(08bit)@SOIC8 [(SA602A)]
AF93BC46(16bit)
AF93BC46(16bit)@TSOP8 [(SA026)]
AF93BC56(08bit)@SOIC8 [(SA602A)]
AF93BC56(16bit)
AF93BC56(16bit)@TSOP8 [(SA026)]
AF93BC66(08bit)@SOIC8 [(SA602A)]
AF93BC66(16bit)
AF93BC66(16bit)@TSOP8 [(SA026)]
AF93BC86(08bit)@SOIC8 [(SA602A)]
AF93BC86(16bit)
AF93BC86(16bit)@TSOP8 [(SA026)]
AF93C46(08bit)@SOIC8 [(SA602A)]
AF93C46(16bit)
AF93C46(16bit)@TSOP8 [(SA026)]
AF93C56(08bit)@SOIC8 [(SA602A)]
AF93C56(16bit)
AF93C56(16bit)@TSOP8 [(SA026)]
AF93C66(08bit)@SOIC8 [(SA602A)]
AF93C66(16bit)
AF93C66(16bit)@TSOP8 [(SA026)]
AF93C86(08bit)@SOIC8 [(SA602A)]
AF93C86(16bit)
AF93C86(16bit)@TSOP8 [(SA026)]

AF24BC01@SOIC8 [(SA602A)]
AF24BC02
AF24BC02@TSSOP8 [(SA026)]
AF24BC04@SOIC8 [(SA602A)]
AF24BC08
AF24BC08@TSSOP8 [(SA026)]
AF24BC128@SOIC8 [(SA602A)]
AF24BC16
AF24BC16@TSSOP8 [(SA026)]
AF24BC256@SOIC8 [(SA602A)]
AF24BC32
AF24BC32@TSOP8 [(SA026)]
AF24BC64@SOIC8 [(SA602A)]
AF24C128
AF24C128@TSOP8 [(SA026)]
AF24C256@SOIC8 [(SA602A)]
AF24C32
AF24C32@TSOP8 [(SA026)]
AF24C64@SOIC8 [(SA602A)]
AF25BC128
AF25BC128@TSOP8 [(SA026)]
AF25BC256@SOIC8 [(SA602A)]
AF93BC46(08bit)
AF93BC46(08bit)@TSOP8 [(SA026)]
AF93BC46(16bit)@SOIC8 [(SA602A)]
AF93BC56(08bit)
AF93BC56(08bit)@TSOP8 [(SA026)]
AF93BC56(16bit)@SOIC8 [(SA602A)]
AF93BC66(08bit)
AF93BC66(08bit)@TSOP8 [(SA026)]
AF93BC66(16bit)@SOIC8 [(SA602A)]
AF93BC86(08bit)
AF93BC86(08bit)@TSOP8 [(SA026)]
AF93BC86(16bit)@SOIC8 [(SA602A)]
AF93C46(08bit)
AF93C46(08bit)@TSOP8 [(SA026)]
AF93C46(16bit)@SOIC8 [(SA602A)]
AF93C56(08bit)
AF93C56(08bit)@TSOP8 [(SA026)]
AF93C56(16bit)@SOIC8 [(SA602A)]
AF93C66(08bit)
AF93C66(08bit)@TSOP8 [(SA026)]
AF93C66(16bit)@SOIC8 [(SA602A)]
AF93C86(08bit)
AF93C86(08bit)@TSOP8 [(SA026)]
AF93C86(16bit)@SOIC8 [(SA602A)]

```

ARTSCHIP

E (E) PROM/FRAM/NVRAM

24AA02	24AA02@MSOP8 [(SA666)]
24AA02@SOIC8 [(SA602A)]	24AA02@SOT5 [(SA698)]
24AA02@TSSOP8 [(SA026)]	24LC01A
24LC01A@SOIC8 [(SA602A)]	24LC01A@SOT5 [(SA698)]
24LC01A@TSSOP8 [(SA026)]	24LC01B
24LC01B@SOIC8 [(SA602A)]	24LC01B@SOT5 [(SA698)]
24LC01B@TSSOP8 [(SA026)]	24LC02A
24LC02A@SOIC8 [(SA602A)]	24LC02A@SOT5 [(SA698)]
24LC02A@TSSOP8 [(SA026)]	24LC02B
24LC02B@MSOP8 [(SA666)]	24LC02B@SOIC8 [(SA602A)]
24LC02B@SOT5 [(SA698)]	24LC02B@TSSOP8 [(SA026)]
24LC04A	24LC04A@SOIC8 [(SA602A)]
24LC04A@SOT5 [(SA698)]	24LC04A@TSSOP8 [(SA026)]
24LC04B	24LC04B@MSOP8 [(SA666)]
24LC04B@SOIC8 [(SA602A)]	24LC04B@SOT5 [(SA698)]
24LC04B@TSSOP8 [(SA026)]	24LC08A
24LC08A@SOIC8 [(SA602A)]	24LC08A@SOT5 [(SA698)]
24LC08A@TSSOP8 [(SA026)]	24LC08B
24LC08B@MSOP8 [(SA666)]	24LC08B@SOIC8 [(SA602A)]
24LC08B@SOT5 [(SA698)]	24LC08B@TSSOP8 [(SA026)]
24LC16A	24LC16A@SOIC8 [(SA602A)]
24LC16A@SOT5 [(SA698)]	24LC16A@TSSOP8 [(SA026)]
24LC256B	24LC256B@MSOP8 [(SA666)]
24LC256B@SOIC8 [(SA602A)]	24LC256B@TSSOP8 [(SA026)]
24LC32	24LC32@SOIC14 [(SA026)]
24LC32@SOIC8 [(SA602A)]	24LC32@TSSOP8 [(SA026)]
24LC64	24LC64@SOIC14 [(SA026)]
24LC64@SOIC8 [(SA602A)]	24LC64@TSSOP8 [(SA026)]

ASAHI KASEI(AKM)**E (E) PROM/FRAM/NVRAM**

AK27CX161	AK27CX162
AK27CX321	AK27CX322
AK27CX641	AK27CX642
AK6002A(F)@SOP8 [(SA602A)]	AK6002A(V)@TSSOP8 [(SA026)]
AK6003A(V)@TSSOP8 [(SA026)]	AK6004A(F)@SOP8 [(SA602A)]
AK6004A(M)@SSOP8 [(SA605A)]	AK6008A(F)@SOP8 [(SA602A)]
AK6010A(F)@SOP8 [(SA602A)]	AK6012A(F)@SOP8 [(SA602A)]
AK6416A(M)@SSOP8 [(SA026)]	AK6416C(F)@SOP8 [(SA602A)]
AK6420A(F)@SOP8 [(SA602A)]	AK6420A(M)@SSOP8 [(SA605A)]
AK6420B(H)@MSOP8 [(SA666)]	AK6440A(F)@SOP8 [(SA602A)]
AK6440A(M)@SSOP8 [(SA605A)]	AK6440B(H)@MSOP8 [(SA666)]
AK6480A(F)@SOP8 [(SA602A)]	AK6480A(M)@SSOP8 [(SA605A)]
AK6480B(H)@MSOP8 [(SA666)]	AK6480C(F)@SOP8 [(SA602A)]
AK6480C(H)@MSOP8 [(SA666)]	AK6480C(L)@SON8
AK6480C(M)@SSOP8 [(SA605A)]	AK6481C(H)@MSOP8 [(SA666)]
AK6481C(M)@SSOP8 [(SA605A)]	AK6508C(T)@MSOP8 [(SA666)]
AK6508C(U)@USON8	AK6510C(L)@SONW8
AK6510C(M)@SSOP8 [(SA026)]	AK6512C(L)@SONW8
AK6512C(M)@SSOP8 [(SA026)]	AK6514C(F)@SOP8 [(SA602A)]
AK6514C(N)@QFN20 [(SA692)]	AK6516C(F)@SOP8 [(SA602A)]
AK93C10A(F)@SOP8 [(SA602A)]	AK93C41A(V)@TSSOP8 [(SA026)]
AK93C45	AK93C45(F)@SOP8 [(SA602A)]
AK93C45A(F)@SOP8 [(SA602A)]	AK93C45A(NF)@SOP8 [(SA602A)]
AK93C45A(V)@TSSOP8 [(SA026)]	AK93C45B(H)@MSOP8 [(SA666)]
AK93C45B(L)@SON8	AK93C45C(T)@MSOP8 [(SA666)]
AK93C45C(U)@USON8	AK93C45L
AK93C45L(F)@SOP8 [(SA602A)]	AK93C46
AK93C46(F)@SOP8 [(SA602A)]	AK93C46A(F)@SOP8 [(SA602A)]
AK93C46A(NF)@SOP8 [(SA602A)]	AK93C46A(V)@TSSOP8 [(SA026)]
AK93C46B(H)@MSOP8 [(SA666)]	AK93C46B(L)@SON8
AK93C46C(T)@MSOP8 [(SA666)]	AK93C46C(U)@USON8
AK93C46L	AK93C46L(F)@SOP8 [(SA602A)]
AK93C51A(V)@TSSOP8 [(SA026)]	AK93C55
AK93C55(F)@SOP8 [(SA602A)]	AK93C55A(F)@SOP8 [(SA602A)]
AK93C55A(NF)@SOP8 [(SA602A)]	AK93C55A(V)@TSSOP8 [(SA026)]
AK93C55B(H)@MSOP8 [(SA666)]	AK93C55B(L)@SON8
AK93C55C(T)@MSOP8 [(SA666)]	AK93C55C(U)@USON8
AK93C55L	AK93C55L(F)@SOP8 [(SA602A)]
AK93C56	AK93C56(F)@SOP8 [(SA602A)]
AK93C56A(F)@SOP8 [(SA602A)]	AK93C56A(NF)@SOP8 [(SA602A)]
AK93C56A(V)@TSSOP8 [(SA026)]	AK93C56B(H)@MSOP8 [(SA666)]
AK93C56B(L)@SON8	AK93C56C(T)@MSOP8 [(SA666)]

AK93C56C(U)@USON8	AK93C56L
AK93C56L(F)@SOP8 [(SA602A)]	AK93C61A(V)@TSSOP8 [(SA026)]
AK93C65	AK93C65(F)@SOP8 [(SA602A)]
AK93C65A(F)@SOP8 [(SA602A)]	AK93C65A(NF)@SOP8 [(SA602A)]
AK93C65A(V)@TSSOP8 [(SA026)]	AK93C65B(H)@MSOP8 [(SA666)]
AK93C65B(L)@SON8	AK93C65C(T)@MSOP8 [(SA666)]
AK93C65C(U)@USON8	AK93C65L
AK93C65L(F)@SOP8 [(SA602A)]	AK93C66
AK93C66(F)@SOP8 [(SA602A)]	AK93C66A(F)@SOP8 [(SA602A)]
AK93C66A(NF)@SOP8 [(SA602A)]	AK93C66A(V)@TSSOP8 [(SA026)]
AK93C66B(H)@MSOP8 [(SA666)]	AK93C66B(L)@SON8
AK93C66C(T)@MSOP8 [(SA666)]	AK93C66C(U)@USON8
AK93C66L	AK93C66L(F)@SOP8 [(SA602A)]
AK93C75	AK93C75(F)@SOP8 [(SA602A)]
AK93C75A(F)@SOP8 [(SA602A)]	AK93C75A(NF)@SOP8 [(SA602A)]
AK93C75A(V)@TSSOP8 [(SA026)]	AK93C75B(H)@MSOP8 [(SA666)]
AK93C75L	AK93C75L(F)@SOP8 [(SA602A)]
AK93C85	AK93C85(F)@SOP8 [(SA602A)]
AK93C85L	AK93C85L(F)@SOP8 [(SA602A)]
AK93C95A(F)@SOP8 [(SA602A)]	AK9822(M)@SSOP8 [(SA026)]
AK9824(M)@SSOP8 [(SA026)]	AK9844@SOIC14 [(SA602)]

ASD

E(E) PROM/FRAM/NVRAM

AE29F1008	AE29F2008
-----------	-----------

ASI

E(E) PROM/FRAM/NVRAM

AS58C1001	AS58C1001@PLCC32 [(SA015A1T)]
AS58C1001@SSOP32 [(SA438T)]	

ASP

MICROCONTROLLER

AP827C51	AP827C51@PLCC44 [(SA244)]
AP827C52	AP827C52@PLCC44 [(SA244)]
AP827C54	AP827C54@PLCC44 [(SA244)]
AP827C58	AP827C58@PLCC44 [(SA244)]

ATC

E(E) PROM/FRAM/NVRAM

ATC24C02	ATC24C02@SOIC8 [(SA602A)]
ATC24C02@TSSOP8 [(SA026)]	ATC24C04
ATC24C04@SOIC8 [(SA602A)]	ATC24C04@TSSOP8 [(SA026)]
ATC24C08	ATC24C08@SOIC8 [(SA602A)]
ATC24C08@TSSOP8 [(SA026)]	ATC24C16
ATC24C16@SOIC8 [(SA602A)]	ATC24C16@TSSOP8 [(SA026)]
ATC24LC02	ATC24LC02@SOIC8 [(SA602A)]
ATC24LC02@TSSOP8 [(SA026)]	ATC24LC02A
ATC24LC02A@SOIC8 [(SA602A)]	ATC24LC02A@TSSOP8 [(SA026)]
ATC24LC04	ATC24LC04@SOIC8 [(SA602A)]
ATC24LC04@TSSOP8 [(SA026)]	ATC24LC08
ATC24LC08@SOIC8 [(SA602A)]	ATC24LC08@TSSOP8 [(SA026)]
ATC24LC16	ATC24LC16@SOIC8 [(SA602A)]
ATC24LC16@TSSOP8 [(SA026)]	ATC93C46(08bit)
ATC93C46(08bit)@SOIC8 [(SA602A)]	ATC93C46(16bit)
ATC93C46(16bit)@SOIC8 [(SA602A)]	
ATC93C46R(08bit)@SOIC8 [(SA602A)]	
ATC93C46R(16bit)@SOIC8 [(SA602A)]	
ATC93C56(08bit)	ATC93C56(08bit)@SOIC8 [(SA602A)]
ATC93C56(16bit)	ATC93C56(16bit)@SOIC8 [(SA602A)]

ATC93C56R (08bit)@SOIC8 [(SA602A)]	
ATC93C56R (16bit)@SOIC8 [(SA602A)]	
ATC93C66 (08bit)	ATC93C66 (08bit)@SOIC8 [(SA602A)]
ATC93C66 (16bit)	ATC93C66 (16bit)@SOIC8 [(SA602A)]
ATC93C66R (08bit)@SOIC8 [(SA602A)]	
ATC93C66R (16bit)@SOIC8 [(SA602A)]	
ATC93LC46 (08bit)	
ATC93LC46 (08bit)@SOIC8 [(SA602A)]	
ATC93LC46 (16bit)	
ATC93LC46 (16bit)@SOIC8 [(SA602A)]	
ATC93LC46R (08bit)@SOIC8 [(SA602A)]	
ATC93LC46R (16bit)@SOIC8 [(SA602A)]	
ATC93LC56 (08bit)	
ATC93LC56 (08bit)@SOIC8 [(SA602A)]	
ATC93LC56 (16bit)	
ATC93LC56 (16bit)@SOIC8 [(SA602A)]	
ATC93LC56R (08bit)@SOIC8 [(SA602A)]	
ATC93LC56R (16bit)@SOIC8 [(SA602A)]	
ATC93LC66 (08bit)	
ATC93LC66 (08bit)@SOIC8 [(SA602A)]	
ATC93LC66 (16bit)	
ATC93LC66 (16bit)@SOIC8 [(SA602A)]	
ATC93LC66R (08bit)@SOIC8 [(SA602A)]	
ATC93LC66R (16bit)@SOIC8 [(SA602A)]	

ATMEL

E(E) PROM/FRAM/NVRAM

AT17C002@PLCC20 [(SA001A)]	AT17C002@PLCC44 [(SA244)]
AT17C002@SOIC20 [(SA404)]	AT17C002@TQFP44 [(SA245A)]
AT17C002A@PLCC20 [(SA001A)]	AT17C002A@TQFP32 [(SA663)]
AT17C010	AT17C010@PLCC20 [(SA001A)]
AT17C010A	AT17C010A@PLCC20 [(SA001A)]
AT17C040@PLCC44 [(SA244)]	AT17C040@TQFP44 [(SA245A)]
AT17C128	AT17C128@PLCC20 [(SA001A)]
AT17C128@SOIC20 [(SA404)]	AT17C128@SOIC8 [(SA602A)]
AT17C128A@PLCC20 [(SA001A)]	AT17C256
AT17C256@PLCC20 [(SA001A)]	AT17C256@SOIC20 [(SA404)]
AT17C256@SOIC8 [(SA602A)]	AT17C256A@PLCC20 [(SA001A)]
AT17C512	AT17C512@PLCC20 [(SA001A)]
AT17C512A	AT17C512A@PLCC20 [(SA001A)]
AT17C65	AT17C65@PLCC20 [(SA001A)]
AT17C65@SOIC20 [(SA404)]	AT17C65@SOIC8 [(SA602A)]
AT17C65A@PLCC20 [(SA001A)]	AT17F040@LAP8 [(SA760)]
AT17F040@PLCC20 [(SA001A)]	
AT17F040@PLCC20 (Virtex Pinout) [(SA001A)]	
AT17F040A@LAP8 [(SA760)]	AT17F040A@PLCC20 [(SA001A)]
AT17F040A@TQFP32 [(SA663)]	AT17F080@LAP8 [(SA760)]
AT17F080@PLCC20 [(SA001A)]	AT17F080@PLCC44 [(SA244)]
AT17F080@TQFP44 [(SA245A)]	AT17F080A@LAP8 [(SA760)]
AT17F080A@PLCC20 [(SA001A)]	AT17F080A@TQFP32 [(SA001A)]
AT17F16@LAP8 [(SA760)]	AT17F16@PLCC20 [(SA001A)]
AT17F16@PLCC44 [(SA244)]	AT17F16@TQFP44 [(SA245A)]
AT17F16A@LAP8 [(SA760)]	AT17F16A@PLCC20 [(SA001A)]
AT17F32@PLCC44 [(SA244)]	AT17F32A@PLCC44 [(SA244)]
AT17LV002@PLCC20 [(SA001A)]	AT17LV002@PLCC44 [(SA244)]
AT17LV002@SOIC20 [(SA404)]	AT17LV002@TQFP44 [(SA245A)]
AT17LV002A@PLCC20 [(SA001A)]	AT17LV002A@TQFP32 [(SA663)]
AT17LV010	AT17LV010@PLCC20 [(SA001A)]
AT17LV010A	AT17LV010A@PLCC20 [(SA001A)]
AT17LV040@PLCC44 [(SA244)]	AT17LV040@TQFP44 [(SA245A)]
AT17LV128	AT17LV128@PLCC20 [(SA001A)]
AT17LV128@SOIC20 [(SA404)]	AT17LV128@SOIC8 [(SA602A)]
AT17LV128A@PLCC20 [(SA001A)]	AT17LV256
AT17LV256@PLCC20 [(SA001A)]	AT17LV256@SOIC20 [(SA404)]
AT17LV256@SOIC8 [(SA602A)]	AT17LV256A@PLCC20 [(SA001A)]
AT17LV512	AT17LV512@PLCC20 [(SA001A)]
AT17LV512A	AT17LV512A@PLCC20 [(SA001A)]
AT17LV65	AT17LV65@PLCC20 [(SA001A)]
AT17LV65@SOIC20 [(SA404)]	AT17LV65@SOIC8 [(SA602A)]
AT17LV65A@PLCC20 [(SA001A)]	AT17N002@SOIC20 [(SA404)]
AT17N002@TQFP44 [(SA245A)]	AT17N010
AT17N010@SOIC20 [(SA404)]	AT17N040@TQFP44 [(SA245A)]
AT17N256	AT17N256@SOIC20 [(SA404)]
AT17N256@SOIC8 [(SA602A)]	AT17N512
AT17N512@SOIC20 [(SA404)]	AT24C01

AT24C01@MSOP8 [(SA666)]	AT24C01@SOIC8 [(SA602A)]
AT24C01@TSSOP8 [(SA026)]	AT24C01A
AT24C01A@MAP8 [(SA724)]	AT24C01A@SOIC8 [(SA602A)]
AT24C01A@SOT23-5 [(SA717)]	AT24C01A@TSSOP8 [(SA026)]
AT24C01B	AT24C01B@dBGA2
AT24C01B@MAP8 [(SA724)]	AT24C01B@SOIC8 [(SA602A)]
AT24C01B@SOT23 [(SA717)]	AT24C01B@TSSOP8 [(SA026)]
AT24C02	AT24C02@SOIC8 [(SA602A)]
AT24C02@TSSOP8 [(SA026)]	AT24C02A
AT24C02A@SOIC8 [(SA602A)]	AT24C02A@TSSOP8 [(SA026)]
AT24C02B	AT24C02B@dBGA2
AT24C02B@MAP8 [(SA724)]	AT24C02B@SOIC8 [(SA602A)]
AT24C02B@SOT23 [(SA717)]	AT24C02B@TSSOP8 [(SA026)]
AT24C04	AT24C04@MAP8 [(SA724)]
AT24C04@SOIC8 [(SA602A)]	AT24C04@SOT23-5 [(SA717)]
AT24C04@TSSOP8 [(SA026)]	AT24C04A
AT24C04A@MAP8 [(SA724)]	AT24C04A@SOIC8 [(SA602A)]
AT24C04A@TSSOP8 [(SA026)]	AT24C08
AT24C08@MAP8 [(SA724)]	AT24C08@SOIC8 [(SA602A)]
AT24C08@TSSOP8 [(SA026)]	AT24C08A
AT24C08A@MAP8 [(SA724)]	AT24C08A@SOIC8 [(SA602A)]
AT24C08A@TSSOP8 [(SA026)]	AT24C1024
AT24C1024@LAP8 [(SA724)]	AT24C1024@SAP8 [(SA684)]
AT24C1024@SOIC8 [(SA023A)]	AT24C1024B(1.8V)
AT24C1024B(1.8V)@LAP8 [(SA724)]	AT24C1024B(1.8V)@SAP8 [(SA684)]
AT24C1024B(1.8V)@SOIC8 [(SA023A)]	
AT24C1024B(1.8V)@TSSOP8 [(SA026)]	
AT24C1024B(2.5V)	AT24C1024B(2.5V)@LAP8 [(SA724)]
AT24C1024B(2.5V)@SAP8 [(SA684)]	
AT24C1024B(2.5V)@SOIC8 [(SA023A)]	
AT24C1024B(2.5V)@TSSOP8 [(SA026)]	
AT24C11	AT24C11@SOIC8 [(SA602A)]
AT24C11@TSSOP8 [(SA026)]	AT24C128(1.8V)
AT24C128(1.8V)@MAP8 [(SA724)]	AT24C128(1.8V)@SAP8 [(SA683)]
AT24C128(1.8V)@SOIC8 [(SA602A)]	AT24C128(1.8V)@TSSOP8 [(SA026)]
AT24C128(2.7V)	AT24C128(2.7V)@MAP8 [(SA724)]
AT24C128(2.7V)@SAP8 [(SA683)]	AT24C128(2.7V)@SOIC8 [(SA602A)]
AT24C128(2.7V)@TSSOP8 [(SA026)]	AT24C128B
AT24C128B@MAP8 [(SA724)]	AT24C128B@SAP8 [(SA683)]
AT24C128B@SOIC8 [(SA602A)]	AT24C128B@TSSOP8 [(SA026)]
AT24C16	AT24C16@SOIC8 [(SA602A)]
AT24C16@TSSOP8 [(SA026)]	AT24C164
AT24C164@SOIC8 [(SA602A)]	AT24C16A
AT24C16A@MAP8 [(SA724)]	AT24C16A@SOIC8 [(SA602A)]
AT24C16A@TSSOP8 [(SA026)]	AT24C16B
AT24C16B@MAP8 [(SA724)]	AT24C16B@SOIC8 [(SA602A)]
AT24C16B@TSSOP8 [(SA026)]	AT24C21
AT24C21@SOIC8 [(SA602A)]	AT24C256(1.8V)
AT24C256(1.8V)@MAP8 [(SA724)]	AT24C256(1.8V)@SAP8 [(SA683)]
AT24C256(1.8V)@SOIC8 [(SA602A)]	AT24C256(1.8V)@TSSOP8 [(SA026)]
AT24C256(2.7V)	AT24C256(2.7V)@MAP8 [(SA724)]
AT24C256(2.7V)@SAP8 [(SA683)]	AT24C256(2.7V)@SOIC8 [(SA602A)]
AT24C256(2.7V)@TSSOP8 [(SA026)]	AT24C256B
AT24C256B@MAP8 [(SA724)]	AT24C256B@SAP8 [(SA683)]
AT24C256B@SOIC8 [(SA602A)]	AT24C256B@TSSOP8 [(SA026)]
AT24C32	AT24C32@SOIC8 [(SA602A)]
AT24C32@TSSOP8 [(SA026)]	AT24C32A
AT24C32A@MAP8 [(SA724)]	AT24C32A@SOIC8 [(SA602A)]
AT24C32A@TSSOP8 [(SA026)]	AT24C32C
AT24C32C@dBGA8 [(BBBB)]	AT24C32C@MAP8 [(SA724)]
AT24C32C@SAP8 [(SA683)]	AT24C32C@SOIC8 [(SA602A)]
AT24C32C@TSSOP8 [(SA026)]	AT24C512(1.8V)
AT24C512(1.8V)@LAP8 [(SA684)]	AT24C512(1.8V)@SAP8 [(SA683)]
AT24C512(1.8V)@SOIC8 [(SA602A)]	AT24C512(1.8V)@TSSOP8 [(SA026)]
AT24C512(2.7V)	AT24C512(2.7V)@LAP8 [(SA684)]
AT24C512(2.7V)@SAP8 [(SA683)]	AT24C512(2.7V)@SOIC8 [(SA602A)]
AT24C512(2.7V)@TSSOP8 [(SA026)]	AT24C512B
AT24C512B@LAP8 [(SA684)]	AT24C512B@SAP8 [(SA683)]
AT24C512B@SOIC8 [(SA602A)]	AT24C512B@TSSOP8 [(SA026)]
AT24C64	AT24C64@SOIC8 [(SA602A)]
AT24C64@TSSOP8 [(SA026)]	AT24C64A
AT24C64A@MAP8 [(SA724)]	AT24C64A@SOIC8 [(SA602A)]
AT24C64A@TSSOP8 [(SA026)]	AT24C64B
AT24C64B@SOIC8 [(SA602A)]	AT24C64B@TSSOP8 [(SA026)]
AT24C64C	AT24C64C@dBGA8 [(BBBB)]
AT24C64C@MAP8 [(SA724)]	AT24C64C@SAP8 [(SA683)]
AT24C64C@SOIC8 [(SA602A)]	AT24C64C@TSSOP8 [(SA026)]
AT24CS128	AT24CS128@SOIC8 [(SA602A)]
AT24HC02B	AT24HC02B@SOIC8 [(SA602A)]
AT24HC02B@TSSOP8 [(SA026)]	AT24RF08AN@SOIC8 [(SA602A)]
AT24RF08AT@TSSOP14 [(SA026)]	AT24RF08BN@SOIC8 [(SA602A)]

AT24RF08BT@TSSOP14 [(SA026)]	AT24RF08CN@SOIC8 [(SA602A)]
AT24RF08CT@TSSOP14 [(SA026)]	AT25010
AT25010@SOIC8 [(SA602A)]	AT25010A
AT25010A@SOIC8 [(SA602A)]	AT25010A@TSSOP8 [(SA026)]
AT25020	AT25020@SOIC8 [(SA602A)]
AT25020A	AT25020A@SOIC8 [(SA602A)]
AT25020A@TSSOP8 [(SA026)]	AT25040
AT25040 (ISP) [ISP-HEADER01]	AT25040@SOIC8 [(SA602A)]
AT25040@SOIC8 (ISP) [ISP-HEADER01]	AT25040A (ISP) [ISP-HEADER01]
AT25040A	
AT25040A@SOIC8 [(SA602A)]	
AT25040A@SOIC8 (ISP) [ISP-HEADER01]	
AT25080	AT25080@SOIC8 [(SA602A)]
AT25080@TSSOP14 [(SA026)]	AT25080@TSSOP20 [(SA026)]
AT25080A	AT25080A@SOIC8 [(SA602A)]
AT25080A@TSSOP14 [(SA026)]	AT25080B
AT25080B@dBG8 [(BBBB)]	AT25080B@MAP8 [(SA724)]
AT25080B@SOIC8 [(SA602A)]	AT25080B@TSSOP8 [(SA026)]
AT25128	AT25128@SOIC16 [(SA602)]
AT25128@SOIC8 [(SA602A)]	AT25128@TSSOP14 [(SA026)]
AT25128@TSSOP20 [(SA026)]	AT25128A
AT25128A@dBG8 [(BBBB)]	AT25128A@SAP8 [(SA683)]
AT25128A@SOIC8 (4.0) [(SA602A)]	AT25128A@SOIC8 (5.4) [(SA605A)]
AT25128A@TSSOP14 [(SA026)]	AT25128A@TSSOP8 [(SA026)]
AT25160	AT25160@SOIC8 [(SA602A)]
AT25160@TSSOP14 [(SA026)]	AT25160@TSSOP20 [(SA026)]
AT25160A	AT25160A@SOIC8 [(SA602A)]
AT25160A@TSSOP14 [(SA026)]	AT25160B
AT25160B@dBG8 [(BBBB)]	AT25160B@MAP8 [(SA724)]
AT25160B@SOIC8 [(SA602A)]	AT25160B@TSSOP8 [(SA026)]
AT25256	AT25256@SOIC16 [(SA602)]
AT25256@SOIC8 [(SA602A)]	AT25256@TSSOP14 [(SA026)]
AT25256@TSSOP20 [(SA026)]	AT25256A
AT25256A@dBG8 [(BBBB)]	AT25256A@SAP8 [(SA683)]
AT25256A@SOIC8 (4.0) [(SA602A)]	AT25256A@SOIC8 (5.4) [(SA605A)]
AT25256A@TSSOP14 [(SA026)]	AT25256A@TSSOP8 [(SA026)]
AT25320	AT25320@SOIC8 [(SA602A)]
AT25320@TSSOP14 [(SA026)]	AT25320@TSSOP20 [(SA026)]
AT25320A	AT25320A@SOIC8 [(SA602A)]
AT25320A@TSSOP14 [(SA026)]	AT25320B
AT25320B@dBG8 [(BBBB)]	AT25320B@MAP8 [(SA724)]
AT25320B@SOIC8 [(SA602A)]	AT25320B@TSSOP8 [(SA026)]
AT25640	AT25640@SOIC8 [(SA602A)]
AT25640@TSSOP14 [(SA026)]	AT25640@TSSOP20 [(SA026)]
AT25640A	AT25640A@SOIC8 [(SA602A)]
AT25640A@TSSOP14 [(SA026)]	AT25640B
AT25640B@dBG8 [(BBBB)]	AT25640B@MAP8 [(SA724)]
AT25640B@SOIC8 [(SA602A)]	AT25640B@TSSOP8 [(SA026)]
AT25DF021@SOIC8 [(SA602A)]	AT25DF021@UDFN8 [(SA683)]
AT25DF041A@MLF8 [(SA683)]	AT25DF041A@SOIC8 (4.0) [(SA602A)]
AT25DF041A@SOIC8 (5.4) [(SA605A)]	AT25DF081@SOIC8 [(SA602A)]
AT25DF081@UDFN8 [(SA683)]	AT25DF161@MLF8 [(SA683)]
AT25DF161@SOIC8 (4.0) [(SA602A)]	AT25DF161@SOIC8 (5.4) [(SA605A)]
AT25DF321@SOIC16 [(SA404)]	AT25DF321@SOIC8 [(SA605A)]
AT25DF641@SOIC16 [(SA404)]	AT25DF641@VDFN8 [(SA683)]
AT25F1024	AT25F1024 (W)@SOIC8 [(SA605A)]
AT25F1024 (W)@VQFPN8 [(SA684)]	AT25F1024@SOIC8 [(SA602A)]
AT25F1024@VQFPN8 [(SA683)]	AT25F1024A
AT25F1024A (W)@SOIC8 [(SA605A)]	AT25F1024A (W)@VQFPN8 [(SA684)]
AT25F1024A@SOIC8 [(SA602A)]	AT25F1024A@VQFPN8 [(SA683)]
AT25F2048	AT25F2048 (W)@SOIC8 [(SA605A)]
AT25F2048 (W)@VQFPN8 [(SA684)]	AT25F2048@SOIC8 [(SA602A)]
AT25F2048@VQFPN8 [(SA683)]	AT25F2048A
AT25F2048A (W)@SOIC8 [(SA605A)]	AT25F2048A (W)@VQFPN8 [(SA684)]
AT25F2048A@SOIC8 [(SA602A)]	AT25F2048A@VQFPN8 [(SA683)]
AT25F4096	AT25F4096 (W)@SOIC8 [(SA605A)]
AT25F4096 (W)@VQFPN8 [(SA684)]	AT25F4096@SOIC8 [(SA602A)]
AT25F4096@VQFPN8 [(SA683)]	AT25F4096A
AT25F4096A (W)@SOIC8 [(SA605A)]	AT25F4096A (W)@VQFPN8 [(SA684)]
AT25F4096A@SOIC8 [(SA602A)]	AT25F4096A@VQFPN8 [(SA683)]
AT25F512	AT25F512 (W)@SOIC8 [(SA605A)]
AT25F512 (W)@VQFPN8 [(SA684)]	AT25F512@SOIC8 [(SA602A)]
AT25F512@VQFPN8 [(SA683)]	AT25F512A
AT25F512A (W)@SOIC8 [(SA605A)]	AT25F512A (W)@VQFPN8 [(SA684)]
AT25F512A@SOIC8 [(SA602A)]	AT25F512A@VQFPN8 [(SA683)]
AT25F512B@SOIC8 [(SA602A)]	AT25F512B@UDFN8 [(SA724)]
AT25FS010@SAP8 [(SA683)]	AT25FS010@SOIC8 [(SA602A)]
AT25FS040@SAP8 [(SA683)]	AT25FS040@SOIC8 [(SA602A)]
AT25HP256	AT25HP256 (W)@VQFPN8 [(SA684)]
AT25HP256@SOIC16 [(SA404)]	AT25HP256@SOIC8 [(SA602A)]
AT25HP256@VQFPN8 [(SA683)]	AT25HP512

AT25HP512(W)@VQFPN8 [(SA684)]	AT25HP512@SOIC16 [(SA404)]
AT25HP512@SOIC8 [(SA602A)]	AT25HP512@VQFPN8 [(SA683)]
AT25P1024@SOIC20 [(SA404)]	AT25P1024@VQFPN8 [(SA684)]
AT26DF041@MLF8 [(SA683)]	AT26DF041@SOIC8(4.0) [(SA602A)]
AT26DF041@SOIC8(5.4) [(SA605A)]	AT26DF081@SOIC8(4.0) [(SA602A)]
AT26DF081@SOIC8(5.4) [(SA605A)]	AT26DF081A@SOIC8(4.0) [(SA602A)]
AT26DF081A@SOIC8(5.4) [(SA605A)]	AT26DF161@MLF8 [(SA683)]
AT26DF161@SOIC8 [(SA683)]	AT26DF161A@MLF8 [(SA683)]
AT26DF161A@SOIC8 [(SA605A)]	AT26DF321@MLF8(5*6mm) [(SA683)]
AT26DF321@MLF8(6*8mm) [(SA684)]	AT26DF321@SOIC16 [(SA404)]
AT26DF321@SOIC8 [(SA605A)]	AT26F004@MLF8 [(SA683)]
AT26F004@SOIC8(4.0) [(SA602A)]	AT26F004@SOIC8(5.4) [(SA605A)]
AT27011	AT27011@PLCC32 [(SA015A1T)]
AT27256	AT2732A
AT27BV010	AT27BV010@PLCC32 [(SA015A1T)]
AT27BV010@TSOP32 [(SA620)]	AT27BV020
AT27BV020@PLCC32 [(SA015A1T)]	AT27BV020@TSOP32 [(SA620)]
AT27BV040	AT27BV040@PLCC32 [(SA015A1T)]
AT27BV040@TSOP32 [(SA620)]	AT27BV1024@PLCC44 [(SA244)]
AT27BV1024@TSOP40 [(SA623)]	AT27BV256
AT27BV256@PLCC32 [(SA015A1T)]	AT27BV256@TSOP28 [(SA430T)]
AT27BV4096	AT27BV4096@PLCC44 [(SA244)]
AT27BV4096@TSOP40 [(SA623)]	AT27BV512
AT27BV512@PLCC32 [(SA015A1T)]	AT27BV512@SOIC28 [(SA630)]
AT27BV512@TSOP28 [(SA430T)]	AT27BV520@SOIC20 [(SA404)]
AT27BV520@TSOP28 [(SA430T)]	AT27BV520@TSSOP20 [(SA026)]
AT27C010	AT27C010@PLCC32 [(SA015A1T)]
AT27C010@TSOP32 [(SA410T)]	AT27C010L
AT27C010L@PLCC32 [(SA015A1T)]	AT27C010L@TSOP32 [(SA410T)]
AT27C020	AT27C020@PLCC32 [(SA015A1T)]
AT27C020@TSOP32 [(SA410T)]	AT27C040
AT27C040@PLCC32 [(SA015A1T)]	AT27C040@TSOP32 [(SA410T)]
AT27C080	AT27C080@PLCC32 [(SA015A1T)]
AT27C080@TSOP32 [(SA410T)]	AT27C1024
AT27C1024@PLCC44 [(SA244)]	AT27C1024@TSOP40 [(SA623)]
AT27C1024L	AT27C1024L@PLCC44 [(SA244)]
AT27C128	AT27C128@PLCC32 [(SA015A1T)]
AT27C2048	AT27C2048@PLCC44 [(SA244)]
AT27C2048@TSOP40 [(SA623)]	AT27C256
AT27C256@PLCC32 [(SA015A1T)]	AT27C256R
AT27C256R@PLCC32 [(SA015A1T)]	AT27C256R@SOIC28 [(SA630)]
AT27C256R@TSOP28 [(SA430T)]	AT27C4096
AT27C4096@PLCC44 [(SA244)]	AT27C4096@TSOP40 [(SA623)]
AT27C512	AT27C512@PLCC32 [(SA015A1T)]
AT27C512R	AT27C512R@PLCC32 [(SA015A1T)]
AT27C512R@SOIC28 [(SA630)]	AT27C512R@TSOP28 [(SA430T)]
AT27C513	AT27C513@PLCC32 [(SA015A1T)]
AT27C513@SOIC28 [(SA630)]	AT27C513R
AT27C513R@PLCC32 [(SA015A1T)]	AT27C513R@SOIC28 [(SA630)]
AT27C515	AT27C515@PLCC32 [(SA015A1T)]
AT27C516	AT27C516@PLCC44 [(SA244)]
AT27C516@TSOP40 [(SA623)]	AT27C516@PLCC32 [(SA015A1T)]
AT27C520@TSOP28 [(SA430T)]	AT27C520@SOIC20 [(SA404)]
AT27C64	AT27C520@TSSOP20 [(SA026)]
AT27C800@PLCC44 [(SA244)]	AT27C800
AT27HC1024	AT27C800@PSOP44 [(SA638)]
AT27HC256	AT27HC1024@PLCC44 [(SA244)]
AT27HC256L	AT27HC256@PLCC32 [(SA015A1T)]
AT27HC256R	AT27HC256L@PLCC32 [(SA015A1T)]
AT27HC256RL	AT27HC256R@PLCC32 [(SA015A1T)]
AT27HC64	AT27HC256RL@PLCC32 [(SA015A1T)]
AT27HC641	AT27HC64@PLCC32 [(SA015A1T)]
AT27HC641R	AT27HC641@PLCC28 [(SA008A)]
AT27HC642	AT27HC641R@PLCC28 [(SA008A)]
AT27HC642R	AT27HC642@PLCC28 [(SA008A)]
AT27HC64L	AT27HC642R@PLCC28 [(SA008A)]
AT27LV010	AT27HC64L@PLCC32 [(SA015A1T)]
AT27LV010@TSOP32 [(SA620)]	AT27LV010@PLCC32 [(SA015A1T)]
AT27LV010A@PLCC32 [(SA015A1T)]	AT27LV010A
AT27LV020A	AT27LV010A@TSOP32 [(SA620)]
AT27LV020A@TSOP32 [(SA620)]	AT27LV020A@PLCC32 [(SA015A1T)]
AT27LV040@PLCC32 [(SA015A1T)]	AT27LV040
AT27LV040A	AT27LV040@TSOP32 [(SA620)]
AT27LV040A@TSOP32 [(SA620)]	AT27LV040A@PLCC32 [(SA015A1T)]
AT27LV1024	AT27LV1024
AT27LV256A@PLCC32 [(SA015A1T)]	AT27LV256A
AT27LV256A@TSOP28 [(SA430T)]	AT27LV256A@SOIC28 [(SA630)]
AT27LV256R@PLCC32 [(SA015A1T)]	AT27LV256R
AT27LV256R@TSOP28 [(SA430T)]	AT27LV256R@SOIC28 [(SA630)]
AT27LV4096@PLCC44 [(SA244)]	AT27LV4096
AT27LV512A@PLCC32 [(SA015A1T)]	AT27LV512A
	AT27LV512A@SOIC28 [(SA630)]

AT27LV512A@TSOP28 [(SA430T)]	AT27LV512R
AT27LV512R@PLCC32 [(SA015A1T)]	AT27LV512R@TSOP28 [(SA430T)]
AT27LV520@SOIC20 [(SA404)]	AT27LV520@TSOP28 [(SA430T)]
AT27LV520@TSSOP20 [(SA026)]	AT27LV800
AT27LV800@PSOP44 [(SA638)]	AT28BV16
AT28BV16@PLCC32 [(SA015A1T)]	AT28BV16@SOIC24 [(SA404)]
AT28BV16@TSOP28 [(SA430T)]	AT28BV256
AT28BV256@PLCC32 [(SA015A1T)]	AT28BV256@SOIC28 [(SA404)]
AT28BV256@TSOP28 [(SA430T)]	AT28BV64
AT28BV64@PLCC32 [(SA015A1T)]	AT28BV64@SOIC28 [(SA404)]
AT28BV64@TSOP28 [(SA430T)]	AT28BV64B
AT28BV64B@PLCC32 [(SA015A1T)]	AT28BV64B@SOIC28 [(SA404)]
AT28BV64B@TSOP28 [(SA430T)]	AT28C010
AT28C010@PLCC32 [(SA015A1T)]	AT28C010@PLCC44 [(SA244)]
AT28C010@TSOP32 [(SA410T)]	AT28C010E
AT28C010E@PLCC32 [(SA015A1T)]	AT28C010E@PLCC44 [(SA244)]
AT28C010E@TSOP32 [(SA410T)]	AT28C04
AT28C04@PLCC32 [(SA015A1T)]	AT28C040
AT28C04@PLCC32 [(SA015A1T)]	AT28C04E
AT28C04E@PLCC32 [(SA015A1T)]	AT28C04F
AT28C04F@PLCC32 [(SA015A1T)]	AT28C16
AT28C16@PLCC32 [(SA015A1T)]	AT28C16@SOIC24 [(SA404)]
AT28C16@TSOP28 [(SA430T)]	AT28C16E
AT28C16E@PLCC32 [(SA015A1T)]	AT28C16F
AT28C16F@PLCC32 [(SA015A1T)]	AT28C17
AT28C17@PLCC32 [(SA015A1T)]	AT28C17@SOIC28 [(SA404)]
AT28C17E	AT28C17E@PLCC32 [(SA015A1T)]
AT28C17F	AT28C17F@PLCC32 [(SA015A1T)]
AT28C256	AT28C256@PLCC32 [(SA015A1T)]
AT28C256@SOIC28 [(SA404)]	AT28C256@TSOP28 [(SA430T)]
AT28C256E	AT28C256E@PLCC32 [(SA015A1T)]
AT28C256F	AT28C256F@PLCC32 [(SA015A1T)]
AT28C64	AT28C64@PLCC32 [(SA015A1T)]
AT28C64@SOIC28 [(SA404)]	AT28C64@TSOP28 [(SA430T)]
AT28C64B	AT28C64B@PLCC32 [(SA015A1T)]
AT28C64B@SOIC28 [(SA404)]	AT28C64B@TSOP28 [(SA430T)]
AT28C64E	AT28C64E@PLCC32 [(SA015A1T)]
AT28C64E@TSOP28 [(SA430T)]	AT28C64F
AT28C64F@PLCC32 [(SA015A1T)]	AT28C64F@TSOP28 [(SA430T)]
AT28C64X	AT28C64X@PLCC32 [(SA015A1T)]
AT28C64X@SOIC28 [(SA404)]	AT28C64X@TSOP28 [(SA430T)]
AT28HC04	AT28HC16
AT28HC16L	AT28HC191
AT28HC191L	AT28HC256
AT28HC256@PLCC32 [(SA015A1T)]	AT28HC256@TSOP28 [(SA430T)]
AT28HC256E	AT28HC256E@PLCC32 [(SA015A1T)]
AT28HC256F	AT28HC256F@PLCC32 [(SA015A1T)]
AT28HC256L	AT28HC256L@PLCC32 [(SA015A1T)]
AT28HC256LE	AT28HC256LE@PLCC32 [(SA015A1T)]
AT28HC291	AT28HC291@PLCC28 [(SA008A)]
AT28HC291L	AT28HC291L@PLCC28 [(SA008A)]
AT28HC64	AT28HC64@PLCC32 [(SA015A1T)]
AT28HC64@TSOP28 [(SA430T)]	AT28HC64B
AT28HC64B@PLCC32 [(SA015A1T)]	AT28HC64B@SOIC28 [(SA404)]
AT28HC64B@TSOP28 [(SA430T)]	AT28HC64BF
AT28HC64BF@PLCC32 [(SA015A1T)]	AT28HC64BF@SOIC28 [(SA404)]
AT28HC64BF@TSOP28 [(SA430T)]	AT28HC64L
AT28HC64L@PLCC32 [(SA015A1T)]	AT28HC64L@TSOP28 [(SA430T)]
AT28LV010	AT28LV010@PLCC32 [(SA015A1T)]
AT28LV010@TSOP32 [(SA410T)]	AT28LV256
AT28LV256@PLCC32 [(SA015A1T)]	AT28LV256@TSOP28 [(SA430T)]
AT28LV64	AT28LV64@PLCC32 [(SA015A1T)]
AT28LV64B	AT28LV64B@PLCC32 [(SA015A1T)]
AT28LV64B@SOIC28 [(SA404)]	AT28LV64B@TSOP28 [(SA430T)]
AT28MC010	AT28MC010@PLCC32 [(SA015A1T)]
AT28MC010@PLCC44 [(SA244)]	AT28MC010@TSOP32 [(SA410T)]
AT28MC020	AT28MC020@PLCC32 [(SA015A1T)]
AT28MC020@PLCC44 [(SA244)]	AT28MC020@TSOP32 [(SA410T)]
AT28MC040	AT28MC040@PLCC32 [(SA015A1T)]
AT28MC040@PLCC44 [(SA244)]	AT28MC040@TSOP32 [(SA410T)]
AT28PC64	AT28PC64@PLCC32 [(SA015A1T)]
AT28PC64@TSOP28 [(SA430T)]	AT28PC64E
AT28PC64E@PLCC32 [(SA015A1T)]	AT28PC64E@TSOP28 [(SA430T)]
AT29BV010A@PLCC32 [(SA015A1T)]	AT29BV010A@TSOP32 [(SA410T)]
AT29BV020@PLCC32 [(SA015A1T)]	AT29BV020@TSOP32 [(SA410T)]
AT29BV040A@TSOP32 [(SA410T)]	AT29C010
AT29C010@PLCC32 [(SA015A1T)]	AT29C010@TSOP32 [(SA410T)]
AT29C010A	AT29C010A@PLCC32 [(SA015A1T)]
AT29C010A@TSOP32 [(SA410T)]	AT29C020
AT29C020@PLCC32 [(SA015A1T)]	AT29C020@TSOP32 [(SA410T)]
	AT29C040@PLCC32 [(SA015A1T)]

AT29C040@TSOP32 [(SA410T)]	AT29C040A
AT29C040A@PLCC32 [(SA015A1T)]	AT29C040A@TSOP32 [(SA410T)]
AT29C1024@PLCC44 [(SA244)]	AT29C1024@TSOP48 [(SA247-B005)]
AT29C256	AT29C256@PLCC32 [(SA015A1T)]
AT29C256@TSOP28 [(SA430T)]	AT29C257
AT29C257@PLCC32 [(SA015A1T)]	AT29C512
AT29C512@PLCC32 [(SA015A1T)]	AT29C512@TSOP32 [(SA410T)]
AT29LV010	AT29LV010@PLCC32 [(SA015A1T)]
AT29LV010@TSOP32 [(SA410T)]	AT29LV010A@PLCC32 [(SA015A1T)]
AT29LV010A@TSOP32 [(SA410T)]	AT29LV020
AT29LV020@PLCC32 [(SA015A1T)]	AT29LV020@TSOP32 [(SA410T)]
AT29LV040@TSOP32 [(SA410T)]	AT29LV040A
AT29LV040A@PLCC32 [(SA015A1T)]	AT29LV040A@TSOP32 [(SA410T)]
AT29LV1024@PLCC44 [(SA244)]	AT29LV1024@TSOP48 [(SA247-B005)]
AT29LV256	AT29LV256@PLCC32 [(SA015A1T)]
AT29LV256@TSOP28 [(SA430T)]	AT29LV512
AT29LV512@PLCC32 [(SA015A1T)]	AT29LV512@TSOP32 [(SA410T)]
AT32C16	AT32C16@PLCC44 [(SA244)]
AT34C02	AT34C02@SOIC8 [(SA602A)]
AT34C02@TSSOP8 [(SA026)]	AT34C02B
AT34C02B@SOIC8 [(SA602A)]	AT34C02B@TSSOP8 [(SA026)]
AT34C02C	AT34C02C@dBG8 [(BBBB)]
AT34C02C@MAP8 [(SA724)]	AT34C02C@SOIC8 [(SA602A)]
AT34C02C@TSSOP8 [(SA026)]	
AT45BCM021D(page256)@SOIC8 [(SA605A)]	
AT45BCM021D(page256)@SOIC8(ISP) [ISP-HEADER01]	
AT45BCM021D(page264)@SOIC8 [(SA605A)]	
AT45BCM021D(page264)@SOIC8(ISP) [ISP-HEADER01]	
AT45D011@PLCC32 [(SA015A1T)]	AT45D011@SOIC8 [(SA605A)]
AT45D011@TSSOP14 [(SA026)]	AT45D021@PLCC32 [(SA015A1T)]
AT45D021@SOIC28 [(SA630)]	AT45D021@TSOP28 [(SA430T)]
AT45D041@PLCC32 [(SA015A1T)]	AT45D041@SOIC28 [(SA630)]
AT45D041@TSOP28 [(SA430T)]	AT45D081@SOIC28 [(SA630)]
AT45D081@TSOP32 [(SA410T)]	AT45D161@PLCC32 [(SA015A1T)]
AT45D161@SOIC28 [(SA630)]	AT45D161@TSOP28 [(SA430T)]
AT45DB011@PLCC32 [(SA015A1T)]	AT45DB011@SOIC8 [(SA605A)]
AT45DB011@TSSOP14 [(SA026)]	AT45DB011B@PLCC32 [(SA015A1T)]
AT45DB011B@PLCC32(ISP) [ISP-HEADER01]	
AT45DB011B@SOIC8 [(SA605A)]	
AT45DB011B@SOIC8(ISP) [ISP-HEADER01]	
AT45DB011B@TSSOP14 [(SA026)]	
AT45DB011B@TSSOP14(ISP) [ISP-HEADER01]	
AT45DB011D(page264)@QFN8 [(SA683)]	
AT45DB011D(page264)@QFN8(ISP) [ISP-HEADER01]	
AT45DB011D(page264)@SOIC8 [(SA023A)]	
AT45DB011D(page264)@SOIC8(ISP) [ISP-HEADER01]	
AT45DB021@PLCC32 [(SA015A1T)]	AT45DB021@SOIC28 [(SA630)]
AT45DB021@TSOP28 [(SA430T)]	AT45DB021A@PLCC32 [(SA015A1T)]
AT45DB021A@PLCC32(ISP) [ISP-HEADER01]	
AT45DB021A@SOIC28 [(SA630)]	
AT45DB021A@SOIC28(ISP) [ISP-HEADER01]	
AT45DB021A@TSOP28 [(SA430T)]	
AT45DB021A@TSOP28(ISP) [ISP-HEADER01]	
AT45DB021B@CBGA9 [(SA677A-B089A-K080F001N)]	
AT45DB021B@CBGA9(ISP) [ISP-HEADER01]	
AT45DB021B@SOIC28 [(SA630)]	
AT45DB021B@SOIC28(ISP) [ISP-HEADER01]	
AT45DB021B@SOIC8 [(SA023A)]	
AT45DB021B@SOIC8(ISP) [ISP-HEADER01]	
AT45DB021B@TSOP28 [(SA430T)]	
AT45DB021B@TSOP28(ISP) [ISP-HEADER01]	
AT45DB021D6(page264)@CASON8 [(SA683)]	
AT45DB021D6(page264)@CASON8(ISP) [ISP-HEADER01]	
AT45DB021D6(page264)@SOIC8 [(SA023A)]	
AT45DB021D6(page264)@SOIC8(ISP) [ISP-HEADER01]	
AT45DB041@PLCC32 [(SA015A1T)]	AT45DB041@SOIC28 [(SA630)]
AT45DB041@TSOP28 [(SA430T)]	AT45DB041A@PLCC32 [(SA015A1T)]
AT45DB041A@PLCC32(ISP) [ISP-HEADER01]	
AT45DB041A@SOIC28 [(SA630)]	
AT45DB041A@SOIC28(ISP) [ISP-HEADER01]	
AT45DB041A@TSOP28 [(SA430T)]	
AT45DB041A@TSOP28(ISP) [ISP-HEADER01]	
AT45DB041B@CASON8 [(SA684)]	AT45DB041B@CASON8(ISP) [(SA684)]
AT45DB041B@CBGA14 [(SA677A-B089A-K080F001N)]	
AT45DB041B@CBGA14(ISP) [ISP-HEADER01]	
AT45DB041B@SOIC28 [(SA630)]	
AT45DB041B@SOIC28(ISP) [ISP-HEADER01]	
AT45DB041B@SOIC8 [(SA605A)]	
AT45DB041B@SOIC8(ISP) [ISP-HEADER01]	
AT45DB041B@TSOP28 [(SA430T)]	
AT45DB041B@TSOP28(ISP) [ISP-HEADER01]	

AT45DB041D(page256)@QFN8 [(SA683)]
 AT45DB041D(page256)@QFN8(ISP) [ISP-HEADER01]
 AT45DB041D(page256)@SOIC8 [(SA605A)]
 AT45DB041D(page256)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB041D(page264)@QFN8 [(SA683)]
 AT45DB041D(page264)@QFN8(ISP) [ISP-HEADER01]
 AT45DB041D(page264)@SOIC8 [(SA605A)]
 AT45DB041D(page264)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB081@SOIC28 [(SA630)] AT45DB081@TSOP32 [(SA410T)]
 AT45DB081A@PLCC32 [(SA015A1T)]
 AT45DB081A@PLCC32(ISP) [ISP-HEADER01]
 AT45DB081A@SOIC28 [(SA630)]
 AT45DB081A@SOIC28(ISP) [ISP-HEADER01]
 AT45DB081A@TSOP28 [(SA430T)]
 AT45DB081A@TSOP28(ISP) [ISP-HEADER01]
 AT45DB081B@CASON8 [(SA684)] AT45DB081B@CASON8(ISP) [(SA684)]
 AT45DB081B@CBGA14 [(SA677A-B089A-K080F001N)]
 AT45DB081B@CBGA14(ISP) [ISP-HEADER01]
 AT45DB081B@SOIC28 [(SA630)]
 AT45DB081B@SOIC28(ISP) [ISP-HEADER01]
 AT45DB081B@SOIC8 [(SA605A)]
 AT45DB081B@SOIC8(ISP) [ISP-HEADER01]
 AT45DB081B@TSOP28 [(SA430T)]
 AT45DB081B@TSOP28(ISP) [ISP-HEADER01]
 AT45DB081D(page256)@MLF8 [(SA683)]
 AT45DB081D(page256)@QFN8(ISP) [ISP-HEADER01]
 AT45DB081D(page256)@SOIC8 [(SA023A)]
 AT45DB081D(page256)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB081D(page264)@MLF8 [(SA683)]
 AT45DB081D(page264)@QFN8(ISP) [ISP-HEADER01]
 AT45DB081D(page264)@SOIC8 [(SA023A)]
 AT45DB081D(page264)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB161@PLCC32 [(SA015A1T)] AT45DB161@SOIC28 [(SA630)]
 AT45DB161@TSOP28 [(SA430T)]
 AT45DB161B@CASON8(ISP) [ISP-HEADER01]
 AT45DB161B@CASON8 [(SA684)] AT45DB161B@SOIC28 [(SA630)]
 AT45DB161B@SOIC28(ISP) [ISP-HEADER01]
 AT45DB161B@TSOP28 [(SA430T)]
 AT45DB161B@TSOP28(ISP) [ISP-HEADER01]
 AT45DB161D(page512)@QFN8 [(SA683)]
 AT45DB161D(page512)@QFN8(ISP) [ISP-HEADER01]
 AT45DB161D(page512)@SOIC8 [(SA605A)]
 AT45DB161D(page512)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB161D(page512)@TSOP28 [(SA430T)]
 AT45DB161D(page512)@TSOP28(ISP) [ISP-HEADER01]
 AT45DB161D(page528)@QFN8 [(SA683)]
 AT45DB161D(page528)@QFN8(ISP) [ISP-HEADER01]
 AT45DB161D(page528)@SOIC8 [(SA605A)]
 AT45DB161D(page528)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB161D(page528)@TSOP28 [(SA430T)]
 AT45DB161D(page528)@TSOP28(ISP) [ISP-HEADER01]
 AT45DB321@TSOP32 [(SA410T)] AT45DB321B@SOIC28 [(SA630)]
 AT45DB321B@SOIC28(ISP) [ISP-HEADER01]
 AT45DB321B@TSOP32 [(SA410T)]
 AT45DB321B@TSOP32(ISP) [ISP-HEADER01]
 AT45DB321C@CASON8 [(SA684)]
 AT45DB321C@CASON8(ISP) [ISP-HEADER01]
 AT45DB321C@SOIC28 [(SA630)]
 AT45DB321C@SOIC28(ISP) [ISP-HEADER01]
 AT45DB321C@TSOP28 [(SA430T)]
 AT45DB321C@TSOP28(ISP) [ISP-HEADER01]
 AT45DB321D(page512)@QFN8 [(SA683)]
 AT45DB321D(page512)@QFN8(ISP) [ISP-HEADER01]
 AT45DB321D(page512)@SOIC8 [(SA023A)]
 AT45DB321D(page512)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB321D(page512)@TSOP28 [(SA430T)]
 AT45DB321D(page512)@TSOP28(ISP) [ISP-HEADER01]
 AT45DB321D(page528)@QFN8 [(SA683)]
 AT45DB321D(page528)@QFN8(ISP) [ISP-HEADER01]
 AT45DB321D(page528)@SOIC8 [(SA023A)]
 AT45DB321D(page528)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB321D(page528)@TSOP28 [(SA430T)]
 AT45DB321D(page528)@TSOP28(ISP) [ISP-HEADER01]
 AT45DB642@TSOP40 [(SA409T)]
 AT45DB642@TSOP40(ISP) [ISP-HEADER01]
 AT45DB642D(page1024)@CASON8 [(SA684)]
 AT45DB642D(page1024)@CASON8(ISP) [(ISP-HEADER01)]
 AT45DB642D(page1024)@TSOP28 [(SA430)]
 AT45DB642D(page1024)@TSOP28(ISP) [(ISP-HEADER01)]
 AT45DB642D(page1056)@CASON8 [(SA684)]
 AT45DB642D(page1056)@CASON8(ISP) [(ISP-HEADER01)]

```

AT45DB642D(page1056)@TSOP28 [(SA430)]
AT45DB642D(page1056)@TSOP28(ISP) [(ISP-HEADER01)]
AT45DCB008D4(page1024) [(CARD005-B005)]
AT45DCB008D4(page1024)(ISP) [(ISP-HEADER01)]
AT45DCB008D6(page1056) [(CARD005-B005)]
AT45DCB008D6(page1056)(ISP) [(ISP-HEADER01)]
AT49BV001 AT49BV001@PLCC32 [(SA015A1T)]
AT49BV001@TSOP32 [(SA410T)] AT49BV001@VSOP32 [(SA620)]
AT49BV001A AT49BV001A@PLCC32 [(SA015A1T)]
AT49BV001A@TSOP32 [(SA410T)] AT49BV001A@VSOP32 [(SA620)]
AT49BV001AN AT49BV001AN@PLCC32 [(SA015A1T)]
AT49BV001AN@TSOP32 [(SA410T)] AT49BV001AN@VSOP32 [(SA620)]
AT49BV001ANT AT49BV001ANT@PLCC32 [(SA015A1T)]
AT49BV001ANT@TSOP32 [(SA410T)] AT49BV001ANT@VSOP32 [(SA620)]
AT49BV001AT AT49BV001AT@PLCC32 [(SA015A1T)]
AT49BV001AT@TSOP32 [(SA410T)] AT49BV001AT@VSOP32 [(SA620)]
AT49BV001N AT49BV001N@PLCC32 [(SA015A1T)]
AT49BV001N@TSOP32 [(SA410T)] AT49BV001N@VSOP32 [(SA620)]
AT49BV001NT AT49BV001NT@PLCC32 [(SA015A1T)]
AT49BV001NT@TSOP32 [(SA410T)] AT49BV001NT@VSOP32 [(SA620)]
AT49BV001T AT49BV001T@PLCC32 [(SA015A1T)]
AT49BV001T@TSOP32 [(SA410T)] AT49BV001T@VSOP32 [(SA620)]
AT49BV002 AT49BV002@PLCC32 [(SA015A1T)]
AT49BV002@TSOP32 [(SA410T)] AT49BV002@VSOP32 [(SA620)]
AT49BV002A AT49BV002A@PLCC32 [(SA015A1T)]
AT49BV002A@TSOP32 [(SA410T)] AT49BV002A@VSOP32 [(SA620)]
AT49BV002AN AT49BV002AN@PLCC32 [(SA015A1T)]
AT49BV002AN@TSOP32 [(SA410T)] AT49BV002AN@VSOP32 [(SA620)]
AT49BV002ANT AT49BV002ANT@PLCC32 [(SA015A1T)]
AT49BV002ANT@TSOP32 [(SA410T)] AT49BV002ANT@VSOP32 [(SA620)]
AT49BV002AT AT49BV002AT@PLCC32 [(SA015A1T)]
AT49BV002AT@TSOP32 [(SA410T)] AT49BV002AT@VSOP32 [(SA620)]
AT49BV002N AT49BV002N@PLCC32 [(SA015A1T)]
AT49BV002N@TSOP32 [(SA410T)] AT49BV002N@VSOP32 [(SA620)]
AT49BV002NT AT49BV002NT@PLCC32 [(SA015A1T)]
AT49BV002NT@TSOP32 [(SA410T)] AT49BV002NT@VSOP32 [(SA620)]
AT49BV002T AT49BV002T@PLCC32 [(SA015A1T)]
AT49BV002T@TSOP32 [(SA410T)] AT49BV002T@VSOP32 [(SA620)]
AT49BV010 AT49BV010@PLCC32 [(SA015A1T)]
AT49BV010@TSOP32 [(SA410T)] AT49BV020
AT49BV020@PLCC32 [(SA015A1T)] AT49BV020@TSOP32 [(SA410T)]
AT49BV040 AT49BV040@PLCC32 [(SA015A1T)]
AT49BV040@TSOP32 [(SA410T)] AT49BV040A@PLCC32 [(SA015A1T)]
AT49BV040B@PLCC32 [(SA015A1T-B001)] AT49BV040A@VSOP32 [(SA620)]
AT49BV040B@TSOP32 [(SA410T-B003)]
AT49BV040B@VSOP32 [(SA620-B005)] AT49BV040T
AT49BV040T@PLCC32 [(SA015A1T)] AT49BV040T@TSOP32 [(SA410T)]
AT49BV080@PSOP44 [(SA638)] AT49BV080@TSOP40 [(SA409T)]
AT49BV080T@PSOP44 [(SA638)] AT49BV080T@TSOP40 [(SA409T)]
AT49BV1024A@TSOP40 [(SA623)] AT49BV1614@TSOP48 [(SA247-B005)]
AT49BV1614A@TSOP48 [(SA247-B005)] AT49BV1614AT@TSOP48 [(SA247-B005)]
AT49BV1614T@TSOP48 [(SA247-B005)]
AT49BV2048@PSOP44 [(SA638)] AT49BV2048@TSOP48 [(SA247-B005)]
AT49BV2048A@PSOP44 [(SA638)]
AT49BV2048A@TSOP48 [(SA247-B005)]
AT49BV2048B@TSOP48 [(SA247-B005)]
AT49BV512 AT49BV512@PLCC32 [(SA015A1T)]
AT49BV512@TSOP32 [(SA410T)] AT49BV512@VSOP32 [(SA620)]
AT49F001 AT49F001@PLCC32 [(SA015A1T)]
AT49F001@TSOP32 [(SA410T)] AT49F001@VSOP32 [(SA620)]
AT49F001A AT49F001A@PLCC32 [(SA015A1T)]
AT49F001A@TSOP32 [(SA410T)] AT49F001A@VSOP32 [(SA620)]
AT49F001AN AT49F001AN@PLCC32 [(SA015A1T)]
AT49F001AN@TSOP32 [(SA410T)] AT49F001AN@VSOP32 [(SA620)]
AT49F001ANT AT49F001ANT@PLCC32 [(SA015A1T)]
AT49F001ANT@TSOP32 [(SA410T)] AT49F001ANT@VSOP32 [(SA620)]
AT49F001AT AT49F001AT@PLCC32 [(SA015A1T)]
AT49F001AT@TSOP32 [(SA410T)] AT49F001AT@VSOP32 [(SA620)]
AT49F001N AT49F001N@PLCC32 [(SA015A1T)]
AT49F001N@TSOP32 [(SA410T)] AT49F001N@VSOP32 [(SA620)]
AT49F001NT AT49F001NT@PLCC32 [(SA015A1T)]
AT49F001NT@TSOP32 [(SA410T)] AT49F001NT@VSOP32 [(SA620)]
AT49F001T AT49F001T@PLCC32 [(SA015A1T)]
AT49F001T@TSOP32 [(SA410T)] AT49F001T@VSOP32 [(SA620)]
AT49F002 AT49F002@PLCC32 [(SA015A1T)]
AT49F002@TSOP32 [(SA410T)] AT49F002@VSOP32 [(SA620)]
AT49F002A AT49F002A@PLCC32 [(SA015A1T)]
AT49F002A@TSOP32 [(SA410T)] AT49F002A@VSOP32 [(SA620)]
AT49F002AN AT49F002AN@PLCC32 [(SA015A1T)]

```

AT49F002AN@TSOP32 [(SA410T)]	AT49F002AN@VSOP32 [(SA620)]
AT49F002ANT	AT49F002ANT@PLCC32 [(SA015A1T)]
AT49F002ANT@TSOP32 [(SA410T)]	AT49F002ANT@VSOP32 [(SA620)]
AT49F002AT	AT49F002AT@PLCC32 [(SA015A1T)]
AT49F002AT@TSOP32 [(SA410T)]	AT49F002AT@VSOP32 [(SA620)]
AT49F002N	AT49F002N@PLCC32 [(SA015A1T)]
AT49F002N@TSOP32 [(SA410T)]	AT49F002N@VSOP32 [(SA620)]
AT49F002NT	AT49F002NT@PLCC32 [(SA015A1T)]
AT49F002NT@TSOP32 [(SA410T)]	AT49F002NT@VSOP32 [(SA620)]
AT49F002T	AT49F002T@PLCC32 [(SA015A1T)]
AT49F002T@TSOP32 [(SA410T)]	AT49F002T@VSOP32 [(SA620)]
AT49F008@TSOP40 [(SA409T)]	AT49F008A@TSOP40 [(SA409T)]
AT49F008AT@TSOP40 [(SA409T)]	AT49F010
AT49F010@PLCC32 [(SA015A1T)]	AT49F010@TSOP32 [(SA410T)]
AT49F020	AT49F020@PLCC32 [(SA015A1T)]
AT49F020@TSOP32 [(SA410T)]	AT49F040
AT49F040@PLCC32 [(SA015A1T)]	AT49F040@TSOP32 [(SA410T)]
AT49F040A	AT49F040A@PLCC32 [(SA015A1T)]
AT49F040A@TSOP32 [(SA410T)]	AT49F080@PSOP44 [(SA638)]
AT49F080@TSOP40 [(SA409T)]	AT49F080T@PSOP44 [(SA638)]
AT49F080T@TSOP40 [(SA409T)]	AT49F1024@TSOP40 [(SA623)]
AT49F1024A@TSOP40 [(SA623)]	AT49F1025@PLCC44 [(SA244)]
AT49F1614@TSOP48 [(SA247-B005)]	AT49F1614T@TSOP48 [(SA247-B005)]
AT49F2048@PSOP44 [(SA638)]	AT49F2048@TSOP48 [(SA247-B005)]
AT49F2048A@PSOP44 [(SA638)]	AT49F2048A@TSOP48 [(SA247-B005)]
AT49F4096@PSOP44 [(SA638)]	AT49F4096@TSOP48 [(SA247-B005)]
AT49F4096A@PSOP44 [(SA638)]	AT49F4096A@TSOP48 [(SA247-B005)]
AT49F512	AT49F512@PLCC32 [(SA015A1T)]
AT49F512@TSOP32 [(SA410T)]	AT49F512@VSOP32 [(SA620)]
AT49F516@PLCC44 [(SA244)]	AT49F516@TSOP40 [(SA623)]
AT49F8192@PSOP44 [(SA638)]	AT49F8192@TSOP48 [(SA247-B005)]
AT49F8192A@PSOP44 [(SA638)]	AT49F8192A@TSOP48 [(SA247-B005)]
AT49F8192AT@PSOP44 [(SA638)]	
AT49F8192AT@TSOP48 [(SA247-B005)]	
AT49F8192T@PSOP44 [(SA638)]	AT49F8192T@TSOP48 [(SA247-B005)]
AT49HBV010	AT49HBV010@PLCC32 [(SA015A1T)]
AT49HBV010@TSOP32 [(SA410T)]	AT49HF010
AT49HF010@PLCC32 [(SA015A1T)]	AT49HF010@TSOP32 [(SA410T)]
AT49HLV010	AT49HLV010@PLCC32 [(SA015A1T)]
AT49HLV010@TSOP32 [(SA410T)]	AT49LH002@PLCC32 [(SA015A1T)]
AT49LH002@TSOP40 [(SA409T)]	AT49LH004@PLCC32 [(SA015A1T)]
AT49LH004@TSOP40 [(SA409T)]	AT49LH00B4@PLCC32 [(SA015A1T)]
AT49LH00B4@TSOP40 [(SA409T)]	AT49LL020@PLCC32 [(SA015A1T)]
AT49LL020@TSOP40 [(SA409T)]	AT49LL040@PLCC32 [(SA015A1T)]
AT49LL040@TSOP40 [(SA409T)]	AT49LL080@PLCC32 [(SA015A1T)]
AT49LL080@TSOP40 [(SA409T)]	AT49LV001
AT49LV001@PLCC32 [(SA015A1T)]	AT49LV001@TSOP32 [(SA410T)]
AT49LV001@VSOP32 [(SA620)]	AT49LV001N
AT49LV001N@PLCC32 [(SA015A1T)]	AT49LV001N@TSOP32 [(SA410T)]
AT49LV001N@VSOP32 [(SA620)]	AT49LV001NT
AT49LV001NT@PLCC32 [(SA015A1T)]	AT49LV001NT@TSOP32 [(SA410T)]
AT49LV001NT@VSOP32 [(SA620)]	AT49LV001T
AT49LV001T@PLCC32 [(SA015A1T)]	AT49LV001T@TSOP32 [(SA410T)]
AT49LV001T@VSOP32 [(SA620)]	AT49LV002
AT49LV002@PLCC32 [(SA015A1T)]	AT49LV002@TSOP32 [(SA410T)]
AT49LV002@VSOP32 [(SA620)]	AT49LV002N
AT49LV002N@PLCC32 [(SA015A1T)]	AT49LV002N@TSOP32 [(SA410T)]
AT49LV002N@VSOP32 [(SA620)]	AT49LV002NT
AT49LV002NT@PLCC32 [(SA015A1T)]	AT49LV002NT@TSOP32 [(SA410T)]
AT49LV002NT@VSOP32 [(SA620)]	AT49LV002T
AT49LV002T@PLCC32 [(SA015A1T)]	AT49LV002T@TSOP32 [(SA410T)]
AT49LV002T@VSOP32 [(SA620)]	AT49LV010
AT49LV010@PLCC32 [(SA015A1T)]	AT49LV010@TSOP32 [(SA410T)]
AT49LV020	AT49LV020@PLCC32 [(SA015A1T)]
AT49LV020@TSOP32 [(SA410T)]	AT49LV040
AT49LV040@PLCC32 [(SA015A1T)]	AT49LV040@TSOP32 [(SA410T)]
AT49LV040T	AT49LV040T@PLCC32 [(SA015A1T)]
AT49LV040T@TSOP32 [(SA410T)]	AT49LV080@PSOP44 [(SA638)]
AT49LV080@TSOP40 [(SA409T)]	AT49LV080T@PSOP44 [(SA638)]
AT49LV080T@TSOP40 [(SA409T)]	AT49LV1024@TSOP40 [(SA623)]
AT49LV1024A@TSOP40 [(SA623)]	AT49LV1025@PLCC44 [(SA244)]
AT49LV1614@TSOP48 [(SA247-B005)]	
AT49LV1614A@TSOP48 [(SA247-B005)]	
AT49LV1614AT@TSOP48 [(SA247-B005)]	
AT49LV1614T@TSOP48 [(SA247-B005)]	
AT49LV2048@PSOP44 [(SA638)]	AT49LV2048@TSOP48 [(SA247-B005)]
AT49LV2048A@PSOP44 [(SA638)]	
AT49LV2048A@TSOP48 [(SA247-B005)]	
AT49LV2048B@TSOP48 [(SA247-B005)]	
AT49LW040@PLCC32 [(SA015A1T)]	AT49LW040@TSOP40 [(SA409T)]
AT49LW080@PLCC32 [(SA015A1T)]	AT49LW080@TSOP40 [(SA409T)]

AT59C11	AT59C11@SOIC8 [(SA602A)]
AT59C12	AT59C12@SOIC8 [(SA602A)]
AT59C13	AT59C13@SOIC8 [(SA602A)]
AT59C22	AT59C22@SOIC8 [(SA602A)]
AT93C46(08bit)	AT93C46(08bit)@SOIC8 [(SA602A)]
AT93C46(08bit)@TSSOP8 [(SA026)]	AT93C46(16bit)
AT93C46(16bit)@SOIC8 [(SA602A)]	AT93C46(16bit)@TSSOP8 [(SA026)]
AT93C46A	AT93C46A@SOIC8 [(SA602A)]
AT93C46A@TSSOP8 [(SA026)]	AT93C46C
AT93C46C@SOIC8 [(SA602A)]	AT93C46C@TSSOP8 [(SA026)]
AT93C46D(08bit)	AT93C46D(08bit)@dBGA8 [(BBBB)]
AT93C46D(08bit)@MAP8 [(SA724)]	AT93C46D(08bit)@SOIC8 [(SA602A)]
AT93C46D(08bit)@TSSOP8 [(SA026)]	AT93C46D(16bit)
AT93C46D(16bit)@dBGA8 [(BBBB)]	AT93C46D(16bit)@MAP8 [(SA724)]
AT93C46D(16bit)@SOIC8 [(SA602A)]	AT93C46D(16bit)@TSSOP8 [(SA026)]
AT93C46E	AT93C46E@SOIC8 [(SA602A)]
AT93C46E@TSSOP8 [(SA026)]	AT93C56(08bit)
AT93C56(08bit)@SOIC8 [(SA602A)]	AT93C56(16bit)
AT93C56(16bit)@SOIC8 [(SA602A)]	AT93C56A(08bit)
AT93C56A(08bit)@SOIC8 [(SA602A)]	AT93C56A(08bit)@TSSOP8 [(SA026)]
AT93C56A(16bit)	AT93C56A(16bit)@SOIC8 [(SA602A)]
AT93C56A(16bit)@TSSOP8 [(SA026)]	AT93C57
AT93C57@SOIC8 [(SA602A)]	AT93C66(08bit)
AT93C66(08bit)@SOIC8 [(SA602A)]	AT93C66(16bit)
AT93C66(16bit)@SOIC8 [(SA602A)]	AT93C66A(08bit)
AT93C66A(08bit)@SOIC8 [(SA602A)]	AT93C66A(08bit)@TSSOP8 [(SA026)]
AT93C66A(16bit)	AT93C66A(16bit)@SOIC8 [(SA602A)]
AT93C66A(16bit)@TSSOP8 [(SA026)]	AT93C86(08bit)
AT93C86(08bit)@SOIC8 [(SA602A)]	AT93C86(08bit)@TSSOP8 [(SA026)]
AT93C86(16bit)	AT93C86(16bit)@SOIC8 [(SA602A)]
AT93C86(16bit)@TSSOP8 [(SA026)]	AT93C86A(08bit)
AT93C86A(08bit)@SOIC8 [(SA602A)]	AT93C86A(08bit)@TSSOP8 [(SA026)]
AT93C86A(16bit)	AT93C86A(16bit)@SOIC8 [(SA602A)]
AT93C86A(16bit)@TSSOP8 [(SA026)]	

DRAM & SRAM

AT3864L	AT3864L@TSOP28 [(SA643)]
AT38H256	AT38H256@TSOP28 [(SA643)]

PLD

ATF16LV8C	ATF16LV8C@PLCC20 [(SA001A)]
ATF16LV8C@SOIC20 [(SA404)]	ATF16LV8C@TSOP20 [(SA026)]
ATF16LV8CEXT	ATF16LV8CEXT@PLCC20 [(SA001A)]
ATF16LV8CEXT@SOIC20 [(SA404)]	ATF16LV8CEXT@TSOP20 [(SA026)]
ATF16V8B	ATF16V8B@PLCC20 [(SA001A)]
ATF16V8B@SOIC20 [(SA404)]	ATF16V8B@TSOP20 [(SA026)]
ATF16V8BL	ATF16V8BL@PLCC20 [(SA001A)]
ATF16V8BL@SOIC20 [(SA404)]	ATF16V8BL@TSOP20 [(SA026)]
ATF16V8BQ	ATF16V8BQ@PLCC20 [(SA001A)]
ATF16V8BQ@SOIC20 [(SA404)]	ATF16V8BQ@TSOP20 [(SA026)]
ATF16V8BQL	ATF16V8BQL@PLCC20 [(SA001A)]
ATF16V8BQL@SOIC20 [(SA404)]	ATF16V8BQL@TSOP20 [(SA026)]
ATF16V8C	ATF16V8C@PLCC20 [(SA001A)]
ATF16V8C@SOIC20 [(SA404)]	ATF16V8C@TSOP20 [(SA026)]
ATF16V8CEXT	ATF16V8CEXT@PLCC20 [(SA001A)]
ATF16V8CEXT@SOIC20 [(SA404)]	ATF16V8CEXT@TSOP20 [(SA026)]
ATF16V8CZ	ATF16V8CZ@PLCC20 [(SA001A)]
ATF16V8CZ@SOIC20 [(SA404)]	ATF16V8CZ@TSOP20 [(SA026)]
ATF20V8B	ATF20V8B@PLCC28 [(SA008A)]
ATF20V8B@SOIC24 [(SA404)]	ATF20V8BL
ATF20V8BL@PLCC28 [(SA008A)]	ATF20V8BL@SOIC24 [(SA404)]
ATF20V8BQ	ATF20V8BQ@PLCC28 [(SA008A)]
ATF20V8BQ@SOIC24 [(SA404)]	ATF20V8BQL
ATF20V8BQL@PLCC28 [(SA008A)]	ATF20V8BQL@SOIC24 [(SA404)]
ATF22LV10C	ATF22LV10C(UES)
ATF22LV10C(UES)@PLCC28 [(SA008A)]	ATF22LV10C@SOIC24 [(SA404)]
ATF22LV10C(UES)@SOIC24 [(SA404)]	ATF22LV10CEXT
ATF22LV10C(UES)@TSSOP24 [(SA643)]	ATF22LV10CEXT@SOIC24 [(SA404)]
ATF22LV10C@PLCC28 [(SA008A)]	ATF22LV10CQ
ATF22LV10C@TSSOP24 [(SA643)]	
ATF22LV10CEXT@PLCC28 [(SA008A)]	
ATF22LV10CEXT@TSSOP24 [(SA643)]	
ATF22LV10CQ(UES)	
ATF22LV10CQ(UES)@PLCC28 [(SA008A)]	
ATF22LV10CQ(UES)@SOIC24 [(SA404)]	
ATF22LV10CQ(UES)@TSSOP24 [(SA643)]	

```

ATF22LV10CQ@PLCC28 [(SA008A)]      ATF22LV10CQ@SOIC24 [(SA404)]
ATF22LV10CQ@TSSOP24 [(SA643)]      ATF22LV10CQZ
ATF22LV10CQZ(UES)
ATF22LV10CQZ(UES)@PLCC28 [(SA008A)]
ATF22LV10CQZ(UES)@SOIC24 [(SA404)]
ATF22LV10CQZ(UES)@TSSOP24 [(SA643)]
ATF22LV10CQZ@PLCC28 [(SA008A)]      ATF22LV10CQZ@SOIC24 [(SA404)]
ATF22LV10CQZ@TSSOP24 [(SA643)]      ATF22LV10CZ
ATF22LV10CZ(UES)
ATF22LV10CZ(UES)@PLCC28 [(SA008A)]
ATF22LV10CZ(UES)@SOIC24 [(SA404)]
ATF22LV10CZ(UES)@TSSOP24 [(SA643)]
ATF22LV10CZ@PLCC28 [(SA008A)]      ATF22LV10CZ@SOIC24 [(SA404)]
ATF22LV10CZ@TSSOP24 [(SA643)]      ATF22V10B
ATF22V10B(UES)                       ATF22V10B(UES)@PLCC28 [(SA008A)]
ATF22V10B(UES)@SOIC24 [(SA404)]      ATF22V10B@PLCC28 [(SA008A)]
ATF22V10B@SOIC24 [(SA404)]          ATF22V10BL
ATF22V10BL(UES)
ATF22V10BL(UES)@PLCC28 [(SA008A)]
ATF22V10BL(UES)@SOIC24 [(SA404)]      ATF22V10BL@PLCC28 [(SA008A)]
ATF22V10BL@SOIC24 [(SA404)]          ATF22V10BQ
ATF22V10BQ(UES)
ATF22V10BQ(UES)@PLCC28 [(SA008A)]
ATF22V10BQ(UES)@SOIC24 [(SA404)]      ATF22V10BQ@PLCC28 [(SA008A)]
ATF22V10BQ@SOIC24 [(SA404)]          ATF22V10BQL
ATF22V10BQL(UES)
ATF22V10BQL(UES)@PLCC28 [(SA008A)]
ATF22V10BQL(UES)@SOIC24 [(SA404)]      ATF22V10BQL@SOIC24 [(SA404)]
ATF22V10BQL@PLCC28 [(SA008A)]        ATF22V10C(UES)
ATF22V10C                             ATF22V10C(UES)@SOIC24 [(SA404)]
ATF22V10C(UES)@PLCC28 [(SA008A)]      ATF22V10C@PLCC28 [(SA008A)]
ATF22V10C(UES)@TSSOP24 [(SA643)]      ATF22V10C@TSSOP24 [(SA643)]
ATF22V10C@SOIC24 [(SA404)]           ATF22V10C@TSSOP24 [(SA643)]
ATF22V10CEXT                           ATF22V10CEXT@PLCC28 [(SA008A)]
ATF22V10CEXT@SOIC24 [(SA404)]          ATF22V10CEXT@TSSOP24 [(SA643)]
ATF22V10CQ                               ATF22V10CQ(UES)
ATF22V10CQ(UES)@PLCC28 [(SA008A)]
ATF22V10CQ(UES)@SOIC24 [(SA404)]
ATF22V10CQ(UES)@TSSOP24 [(SA643)]
ATF22V10CQ@PLCC28 [(SA008A)]          ATF22V10CQ@SOIC24 [(SA404)]
ATF22V10CQ@TSSOP24 [(SA643)]          ATF22V10CQZ
ATF22V10CQZ(UES)
ATF22V10CQZ(UES)@PLCC28 [(SA008A)]
ATF22V10CQZ(UES)@SOIC24 [(SA404)]
ATF22V10CQZ(UES)@TSSOP24 [(SA643)]
ATF22V10CQZ@PLCC28 [(SA008A)]          ATF22V10CQZ@SOIC24 [(SA404)]
ATF22V10CQZ@TSSOP24 [(SA643)]          ATF22V10CZ
ATF22V10CZ(UES)
ATF22V10CZ(UES)@PLCC28 [(SA008A)]
ATF22V10CZ(UES)@SOIC24 [(SA404)]
ATF22V10CZ(UES)@TSSOP24 [(SA643)]
ATF22V10CZ@PLCC28 [(SA008A)]          ATF22V10CZ@SOIC24 [(SA404)]
ATF22V10CZ@TSSOP24 [(SA643)]          ATF750C
ATF750C                                  (ATF750C mode)
(ATV750 mode)                            ATF750C
(ATV750B mode)
ATF750C@PLCC28 (ATF750C mode) [(SA008A)]
ATF750C@PLCC28 (ATV750 mode) [(SA008A)]
ATF750C@PLCC28 (ATV750B mode) [(SA008A)]
ATF750C@SOIC24 (ATF750C mode) [(SA404)]
ATF750C@SOIC24 (ATV750 mode) [(SA404)]
ATF750C@SOIC24 (ATV750B mode) [(SA404)]
ATF750CEXT (ATF750C mode)
ATF750CEXT@PLCC28 (ATF750C mode) [(SA008A)]
ATF750CEXT@SOIC24 (ATF750C mode) [(SA404)]
ATF750CL (ATV750 mode) ATF750CL (ATV750B mode)
(ATV750 mode) [(SA008A)]
ATF750CL@PLCC28 (ATV750B mode) [(SA008A)]
ATF750CL@PLCC28 (ATV750 mode) [(SA404)]
ATF750CL@SOIC24 (ATV750B mode) [(SA404)]
ATF750LVC (ATF750C mode) ATF750LVC (ATV750 mode)
(ATV750B mode) [(SA008A)]
ATF750LVC@PLCC28 (ATF750C mode) [(SA008A)]
ATF750LVC@PLCC28 (ATV750 mode) [(SA008A)]
ATF750LVC@PLCC28 (ATV750B mode) [(SA008A)]
ATF750LVC@SOIC24 (ATF750C mode) [(SA404)]
ATF750LVC@SOIC24 (ATV750 mode) [(SA404)]
ATF750LVC@SOIC24 (ATV750B mode) [(SA404)]
ATF750LVCEXT (ATF750C mode)
ATF750LVCEXT@PLCC28 (ATF750C mode) [(SA008A)]
ATF750LVCEXT@SOIC24 (ATF750C mode) [(SA404)]
ATF750LVCL (ATF750C mode) ATF750LVCL (ATV750 mode)
(ATV750B mode) [(SA008A)]
ATF750LVCL (ATV750B mode)

```

```

ATF750LVCL@PLCC28 (ATF750C mode) [(SA008A)]
ATF750LVCL@PLCC28 (ATV750 mode) [(SA008A)]
ATF750LVCL@PLCC28 (ATV750B mode) [(SA008A)]
ATF750LVCL@SOIC24 (ATF750C mode) [(SA404)]
ATF750LVCL@SOIC24 (ATV750 mode) [(SA404)]
ATF750LVCL@SOIC24 (ATV750B mode) [(SA404)]
ATV750 ATV750@PLCC28 [(SA008A)]
ATV750@SOIC24 [(SA404)] ATV750B
ATV750B@PLCC28 [(SA008A)] ATV750B@SOIC24 [(SA404)]
ATV750BL ATV750BL@PLCC28 [(SA008A)]
ATV750BL@SOIC24 [(SA404)] ATV750L
ATV750L@PLCC28 [(SA008A)] ATV750L@SOIC24 [(SA404)]

```

MICROCONTROLLER

```

AT80F51 AT80F51@PLCC44 [(SA244)]
AT80F51@TQFP44 [(SA245A)] AT80F52
AT80F52@PLCC44 [(SA244)] AT80F52@TQFP44 [(SA245A)]
AT87F51 AT87F51@PLCC44 [(SA244)]
AT87F51@TQFP44 [(SA245A)] AT87F51RC
AT87F51RC@PLCC44 [(SA244)] AT87F51RC@TQFP44 [(SA245A)]
AT87F52 AT87F52@PLCC44 [(SA244)]
AT87F52@TQFP44 [(SA245A)] AT87F55
AT87F55@PLCC44 [(SA244)] AT87F55@TQFP44 [(SA245A)]
AT87F55WD AT87F55WD@PLCC44 [(SA244)]
AT87F55WD@TQFP44 [(SA245A)] AT87LV51
AT87LV51@PLCC44 [(SA244)] AT87LV51@TQFP44 [(SA245A)]
AT87LV52 AT87LV52@PLCC44 [(SA244)]
AT87LV52@TQFP44 [(SA245A)] AT89C1051
AT89C1051@SOIC20 [(SA404)] AT89C1051U
AT89C1051U@SOIC20 [(SA404)] AT89C2051
AT89C2051@SOIC20 [(SA404)] AT89C2051X2
AT89C2051X2@SOIC20 [(SA404)] AT89C4051
AT89C4051@SOIC20 [(SA404)] AT89C51
AT89C51@PLCC44 [(SA244)] AT89C51@TQFP44 [(SA245A)]
AT89C5130A@QFN32 [(SA701)] AT89C5130A@SOIC28 [(SA404)]
AT89C5130AM@QFN32 [(SA701)] AT89C5130AM@SOIC28 [(SA404)]
AT89C5131@MLF48 [(SA696)] AT89C5131@SOIC28 [(SA404)]
AT89C5131A@QFN32 [(SA701)] AT89C5131A@SOIC28 [(SA404)]
AT89C5131AL@QFN32 [(SA701)] AT89C5131AL@SOIC28 [(SA404)]
AT89C5131AM@QFN32 [(SA701)] AT89C5131AM@SOIC28 [(SA404)]
AT89C51AC2@PLCC44 [(SA244)] AT89C51AC2@TQFP44 [(SA245A)]
AT89C51AC3@PLCC44 [(SA244)] AT89C51AC3@TQFP44 [(SA245A)]
AT89C51CC01@PLCC44 [(SA244)] AT89C51CC01@TQFP44 [(SA245A)]
AT89C51CC03A@PLCC44 [(SA244)] AT89C51CC03A@TQFP44 [(SA245A)]
AT89C51CC03C@PLCC44 [(SA244)] AT89C51CC03C@TQFP44 [(SA245A)]
AT89C51CC03U@PLCC44 [(SA244)] AT89C51CC03U@TQFP44 [(SA245A)]
AT89C51ED2 AT89C51ED2@PLCC44 [(SA244)]
AT89C51ED2@TQFP44 [(SA245A)] AT89C51IC2@PLCC44 [(SA244)]
AT89C51IC2@TQFP44 [(SA245A)] AT89C51ID2
AT89C51ID2@PLCC44 [(SA244)] AT89C51ID2@TQFP44 [(SA245A)]
AT89C51RB2 AT89C51RB2@PLCC44 [(SA244)]
AT89C51RB2@TQFP44 [(SA245A)] AT89C51RC
AT89C51RC@PLCC44 [(SA244)] AT89C51RC@TQFP44 [(SA245A)]
AT89C51RC2 AT89C51RC2@PLCC44 [(SA244)]
AT89C51RC2@TQFP44 [(SA245A)] AT89C51RD2
AT89C51RD2@PLCC44 [(SA244)] AT89C51RD2@TQFP44 [(SA245A)]
AT89C51RE2@PLCC44 [(SA244)] AT89C51RE2@TQFP44 [(SA675)]
AT89C52 AT89C52@PLCC44 [(SA244)]
AT89C52@TQFP44 [(SA245A)] AT89C55
AT89C55@PLCC44 [(SA244)] AT89C55@TQFP44 [(SA245A)]
AT89C55WD AT89C55WD@PLCC44 [(SA244)]
AT89C55WD@TQFP44 [(SA245A)] AT89LP2051
AT89LP2051@SOIC20 [(SA404)] AT89LP2051@TSSOP20 [(SA026)]
AT89LP2052 AT89LP2052(ISP) [(ISP-HEADER01)]
AT89LP2052@SOIC20 [(SA404)]
AT89LP2052@SOIC20(ISP) [(ISP-HEADER01)]
AT89LP2052@TSSOP20 [(SA026)]
AT89LP2052@TSSOP20(ISP) [(ISP-HEADER01)]
AT89LP213 AT89LP213(ISP) [(ISP-HEADER01)]
AT89LP213@TSSOP14 [(SA026)]
AT89LP213@TSSOP14(ISP) [(ISP-HEADER01)]
AT89LP214 AT89LP214(ISP) [(ISP-HEADER01)]
AT89LP214@TSSOP14 [(SA026)]
AT89LP214@TSSOP14(ISP) [(ISP-HEADER01)]
AT89LP216 AT89LP216(ISP) [(ISP-HEADER01)]
AT89LP216@TSSOP16 [(SA026)]
AT89LP216@TSSOP16(ISP) [(ISP-HEADER01)]
AT89LP4051 AT89LP4051@SOIC20 [(SA404)]

```


AT89LP4051@TSSOP20 [(SA026)]	AT89LP4052
AT89LP4052(ISP) [ISP-HEADER01]	AT89LP4052@SOIC20 [(SA404)]
AT89LP4052@SOIC20(ISP) [ISP-HEADER01]	
AT89LP4052@TSSOP20 [(SA026)]	
AT89LP4052@TSSOP20(ISP) [ISP-HEADER01]	
AT89LP428	AT89LP428(ISP) [ISP-HEADER01]
AT89LP428@PLCC32 [(SA015A1T)]	
AT89LP428@PLCC32(ISP) [ISP-HEADER01]	
AT89LP428@TQFP32 [(SA636)]	
AT89LP428@TQFP32(ISP) [ISP-HEADER01]	
AT89LP828	AT89LP828(ISP) [ISP-HEADER01]
AT89LP828@PLCC32 [(SA015A1T)]	
AT89LP828@PLCC32(ISP) [ISP-HEADER01]	
AT89LP828@TQFP32 [(SA636)]	
AT89LP828@TQFP32(ISP) [ISP-HEADER01]	
AT89LS51	AT89LS51(ISP) [ISP-HEADER01]
AT89LS51@PLCC44 [(SA244)]	
AT89LS51@PLCC44(ISP) [ISP-HEADER01]	
AT89LS51@TQFP44 [(SA245A)]	
AT89LS51@TQFP44(ISP) [ISP-HEADER01]	
AT89LS52	AT89LS52(ISP) [ISP-HEADER01]
AT89LS52@PLCC44 [(SA244)]	
AT89LS52@PLCC44(ISP) [ISP-HEADER01]	
AT89LS52@TQFP44 [(SA245A)]	
AT89LS52@TQFP44(ISP) [ISP-HEADER01]	
AT89LS53	AT89LS53(ISP) [ISP-HEADER01]
AT89LS53@PLCC44 [(SA244)]	
AT89LS53@PLCC44(ISP) [ISP-HEADER01]	
AT89LS53@TQFP44 [(SA245A)]	
AT89LS53@TQFP44(ISP) [ISP-HEADER01]	
AT89LS8252	AT89LS8252(ISP) [ISP-HEADER01]
AT89LS8252@PLCC44 [(SA244)]	
AT89LS8252@PLCC44(ISP) [ISP-HEADER01]	
AT89LS8252@TQFP44 [(SA245A)]	
AT89LS8252@TQFP44(ISP) [ISP-HEADER01]	
AT89LV51	AT89LV51@PLCC44 [(SA244)]
AT89LV51@TQFP44 [(SA245A)]	AT89LV52
AT89LV52@PLCC44 [(SA244)]	AT89LV52@TQFP44 [(SA245A)]
AT89LV55	AT89LV55@PLCC44 [(SA244)]
AT89LV55@TQFP44 [(SA245A)]	AT89S2051
AT89S2051@SOIC20 [(SA404)]	AT89S4051
AT89S4051@SOIC20 [(SA404)]	AT89S51
AT89S51(ISP) [ISP-HEADER01]	AT89S51@PLCC44 [(SA244)]
AT89S51@PLCC44(ISP) [ISP-HEADER01]	
AT89S51@TQFP44 [(SA245A)]	
AT89S51@TQFP44(ISP) [ISP-HEADER01]	
AT89S52	AT89S52(ISP) [ISP-HEADER01]
AT89S52@PLCC44 [(SA244)]	
AT89S52@PLCC44(ISP) [ISP-HEADER01]	
AT89S52@TQFP44 [(SA245A)]	
AT89S52@TQFP44(ISP) [ISP-HEADER01]	
AT89S53	AT89S53(ISP) [ISP-HEADER01]
AT89S53@PLCC44 [(SA244)]	
AT89S53@PLCC44(ISP) [ISP-HEADER01]	
AT89S53@TQFP44 [(SA245A)]	
AT89S53@TQFP44(ISP) [ISP-HEADER01]	
AT89S54	AT89S54@PLCC44 [(SA244)]
AT89S54@TQFP44 [(SA245A)]	AT89S58
AT89S58@PLCC44 [(SA244)]	AT89S58@TQFP44 [(SA245A)]
AT89S64	AT89S64@PLCC44 [(SA244)]
AT89S64@TQFP44 [(SA245A)]	AT89S8252
AT89S8252(ISP) [ISP-HEADER01]	AT89S8252@PLCC44 [(SA244)]
AT89S8252@PLCC44(ISP) [ISP-HEADER01]	
AT89S8252@TQFP44 [(SA245A)]	
AT89S8252@TQFP44(ISP) [ISP-HEADER01]	
AT89S8253	AT89S8253(ISP) [ISP-HEADER01]
AT89S8253@PLCC44 [(SA244)]	
AT89S8253@PLCC44(ISP) [ISP-HEADER01]	
AT89S8253@TQFP44 [(SA245A)]	
AT89S8253@TQFP44(ISP) [ISP-HEADER01]	
AT90CAN128@QFN64(ISP) [ISP-HEADER01]	
AT90CAN128@TQFP64(ISP) [ISP-HEADER01]	
AT90CAN32@QFN64(ISP) [ISP-HEADER01]	
AT90CAN32@TQFP64(ISP) [ISP-HEADER01]	
AT90CAN64@QFN64(ISP) [ISP-HEADER01]	
AT90CAN64@TQFP64(ISP) [ISP-HEADER01]	
AT90LS2323	AT90LS2323(ISP) [ISP-HEADER01]
AT90LS2323@SOIC8 [(SA605A)]	
AT90LS2323@SOIC8(ISP) [ISP-HEADER01]	
AT90LS2333	AT90LS2333(ISP) [ISP-HEADER01]
AT90LS2333@TQFP32 [(SA663)]	

```

AT90LS2333@TQFP32( ISP) [ ISP-HEADER01]
AT90LS2343 AT90LS2343( ISP) [ ISP-HEADER01]
AT90LS2343@SOIC8 [(SA605A)]
AT90LS2343@SOIC8( ISP) [ ISP-HEADER01]
AT90LS4433 AT90LS4433( ISP) [ ISP-HEADER01]
AT90LS4433@TQFP32 [(SA663)]
AT90LS4433@TQFP32( ISP) [ ISP-HEADER01]
AT90LS4434 AT90LS4434( ISP) [ ISP-HEADER01]
AT90LS4434@PLCC44 [(SA244)]
AT90LS4434@PLCC44( ISP) [ ISP-HEADER01]
AT90LS4434@TQFP44 [(SA245A)]
AT90LS4434@TQFP44( ISP) [ ISP-HEADER01]
AT90LS8535 AT90LS8535( ISP) [ ISP-HEADER01]
AT90LS8535@PLCC44 [(SA244)]
AT90LS8535@PLCC44( ISP) [ ISP-HEADER01]
AT90LS8535@TQFP44 [(SA245A)]
AT90LS8535@TQFP44( ISP) [ ISP-HEADER01]
AT90PWM1@SOIC24 [(SA404)] AT90PWM2@SOIC24 [(SA404)]
AT90PWM2@SOIC24( ISP) [ ISP-HEADER01]
AT90PWM216@SOIC24 [(SA404)] AT90PWM2B@SOIC24 [(SA404)]
AT90PWM2B@SOIC24( ISP) [ ISP-HEADER01]
AT90PWM3@QFN32 [(SA701)]
AT90PWM3@QFN32( ISP) [ ISP-HEADER01]
AT90PWM3@SOIC32 [(SA715)]
AT90PWM3@SOIC32( ISP) [ ISP-HEADER01]
AT90PWM316@QFN32 [(SA701)] AT90PWM316@SOIC32 [(SA715)]
AT90PWM3B@QFN32 [(SA701)]
AT90PWM3B@QFN32( ISP) [ ISP-HEADER01]
AT90PWM3B@SOIC32 [(SA715)]
AT90PWM3B@SOIC32( ISP) [ ISP-HEADER01]
AT90S1200 AT90S1200( ISP) [ ISP-HEADER01]
AT90S1200@SOIC20 [(SA404)]
AT90S1200@SOIC20( ISP) [ ISP-HEADER01]
AT90S1200@SSOP20 [(SA626A)]
AT90S1200@SSOP20( ISP) [ ISP-HEADER01]
AT90S1200A AT90S1200A( ISP) [ ISP-HEADER01]
AT90S1200A@SOIC20 [(SA404)]
AT90S1200A@SOIC20( ISP) [ ISP-HEADER01]
AT90S1200A@SSOP20 [(SA626A)]
AT90S1200A@SSOP20( ISP) [ ISP-HEADER01]
AT90S2313 AT90S2313( ISP) [ ISP-HEADER01]
AT90S2313@SOIC20 [(SA404)]
AT90S2313@SOIC20( ISP) [ ISP-HEADER01]
AT90S2323 AT90S2323( ISP) [ ISP-HEADER01]
AT90S2323@SOIC8 [(SA605A)]
AT90S2323@SOIC8( ISP) [ ISP-HEADER01]
AT90S2333 AT90S2333( ISP) [ ISP-HEADER01]
AT90S2333@TQFP32 [(SA663)]
AT90S2333@TQFP32( ISP) [ ISP-HEADER01]
AT90S2343 AT90S2343( ISP) [ ISP-HEADER01]
AT90S2343@SOIC8 [(SA605A)]
AT90S2343@SOIC8( ISP) [ ISP-HEADER01]
AT90S4414 AT90S4414( ISP) [ ISP-HEADER01]
AT90S4414@PLCC44 [(SA244)]
AT90S4414@PLCC44( ISP) [ ISP-HEADER01]
AT90S4414@TQFP44 [(SA245A)]
AT90S4414@TQFP44( ISP) [ ISP-HEADER01]
AT90S4433 AT90S4433( ISP) [ ISP-HEADER01]
AT90S4433@TQFP32 [(SA663)]
AT90S4433@TQFP32( ISP) [ ISP-HEADER01]
AT90S4434 AT90S4434( ISP) [ ISP-HEADER01]
AT90S4434@PLCC44 [(SA244)]
AT90S4434@PLCC44( ISP) [ ISP-HEADER01]
AT90S4434@TQFP44 [(SA245A)]
AT90S4434@TQFP44( ISP) [ ISP-HEADER01]
AT90S8515 AT90S8515( ISP) [ ISP-HEADER01]
AT90S8515@PLCC44 [(SA244)]
AT90S8515@PLCC44( ISP) [ ISP-HEADER01]
AT90S8515@TQFP44 [(SA245A)]
AT90S8515@TQFP44( ISP) [ ISP-HEADER01]
AT90S8535 AT90S8535( ISP) [ ISP-HEADER01]
AT90S8535@PLCC44 [(SA244)]
AT90S8535@PLCC44( ISP) [ ISP-HEADER01]
AT90S8535@TQFP44 [(SA245A)]
AT90S8535@TQFP44( ISP) [ ISP-HEADER01]
AT90USB1286@QFN64( ISP) [ ISP-HEADER01]
AT90USB1286@TQFP64( ISP) [ ISP-HEADER01]
AT90USB1287@QFN64( ISP) [ ISP-HEADER01]
AT90USB1287@TQFP64( ISP) [ ISP-HEADER01]
AT90USB646@QFN64( ISP) [ ISP-HEADER01]
AT90USB646@TQFP64( ISP) [ ISP-HEADER01]

```

```

AT90USB647@QFN64(ISP) [ISP-HEADER01]
AT90USB647@TQFP64(ISP) [ISP-HEADER01]
ATAM862@SSO24 [(SA026)] ATAM893@SSO20 [(SA026)]
ATAM894@SSO24 [(SA026)]
ATMEGA128@QFN64(ISP) [ISP-HEADER01]
ATMEGA128@TQFP64(ISP) [ISP-HEADER01]
ATMEGA1280@TQFP100(ISP) [ISP-HEADER01]
ATMEGA1280V@TQFP100(ISP) [ISP-HEADER01]
ATMEGA128L@QFN64(ISP) [ISP-HEADER01]
ATMEGA128L@TQFP64(ISP) [ISP-HEADER01]
ATMEGA16 ATMEGA16(fast)
ATMEGA16(fast)@MLF44 [(SA712)] ATMEGA16(fast)@TQFP44 [(SA245A)]
ATMEGA16(ISP) [ISP-HEADER01] ATMEGA16@MLF44 [(SA712)]
ATMEGA16@MLF44(ISP) [ISP-HEADER01]
ATMEGA16@TQFP44 [(SA245A)]
ATMEGA16@TQFP44(ISP) [ISP-HEADER01]
ATMEGA161 ATMEGA161@TQFP44 [(SA245A)]
ATMEGA161L ATMEGA161L@TQFP44 [(SA245A)]
ATMEGA162 ATMEGA162(ISP) [ISP-HEADER01]
ATMEGA162@MLF44 [(SA712)]
ATMEGA162@PLCC44(ISP) [ISP-HEADER01]
ATMEGA162@TQFP44 [(SA245A)]
ATMEGA162@TQFP44(ISP) [ISP-HEADER01]
ATMEGA162V ATMEGA162V@MLF44 [(SA712)]
ATMEGA162V@TQFP44 [(SA245A)] ATMEGA163
ATMEGA163@TQFP44 [(SA245A)] ATMEGA163L
ATMEGA163L@TQFP44 [(SA245A)] ATMEGA164P
ATMEGA164P@MLP44 [(SA712)] ATMEGA164P@TQFP44 [(SA245A)]
ATMEGA164PL ATMEGA164PL@MLP44 [(SA712)]
ATMEGA164PL@TQFP44 [(SA245A)]
ATMEGA165@QFN64(ISP) [ISP-HEADER01]
ATMEGA165@TQFP64(ISP) [ISP-HEADER01]
ATMEGA168 ATMEGA168(ISP) [ISP-HEADER01]
ATMEGA168@MLP32 [(SA686)]
ATMEGA168@MLP32(ISP) [ISP-HEADER01]
ATMEGA168@TQFP32 [(SA663)]
ATMEGA168@TQFP32(ISP) [ISP-HEADER01]
ATMEGA168P ATMEGA168P(ISP) [ISP-HEADER01]
ATMEGA168P@MLP32 [(SA686)]
ATMEGA168P@MLP32(ISP) [ISP-HEADER01]
ATMEGA168P@TQFP32 [(SA663)]
ATMEGA168P@TQFP32(ISP) [ISP-HEADER01]
ATMEGA168PA ATMEGA168PA@MLP32 [(SA686)]
ATMEGA168PA@TQFP32 [(SA663)] ATMEGA168PV
ATMEGA168PV(ISP) [ISP-HEADER01] ATMEGA168PV@MLP32 [(SA686)]
ATMEGA168PV@MLP32(ISP) [ISP-HEADER01]
ATMEGA168PV@TQFP32 [(SA663)]
ATMEGA168PV@TQFP32(ISP) [ISP-HEADER01]
ATMEGA168V ATMEGA168V(ISP) [ISP-HEADER01]
ATMEGA168V@MLP32 [(SA686)]
ATMEGA168V@MLP32(ISP) [ISP-HEADER01]
ATMEGA168V@TQFP32 [(SA663)]
ATMEGA168V@TQFP32(ISP) [ISP-HEADER01]
ATMEGA169@MLF64(ISP) [ISP-HEADER01]
ATMEGA169@TQFP64(ISP) [ISP-HEADER01]
ATMEGA169PV@MLF64(ISP) [ISP-HEADER01]
ATMEGA169PV@TQFP64(ISP) [ISP-HEADER01]
ATMEGA16L ATMEGA16L(fast)
ATMEGA16L(fast)@MLF44 [(SA712)]
ATMEGA16L(fast)@TQFP44 [(SA245A)]
ATMEGA16L(ISP) [ISP-HEADER01] ATMEGA16L@MLF44 [(SA712)]
ATMEGA16L@MLF44(ISP) [ISP-HEADER01]
ATMEGA16L@TQFP44 [(SA245A)]
ATMEGA16L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA2560@TQFP100(ISP) [ISP-HEADER01]
ATMEGA2560V@TQFP100(ISP) [ISP-HEADER01]
ATMEGA2561@QFN64(ISP) [ISP-HEADER01]
ATMEGA2561@TQFP64(ISP) [ISP-HEADER01]
ATMEGA2561V@QFN64(ISP) [ISP-HEADER01]
ATMEGA2561V@TQFP64(ISP) [ISP-HEADER01]
ATMEGA32 ATMEGA32(fuse)
ATMEGA32(fuse)@MLF44 [(SA712)] ATMEGA32(fuse)@PLCC44 [(SA244)]
ATMEGA32(fuse)@TQFP44 [(SA245A)] ATMEGA32(ISP) [ISP-HEADER01]
ATMEGA32(new) ATMEGA32(new)(fast)
ATMEGA32(new)(fast)@MLF44 [(SA712)]
ATMEGA32(new)(fast)@PLCC44 [(SA244)]
ATMEGA32(new)(fast)@TQFP44 [(SA245A)]
ATMEGA32(new)@MLF44 [(SA712)] ATMEGA32(new)@PLCC44 [(SA244)]
ATMEGA32(new)@TQFP44 [(SA245A)] ATMEGA32@MLF44 [(SA712)]
ATMEGA32@MLF44(ISP) [ISP-HEADER01]
ATMEGA32@PLCC44 [(SA244)] ATMEGA32@TQFP44 [(SA245A)]

```

```

ATMEGA32@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA323 ATMEGA323@TQFP44 [(SA245A)]
ATMEGA323L ATMEGA323L@TQFP44 [(SA245A)]
ATMEGA324P ATMEGA324P@MLP44 [(SA712)]
ATMEGA324P@TQFP44 [(SA245A)] ATMEGA324PL
ATMEGA324PL@MLP44 [(SA712)] ATMEGA324PL@TQFP44 [(SA245A)]
ATMEGA3250@TQFP100 (ISP) [ISP-HEADER01]
ATMEGA325P@TQFP64 (ISP) [ISP-HEADER01]
ATMEGA325V@QFN64 (ISP) [ISP-HEADER01]
ATMEGA328P ATMEGA328P (ISP) [ISP-HEADER01]
ATMEGA328P@MLP32 [(SA686)]
ATMEGA328P@MLP32 (ISP) [ISP-HEADER01]
ATMEGA328P@TQFP32 [(SA663)]
ATMEGA328P@TQFP32 (ISP) [ISP-HEADER01]
ATMEGA328PV ATMEGA328PV (ISP) [ISP-HEADER01]
ATMEGA328PV@MLP32 [(SA686)]
ATMEGA328PV@MLP32 (ISP) [ISP-HEADER01]
ATMEGA328PV@TQFP32 [(SA663)]
ATMEGA328PV@TQFP32 (ISP) [ISP-HEADER01]
ATMEGA329@QFN64 (ISP) [ISP-HEADER01]
ATMEGA3290@TQFP100 (ISP) [ISP-HEADER01]
ATMEGA329P@TQFP64 (ISP) [ISP-HEADER01]
ATMEGA32L ATMEGA32L (fuse)
ATMEGA32L (fuse)@MLF44 [(SA712)] ATMEGA32L (fuse)@PLCC44 [(SA244)]
ATMEGA32L (fuse)@TQFP44 [(SA245A)]
ATMEGA32L (ISP) [ISP-HEADER01] ATMEGA32L (new)
ATMEGA32L (new) (fast)
ATMEGA32L (new) (fast)@MLF44 [(SA712)]
ATMEGA32L (new) (fast)@PLCC44 [(SA244)]
ATMEGA32L (new) (fast)@TQFP44 [(SA245A)]
ATMEGA32L (new)@MLF44 [(SA712)] ATMEGA32L (new)@PLCC44 [(SA244)]
ATMEGA32L (new)@TQFP44 [(SA245A)] ATMEGA32L@MLF44 [(SA712)]
ATMEGA32L@MLF44 (ISP) [ISP-HEADER01]
ATMEGA32L@PLCC44 [(SA244)] ATMEGA32L@TQFP44 [(SA245A)]
ATMEGA32L@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA406@LQFP48 [(SA248)] ATMEGA48
ATMEGA48 (ISP) [ISP-HEADER01] ATMEGA48@MLP32 [(SA686)]
ATMEGA48@MLP32 (ISP) [ISP-HEADER01]
ATMEGA48@TQFP32 [(SA663)]
ATMEGA48@TQFP32 (ISP) [ISP-HEADER01]
ATMEGA48P ATMEGA48P@MLP32 [(SA686)]
ATMEGA48P@TQFP32 [(SA663)] ATMEGA48PA
ATMEGA48PA@MLP32 [(SA686)] ATMEGA48PA@TQFP32 [(SA663)]
ATMEGA48PV ATMEGA48PV@MLP32 [(SA686)]
ATMEGA48PV@TQFP32 [(SA663)] ATMEGA48V
ATMEGA48V (ISP) [ISP-HEADER01] ATMEGA48V@MLP32 [(SA686)]
ATMEGA48V@MLP32 (ISP) [ISP-HEADER01]
ATMEGA48V@TQFP32 [(SA663)]
ATMEGA48V@TQFP32 (ISP) [ISP-HEADER01]
ATMEGA64@QFN64 (ISP) [ISP-HEADER01]
ATMEGA64@TQFP64 (ISP) [ISP-HEADER01]
ATMEGA644 ATMEGA644 (ISP) [ISP-HEADER01]
ATMEGA644@MLF44 [(SA712)]
ATMEGA644@MLF44 (ISP) [ISP-HEADER01]
ATMEGA644@TQFP44 [(SA245A)]
ATMEGA644@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA644P ATMEGA644P (ISP) [ISP-HEADER01]
ATMEGA644P@MLF44 [(SA712)]
ATMEGA644P@MLF44 (ISP) [ISP-HEADER01]
ATMEGA644P@TQFP44 [(SA245A)]
ATMEGA644P@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA644PV ATMEGA644PV (ISP) [ISP-HEADER01]
ATMEGA644PV@MLF44 [(SA712)]
ATMEGA644PV@MLF44 (ISP) [ISP-HEADER01]
ATMEGA644PV@TQFP44 [(SA245A)]
ATMEGA644PV@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA644V ATMEGA644V (ISP) [ISP-HEADER01]
ATMEGA644V@MLF44 [(SA712)]
ATMEGA644V@MLF44 (ISP) [ISP-HEADER01]
ATMEGA644V@TQFP44 [(SA245A)]
ATMEGA644V@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA645@QFN64 (ISP) [ISP-HEADER01]
ATMEGA645@TQFP64 (ISP) [ISP-HEADER01]
ATMEGA6450@TQFP100 (ISP) [ISP-HEADER01]
ATMEGA649@TQFP64 (ISP) [ISP-HEADER01]
ATMEGA6490@TQFP100 (ISP) [ISP-HEADER01]
ATMEGA649V@QFN64 (ISP) [ISP-HEADER01]
ATMEGA64L@QFN64 (ISP) [ISP-HEADER01]
ATMEGA64L@TQFP64 (ISP) [ISP-HEADER01]
ATMEGA8 ATMEGA8 (fast)
ATMEGA8 (fast)@TQFP32 [(SA663)] ATMEGA8 (ISP) [ISP-HEADER01]

```

```

ATMEGA8@MLF32 [(SA686)]
ATMEGA8@MLF32(ISP) [ISP-HEADER01]
ATMEGA8@TQFP32 [(SA663)]
ATMEGA8@TQFP32(ISP) [ISP-HEADER01]
ATMEGA8515 ATMEGA8515(fast)
ATMEGA8515(fast)@PLCC44 [(SA244)]
ATMEGA8515(fast)@TQFP44 [(SA245A)]
ATMEGA8515(ISP) [ISP-HEADER01] ATMEGA8515@PLCC44 [(SA244)]
ATMEGA8515@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8515@TQFP44 [(SA245A)]
ATMEGA8515@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8515L ATMEGA8515L(fast)
ATMEGA8515L(fast)@PLCC44 [(SA244)]
ATMEGA8515L(fast)@TQFP44 [(SA245A)]
ATMEGA8515L(ISP) [ISP-HEADER01] ATMEGA8515L@PLCC44 [(SA244)]
ATMEGA8515L@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8515L@TQFP44 [(SA245A)]
ATMEGA8515L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8535 ATMEGA8535(fast)
ATMEGA8535(fast)@MLF44 [(SA712)]
ATMEGA8535(fast)@PLCC44 [(SA244)]
ATMEGA8535(fast)@TQFP44 [(SA245A)]
ATMEGA8535(ISP) [ISP-HEADER01] ATMEGA8535@PLCC44 [(SA244)]
ATMEGA8535@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8535@TQFP44 [(SA245A)]
ATMEGA8535@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8535L ATMEGA8535L(fast)
ATMEGA8535L(fast)@MLF44 [(SA712)]
ATMEGA8535L(fast)@PLCC44 [(SA244)]
ATMEGA8535L(fast)@TQFP44 [(SA245A)]
ATMEGA8535L(ISP) [ISP-HEADER01] ATMEGA8535L@PLCC44 [(SA244)]
ATMEGA8535L@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8535L@TQFP44 [(SA245A)]
ATMEGA8535L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA88 ATMEGA88(ISP) [ISP-HEADER01]
ATMEGA88@MLP32 [(SA686)]
ATMEGA88@MLP32(ISP) [ISP-HEADER01]
ATMEGA88@TQFP32 [(SA663)]
ATMEGA88@TQFP32(ISP) [ISP-HEADER01]
ATMEGA88P ATMEGA88P@MLP32 [(SA686)]
ATMEGA88P@TQFP32 [(SA663)] ATMEGA88PA
ATMEGA88PA@MLP32 [(SA686)] ATMEGA88PA@TQFP32 [(SA663)]
ATMEGA88PV ATMEGA88PV@MLP32 [(SA686)]
ATMEGA88PV@TQFP32 [(SA663)] ATMEGA88V
ATMEGA88V(ISP) [ISP-HEADER01] ATMEGA88V@MLP32 [(SA686)]
ATMEGA88V@MLP32(ISP) [ISP-HEADER01]
ATMEGA88V@TQFP32 [(SA663)]
ATMEGA88V@TQFP32(ISP) [ISP-HEADER01]
ATMEGA88L ATMEGA88L(fast)
ATMEGA88L(fast)@TQFP32 [(SA663)] ATMEGA88L(ISP) [ISP-HEADER01]
ATMEGA88L@MLF32 [(SA686)]
ATMEGA88L@MLF32(ISP) [ISP-HEADER01]
ATMEGA88L@TQFP32 [(SA663)]
ATMEGA88L@TQFP32(ISP) [ISP-HEADER01]
ATtiny10 ATtiny10(ISP) [ISP-HEADER01]
ATtiny10@SOIC8 [(SA605A)]
ATtiny10@SOIC8(ISP) [ISP-HEADER01]
ATtiny10@SOT23 [(SA717)]
ATtiny10@SOT23(ISP) [ISP-HEADER01]
ATtiny11 ATtiny11(ISP) [ISP-HEADER01]
ATtiny11@SOIC8 [(SA605A)]
ATtiny11@SOIC8(ISP) [ISP-HEADER01]
ATtiny11L ATtiny11L(ISP) [ISP-HEADER01]
ATtiny11L@SOIC8 [(SA605A)]
ATtiny11L@SOIC8(ISP) [ISP-HEADER01]
ATtiny12 ATtiny12(ISP) [ISP-HEADER01]
ATtiny12@SOIC8 [(SA605A)]
ATtiny12@SOIC8(ISP) [ISP-HEADER01]
ATtiny12L ATtiny12L(ISP) [ISP-HEADER01]
ATtiny12L@SOIC8 [(SA605A)]
ATtiny12L@SOIC8(ISP) [ISP-HEADER01]
ATtiny12V ATtiny12V(ISP) [ISP-HEADER01]
ATtiny12V@SOIC8 [(SA605A)]
ATtiny12V@SOIC8(ISP) [ISP-HEADER01]
ATtiny13 ATtiny13(Fuse)
ATtiny13(Fuse)@QFN10 [(SA695A)] ATtiny13(Fuse)@QFN20 [(SA692)]
ATtiny13(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13(ISP) [ISP-HEADER01] ATtiny13@QFN10 [(SA695A)]
ATtiny13@QFN10(ISP) [ISP-HEADER01]
ATtiny13@QFN20 [(SA692)]

```

```

Attiny13@QFN20 (ISP) [ISP-HEADER01]
Attiny13@SOIC8(3.9*6.2) [(SA602A)]
Attiny13@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
Attiny13@SOIC8(5.5*8.0) [(SA605A)]
Attiny13@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
Attiny13A
Attiny13A(Fuse)@QFN10 [(SA695A)]
Attiny13A(Fuse)@QFN20 [(SA692)]
Attiny13A(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
Attiny13A(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
Attiny13A@QFN10 [(SA695A)]
Attiny13A@QFN20 [(SA692)]
Attiny13A@SOIC8(3.9*6.2) [(SA602A)]
Attiny13A@SOIC8(5.5*8.0) [(SA605A)]
Attiny13V
Attiny13V(Fuse)@QFN10 [(SA695A)]
Attiny13V(Fuse)@QFN20 [(SA692)]
Attiny13V(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
Attiny13V(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
Attiny13V(ISP) [ISP-HEADER01]
Attiny13V@QFN10 [(SA695A)]
Attiny13V@QFN20 [(SA692)]
Attiny13V@QFN20(ISP) [ISP-HEADER01]
Attiny13V@SOIC8(3.9*6.2) [(SA602A)]
Attiny13V@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
Attiny13V@SOIC8(5.5*8.0) [(SA605A)]
Attiny13V@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
Attiny15
Attiny15(ISP) [ISP-HEADER01]
Attiny15@SOIC8 [(SA605A)]
Attiny15@SOIC8(ISP) [ISP-HEADER01]
Attiny15L
Attiny15L(ISP) [ISP-HEADER01]
Attiny15L@SOIC8 [(SA605A)]
Attiny15L@SOIC8(ISP) [ISP-HEADER01]
Attiny2313
Attiny2313(ISP) [ISP-HEADER01]
Attiny2313@MLF20 [(SA692)]
Attiny2313@MLF20(ISP) [ISP-HEADER01]
Attiny2313@SOIC20 [(SA404)]
Attiny2313@SOIC20(ISP) [ISP-HEADER01]
Attiny2313V
Attiny2313V(ISP) [ISP-HEADER01]
Attiny2313V@MLF20 [(SA692)]
Attiny2313V@MLF20(ISP) [ISP-HEADER01]
Attiny2313V@SOIC20 [(SA404)]
Attiny2313V@SOIC20(ISP) [ISP-HEADER01]
Attiny24
Attiny24(Fuse)
Attiny24(Fuse)@QFN20 [(SA692)]
Attiny24(Fuse)@SOIC14 [(SA602)]
Attiny24(ISP) [ISP-HEADER01]
Attiny24@QFN20 [(SA692)]
Attiny24@QFN20(ISP) [ISP-HEADER01]
Attiny24@SOIC14 [(SA602)]
Attiny24@SOIC14(ISP) [ISP-HEADER01]
Attiny24V
Attiny24V(Fuse)
Attiny24V(Fuse)@QFN20 [(SA692)]
Attiny24V(Fuse)@SOIC14 [(SA602)]
Attiny24V(ISP) [ISP-HEADER01]
Attiny24V@QFN20 [(SA692)]
Attiny24V@QFN20(ISP) [ISP-HEADER01]
Attiny24V@SOIC14 [(SA602)]
Attiny24V@SOIC14(ISP) [ISP-HEADER01]
Attiny25
Attiny25(ISP) [ISP-HEADER01]
Attiny25@QFN20 [(SA692)]
Attiny25@QFN20(ISP) [ISP-HEADER01]
Attiny25@SOIC8 [(SA023A)]
Attiny25@SOIC8(ISP) [ISP-HEADER01]
Attiny26
Attiny26(ISP) [ISP-HEADER01]
Attiny26(new)
Attiny26(new)(ISP) [ISP-HEADER01]
Attiny26(new)@QFN32 [(SA686)]
Attiny26(new)@SOIC20 [(SA404)]
Attiny26(new)@SOIC20(ISP) [ISP-HEADER01]
Attiny26(new)@TSSOP20 [(SA026)]
Attiny26(new)@TSSOP20(ISP) [ISP-HEADER01]
Attiny26@QFN32 [(SA686)]
Attiny26@SOIC20 [(SA404)]
Attiny26@SOIC20(ISP) [ISP-HEADER01]
Attiny26@TSSOP20 [(SA026)]
Attiny26@TSSOP20(ISP) [ISP-HEADER01]
Attiny261
Attiny261(ISP) [ISP-HEADER01]
Attiny261@MLP32 [(SA686)]
Attiny261@MLP32(ISP) [ISP-HEADER01]
Attiny261@SOIC20 [(SA404)]
Attiny261@SOIC20(ISP) [ISP-HEADER01]
Attiny261V
Attiny261V(ISP) [ISP-HEADER01]
Attiny261V@MLP32 [(SA686)]
Attiny261V@MLP32(ISP) [ISP-HEADER01]
Attiny261V@SOIC20 [(SA404)]
Attiny261V@SOIC20(ISP) [ISP-HEADER01]
Attiny26L
Attiny26L(ISP) [ISP-HEADER01]
Attiny26L(new)
Attiny26L(new)(ISP) [ISP-HEADER01]

```

```

ATtiny26L(new)@QFN32 [(SA686)]          ATtiny26L(new)@SOIC20 [(SA404)]
ATtiny26L(new)@SOIC20(ISP) [ISP-HEADER01]
ATtiny26L(new)@TSSOP20 [(SA026)]
ATtiny26L(new)@TSSOP20(ISP) [ISP-HEADER01]
ATtiny26L@QFN32 [(SA686)]              ATtiny26L@SOIC20 [(SA404)]
ATtiny26L@SOIC20(ISP) [ISP-HEADER01]
ATtiny26L@TSSOP20 [(SA026)]
ATtiny26L@TSSOP20(ISP) [ISP-HEADER01]
ATtiny28L                               ATtiny28L@TQFP32 [(SA663)]
ATtiny28V                               ATtiny28V@TQFP32 [(SA663)]
ATtiny44                               ATtiny44(ISP) [ISP-HEADER01]
ATtiny44@QFN20 [(SA692)]
ATtiny44@QFN20(ISP) [ISP-HEADER01]
ATtiny44@SOIC14 [(SA602)]
ATtiny44@SOIC14(ISP) [ISP-HEADER01]
ATtiny45
ATtiny45(ISP)(12V) [ISP-HEADER01]
ATtiny45(ISP)(5V) [ISP-HEADER01]      ATtiny45@QFN20 [(SA692)]
ATtiny45@QFN20(ISP)(12V) [ISP-HEADER01]
ATtiny45@QFN20(ISP)(5V) [ISP-HEADER01]
ATtiny45@SOIC8 [(S605)]
ATtiny45@SOIC8(ISP)(12V) [ISP-HEADER01]
ATtiny45@SOIC8(ISP)(5V) [ISP-HEADER01]
ATtiny461                               ATtiny461(ISP) [ISP-HEADER01]
ATtiny461@MLP32 [(SA686)]
ATtiny461@MLP32(ISP) [ISP-HEADER01]
ATtiny461@SOIC20 [(SA404)]
ATtiny461@SOIC20(ISP) [ISP-HEADER01]
ATtiny461V                               ATtiny461V(ISP) [ISP-HEADER01]
ATtiny461V@MLP32 [(SA686)]
ATtiny461V@MLP32(ISP) [ISP-HEADER01]
ATtiny461V@SOIC20 [(SA404)]
ATtiny461V@SOIC20(ISP) [ISP-HEADER01]
ATtiny48                               ATtiny48(ISP) [ISP-HEADER01]
ATtiny48@MLF32 [(SA686)]
ATtiny48@MLF32(ISP) [ISP-HEADER01]
ATtiny48@TQFP32 [(SA663)]
ATtiny48@TQFP32(ISP) [ISP-HEADER01]
ATtiny48V                               ATtiny48V(ISP) [ISP-HEADER01]
ATtiny48V@MLF32 [(SA686)]
ATtiny48V@MLF32(ISP) [ISP-HEADER01]
ATtiny48V@TQFP32 [(SA663)]
ATtiny48V@TQFP32(ISP) [ISP-HEADER01]
ATtiny84                               ATtiny84(ISP) [ISP-HEADER01]
ATtiny84@QFN20 [(SA692)]
ATtiny84@QFN20(ISP) [ISP-HEADER01]
ATtiny84@SOIC14 [(SA602)]
ATtiny84@SOIC14(ISP) [ISP-HEADER01]
ATtiny85
ATtiny85(ISP)(12V) [ISP-HEADER01]
ATtiny85(ISP)(5V) [ISP-HEADER01]      ATtiny85@QFN20 [(SA692)]
ATtiny85@QFN20(ISP)(12V) [ISP-HEADER01]
ATtiny85@QFN20(ISP)(5V) [ISP-HEADER01]
ATtiny85@SOIC8 [(S605)]
ATtiny85@SOIC8(ISP)(12V) [ISP-HEADER01]
ATtiny85@SOIC8(ISP)(5V) [ISP-HEADER01]
ATtiny861                               ATtiny861(ISP) [ISP-HEADER01]
ATtiny861@MLP32 [(SA686)]
ATtiny861@MLP32(ISP) [ISP-HEADER01]
ATtiny861@SOIC20 [(SA404)]
ATtiny861@SOIC20(ISP) [ISP-HEADER01]
ATtiny861V                               ATtiny861V(ISP) [ISP-HEADER01]
ATtiny861V@MLP32 [(SA686)]
ATtiny861V@MLP32(ISP) [ISP-HEADER01]
ATtiny861V@SOIC20 [(SA404)]
ATtiny861V@SOIC20(ISP) [ISP-HEADER01]
ATtiny88                               ATtiny88(ISP) [ISP-HEADER01]
ATtiny88@MLF32 [(SA686)]
ATtiny88@MLF32(ISP) [ISP-HEADER01]
ATtiny88@TQFP32 [(SA663)]
ATtiny88@TQFP32(ISP) [ISP-HEADER01]
ATtiny88V                               ATtiny88V(ISP) [ISP-HEADER01]
ATtiny88V@MLF32 [(SA686)]
ATtiny88V@MLF32(ISP) [ISP-HEADER01]
ATtiny88V@TQFP32 [(SA663)]
ATtiny88V@TQFP32(ISP) [ISP-HEADER01]
T89F64                               T89F64@PLCC44 [(SA244)]
T89F64@TQFP44 [(SA245A)]

```

ATMEL W&M

MICROCONTROLLER

AT89C5115@PLCC28 [(SA008A)]	AT89C5115@SOIC28 [(SA404)]
AT89C5115@TQFP32 [(SA663)]	AT89C51CC02@PLCC28 [(SA008A)]
AT89C51CC02@SOIC28 [(SA404)]	AT89C51CC02@TQFP32 [(SA663)]
T89C5115@PLCC28 [(SA008A)]	T89C5115@SOIC28 [(SA404)]
T89C5115@TQFP32 [(SA663)]	T89C51AC2@PLCC44 [(SA244)]
T89C51AC2@TQFP44 [(SA245A)]	T89C51CC01@PLCC44 [(SA244)]
T89C51CC01@TQFP44 [(SA245A)]	T89C51CC02@PLCC28 [(SA008A)]
T89C51CC02@SOIC28 [(SA404)]	T89C51CC02@SOIC28 [(SA404)]
T89C51CC02@TQFP32 [(SA663)]	T89C51IB2@PLCC44 [(SA244)]
T89C51IB2@TQFP44 [(SA245A)]	T89C51IC2@PLCC44 [(SA244)]
T89C51IC2@TQFP44 [(SA245A)]	T89C51RB2
T89C51RB2@PLCC44 [(SA244)]	T89C51RB2@TQFP44 [(SA245A)]
T89C51RC2	T89C51RC2@PLCC44 [(SA244)]
T89C51RC2@TQFP44 [(SA245A)]	T89C51RD2
T89C51RD2@PLCC44 [(SA244)]	T89C51RD2@TQFP44 [(SA245A)]
T89F64	T89F64@PLCC44 [(SA244)]
T89F64@TQFP44 [(SA245A)]	TS87C51RB2
TS87C51RB2@PLCC44 [(SA244)]	TS87C51RB2@TQFP44 [(SA245A)]
TS87C51RC2	TS87C51RC2@PLCC44 [(SA244)]
TS87C51RC2@TQFP44 [(SA245A)]	TS87C51RD2
TS87C51RD2@PLCC44 [(SA244)]	TS87C51RD2@TQFP44 [(SA245A)]
TS87C51U2	TS87C51U2@PLCC44 [(SA244)]
TS87C51U2@TQFP44 [(SA245A)]	TS87C52X2
TS87C52X2@PLCC44 [(SA244)]	TS87C52X2@TQFP44 [(SA245A)]
TS87C54X2	TS87C54X2@PLCC44 [(SA244)]
TS87C54X2@TQFP44 [(SA245A)]	TS87C58X2
TS87C58X2@PLCC44 [(SA244)]	TS87C58X2@TQFP44 [(SA245A)]
TSC87251A1@PLCC44 [(SA244)]	TSC87251G1
TSC87251G1@PLCC44 [(SA244)]	TSC87251G1A
TSC87251G1A@PLCC44 [(SA244)]	TSC87251G2D
TSC87251G2D@PLCC44 [(SA244)]	TSC87251G2D@TQFP44 [(SA245A)]
TSC87C51	TSC87C51@PLCC44 [(SA244)]
TSC87C51@TQFP44 [(SA245A)]	

ATMEL-CUSTOMER

E(E) PROM/FRAM/NVRAM

AT24C01	AT24C02
AT24C04	AT24C08
AT24C16	

AUSTIN

E(E) PROM/FRAM/NVRAM

AS8E512K8	AS8E512K8@SOJ32 [(SA661)]
-----------	---------------------------

BELLING-SYSTRON

MICROCONTROLLER

CM5001

BENCHMARK

E(E) PROM/FRAM/NVRAM

BQ4010	BQ4010Y
BQ4011	BQ4011Y
BQ4013	BQ4013Y
BQ4014	BQ4014Y
BQ4015	BQ4015Y

BQ4832Y

BQ4842Y

BRIGHT**E (E) PROM/FRAM/NVRAM**

BM29F040
 BM29F040@TSOP32 [(SA410T)]
 BM29F400B@TSOP48 [(SA247-B005)]
 BM29F400T@TSOP48 [(SA247-B005)]

BM29F040@PLCC32 [(SA015A1T)]
 BM29F400B@PSOP44 [(SA638-B006)]
 BM29F400T@PSOP44 [(SA638-B006)]

CATALYST**E (E) PROM/FRAM/NVRAM**

CAT1021(L)
 CAT1021(R)@MSOP8 [(SA026)]
 CAT1021(U)@TSSOP8 [(SA026)]
 CAT1021(Y)@TSSOP8 [(SA026)]
 CAT1022(L)
 CAT1022(R)@MSOP8 [(SA026)]
 CAT1022(U)@TSSOP8 [(SA026)]
 CAT1022(Y)@TSSOP8 [(SA026)]
 CAT1023(L)
 CAT1023(R)@MSOP8 [(SA026)]
 CAT1023(U)@TSSOP8 [(SA026)]
 CAT1023(Y)@TSSOP8 [(SA026)]
 CAT1024(L)
 CAT1024(R)@MSOP8 [(SA026)]
 CAT1024(U)@TSSOP8 [(SA026)]
 CAT1024(Y)@TSSOP8 [(SA026)]
 CAT1025(L)
 CAT1025(R)@MSOP8 [(SA026)]
 CAT1025(U)@TSSOP8 [(SA026)]
 CAT1025(Y)@TSSOP8 [(SA026)]
 CAT1026(L)
 CAT1026(R)@MSOP8 [(SA026)]
 CAT1026(U)@TSSOP8 [(SA026)]
 CAT1026(Y)@TSSOP8 [(SA026)]
 CAT1027(L)
 CAT1027(R)@MSOP8 [(SA026)]
 CAT1027(U)@TSSOP8 [(SA026)]
 CAT1027(Y)@TSSOP8 [(SA026)]
 CAT1161(J)@SOIC8 [(SA602A)]
 CAT1162(J)@SOIC8 [(SA602A)]
 CAT1163(J)@SOIC8 [(SA602A)]
 CAT1320
 CAT1320@TDFN8
 CAT1321
 CAT1321@TDFN8
 CAT14002@SOIC8 [(SA602A)]
 CAT14008@SOIC8 [(SA602A)]
 CAT15002@SOIC8 [(SA602A)]
 CAT15008@SOIC8 [(SA602A)]
 CAT1640
 CAT1640@TDFN8
 CAT1641
 CAT1641@TDFN8
 CAT2210
 CAT2210I
 CAT2212
 CAT2212I
 CAT22C10
 CAT22C10I
 CAT22C12
 CAT22C12I
 CAT24AC128
 CAT24AC128@TSSOP14 [(SA026)]
 CAT24C00
 CAT24C00@TSSOP8 [(SA026)]
 CAT24C01@SOIC14 [(SA602)]
 CAT24C01@TSSOP8 [(SA026)]
 CAT24C01B(L)
 CAT24C01B(R)@MSOP8 [(SA026)]

CAT1021(P)
 CAT1021(S)@SOIC8 [(SA602A)]
 CAT1021(V)@SOIC8 [(SA602A)]
 CAT1021(Z)@MSOP8 [(SA026)]
 CAT1022(P)
 CAT1022(S)@SOIC8 [(SA602A)]
 CAT1022(V)@SOIC8 [(SA602A)]
 CAT1022(Z)@MSOP8 [(SA026)]
 CAT1023(P)
 CAT1023(S)@SOIC8 [(SA602A)]
 CAT1023(V)@SOIC8 [(SA602A)]
 CAT1023(Z)@MSOP8 [(SA026)]
 CAT1024(P)
 CAT1024(S)@SOIC8 [(SA602A)]
 CAT1024(V)@SOIC8 [(SA602A)]
 CAT1024(Z)@MSOP8 [(SA026)]
 CAT1025(P)
 CAT1025(S)@SOIC8 [(SA602A)]
 CAT1025(V)@SOIC8 [(SA602A)]
 CAT1025(Z)@MSOP8 [(SA026)]
 CAT1026(P)
 CAT1026(S)@SOIC8 [(SA602A)]
 CAT1026(V)@SOIC8 [(SA602A)]
 CAT1026(Z)@MSOP8 [(SA026)]
 CAT1027(P)
 CAT1027(S)@SOIC8 [(SA602A)]
 CAT1027(V)@SOIC8 [(SA602A)]
 CAT1027(Z)@MSOP8 [(SA026)]
 CAT1161(P)
 CAT1162(P)
 CAT1163(P)
 CAT1320@SOIC8 [(SA602A)]
 CAT1320@TSSOP8 [(SA026)]
 CAT1321@SOIC8 [(SA602A)]
 CAT1321@TSSOP8 [(SA026)]
 CAT14004@SOIC8 [(SA602A)]
 CAT14016@SOIC8 [(SA602A)]
 CAT15004@SOIC8 [(SA602A)]
 CAT15016@SOIC8 [(SA602A)]
 CAT1640@SOIC8 [(SA602A)]
 CAT1640@TSSOP8 [(SA026)]
 CAT1641@SOIC8 [(SA602A)]
 CAT1641@TSSOP8 [(SA026)]
 CAT2210@SOIC16 [(SA404)]
 CAT2210I@SOIC16 [(SA404)]
 CAT2212@SOIC20 [(SA404)]
 CAT2212I@SOIC20 [(SA404)]
 CAT22C10@SOIC16 [(SA404)]
 CAT22C10I@SOIC16 [(SA404)]
 CAT22C12@SOIC20 [(SA404)]
 CAT22C12I@SOIC20 [(SA404)]
 CAT24AC128@SOIC8 [(SA602A)]
 CAT24AC128@UDFN8 [(SA724)]
 CAT24C00@SOIC8 [(SA602A)]
 CAT24C01
 CAT24C01@SOIC8 [(SA602A)]
 CAT24C01B(J)@SOIC8 [(SA602A)]
 CAT24C01B(P)
 CAT24C01B(U)@TSSOP8 [(SA026)]

CAT24C01B(W)@SOIC8 [(SA602A)]	CAT24C01B(Y)@TSSOP8 [(SA026)]
CAT24C01B(Z)@MSOP8 [(SA026)]	CAT24C02
CAT24C02@SOIC14 [(SA602)]	CAT24C02@SOIC8 [(SA602A)]
CAT24C02@TSSOP8 [(SA026)]	CAT24C021
CAT24C022	CAT24C023
CAT24C03	CAT24C03@SOIC8 [(SA602A)]
CAT24C03@TSSOP8 [(SA026)]	CAT24C04
CAT24C04@SOIC14 [(SA602)]	CAT24C04@SOIC8 [(SA602A)]
CAT24C04@TSSOP8 [(SA026)]	CAT24C041
CAT24C042	CAT24C043
CAT24C05	CAT24C05@SOIC8 [(SA602A)]
CAT24C05@TSSOP8 [(SA026)]	CAT24C08
CAT24C08@SOIC14 [(SA602)]	CAT24C08@SOIC8 [(SA602A)]
CAT24C08@TSSOP8 [(SA026)]	CAT24C081
CAT24C082	CAT24C083
CAT24C08I	CAT24C08I@SOIC8 [(SA602A)]
CAT24C09	CAT24C09@SOIC8 [(SA602A)]
CAT24C09@TSSOP8 [(SA026)]	CAT24C128
CAT24C128@SOIC8 [(SA602A)]	CAT24C128@UDFN8 [(SA724)]
CAT24C16	CAT24C16@SOIC14 [(SA602)]
CAT24C16@SOIC8 [(SA602A)]	CAT24C16@TSSOP8 [(SA026)]
CAT24C161	CAT24C162
CAT24C163	CAT24C164
CAT24C164@SOIC8 [(SA602A)]	CAT24C164@TSSOP8 [(SA026)]
CAT24C16I	CAT24C16I@SOIC8 [(SA602A)]
CAT24C208(J)@SOIC8 [(SA602A)]	CAT24C208(L)
CAT24C208(P)	CAT24C208(R)@MSOP8 [(SA666)]
CAT24C208(U)@TSSOP8 [(SA026)]	CAT24C208(W)@SOIC8 [(SA602A)]
CAT24C208(Y)@TSSOP8 [(SA026)]	CAT24C208(Z)@MSOP8 [(SA666)]
CAT24C21	CAT24C21@SOIC8 [(SA602A)]
CAT24C21@TSSOP8 [(SA026)]	CAT24C256
CAT24C256@SOIC8 [(SA602A)]	CAT24C256@TDFN8 [(SA683)]
CAT24C256@TSSOP8 [(SA026)]	CAT24C32
CAT24C32@SOIC8 [(SA602A)]	CAT24C44
CAT24C44@SOIC8 [(SA602A)]	CAT24C64
CAT24C64@SOIC8 [(SA602A)]	CAT24F32
CAT24F32@SOIC8 [(SA602A)]	CAT24F32@TSSOP8 [(SA026)]
CAT24F32A	CAT24F32A@SOIC8 [(SA602A)]
CAT24F32A@TSSOP8 [(SA026)]	CAT24FC01
CAT24FC01@SOIC14 [(SA602)]	CAT24FC01@SOIC8 [(SA602A)]
CAT24FC01@TSSOP8 [(SA026)]	CAT24FC02
CAT24FC02@SOIC14 [(SA602)]	CAT24FC02@SOIC8 [(SA602A)]
CAT24FC02@TSSOP8 [(SA026)]	CAT24FC16
CAT24FC16@SOIC14 [(SA602)]	CAT24FC16@SOIC8 [(SA602A)]
CAT24FC16@TSSOP8 [(SA026)]	CAT24FC17
CAT24FC17@SOIC8 [(SA602A)]	CAT24FC17@TSSOP8 [(SA026)]
CAT24FC256	CAT24FC256@SOIC8 [(SA602A)]
CAT24FC256@TDFN8 [(SA683)]	CAT24FC256@TSSOP8 [(SA026)]
CAT24FC32	CAT24FC32@SOIC8 [(SA602A)]
CAT24FC32@TDFN8 [(SA683)]	CAT24FC32@TSSOP8 [(SA026)]
CAT24FC64	CAT24FC64@SOIC8 [(SA602A)]
CAT24FC64@TDFN8 [(SA683)]	CAT24FC64@TSSOP8 [(SA026)]
CAT24FC65	CAT24FC65@SOIC8 [(SA602A)]
CAT24FC65@TDFN8 [(SA683)]	CAT24FC65@TSSOP8 [(SA026)]
CAT24FC66	CAT24FC66@SOIC8 [(SA602A)]
CAT24FC66@TDFN8 [(SA683)]	CAT24FC66@TSSOP8 [(SA026)]
CAT24LC02	CAT24LC02@SOIC8 [(SA602A)]
CAT24LC02@TSSOP8 [(SA026)]	CAT24WC01
CAT24WC01@SOIC8 [(SA602A)]	CAT24WC01@TSSOP8 [(SA026)]
CAT24WC02	CAT24WC02@SOIC8 [(SA602A)]
CAT24WC02@TSSOP8 [(SA026)]	CAT24WC03
CAT24WC03@SOIC8 [(SA602A)]	CAT24WC03@TSSOP8 [(SA026)]
CAT24WC04	CAT24WC04@SOIC8 [(SA602A)]
CAT24WC04@TSSOP8 [(SA026)]	CAT24WC05
CAT24WC05@SOIC8 [(SA602A)]	CAT24WC05@TSSOP8 [(SA026)]
CAT24WC08	CAT24WC08@SOIC8 [(SA602A)]
CAT24WC08@TSSOP8 [(SA026)]	CAT24WC09
CAT24WC09@SOIC8 [(SA602A)]	CAT24WC09@TSSOP8 [(SA026)]
CAT24WC128	CAT24WC128@SOIC8 [(SA602A)]
CAT24WC129	CAT24WC129@SOIC8 [(SA602A)]
CAT24WC16	CAT24WC16@SOIC8 [(SA602A)]
CAT24WC16@TSSOP8 [(SA026)]	CAT24WC164
CAT24WC164@SOIC8 [(SA602A)]	CAT24WC164@TSSOP8 [(SA026)]
CAT24WC17	CAT24WC17@SOIC8 [(SA602A)]
CAT24WC17@TSSOP8 [(SA026)]	CAT24WC256
CAT24WC256@SOIC8 [(SA602A)]	CAT24WC256@TDFN8 [(SA683)]
CAT24WC256@TSSOP8 [(SA026)]	CAT24WC257
CAT24WC257@SOIC8 [(SA605A)]	CAT24WC32
CAT24WC32@SOIC8 [(SA602A)]	CAT24WC33
CAT24WC33@SOIC8 [(SA602A)]	CAT24WC64
CAT24WC64@SOIC8 [(SA602A)]	CAT24WC65

CAT24WC65@SOIC8 [(SA602A)]	CAT24WC66
CAT24WC66@SOIC8 [(SA602A)]	CAT25010
CAT25010(S)@SOIC8 [(SA605A)]	CAT25010(U)@TSSOP8 [(SA602A)]
CAT25020	CAT25020(S)@SOIC8 [(SA605A)]
CAT25020(U)@TSSOP8 [(SA602A)]	CAT25040
CAT25040(S)@SOIC8 [(SA605A)]	CAT25040(U)@TSSOP8 [(SA602A)]
CAT25080	CAT25080@SOIC8 [(SA602A)]
CAT25080@TDFN8 [(SA724)]	CAT25080@TSSOP8 [(SA026)]
CAT25080@UDFN8 [(BBBB)]	CAT25128
CAT25128@SOIC8[150 mil] [(SA602A)]	
CAT25128@SOIC8[208 mil] [(SA605A)]	
CAT25128@TDFN8 [(SA724)]	CAT25128@TSSOP8 [(SA026)]
CAT25160	CAT25160@SOIC8 [(SA602A)]
CAT25160@TDFN8 [(SA724)]	CAT25160@TSSOP8 [(SA026)]
CAT25160@UDFN8 [(BBBB)]	CAT25256
CAT25256@SOIC8[150 mil] [(SA602A)]	
CAT25256@SOIC8[208 mil] [(SA605A)]	
CAT25256@TDFN8 [(SA602A)]	CAT25256@TSSOP8 [(SA026)]
CAT25320	CAT25320@SOIC8 [(SA602A)]
CAT25320@TDFN8 [(SA724)]	CAT25320@TSSOP8 [(SA026)]
CAT25640	CAT25640@SOIC8 [(SA602A)]
CAT25640@TDFN8 [(SA724)]	CAT25640@TSSOP8 [(SA026)]
CAT25C01	CAT25C01@SOIC16 [(SA602)]
CAT25C01@SOIC8 [(SA602A)]	CAT25C01@TSSOP14 [(SA026)]
CAT25C01@TSSOP8 [(SA026)]	CAT25C02
CAT25C02@SOIC16 [(SA602)]	CAT25C02@SOIC8 [(SA602A)]
CAT25C02@TSSOP14 [(SA026)]	CAT25C02@TSSOP8 [(SA026)]
CAT25C03	CAT25C03@SOIC8 [(SA602A)]
CAT25C03@TSSOP14 [(SA026)]	CAT25C03@TSSOP8 [(SA026)]
CAT25C04	CAT25C04@SOIC16 [(SA602)]
CAT25C04@SOIC8 [(SA602A)]	CAT25C04@TSSOP14 [(SA026)]
CAT25C04@TSSOP8 [(SA026)]	CAT25C05
CAT25C05@SOIC8 [(SA602A)]	CAT25C05@TSSOP14 [(SA026)]
CAT25C05@TSSOP8 [(SA026)]	CAT25C08
CAT25C08@SOIC16 [(SA602)]	CAT25C08@SOIC8 [(SA602A)]
CAT25C08@TSSOP14 [(SA026)]	CAT25C08@TSSOP8 [(SA026)]
CAT25C09	CAT25C09@SOIC8 [(SA602A)]
CAT25C09@TSSOP14 [(SA026)]	CAT25C09@TSSOP8 [(SA026)]
CAT25C11	CAT25C11@SOIC8 [(SA602A)]
CAT25C11@TSSOP14 [(SA026)]	CAT25C11@TSSOP8 [(SA026)]
CAT25C128	CAT25C128@SOIC16 [(SA602)]
CAT25C128@SOIC8[150 mil] [(SA602A)]	
CAT25C128@SOIC8[208 mil] [(SA605A)]	
CAT25C128@TSSOP14 [(SA026)]	CAT25C128@TSSOP20 [(SA026)]
CAT25C16	CAT25C16@SOIC16 [(SA602)]
CAT25C16@SOIC8 [(SA602A)]	CAT25C16@TSSOP14 [(SA026)]
CAT25C16@TSSOP8 [(SA026)]	CAT25C17
CAT25C17@SOIC8 [(SA602A)]	CAT25C17@TSSOP14 [(SA026)]
CAT25C17@TSSOP8 [(SA026)]	CAT25C256
CAT25C256@SOIC16 [(SA602)]	
CAT25C256@SOIC8[150 mil] [(SA602A)]	CAT25C256@TSSOP20 [(SA026)]
CAT25C256@SOIC8[208 mil] [(SA605A)]	CAT25C32@SOIC8 [(SA602A)]
CAT25C256@TSSOP14 [(SA026)]	CAT25C32@TSSOP20 [(SA026)]
CAT25C32	CAT25C33@SOIC8 [(SA602A)]
CAT25C32@TSSOP14 [(SA026)]	CAT25C64
CAT25C33	CAT25C64@TSSOP14 [(SA026)]
CAT25C33@TSSOP14 [(SA026)]	CAT25C65
CAT25C64@SOIC8 [(SA602A)]	CAT25C65@TSSOP14 [(SA026)]
CAT25C64@TSSOP20 [(SA026)]	CAT27010@PLCC32 [(SA015A1T)]
CAT25C65@SOIC8 [(SA602A)]	CAT27128A
CAT27010	CAT27512
CAT27010@TSOP32 [(SA410T)]	CAT2764A
CAT27256	CAT27C210
CAT27512@PLCC32 [(SA015A1T)]	CAT27HC256
CAT27C16A	CAT27HC256I
CAT27C210@PLCC44 [(SA244)]	CAT28C16A
CAT27HC256@PLCC32 [(SA015A1T)]	CAT28C16A@SOIC24 [(SA404)]
CAT27HC256I@PLCC32 [(SA015A1T)]	CAT28C16AI@PLCC32 [(SA015A1T)]
CAT28C16A@PLCC32 [(SA015A1T)]	CAT28C17A
CAT28C16AI	CAT28C17AI
CAT28C16AI@SOIC24 [(SA404)]	CAT28C256
CAT28C17A@PLCC32 [(SA015A1T)]	CAT28C256@TSOP28 [(SA430T)]
CAT28C17AI@PLCC32 [(SA015A1T)]	CAT28C256I@PLCC32 [(SA015A1T)]
CAT28C256@PLCC32 [(SA015A1T)]	CAT28C257
CAT28C256I	CAT28C257@TSOP28 [(SA430T)]
CAT28C256I@TSOP28 [(SA430T)]	CAT28C512@PLCC32 [(SA015A1T)]
CAT28C257@PLCC32 [(SA015A1T)]	CAT28C512@TSOP40 [(SA409T)]
CAT28C512	CAT28C64A
CAT28C512@TSOP32 [(SA410T)]	CAT28C64A@SOIC28 [(SA404)]
CAT28C513@PLCC32 [(SA015A1T)]	
CAT28C64A@PLCC32 [(SA015A1T)]	

CAT28C64AI	CAT28C64AI@PLCC32 [(SA015A1T)]
CAT28C64AI@SOIC28 [(SA404)]	CAT28C64B
CAT28C64B@PLCC32 [(SA015A1T)]	CAT28C64B@TSOP28 [(SA430T)]
CAT28C64BI	CAT28C64BI@PLCC32 [(SA015A1T)]
CAT28C64BI@TSOP28 [(SA430T)]	CAT28C65B
CAT28C65B@PLCC32 [(SA015A1T)]	CAT28C65B@TSOP28 [(SA430T)]
CAT28C65BI	CAT28C65BI@PLCC32 [(SA015A1T)]
CAT28C65BI@TSOP28 [(SA430T)]	CAT28F001N-B@PLCC32 [(SA015A1T)]
CAT28F001N-T@PLCC32 [(SA015A1T)]	CAT28F001P-B
CAT28F001P-T	CAT28F001T-B@TSOP32 [(SA410T)]
CAT28F001T-T@TSOP32 [(SA410T)]	CAT28F002
CAT28F002@TSOP40 [(SA409T)]	CAT28F010
CAT28F010@PLCC32 [(SA015A1T)]	CAT28F010@TSOP32 [(SA410T)]
CAT28F010I	CAT28F010I@PLCC32 [(SA015A1T)]
CAT28F010I@TSOP32 [(SA410T)]	CAT28F020
CAT28F020(REVERSE)@TSOP32 [(SA410T)]	CAT28F020@TSOP32 [(SA410T)]
CAT28F020@PLCC32 [(SA015A1T)]	CAT28F020I@PLCC32 [(SA015A1T)]
CAT28F020I	CAT28F102
CAT28F020I@TSOP32 [(SA410T)]	CAT28F102@TSOP40 [(SA409T)]
CAT28F102@PLCC44 [(SA244)]	CAT28F512@PLCC32 [(SA015A1T)]
CAT28F512	CAT28F512I
CAT28F512@TSOP32 [(SA410T)]	CAT28F512I@TSOP32 [(SA410T)]
CAT28F512I@PLCC32 [(SA015A1T)]	CAT28LV256@PLCC32 [(SA015A1T)]
CAT28LV256	CAT28LV64
CAT28LV256@TSOP28 [(SA430T)]	CAT28LV64@TSOP28 [(SA430T)]
CAT28LV64@PLCC32 [(SA015A1T)]	CAT28LV65@PLCC32 [(SA015A1T)]
CAT28LV65	CAT33C101(08bit)
CAT28LV65@TSOP28 [(SA430T)]	CAT33C101(16bit)
CAT33C101(08bit)@SOIC8 [(SA602A)]	CAT33C101(16bit)@SOIC8 [(SA602A)]
CAT33C101(16bit)	CAT33C101H(08bit)
CAT33C101(16bit)@SOIC8 [(SA602A)]	CAT33C101H(08bit)@SOIC8 [(SA602A)]
CAT33C101H(08bit)	CAT33C101H(16bit)
CAT33C101H(16bit)@SOIC8 [(SA602A)]	CAT33C101I(08bit)
CAT33C101I(08bit)	CAT33C101I(08bit)@SOIC8 [(SA602A)]
CAT33C101I(08bit)@SOIC8 [(SA602A)]	CAT33C101I(16bit)
CAT33C101I(16bit)	CAT33C101I(16bit)@SOIC8 [(SA602A)]
CAT33C101I(16bit)@SOIC8 [(SA602A)]	CAT33C104(08bit)
CAT33C104(08bit)	CAT33C104(08bit)@SOIC8 [(SA602A)]
CAT33C104(08bit)@SOIC8 [(SA602A)]	CAT33C104(16bit)
CAT33C104(16bit)	CAT33C104(16bit)@SOIC8 [(SA602A)]
CAT33C104(16bit)@SOIC8 [(SA602A)]	CAT33C104I(08bit)
CAT33C104I(08bit)	CAT33C104I(08bit)@SOIC8 [(SA602A)]
CAT33C104I(08bit)@SOIC8 [(SA602A)]	CAT33C104I(16bit)
CAT33C104I(16bit)	CAT33C104I(16bit)@SOIC8 [(SA602A)]
CAT33C104I(16bit)@SOIC8 [(SA602A)]	CAT34AC02
CAT34AC02	CAT34AC02@SOIC8 [(SA602A)]
CAT34AC02@TSSOP8 [(SA026)]	CAT34C02
CAT34C02@SOIC8 [(SA602A)]	CAT34C02@TDFN8 [(SA694)]
CAT34C02@TSSOP8 [(SA026)]	CAT34FC02
CAT34FC02@SOIC8 [(SA602A)]	CAT34FC02@TDFN8 [(SA694)]
CAT34FC02@TSSOP8 [(SA026)]	CAT34RC02
CAT34RC02@SOIC8 [(SA602A)]	CAT34RC02@TDFN8 [(SA694)]
CAT34RC02@TSSOP8 [(SA026)]	CAT34WC02
CAT34WC02@SOIC8 [(SA602A)]	CAT34WC02@TDFN8 [(SA694)]
CAT34WC02@TSSOP8 [(SA026)]	CAT35C102
CAT35C102H	CAT35C102I
CAT35C104(08bit)	
CAT35C104(08bit)@SOIC8 [(SA602A)]	
CAT35C104(16bit)	
CAT35C104(16bit)@SOIC8 [(SA602A)]	
CAT35C104H(08bit)	
CAT35C104H(08bit)@SOIC8 [(SA602A)]	
CAT35C104I(08bit)	
CAT35C104I(08bit)@SOIC8 [(SA602A)]	
CAT35C104I(16bit)	
CAT35C104I(16bit)@SOIC8 [(SA602A)]	
CAT59C11	CAT59C11@SOIC8 [(SA602A)]
CAT59C11A	CAT59C11A@SOIC8 [(SA602A)]
CAT59C11H	CAT59C11H@SOIC8 [(SA602A)]
CAT59C11I	CAT59C11I@SOIC8 [(SA602A)]
CAT64LC10(J)@SOIC8 [(SA602A)]	CAT64LC10(P)
CAT64LC10(S)@SOIC8 [(SA602A)]	CAT64LC10(U)@TSSOP8 [(SA026)]
CAT64LC10(UR)@TSSOP8 [(SA026)]	CAT64LC20(J)@SOIC8 [(SA602A)]
CAT64LC20(P)	CAT64LC20(S)@SOIC8 [(SA602A)]
CAT64LC20(U)@TSSOP8 [(SA026)]	CAT64LC20(UR)@TSSOP8 [(SA026)]
CAT64LC40(J)@SOIC8 [(SA602A)]	CAT64LC40(P)
CAT64LC40(S)@SOIC8 [(SA602A)]	CAT64LC40(U)@TSSOP8 [(SA026)]
CAT64LC40(UR)@TSSOP8 [(SA026)]	CAT93C46(08bit)
CAT93C46(08bit)(J)@SOIC8 [(SA602A)]	

```

CAT93C46(08bit)(K)@SOIC8 [(SA605A)]
CAT93C46(08bit)(S)@SOIC8 [(SA602A)]
CAT93C46(08bit)(U)@TSSOP8 [(SA026)]
CAT93C46(16bit)
CAT93C46(16bit)(J)@SOIC8 [(SA602A)]
CAT93C46(16bit)(K)@SOIC8 [(SA605A)]
CAT93C46(16bit)(S)@SOIC8 [(SA602A)]
CAT93C46(16bit)(U)@TSSOP8 [(SA026)]
CAT93C46A
CAT93C56(08bit)@SOIC8 [(SA602A)]
CAT93C56(16bit)@SOIC8 [(SA602A)]
CAT93C57
CAT93C66(08bit)@SOIC8 [(SA602A)]
CAT93C66(16bit)
CAT93C66(16bit)@TSSOP8 [(SA026)]
CAT93C76(08bit)
CAT93C76(08bit)(J)@SOIC8 [(SA602A)]
CAT93C76(08bit)(K)@SOIC8 [(SA605A)]
CAT93C76(08bit)(S)@SOIC8 [(SA602A)]
CAT93C76(08bit)(U)@TSSOP8 [(SA026)]
CAT93C76(16bit)
CAT93C76(16bit)(J)@SOIC8 [(SA602A)]
CAT93C76(16bit)(K)@SOIC8 [(SA605A)]
CAT93C76(16bit)(S)@SOIC8 [(SA602A)]
CAT93C76(16bit)(U)@TSSOP8 [(SA026)]
CAT93C86(08bit)
CAT93C86(08bit)(J)@SOIC8 [(SA602A)]
CAT93C86(08bit)(K)@SOIC8 [(SA605A)]
CAT93C86(08bit)(S)@SOIC8 [(SA602A)]
CAT93C86(08bit)(U)@TSSOP8 [(SA026)]
CAT93C86(16bit)
CAT93C86(16bit)(J)@SOIC8 [(SA602A)]
CAT93C86(16bit)(K)@SOIC8 [(SA605A)]
CAT93C86(16bit)(S)@SOIC8 [(SA602A)]
CAT93C86(16bit)(U)@TSSOP8 [(SA026)]
CAT93H46(08bit)
CAT93H46(08bit)(J)@SOIC8 [(SA602A)]
CAT93H46(08bit)(K)@SOIC8 [(SA605A)]
CAT93H46(08bit)(S)@SOIC8 [(SA602A)]
CAT93H46(08bit)(U)@TSSOP8 [(SA026)]
CAT93H46(16bit)
CAT93H46(16bit)(J)@SOIC8 [(SA602A)]
CAT93H46(16bit)(K)@SOIC8 [(SA605A)]
CAT93H46(16bit)(S)@SOIC8 [(SA602A)]
CAT93H46(16bit)(U)@TSSOP8 [(SA026)]
CAT93HC46(08bit)
CAT93HC46(08bit)(J)@SOIC8 [(SA602A)]
CAT93HC46(08bit)(K)@SOIC8 [(SA605A)]
CAT93HC46(08bit)(S)@SOIC8 [(SA602A)]
CAT93HC46(08bit)(U)@TSSOP8 [(SA026)]
CAT93HC46(16bit)
CAT93HC46(16bit)(J)@SOIC8 [(SA602A)]
CAT93HC46(16bit)(K)@SOIC8 [(SA605A)]
CAT93HC46(16bit)(S)@SOIC8 [(SA602A)]
CAT93HC46(16bit)(U)@TSSOP8 [(SA026)]

```

DRAM & SRAM

```

CAT71C256
CAT71C256L
CAT71C256@TSOP28 [(SA643)]
CAT71C256L@TSOP28 [(SA643)]

```

CELESTICA

E(E) PROM/FRAM/NVRAM

```

SST49LF160C@TSOP40 [(SA409T)]

```

CERAMATE

E(E) PROM/FRAM/NVRAM

```

24LC02
24LC02@TSSOP8 [(SA026)]
24LC02@SOIC8 [(SA602A)]
24LC08

```

24LC08@SOIC8 [(SA602A)]	24LC08@TSSOP8 [(SA026)]
24LC16	24LC16@SOIC8 [(SA602A)]
24LC16@TSSOP8 [(SA026)]	24LLC02
24LLC02@SOIC8 [(SA602A)]	24LLC02@TSSOP8 [(SA026)]
24LLC08	24LLC08@SOIC8 [(SA602A)]
24LLC08@TSSOP8 [(SA026)]	93LC46
93LC46@SOIC8 [(SA602A)]	93LC46R
93LC46R@SOIC8 [(SA602A)]	93LC56
93LC56@SOIC8 [(SA602A)]	93LC66
93LC66@SOIC8 [(SA602A)]	

CHINA CORE

MICROCONTROLLER

CCM89C51	CCM89C51@PLCC44 [(SA244)]
CCM89C51@TQFP44 [(SA245A)]	CCM89C52
CCM89C52@PLCC44 [(SA244)]	CCM89C52@TQFP44 [(SA245A)]

CHINGIS

E(E) PROM/FRAM/NVRAM

PM24C64	PM24C64@SOIC8 [(SA602A)]
PM24C64@TSOP8 [(SA026)]	PM25LD040(B)@SOIC8 [(SA023A)]
PM25LD040(Q)@WSON8 [(SA683)]	PM25LD040(S)@SOIC8 [(SA602A)]
PM25LV010(B)@SOIC8 [(SA023A)]	PM25LV010(Q)@WSON8 [(SA683)]
PM25LV010(S)@SOIC8 [(SA602A)]	PM25LV010A@SOIC8 [(SA602A)]
PM25LV010A@WSON8 [(SA683)]	PM25LV016@SOIC8 [(SA605A)]
PM25LV016@WSON8 [(SA683)]	PM25LV016A@SOIC8 [(SA605A)]
PM25LV016A@WSON8 [(SA683)]	PM25LV020(B)@SOIC8 [(SA023A)]
PM25LV020(Q)@WSON8 [(SA683)]	PM25LV020(S)@SOIC8 [(SA602A)]
PM25LV040(B)@SOIC8 [(SA023A)]	PM25LV040(Q)@WSON8 [(SA683)]
PM25LV040(S)@SOIC8 [(SA602A)]	PM25LV080@SOIC8 [(SA605A)]
PM25LV080@WSON8 [(SA683)]	PM25LV080A@SOIC8 [(SA605A)]
PM25LV080A@WSON8 [(SA683)]	PM25LV512(B)@SOIC8 [(SA023A)]
PM25LV512(Q)@WSON8 [(SA683)]	PM25LV512(S)@SOIC8 [(SA602A)]
PM25W020(B)@SOIC8 [(SA023A)]	PM25W020(Q)@WSON8 [(SA683)]
PM25W020(S)@SOIC8 [(SA602A)]	PM29F002B
PM29F002B@PLCC32 [(SA015A1T)]	PM29F002T
PM29F002T@PLCC32 [(SA015A1T)]	PM29F004B
PM29F004B@PLCC32 [(SA015A1T)]	PM29F004T
PM29F004T@PLCC32 [(SA015A1T)]	PM29LV002B
PM29LV002B@PLCC32 [(SA015A1T)]	PM29LV002B@VSOP32 [(SA620)]
PM29LV002T	PM29LV002T@PLCC32 [(SA015A1T)]
PM29LV002T@VSOP32 [(SA620)]	PM29LV004B@PLCC32 [(SA015A1T)]
PM29LV004B@VSOP32 [(SA620)]	PM29LV004T@PLCC32 [(SA015A1T)]
PM29LV004T@VSOP32 [(SA620)]	PM29LV104RB@PLCC32 [(SA015A1T)]
PM29LV104RB@VSOP32 [(SA620)]	PM29LV104RT@PLCC32 [(SA015A1T)]
PM29LV104RT@VSOP32 [(SA620)]	PM37LV512
PM37LV512@PLCC32 [(SA015A1T)]	PM37LV512@VSOP32 [(SA620)]
PM39F010	PM39F010@PLCC32 [(SA015A1T)]
PM39F010@VSOP32 [(SA620)]	PM39F020
PM39F020@PLCC32 [(SA015A1T)]	PM39F020@VSOP32 [(SA620)]
PM39F040	PM39F040@PLCC32 [(SA015A1T)]
PM39F040@VSOP32 [(SA620)]	PM39LV010@PLCC32 [(SA015A1T)]
PM39LV010@VSOP32 [(SA620)]	PM39LV010R@PLCC32 [(SA015A1T)]
PM39LV010R@VSOP32 [(SA620)]	PM39LV020@PLCC32 [(SA015A1T)]
PM39LV020@VSOP32 [(SA620)]	PM39LV040@PLCC32 [(SA015A1T)]
PM39LV040@VSOP32 [(SA620)]	PM39LV512@PLCC32 [(SA015A1T)]
PM39LV512@VSOP32 [(SA620)]	PM39LV512R@PLCC32 [(SA015A1T)]
PM39LV512R@VSOP32 [(SA620)]	PM49FL002T@PLCC32 [(SA015A1T)]
PM49FL002T@VSOP32 [(SA620)]	
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]	
PM49FL004T(Low)@VSOP32 [(SA620-B005)]	
PM49FL004T@PLCC32 [(SA015A1T)]	PM49FL004T@VSOP32 [(SA620)]
PM49FL008T@PLCC32 [(SA015A1T)]	PM49FL008T@VSOP32 [(SA620)]
PM49LP002T@PLCC32 [(SA015A1T)]	PM49LP002T@VSOP32 [(SA620)]

CHIPCON

MICROCONTROLLER

CC1010@TQFP64 (ISP) [ISP-HEADER01]

CHIPSWINNER

E (E) PROM/FRAM/NVRAM

CW24C02	CW24C02@SOIC8 [(SA602A)]
CW24C04	CW24C04@SOIC8 [(SA602A)]
CW24C08	CW24C08@SOIC8 [(SA602A)]
CW24C16	CW24C16@SOIC8 [(SA602A)]
CW24C32	CW24C32@SOIC8 [(SA602A)]
CW24C64	CW24C64@SOIC8 [(SA602A)]

MICROCONTROLLER

CW88CS028@SDIP28 [(SA653)]	CW88CS032@SDIP32 [(SA653)]
CW88CS128@SDIP28 [(SA653)]	CW88CS132@SDIP32 [(SA653)]
CW89F1050	CW89F2050
CW89F4050@SDIP28 [(SA653)]	CW89F4050@SOP28 [(SA404)]
CW89F52	CW89F52@LQFP44 [(SA675)]
CW89F54	CW89F54@LQFP44 [(SA675)]

CORERIVER

E (E) PROM/FRAM/NVRAM

CR24C02LI	CR24C02WI@SOIC8 [(SA602)]
CR24C08LI	CR24C08WI@SOIC8 [(SA602)]
CR24C16LI	CR24C16WI@SOIC8 [(SA602)]
CR24C256LI	CR24C256WI@SOIC8 [(SA602)]
CR24C32LI	CR24C32WI@SOIC8 [(SA602)]
CR24C64LI	CR24C64WI@SOIC8 [(SA602)]

CWI

E (E) PROM/FRAM/NVRAM

39LV040@VSOP32 [(SA620)]

CYGNAL

MICROCONTROLLER

C8051F000@TQFP64 (ISP) [(PEP+S616)]	
C8051F001@TQFP48 (ISP) [(SA248)]	C8051F002@TQFP32 (ISP) [(SA663)]
C8051F005@TQFP64 (ISP) [(PEP+S616)]	
C8051F006@TQFP48 (ISP) [(SA248)]	C8051F007@TQFP32 (ISP) [(SA663)]
C8051F010@TQFP64 (ISP) [(PEP+S616)]	
C8051F011@TQFP48 (ISP) [(SA248)]	C8051F012@TQFP32 (ISP) [(SA663)]
C8051F015@TQFP64 (ISP) [(PEP+S616)]	
C8051F016@TQFP48 (ISP) [(SA248)]	C8051F017@TQFP32 (ISP) [(SA663)]
C8051F018@TQFP64 (ISP) [(PEP+S616)]	
C8051F019@TQFP48 (ISP) [(SA248)]	
C8051F020@TQFP100 (ISP) [ISP-HEADER01]	
C8051F021@TQFP64 (ISP) [ISP-HEADER01]	
C8051F022@TQFP100 (ISP) [ISP-HEADER01]	
C8051F023@TQFP64 (ISP) [ISP-HEADER01]	
C8051F040@TQFP100 (ISP) [ISP-HEADER01]	
C8051F041@TQFP64 (ISP) [ISP-HEADER01]	
C8051F042@TQFP100 (ISP) [ISP-HEADER01]	
C8051F043@TQFP64 (ISP) [ISP-HEADER01]	
C8051F044@TQFP100 (ISP) [ISP-HEADER01]	
C8051F045@TQFP64 (ISP) [ISP-HEADER01]	
C8051F046@TQFP100 (ISP) [ISP-HEADER01]	
C8051F047@TQFP64 (ISP) [ISP-HEADER01]	

C8051F206@TQFP48 [(SA248)]	C8051F220@TQFP48 [(SA248)]
C8051F221@TQFP32 [(SA663)]	C8051F226@TQFP48 [(SA248)]
C8051F230@TQFP48 [(SA248)]	C8051F231@TQFP32 [(SA663)]
C8051F236@TQFP48 [(SA248)]	C8051F300 [(SA695A)]
C8051F301 [(SA695A)]	C8051F302 [(SA695A)]
C8051F303 [(SA695A)]	C8051F304 [(SA695A)]
C8051F305 [(SA695A)]	C8051F310@TQFP32 [(SA663)]
C8051F310-GQ@TQFP32 [(SA663)]	C8051F311@QFN28 [(SA697-B006)]
C8051F311-GM@QFN28 [(SA697-B006)]	
C8051F312@TQFP32 [(SA663)]	C8051F312-GQ@TQFP32 [(SA663)]
C8051F313@QFN28 [(SA697-B006)]	
C8051F313-GM@QFN28 [(SA697-B006)]	C8051F314-GQ@TQFP32 [(SA663)]
C8051F314@TQFP32 [(SA663)]	
C8051F315@QFN28 [(SA697-B006)]	
C8051F315-GM@QFN28 [(SA697-B006)]	
C8051F316-GM@QFN24 [(SA710-B006)]	
C8051F317-GM@QFN24 [(SA710-B006)]	
C8051F320@TQFP32 [(SA663)]	C8051F321@QFN28 [(SA697-B006)]
C8051F326@QFN28 [(SA697-B006)]	
C8051F326-GQ@QFN28 [(SA697-B006)]	
C8051F327@QFN28 [(SA697-B006)]	
C8051F327-GQ@QFN28 [(SA697-B006)]	
C8051F330@MLP20 [(SA692)]	C8051F330D
C8051F331@MLP20 [(SA692)]	C8051F332-GM@MLP20 [(SA692)]
C8051F333-GM@MLP20 [(SA692)]	C8051F334-GM@MLP20 [(SA692)]
C8051F335-GM@MLP20 [(SA692)]	C8051F336-GM@QFN20 [(SA692)]
C8051F337-GM@QFN20 [(SA692)]	C8051F338-GM@QFN24 [(SA710)]
C8051F339-GM@QFN24 [(SA710)]	C8051F340-GQ@TQFP48 [(SA248)]
C8051F341-GQ@TQFP48 [(SA248)]	C8051F342-GQ@LQFP32 [(SA663)]
C8051F343-GQ@LQFP32 [(SA663)]	C8051F344-GQ@TQFP48 [(SA248)]
C8051F345-GQ@TQFP48 [(SA248)]	C8051F346-GQ@LQFP32 [(SA663)]
C8051F347-GQ@LQFP32 [(SA663)]	C8051F350-GQ@LQFP32 [(SA663)]
C8051F351-GM@QFN28 [(SA697-B006)]	
C8051F352-GQ@LQFP32 [(SA663)]	
C8051F353-GM@QFN28 [(SA697-B006)]	
C8051F410-GQ@LQFP32 [(SA663)]	C8051F411-GM@QFN28 [(SA697)]
C8051F412-GQ@LQFP32 [(SA663)]	C8051F413-GM@QFN28 [(SA697)]
C8051F520-IM@QFN10 [(SA695A)]	C8051F521-IM@QFN10 [(SA695A)]
C8051F523-IM@QFN10 [(SA695A)]	C8051F524-IM@QFN10 [(SA695A)]
C8051F526-IM@QFN10 [(SA695A)]	C8051F527-IM@QFN10 [(SA695A)]
C8051F530-IM@QFN20 [(SA692)]	C8051F530-IT@TSSOP20 [(SA026)]
C8051F531-IM@QFN20 [(SA692)]	C8051F531-IT@TSSOP20 [(SA026)]
C8051F533-IM@QFN20 [(SA692)]	C8051F533-IT@TSSOP20 [(SA026)]
C8051F534-IM@QFN20 [(SA692)]	C8051F534-IT@TSSOP20 [(SA026)]
C8051F536-IM@QFN20 [(SA692)]	C8051F536-IT@TSSOP20 [(SA026)]
C8051F537-IM@QFN20 [(SA692)]	C8051F537-IT@TSSOP20 [(SA026)]
C8051F610-GQ@QFP32 [(SA663)]	
C8051F611-GM@QFN28 [(SA697-B006)]	
C8051F612-GQ@QFP32 [(SA663)]	
C8051F613-GM@QFN28 [(SA697-B006)]	
C8051F614-GQ@QFP32 [(SA663)]	
C8051F615-GM@QFN28 [(SA697-B006)]	
C8051F616-GM@QFN24 [(SA710-B006)]	
C8051F617-GM@QFN24 [(SA710-B006)]	
C8051T600@QFN11 [(SA695A)]	C8051T600@SOIC14 [(SA602)]
C8051T601@QFN11 [(SA695A)]	C8051T601@SOIC14 [(SA602)]
C8051T602@QFN11 [(SA695A)]	C8051T602@SOIC14 [(SA602)]
C8051T603@QFN11 [(SA695A)]	C8051T603@SOIC14 [(SA602)]
C8051T604@QFN11 [(SA695A)]	C8051T604@SOIC14 [(SA602)]
C8051T605@QFN11 [(SA695A)]	C8051T605@SOIC14 [(SA602)]
SI8250@LQFP32 [(SA663)]	SI8250@QFN28 [(SA697)]
SI8251@LQFP32 [(SA663)]	SI8251@QFN28 [(SA697)]
SI8252@LQFP32 [(SA663)]	SI8252@QFN28 [(SA697)]

CYPRESS

E(E) PROM/FRAM/NVRAM

CY14B256L@SOIC32 [(SA715)]	CY27C010
CY27C010@PLCC32 [(SA015A1T)]	CY27C010@TSOP32 [(SA410T)]
CY27C020	CY27C020@PLCC32 [(SA015A1T)]
CY27C020@TSOP32 [(SA410T)]	CY27C040
CY27C040@PLCC32 [(SA015A1T)]	CY27C040@TSOP32 [(SA410T)]
CY27C128	CY27C128@PLCC32 [(SA015A1T)]
CY27C256	CY27C256@PLCC32 [(SA015A1T)]
CY27C256@TSOP28 [(SA430T)]	CY27C512
CY27C512@PLCC32 [(SA015A1T)]	CY27C512@TSOP28 [(SA430T)]

CY27H010		CY27H010@PLCC32 [(SA015A1T)]
CY27H010@TSOP32 [(SA410T)]		CY27H256
CY27H256@PLCC32 [(SA015A1T)]		CY27H256@TSOP28 [(SA430T)]
CY27H512		CY27H512@PLCC32 [(SA015A1T)]
CY27H512@TSOP28 [(SA430T)]		CY7C225A
CY7C225A@PLCC28 [(SA008A)]		CY7C243
CY7C243@PLCC28 [(SA008A)]		CY7C244
CY7C244@PLCC28 [(SA008A)]		CY7C245
CY7C245@PLCC28 [(SA008A)]		CY7C245A
CY7C245A@PLCC28 [(SA008A)]		CY7C251
CY7C251@PLCC32 [(SA015A1T)]		CY7C254
CY7C254@PLCC32 [(SA015A1T)]		CY7C256
CY7C256@PLCC32 [(SA015A1T)]		CY7C261
CY7C261@PLCC28 [(SA008A)]		CY7C263
CY7C263@PLCC28 [(SA008A)]		CY7C264
CY7C264@PLCC28 [(SA008A)]		CY7C265
CY7C265@PLCC28 [(SA008A)]		CY7C266
CY7C266@PLCC32 [(SA015A1T)]		CY7C268
CY7C268@PLCC32 [(SA015A1T)]		CY7C271
CY7C271@PLCC32 [(SA015A1T)]		CY7C271A
CY7C271A@PLCC32 [(SA015A1T)]		CY7C274
CY7C274@PLCC32 [(SA015A1T)]		CY7C276(25HC)@PLCC44 [(SA244)]
CY7C276(25JC)@PLCC44 [(SA244)]		CY7C276(30JC)@PLCC44 [(SA244)]
CY7C281		CY7C281@PLCC28 [(SA008A)]
CY7C281A		CY7C281A@PLCC28 [(SA008A)]
CY7C282		CY7C282@PLCC28 [(SA008A)]
CY7C282A		CY7C282A@PLCC28 [(SA008A)]
CY7C285		CY7C285@PLCC32 [(SA015A1T)]
CY7C286		CY7C286@PLCC32 [(SA015A1T)]
CY7C287		CY7C287@PLCC32 [(SA015A1T)]
CY7C291		CY7C291@PLCC28 [(SA008A)]
CY7C291A		CY7C291A@PLCC28 [(SA008A)]
CY7C292		CY7C292@PLCC28 [(SA008A)]
CY7C292A		CY7C292A@PLCC28 [(SA008A)]
CY7C293A		CY7C293A@PLCC28 [(SA008A)]
CY8C9520@SSOP28 [(SA626A)]		CY8C9540@SSOP48 [(SA669)]

DRAM & SRAM

CY62128@SOIC32 [(SA687)]		CY62128@SOJ32 [(SA661)]
CY62128@VSOP32 [(SA620)]		CY62128L@SOIC32 [(SA687)]
CY62128L@SOJ32 [(SA661)]		CY62128L@VSOP32 [(SA620)]
CY62128LL@SOIC32 [(SA687)]		CY62128LL@SOJ32 [(SA661)]
CY62128LL@VSOP32 [(SA620)]		CY7C1011@TSOP44 [(SA645)]
CY7C1020@TSOP44 [(SA645)]		CY7C1021@TSOP44 [(SA645)]
CY7C1049@SOJ36 [(SA027)]		CY7C1049@TSOP44 [(SA645)]
CY7C107		CY7C107@SOJ28 [(SA661)]
CY7C147		CY7C167
CY7C167@PLCC20 [(SA001A)]		CY7C167A
CY7C167A@PLCC20 [(SA001A)]		CY7C185
CY7C185@SOIC28 [(SA404)]		CY7C185@SOJ28 [(SA646)]
CY7C186		CY7C187
CY7C187@SOJ24 [(SA646)]		CY7C187A
CY7C187A@SOJ24 [(SA646)]		CY7C193
CY7C193@SOJ28 [(SA646)]		CY7C199
CY7C199@PLCC28 [(SA008A)]		CY7C199@SOJ28 [(SA646)]
CY7C199@TSOP28 [(SA430T)]		

PLD

PALC16L8		PALC16L8@PLCC20 [(SA001A)]
PALC16L8L		PALC16L8L@PLCC20 [(SA001A)]
PALC16R4		PALC16R4@PLCC20 [(SA001A)]
PALC16R4L		PALC16R4L@PLCC20 [(SA001A)]
PALC16R6		PALC16R6@PLCC20 [(SA001A)]
PALC16R6L		PALC16R6L@PLCC20 [(SA001A)]
PALC16R8		PALC16R8@PLCC20 [(SA001A)]
PALC16R8L		PALC16R8L@PLCC20 [(SA001A)]
PALC22V10		PALC22V10@PLCC28 [(SA008A)]
PALC22V10A		PALC22V10A@PLCC28 [(SA008A)]
PALC22V10B		PALC22V10B@PLCC28 [(SA008A)]
PALC22V10D		PALC22V10D@PLCC28 [(SA008A)]
PALC22V10L		PALC22V10L@PLCC28 [(SA008A)]
PALCE16V8		PALCE16V8@PLCC20 [(SA001A)]
PALCE20V8		PALCE20V8@PLCC28 [(SA008A)]
PALCE20V8L		PALCE20V8L@PLCC28 [(SA008A)]
PALCE22V10		PALCE22V10@PLCC28 [(SA008A)]

DALLAS**E (E) PROM/FRAM/NVRAM**

DS1073M-100	DS1073M-60
DS1073M-66	DS1073M-80
DS1073Z-100@SOIC8 [(SA602A)]	DS1073Z-60@SOIC8 [(SA602A)]
DS1073Z-66@SOIC8 [(SA602A)]	DS1073Z-80@SOIC8 [(SA602A)]
DS1077LZ-40@SOIC8 [(SA602A)]	DS1077LZ-50@SOIC8 [(SA602A)]
DS1077LZ-60@SOIC8 [(SA602A)]	DS1077LZ-66@SOIC8 [(SA602A)]
DS1077Z-40@SOIC8 [(SA602A)]	DS1077Z-50@SOIC8 [(SA602A)]
DS1077Z-60@SOIC8 [(SA602A)]	DS1077Z-66@SOIC8 [(SA602A)]
DS1220AB	DS1220AD
DS1220Y	DS1225AB
DS1225AD	DS1225D
DS1225E	DS1225Y
DS1230AB	DS1230W
DS1230Y	DS1235AB
DS1235Y	DS1243Y
DS1244	DS1244Y
DS1245AB	DS1245EE
DS1245P	DS1245W
DS1245Y	DS1248P
DS1248W	DS1248Y
DS1249AB	DS1249W
DS1249Y	DS1250AB
DS1250W	DS1250Y
DS1251AB	DS1251W
DS1251Y	DS1256P
DS1256W	DS1256Y
DS1258AB	DS1258W
DS1258Y	DS1265AB
DS1265W	DS1265Y
DS1270AB	DS1270W
DS1270Y	DS1284
DS1284N	DS1284Q@PLCC28 [(SA008A)]
DS1284QN@PLCC28 [(SA008A)]	DS1286
DS1286I	DS1287
DS1287A	DS12887
DS12887A	DS12C887
DS12C887A	DS1330AB
DS1330WP	DS1330Y
DS1345AB	DS1345P
DS1345W	DS1345Y
DS1350AB	DS1350P
DS1350W	DS1350Y
DS1386(32K)	DS1386(8K)
DS14285	DS14287
DS1485	DS1485@SOIC28 [(SA630)]
DS1486	DS1488
DS1501	DS1511
DS1553	DS1553W
DS1554	DS1554W
DS1556	DS1630AB
DS1630Y	DS1642
DS1643	DS1644
DS1644P	DS1645AB
DS1645EE	DS1645Y
DS1646	DS1647
DS1647LPM	DS1650AB
DS1650Y	DS1687-3
DS1687-5	DS17287-3
DS17287-5	DS1742
DS1742W	DS1743
DS1743P	DS1743W
DS1743WP	DS1744
DS1744P	DS1744W
DS1744WP	DS1746
DS1747	DS1747P
DS1747W	DS1747WP
DS17487-3	DS17487-5
DS17887-3	DS17887-5
DS2406@TO-92	DS2406P@TSOC6
DS2430A@TO-92	DS2430AP@TSOC6 [(SA602A)]
DS2431@TO-92	DS2431P@TSOC6 [(SA602A)]
DS2432P@TSOC6 [(SA602A)]	DS2433@PR-35
DS2433S(3.9)@SOIC8 [(SA602A)]	DS2433S(5.5)@SOIC8 [(SA605A)]
DS2502	DS2502P@TSOC6 [(SA602A)]

DS2502S@SOIC8 [(SA602A)]	DS2502UNW
DS2502UNW@SOIC8 [(SA602A)]	DS2502UNW@TSOC6 [(SA602A)]
DS2506	DS2506S@SOIC8 [(SA023A)]
DS4510@uSOP10	DS4520@TSSOP16 [(SA026)]
DS4550@TSSOP20 [(SA026)]	

MICROCONTROLLER

DS87C520	DS87C520@PLCC44 [(SA244)]
DS87C520@TQFP44 [(SA245A)]	DS89C420
DS89C420 (rev.A)	DS89C420 (rev.A)@PLCC44 [(SA244)]
DS89C420 (rev.A)@TQFP44 [(SA245A)]	
DS89C420@PLCC44 [(SA244)]	DS89C420@TQFP44 [(SA245A)]
DS89C430	DS89C430@PLCC44 [(SA244)]
DS89C430@TQFP44 [(SA245A)]	DS89C440
DS89C440@PLCC44 [(SA244)]	DS89C440@TQFP44 [(SA245A)]
DS89C450	DS89C450@PLCC44 [(SA244)]
DS89C450@TQFP44 [(SA245A)]	

DENSE-PAC

E (E) PROM/FRAM/NVRAM

DPV27C101	DPV27C101@PLCC32 [(SA015A1T)]
DPV27C256	DPV27C256@PLCC32 [(SA015A1T)]
DPV27C512	DPV27C512@PLCC32 [(SA015A1T)]

DEUTRON

E (E) PROM/FRAM/NVRAM

AC25LV010	AC25LV010@SOIC8 [(SA602A)]
AC25LV512	AC25LV512@SOIC8 [(SA602A)]
P439LV010@PLCC32 [(SA015A1T)]	P439LV010@VSOP32 [(SA620)]
P439LV040@PLCC32 [(SA015A1T)]	P439LV040@VSOP32 [(SA620)]
P439LV088@TSOP48 [(SA247-B005)]	P439VF800@TSOP48 [(SA247-B005)]

EFST

E (E) PROM/FRAM/NVRAM

EM25LV010@SOIC8 [(SA602A)]	EM25LV010@VFQFPN8 [(SA684)]
EM25LV512@SOIC8 [(SA602A)]	EM25LV512@VFQFPN8 [(SA684)]
F25L004A@SOIC8 [(SA602A)]	F49B002UA
F49B002UA@PLCC32 [(SA015A1T)]	F49L004BA@PLCC32 [(SA015A1T)]
F49L004BA@TSOP40 [(SA409T)]	F49L004UA@PLCC32 [(SA015A1T)]
F49L004UA@TSOP40 [(SA409T)]	F49L040A@PLCC32 [(SA015A1T)]
F49L040A@VSOP32 [(SA620)]	

ELECTRONIC ARRAYS

E (E) PROM/FRAM/NVRAM

EA2716

EM

MICROCONTROLLER

EM6503@SOIC24 (ISP) [ISP-HEADER01]
EM6504@SOIC24 (ISP) [ISP-HEADER01]
EM6505@SOIC24 (ISP) [ISP-HEADER01]
EM6517@SOIC28 (ISP) [ISP-HEADER01]
EM6520@TQFP44 (ISP) [ISP-HEADER01]

EM6521@TQFP52(ISP) [ISP-HEADER01]
 EM6522@TQFP64(ISP) [ISP-HEADER01]
 EM6540@SOIC18(ISP) [ISP-HEADER01]
 EM6580(ISP) [ISP-HEADER01]
 EM6580@SOIC14(ISP) [ISP-HEADER01]
 EM6580@SOIC8(ISP) [ISP-HEADER01]
 EM6580@TSSOP14(ISP) [ISP-HEADER01]

EMTC

E(E) PROM/FRAM/NVRAM

EM24C02	EM24C02@SOIC8 [(SA602A)]
EM24C02@TSSOP8 [(SA026)]	EM24C04
EM24C04@SOIC8 [(SA602A)]	EM24C04@TSSOP8 [(SA026)]
EM24C08	EM24C08@SOIC8 [(SA602A)]
EM24C08@TSSOP8 [(SA026)]	EM24C16
EM24C16@SOIC8 [(SA602A)]	EM24C16@TSSOP8 [(SA026)]
EM25SL512@SOIC8 [(SA602A)]	EM29SF002AB
EM29SF002AB@PLCC32 [(SA015A1T)]	EM29SF002AB@TSOP32 [(SA410T)]
EM29SF002AT	EM29SF002AT@PLCC32 [(SA015A1T)]
EM29SF002AT@TSOP32 [(SA410T)]	EM29SF002NAB
EM29SF002NAB@PLCC32 [(SA015A1T)]	EM29SF002NAB@TSOP32 [(SA410T)]
EM29SF002NAT	EM29SF002NAT@PLCC32 [(SA015A1T)]
EM29SF002NAT@TSOP32 [(SA410T)]	

EON

E(E) PROM/FRAM/NVRAM

EN25B05(Bottom Boot)@SOP8(4.0) [(SA602A)]
 EN25B05(Bottom Boot)@SOP8(5.4) [(SA605A)]
 EN25B05(Bottom Boot)@VDFN8 [(SA683)]
 EN25B05(Top Boot)@SOP8(4.0) [(SA602A)]
 EN25B05(Top Boot)@SOP8(5.4) [(SA605A)]
 EN25B05(Top Boot)@VDFN8 [(SA683)]
 EN25B10(Bottom Boot)@SOP8(4.0) [(SA602A)]
 EN25B10(Bottom Boot)@SOP8(5.4) [(SA605A)]
 EN25B10(Bottom Boot)@VDFN8 [(SA683)]
 EN25B10(Top Boot)@SOP8(4.0) [(SA602A)]
 EN25B10(Top Boot)@SOP8(5.4) [(SA605A)]
 EN25B10(Top Boot)@VDFN8 [(SA683)]
 EN25B16(Bottom Boot)@SOP8 [(SA605A)]
 EN25B16(Bottom Boot)@SOP8(ISP) [ISP-HEADER01]
 EN25B16(Bottom Boot)@VFQFN8(ISP) [ISP-HEADER01]
 EN25B16(Bottom Boot)@VFQFPN8 [(SA684)]
 EN25B16(Top Boot)@SOP8 [(SA605A)]
 EN25B16(Top Boot)@SOP8(ISP) [ISP-HEADER01]
 EN25B16(Top Boot)@VFQFN8(ISP) [ISP-HEADER01]
 EN25B16(Top Boot)@VFQFPN8 [(SA684)]
 EN25B20(Bottom Boot)@SOP8(4.0) [(SA602A)]
 EN25B20(Bottom Boot)@SOP8(5.4) [(SA605A)]
 EN25B20(Bottom Boot)@VDFN8 [(SA683)]
 EN25B20(Top Boot)@SOP8(4.0) [(SA602A)]
 EN25B20(Top Boot)@SOP8(5.4) [(SA605A)]
 EN25B20(Top Boot)@VDFN8 [(SA683)]
 EN25B32(Bottom Boot)@SOIC16 [(SA404)]
 EN25B32(Bottom Boot)@SOIC16(ISP) [(SA404)]
 EN25B32(Bottom Boot)@SOP8 [(SA605A)]
 EN25B32(Bottom Boot)@SOP8(ISP) [(SA605A)]
 EN25B32(Bottom Boot)@VDFN8 [(SA684)]
 EN25B32(Bottom Boot)@VDFN8(ISP) [(SA684)]
 EN25B32(Top Boot)@SOIC16 [(SA404)]
 EN25B32(Top Boot)@SOIC16(ISP) [(SA404)]
 EN25B32(Top Boot)@SOP8 [(SA605A)]
 EN25B32(Top Boot)@SOP8(ISP) [(SA605A)]
 EN25B32(Top Boot)@VDFN8 [(SA684)]
 EN25B32(Top Boot)@VDFN8(ISP) [(SA684)]
 EN25B40(Bottom Boot)@SOP8(4.0) [(SA602A)]
 EN25B40(Bottom Boot)@SOP8(5.4) [(SA605A)]
 EN25B40(Bottom Boot)@VDFN8 [(SA683)]
 EN25B40(Top Boot)@SOP8(4.0) [(SA602A)]
 EN25B40(Top Boot)@SOP8(5.4) [(SA605A)]
 EN25B40(Top Boot)@VDFN8 [(SA683)]

```

EN25B64(Bottom Boot)@SOIC16 [(SA404)]
EN25B64(Bottom Boot)@SOIC16(ISP) [ISP-HEADER01]
EN25B64(Bottom Boot)@VDFN8 [(SA683)]
EN25B64(Bottom Boot)@VDFN8(ISP) [ISP-HEADER01]
EN25B64(Top Boot)@SOIC16 [(SA404)]
EN25B64(Top Boot)@SOIC16(ISP) [ISP-HEADER01]
EN25B64(Top Boot)@VDFN8 [(SA683)]
EN25B64(Top Boot)@VDFN8(ISP) [ISP-HEADER01]
EN25B80(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B80(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B80(Bottom Boot)@VDFN8 [(SA683)]
EN25B80(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B80(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B80(Top Boot)@VDFN8 [(SA683)]
EN25D16
EN25D16@SOP8 [(SA605A)]
EN25D80
EN25D80@VDFN8 [(SA683)]
EN25F05@SOP8(5.4) [(SA605A)]
EN25F10@SOP8(4.0) [(SA602A)]
EN25F10@VDFN8 [(SA683)]
EN25F16@SOP16 [(SA404)]
EN25F16@VDFN8 [(SA684)]
EN25F20@VDFN8 [(SA683)]
EN25F32@SOIC16 [(SA404)]
EN25F32@VDFN8 [(SA684)]
EN25F40@SOP8(200mil) [(SA605A)]
EN25F80
EN25F80@VDFN8 [(SA683)]
EN25LF05@SOP8(5.4) [(SA605A)]
EN25LF10@SOP8(4.0) [(SA602A)]
EN25LF10@VDFN8 [(SA683)]
EN25LF20@VDFN8 [(SA683)]
EN25LF40@SOP8(200mil) [(SA605A)]
EN25LV010@SOIC8 [(SA602A)]
EN25LV020@SOIC8 [(SA602A)]
EN25LV040@SOIC8 [(SA602A)]
EN25LV080@SOIC8 [(SA602A)]
EN25LV160@SOIC8 [(SA602A)]
EN25LV160@SOIC8(ISP) [ISP-HEADER01]
EN25LV160@VFQFPN8 [(SA683)]
EN25LV160@VFQFPN8(ISP) [ISP-HEADER01]
EN25LV512@SOIC8 [(SA602A)]
EN25P05@SOP8(4.0) [(SA602A)]
EN25P05@VDFN8 [(SA683)]
EN25P10@SOP8(5.4) [(SA605A)]
EN25P16@SOP8 [(SA605A)]
EN25P16@VFQFPN8 [(SA684)]
EN25P16@VFQFPN8(ISP) [ISP-HEADER01]
EN25P20@SOP8(4.0) [(SA602A)]
EN25P20@VDFN8 [(SA683)]
EN25P32@SOIC16(ISP) [(SA404)]
EN25P32@SOP8(ISP) [(SA605A)]
EN25P32@VDFN8(ISP) [(SA684)]
EN25P40@SOP8(5.4) [(SA605A)]
EN25P64@SOIC16 [(SA404)]
EN25P64@SOIC16(ISP) [ISP-HEADER01]
EN25P64@VDFN8 [(SA683)]
EN25P64@VDFN8(ISP) [ISP-HEADER01]
EN25P80@SOP8(4.0) [(SA602A)]
EN25P80@VDFN8 [(SA683)]
EN25Q16@SOP16 [(SA404)]
EN25Q16@VDFN8 [(SA684)]
EN25Q32A@SOP8 [(SA605A)]
EN25Q40@SOP8 [(SA605A)]
EN25Q64@SOP16 [(SA404)]
EN25Q64@VDFN8(5*6mm) [(SA683)]
EN25Q80A@SOP8(4.0) [(SA602A)]
EN25Q80A@VDFN8 [(SA683)]
EN25S10@VDFN8 [(SA724)]
EN25S16@VFQFPN8 [(SA684)]
EN25S20@VDFN8 [(SA724)]
EN25S32(Bottom Boot)@SOIC16 [(SA404)]
EN25S32(Bottom Boot)@SOIC16(ISP) [(SA404)]
EN25S32(Bottom Boot)@SOP8 [(SA605A)]
EN25S32(Bottom Boot)@SOP8(ISP) [(SA605A)]
EN25S32(Bottom Boot)@VDFN8 [(SA684)]
EN25S32(Bottom Boot)@VDFN8(ISP) [(SA684)]
EN25S32(Top Boot)@SOIC16 [(SA404)]
EN25S32(Top Boot)@SOIC16(ISP) [(SA404)]
EN25S32(Top Boot)@SOP8 [(SA605A)]
EN25D16@SOP16 [(SA404)]
EN25D16@VDFN8 [(SA684)]
EN25D80@SOP8 [(SA605A)]
EN25F05@SOP8(4.0) [(SA602A)]
EN25F05@VDFN8 [(SA683)]
EN25F10@SOP8(5.4) [(SA605A)]
EN25F16
EN25F16@SOP8 [(SA605A)]
EN25F20@SOP8 [(SA605A)]
EN25F32
EN25F32@SOP8 [(SA605A)]
EN25F40@SOP8(150mil) [(SA602A)]
EN25F40@VDFN8 [(SA683)]
EN25F80@SOP8 [(SA605A)]
EN25LF05@SOP8(4.0) [(SA602A)]
EN25LF05@VDFN8 [(SA683)]
EN25LF10@SOP8(5.4) [(SA605A)]
EN25LF20@SOP8 [(SA605A)]
EN25LF40@SOP8(150mil) [(SA602A)]
EN25LF40@VDFN8 [(SA683)]
EN25LV010@VFQFPN8 [(SA684)]
EN25LV020@VFQFPN8 [(SA684)]
EN25LV040@VFQFPN8 [(SA684)]
EN25LV080@VFQFPN8 [(SA684)]
EN25LV512@VFQFPN8 [(SA684)]
EN25P05@SOP8(5.4) [(SA605A)]
EN25P10@SOP8(4.0) [(SA602A)]
EN25P10@VDFN8 [(SA683)]
EN25P16@SOP8(ISP) [ISP-HEADER01]
EN25P20@SOP8(5.4) [(SA605A)]
EN25P32@SOIC16 [(SA404)]
EN25P32@SOP8 [(SA605A)]
EN25P32@VDFN8 [(SA684)]
EN25P40@SOP8(4.0) [(SA602A)]
EN25P40@VDFN8 [(SA683)]
EN25P80@SOP8(5.4) [(SA605A)]
EN25Q16
EN25Q16@SOP8 [(SA605A)]
EN25Q32A
EN25Q32A@VDFN8 [(SA683)]
EN25Q40@VDFN8 [(SA683)]
EN25Q64@SOP8 [(SA605)]
EN25Q64@VDFN8(6*8mm) [(SA684)]
EN25Q80A@SOP8(5.4) [(SA605A)]
EN25S10@SOP8 [(SA602A)]
EN25S16@SOP8 [(SA605A)]
EN25S20@SOP8 [(SA605A)]

```

EN25S32(Top Boot)@SOP8(ISP) [(SA605A)]	
EN25S32(Top Boot)@VDFN8 [(SA684)]	
EN25S32(Top Boot)@VDFN8(ISP) [(SA684)]	
EN25S40@SOP8 [(SA605A)]	EN25S40@VDFN8(2*3mm) [(SA724)]
EN25S40@VDFN8(5*6mm) [(SA683)]	EN25S80@SOP8(150mil) [(SA605A)]
EN25S80@SOP8(200mil) [(SA602A)]	EN25S80@VDFN8 [(SA683)]
EN25T16@SOP8 [(SA605A)]	EN25T16@VFQFPN8 [(SA684)]
EN25T80	EN25T80@SOP8 [(SA605A)]
EN25T80@VDFN8 [(SA683)]	EN27C010
EN27C010@PLCC32 [(SA015A1T)]	EN27C512
EN27C512@PLCC32 [(SA015A1T)]	EN29F002AB
EN29F002AB@PLCC32 [(SA015A1T)]	EN29F002AB@TSOP32 [(SA410T)]
EN29F002ANB	EN29F002ANB@PLCC32 [(SA015A1T)]
EN29F002ANB@TSOP32 [(SA410T)]	EN29F002ANT
EN29F002ANT@PLCC32 [(SA015A1T)]	EN29F002ANT@TSOP32 [(SA410T)]
EN29F002AT	EN29F002AT@PLCC32 [(SA015A1T)]
EN29F002AT@TSOP32 [(SA410T)]	EN29F002B
EN29F002B@PLCC32 [(SA015A1T)]	EN29F002B@TSOP32 [(SA410T)]
EN29F002NB	EN29F002NB@PLCC32 [(SA015A1T)]
EN29F002NB@TSOP32 [(SA410T)]	EN29F002NT
EN29F002NT@PLCC32 [(SA015A1T)]	EN29F002NT@TSOP32 [(SA410T)]
EN29F002T	EN29F002T@PLCC32 [(SA015A1T)]
EN29F002T@TSOP32 [(SA410T)]	EN29F010
EN29F010@PLCC32 [(SA015A1T)]	EN29F010@TSOP32 [(SA410T)]
EN29F010@VSOP32 [(SA620)]	EN29F040
EN29F040@PLCC32 [(SA015A1T)]	EN29F040@TSOP32 [(SA410T)]
EN29F040A	EN29F040A@PLCC32 [(SA015A1T)]
EN29F040A@TSOP32 [(SA410T)]	EN29F080@TSOP40 [(SA409T)]
EN29F512	EN29F512@PLCC32 [(SA015A1T)]
EN29F512@TSOP32 [(SA410T)]	EN29F512@VSOP32 [(SA620)]
EN29F800B@TSOP48 [(SA247-B005)]	EN29F800T@TSOP48 [(SA247-B005)]
EN29LV010@PLCC32 [(SA015A1T)]	EN29LV010@TSOP32 [(SA410T)]
EN29LV010@VSOP32 [(SA620)]	EN29LV040@PLCC32 [(SA015A1T)]
EN29LV040@TSOP32 [(SA410T)]	EN29LV040@VSOP32 [(SA620)]
EN29LV040A@PLCC32 [(SA015A1T)]	EN29LV040A@TSOP32 [(SA410T)]
EN29LV040A@VSOP32 [(SA620)]	EN29LV512@PLCC32 [(SA015A1T)]
EN29LV512@TSOP32 [(SA410T)]	EN29LV512@VSOP32 [(SA620)]
EN29LV800B@TSOP48 [(SA247-B005)]	EN29LV800T@TSOP48 [(SA247-B005)]

ESMT

E(E)PROM/FRAM/NVRAM

EM25LV010@SOIC8 [(SA602A)]	EM25LV010@VFQFPN8 [(SA684)]
EM25LV512@SOIC8 [(SA602A)]	EM25LV512@VFQFPN8 [(SA684)]
F25L004AB	
F25L004AB@SOIC8(150mil) [(SA602A)]	
F25L004AB@SOIC8(200mil) [(SA605A)]	
F25L004AT	
F25L004AT@SOIC8(150mil) [(SA602A)]	
F25L004AT@SOIC8(200mil) [(SA605A)]	
F25L008AB@SOIC8 [(SA605A)]	F25L008AT@SOIC8 [(SA605A)]
F25L016AB@SOIC8 [(SA605A)]	F25L016AT@SOIC8 [(SA605A)]
F25L040UA@SOIC8 [(SA602A)]	
F25L08PA(AAI-PROGRAM)@SOIC8 [(SA605A)]	
F25L08PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]	
F25L16PA(AAI-PROGRAM)@SOIC8 [(SA605A)]	
F25L16PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]	
F25L320PA(4K OTP)@SOIC16 [(SA404)]	
F25L320PA(4K OTP)@SOIC8 [(SA605A)]	
F25L320PA@SOIC16 [(SA404)]	F25L320PA@SOIC8 [(SA605A)]
F25L32PA(4K OTP)(new)@SOIC16 [(SA404)]	
F25L32PA(4K OTP)(new)@SOIC8 [(SA605A)]	
F25L32PA(4K OTP)@SOIC16 [(SA404)]	
F25L32PA(4K OTP)@SOIC8 [(SA605A)]	
F25L32PA(new)@SOIC16 [(SA404)]	F25L32PA(new)@SOIC8 [(SA605A)]
F25L32PA@SOIC16 [(SA404)]	F25L32PA@SOIC8 [(SA605A)]
F25L32QA(4K OTP)@SOIC16 [(SA404)]	
F25L32QA(4K OTP)@SOIC8 [(SA605A)]	
F25L32QA@SOIC16 [(SA404)]	F25L32QA@SOIC8 [(SA605A)]
F49B002UA	F49B002UA@PLCC32 [(SA015A1T)]
F49L004BA@PLCC32 [(SA015A1T)]	F49L004BA@TSOP40 [(SA409T)]
F49L004UA@PLCC32 [(SA015A1T)]	F49L004UA@TSOP40 [(SA409T)]
F49L040A@PLCC32 [(SA015A1T)]	F49L040A@VSOP32 [(SA620)]

EXCELSEMI

E (E) PROM/FRAM/NVRAM

ES25M16	ES25M16@SOP16 [(SA404)]
ES25M16@SOP8[150 mil] [(SA602A)]	ES25M16@SOP8[208 mil] [(SA605A)]
ES25M40	ES25M40@SOP16 [(SA404)]
ES25M40@SOP8[150 mil] [(SA602A)]	ES25M40@SOP8[208 mil] [(SA605A)]
ES25M80	ES25M80@SOP16 [(SA404)]
ES25M80@SOP8[150 mil] [(SA602A)]	ES25M80@SOP8[208 mil] [(SA605A)]
ES25P16@SOP8 [(SA605A)]	ES25P40@SOP8 [(SA605A)]
ES25P80@SOP8 [(SA605A)]	

EXEL

E (E) PROM/FRAM/NVRAM

XL24C01A	XL24C02
XL24C04	XL24C16
XL24C16@SOIC8 [(SA602A)]	XL24C32
XL28C256	XL28C256@PLCC32 [(SA015A1T)]
XL28C256@TSOP28 [(SA430T)]	XL9010
XL9010(F) [(SA602A)]	XL9020
XL9020(F) [(SA602A)]	XL9040
XL9040(F) [(SA602A)]	XL9346
XL9346@SOIC8 [(SA602A)]	XL93CS56
XL93CS56@SOIC8 [(SA602A)]	XL93CS56@TSSOP8 [(SA026)]
XL93CS66	XL93CS66@SOIC8 [(SA602A)]
XL93CS66@TSSOP8 [(SA026)]	XL93LC46
XL93LC46@SOIC8 [(SA602A)]	XL93LC46A
XL93LC46A@SOIC8 [(SA602A)]	XL93LC56
XL93LC56@SOIC8 [(SA602A)]	XL93LC56A
XL93LC56A@SOIC8 [(SA602A)]	XL93LC66A
XL93LC66A@SOIC8 [(SA602A)]	XL9764
XLE28C16A	XLE28C16A@PLCC32 [(SA015A1T)]
XLE28C16B	XLE28C16B@PLCC32 [(SA015A1T)]
XLE28C16B@SOIC24 [(SA404)]	XLM28C16A
XLM28C16A@PLCC32 [(SA015A1T)]	XLM46C15
XLM46P15	XLS2804A
XLS2816A	XLS2816A@PLCC32 [(SA015A1T)]
XLS2817A	XLS28C16A
XLS28C16A@PLCC32 [(SA015A1T)]	XLS28C16B
XLS28C16B@PLCC32 [(SA015A1T)]	XLS28C16B@SOIC24 [(SA404)]
XLS28C64B	XLS28C64B@PLCC32 [(SA015A1T)]
XLS28C64B@SOIC28 [(SA404)]	XLS46C15
XLS46P15	XLS93C46
XLS93C46@SOIC8 [(SA602A)]	XLS93C56
XLS93C56@SOIC8 [(SA602A)]	XLS93C66
XLS93C66@SOIC8 [(SA602A)]	XLS93CS46
XLS93CS46@SOIC8 [(SA602A)]	XLS93CS46@TSSOP8 [(SA026)]
XLS93LC06	XLS93LC06@SOIC8 [(SA602A)]
XLS93LC66	XLS93LC66@SOIC8 [(SA602A)]

FAIRCHILD

E (E) PROM/FRAM/NVRAM

FM24C02(M8)@SOIC8 [(SA602A)]	FM24C02(MT8)@TSSOP8 [(SA026)]
FM24C02(N)	FM24C03(M8)@SOIC8 [(SA602A)]
FM24C03(MT8)@TSSOP8 [(SA026)]	FM24C03(N)
FM24C04(M8)@SOIC8 [(SA602A)]	FM24C04(MT8)@TSSOP8 [(SA026)]
FM24C04(N)	FM24C05(M8)@SOIC8 [(SA602A)]
FM24C05(MT8)@TSSOP8 [(SA026)]	FM24C05(N)
FM24C08(M8)@SOIC8 [(SA602A)]	FM24C08(MT8)@TSSOP8 [(SA026)]
FM24C08(N)	FM24C09(M8)@SOIC8 [(SA602A)]
FM24C09(MT8)@TSSOP8 [(SA026)]	FM24C09(N)
FM24C128(MT8)@TSSOP8 [(SA026)]	FM24C128(MW8)@SOIC8 [(SA602A)]
FM24C128(N)	FM24C16(M8)@SOIC8 [(SA602A)]
FM24C16(MT8)@TSSOP8 [(SA026)]	FM24C16(N)
FM24C17(M8)@SOIC8 [(SA602A)]	FM24C17(MT8)@TSSOP8 [(SA026)]
FM24C17(N)	FM24C256(M8)@SOIC8 [(SA602A)]
FM24C256(N)	FM24C32(M8)@SOIC8 [(SA602A)]
FM24C32(N)	FM27C010

FM27C010@PLCC32 [(SA015A1T)]	FM27C010@TSOP32 [(SA410T)]
FM27C040	FM27C040@PLCC32 [(SA015A1T)]
FM27C040@TSOP32 [(SA410T)]	FM27C256
FM27C256@PLCC32 [(SA015A1T)]	FM27C256Q
FM27C256Q@PLCC32 [(SA015A1T)]	FM27C512
FM27C512@PLCC32 [(SA015A1T)]	
FM93C06(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C06(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C06(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C06(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C06(N)(08bit)	FM93C06(N)(16bit)
FM93C14(16bit)	FM93C46(M8)@SOIC8 [(SA602A)]
FM93C46(MT8)@TSSOP8 [(SA026)]	FM93C46(N)
FM93C46A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C46A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C46A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C46A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C46A(N)(08bit)	FM93C46A(N)(16bit)
FM93C56(M8)@SOIC8 [(SA602A)]	FM93C56(MT8)@TSSOP8 [(SA026)]
FM93C56(N)	
FM93C56A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C56A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C56A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C56A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C56A(N)(08bit)	FM93C56A(N)(16bit)
FM93C66(M8)@SOIC8 [(SA602A)]	FM93C66(MT8)@TSSOP8 [(SA026)]
FM93C66(N)	
FM93C66A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C66A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C66A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C66A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C66A(N)(08bit)	FM93C66A(N)(16bit)
FM93C76(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C76(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C76(N)(16bit)	
FM93C76A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C76A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C76A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C76A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C76A(N)(08bit)	FM93C76A(N)(16bit)
FM93C86(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C86(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C86(N)(16bit)	
FM93C86A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C86A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C86A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C86A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C86A(N)(08bit)	FM93C86A(N)(16bit)
FM93CS06(M8)@SOIC8 [(SA602A)]	FM93CS06(MT8)@TSSOP8 [(SA026)]
FM93CS06(N)	FM93CS46(M8)@SOIC8 [(SA602A)]
FM93CS46(MT8)@TSSOP8 [(SA026)]	FM93CS46(N)
FM93CS56(M8)@SOIC8 [(SA602A)]	FM93CS56(MT8)@TSSOP8 [(SA026)]
FM93CS56(N)	FM93CS66(M8)@SOIC8 [(SA602A)]
FM93CS66(MT8)@TSSOP8 [(SA026)]	FM93CS66(N)
FM93S46(M8)@SOIC8 [(SA602A)]	FM93S46(MT8)@TSSOP8 [(SA026)]
FM93S46(N)	FM93S56(M8)@SOIC8 [(SA602A)]
FM93S56(MT8)@TSSOP8 [(SA026)]	FM93S56(N)
FM93S66(M8)@SOIC8 [(SA602A)]	FM93S66(MT8)@TSSOP8 [(SA026)]
FM93S66(N)	MM2716
MM2716E	NM24C02(M8)@SOIC8 [(SA602A)]
NM24C02(MT8)@TSSOP8 [(SA026)]	NM24C02(N)
NM24C02L(M8)@SOIC8 [(SA602A)]	NM24C02L(MT8)@TSSOP8 [(SA026)]
NM24C02L(N)	NM24C03(M8)@SOIC8 [(SA602A)]
NM24C03(MT8)@TSSOP8 [(SA026)]	NM24C03(N)
NM24C04(M8)@SOIC8 [(SA602A)]	NM24C04(MT8)@TSSOP8 [(SA026)]
NM24C04(N)	NM24C05(M8)@SOIC8 [(SA602A)]
NM24C05(MT8)@TSSOP8 [(SA026)]	NM24C05(N)
NM24C08(M8)@SOIC8 [(SA602A)]	NM24C08(MT8)@TSSOP8 [(SA026)]
NM24C08(N)	NM24C09(M8)@SOIC8 [(SA602A)]
NM24C09(MT8)@TSSOP8 [(SA026)]	NM24C09(N)
NM24C16(M8)@SOIC8 [(SA602A)]	NM24C16(MT8)@TSSOP8 [(SA026)]
NM24C16(N)	NM24C17(M8)@SOIC8 [(SA602A)]
NM24C17(MT8)@TSSOP8 [(SA026)]	NM24C17(N)
NM24C65(M8)@SOIC8 [(SA602A)]	NM24C65(N)
NM27C010	NM27C010@PLCC32 [(SA015A1T)]
NM27C010@TSOP32 [(SA410T)]	NM27C020
NM27C020@PLCC32 [(SA015A1T)]	NM27C020@TSOP32 [(SA410T)]
NM27C020Q	NM27C020Q@PLCC32 [(SA015A1T)]
NM27C020Q@TSOP32 [(SA410T)]	NM27C040
NM27C040@PLCC32 [(SA015A1T)]	NM27C040@TSOP32 [(SA410T)]
NM27C128	NM27C128@PLCC32 [(SA015A1T)]

NM27C210	NM27C210@PLCC44 [(SA244)]
NM27C240	NM27C240@PLCC44 [(SA244)]
NM27C256	NM27C256@PLCC32 [(SA015A1T)]
NM27C512	NM27C512@PLCC32 [(SA015A1T)]
NM27C64Q	NM27C64Q@PLCC32 [(SA015A1T)]
NM27LC256	NM27LC256@PLCC32 [(SA015A1T)]
NM27LC512	NM27LC512@PLCC32 [(SA015A1T)]
NM27LV010	NM27LV010@PLCC32 [(SA015A1T)]
NM27LV010@TSOP32 [(SA410T)]	NM27LV210
NM27LV210@PLCC44 [(SA244)]	NM27LV512
NM27LV512@PLCC32 [(SA015A1T)]	NM27P040
NM27P040@PLCC32 [(SA015A1T)]	NM27P040@TSOP32 [(SA410T)]
NM27P210	NM27P210@PLCC44 [(SA244)]
NM27P512	NM27P512@PLCC32 [(SA015A1T)]
NM93C66(M8)(16bit)@SOIC8 [(SA602A)]	NM93CS06(M8)@SOIC8 [(SA602A)]
NM93C66(MT8)(16bit)@TSSOP8 [(SA026)]	NM93CS06(N)
NM93C66(N)(16bit)	NM93CS46(MT8)@TSSOP8 [(SA026)]
NM93CS06(MT8)@TSSOP8 [(SA026)]	NM93CS56(M8)@SOIC8 [(SA602A)]
NM93CS46(M8)@SOIC8 [(SA602A)]	NM93CS56(N)
NM93CS46(N)	NM93CS66(MT8)@TSSOP8 [(SA026)]
NM93CS56(MT8)@TSSOP8 [(SA026)]	NMC2732
NM93CS66(M8)@SOIC8 [(SA602A)]	NMC27C010@PLCC32 [(SA015A1T)]
NM93CS66(N)	NMC27C1024
NMC27C010	NMC27C128B
NMC27C010@TSOP32 [(SA410T)]	NMC27C128BN
NMC27C1024@PLCC44 [(SA244)]	NMC27C128BQ
NMC27C128B@PLCC32 [(SA015A1T)]	NMC27C128CQ
NMC27C128BN@PLCC32 [(SA015A1T)]	NMC27C16BQ
NMC27C128BQ@PLCC32 [(SA015A1T)]	NMC27C16H
NMC27C16	NMC27C16Q
NMC27C16BQE	NMC27C256@PLCC32 [(SA015A1T)]
NMC27C16HQ	NMC27C256B@PLCC32 [(SA015A1T)]
NMC27C256	NMC27C256Q@PLCC32 [(SA015A1T)]
NMC27C256B	NMC27C32B
NMC27C256Q	NMC27C32E
NMC27C32	NMC27C32H
NMC27C32BQ	NMC27C512@PLCC32 [(SA015A1T)]
NMC27C32EH	NMC27C512A@PLCC32 [(SA015A1T)]
NMC27C512	NMC27C512AN@PLCC32 [(SA015A1T)]
NMC27C512A	NMC27C64(BN)
NMC27C512AN	NMC27CP128
NMC27C64	NMC87C257Q@PLCC32 [(SA015A1T)]
NMC27C64(N)	NMC87C257V@PLCC32 [(SA015A1T)]
NMC87C257Q	
NMC87C257V	
NMC9346(M8)(16bit)@SOIC8 [(SA602A)]	
NMC9346(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC9346(N)(16bit)	
NMC93C46(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C46(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C46(N)(16bit)	
NMC93C46A(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C46A(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C46A(N)(16bit)	
NMC93C56(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C56(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C56(N)(16bit)	
NMC93C66(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C66(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C66(N)(16bit)	
NMC93CS06(MT8)@TSSOP8 [(SA026)]	NMC93CS06(M8)@SOIC8 [(SA602A)]
NMC93CS46(M8)@SOIC8 [(SA602A)]	NMC93CS06(N)
NMC93CS46(N)	NMC93CS46(MT8)@TSSOP8 [(SA026)]
NMC93CS56(MT8)@TSSOP8 [(SA026)]	NMC93CS56(M8)@SOIC8 [(SA602A)]
NMC93CS66(M8)@SOIC8 [(SA602A)]	NMC93CS56(N)
NMC93CS66(N)	NMC93CS66(MT8)@TSSOP8 [(SA026)]
	NMC9817

DRAM & SRAM

F1600	F1600@SOJ24 [(SA646)]
F1601	F1601@SOJ24 [(SA646)]
F1620	F1621

MICROCONTROLLER

ACE1001(M8)@SOIC8 [(SA602A)]	ACE1001(M8X)@SOIC8 [(SA602A)]
ACE1001(MT8)@TSSOP8 [(SA026)]	ACE1001(MT8X)@TSSOP8 [(SA026)]
ACE1001E(M8)@SOIC8 [(SA602A)]	ACE1001E(M8X)@SOIC8 [(SA602A)]

ACE1001E(MT8)@TSSOP8 [(SA026)]	ACE1001E(MT8X)@TSSOP8 [(SA026)]
ACE1001L(M8)@SOIC8 [(SA602A)]	ACE1001L(M8X)@SOIC8 [(SA602A)]
ACE1001L(MT8)@TSSOP8 [(SA026)]	ACE1001L(MT8X)@TSSOP8 [(SA026)]
ACE1101(EMT8)@TSSOP8 [(SA026)]	ACE1101(EMT8X)@TSSOP8 [(SA026)]
ACE1101(EN)	ACE1101(EN14)
ACE1101(LMT8)@TSSOP8 [(SA026)]	ACE1101(LMT8X)@TSSOP8 [(SA026)]
ACE1101(LN)	ACE1101(LN14)
ACE1101(MT8)@TSSOP8 [(SA026)]	ACE1101(MT8X)@TSSOP8 [(SA026)]
ACE1101(N)	ACE1101(N14)
ACE1101(VMT8)@TSSOP8 [(SA026)]	ACE1101(VMT8X)@TSSOP8 [(SA026)]
ACE1101(VN)	ACE1101(VN14)
ACE1101B(EMT8)@TSSOP8 [(SA026)]	ACE1101B(EMT8X)@TSSOP8 [(SA026)]
ACE1101B(EN)	ACE1101B(EN14)
ACE1101B(MT8)@TSSOP8 [(SA026)]	ACE1101B(MT8X)@TSSOP8 [(SA026)]
ACE1101B(N)	ACE1101B(N14)
ACE1101B(VMT8)@TSSOP8 [(SA026)]	ACE1101B(VMT8X)@TSSOP8 [(SA026)]
ACE1101B(VN)	ACE1101B(VN14)
ACE1202(dip14)	ACE1202(dip8)
ACE1202(M14)@SOIC14 [(SA602)]	ACE1202(M8)@SOIC8 [(SA602A)]
ACE12022(dip14)	ACE12022(dip8)
ACE12022(M14)@SOIC14 [(SA602)]	ACE12022(M8)@SOIC8 [(SA602A)]
ACE12022B(dip14)	ACE12022B(dip8)
ACE12022B(M14)@SOIC14 [(SA602)]	ACE12022B(M8)@SOIC8 [(SA602A)]
ACE12022BE(dip14)	ACE12022BE(dip8)
ACE12022BE(M14)@SOIC14 [(SA602)]	ACE12022BE(M8)@SOIC8 [(SA602A)]
ACE12022BV(dip14)	ACE12022BV(dip8)
ACE12022BV(M14)@SOIC14 [(SA602)]	ACE12022BV(M8)@SOIC8 [(SA602A)]
ACE12022E(dip14)	ACE12022E(dip8)
ACE12022E(M14)@SOIC14 [(SA602)]	ACE12022E(M8)@SOIC8 [(SA602A)]
ACE1202B(dip14)	ACE1202B(dip8)
ACE1202B(M14)@SOIC14 [(SA602)]	ACE1202B(M8)@SOIC8 [(SA602A)]
ACE1202BE(dip14)	ACE1202BE(dip8)
ACE1202BE(M14)@SOIC14 [(SA602)]	ACE1202BE(M8)@SOIC8 [(SA602A)]
ACE1202BV(dip14)	ACE1202BV(dip8)
ACE1202BV(M14)@SOIC14 [(SA602)]	ACE1202BV(M8)@SOIC8 [(SA602A)]
ACE1202E(dip14)	ACE1202E(dip8)
ACE1202E(M14)@SOIC14 [(SA602)]	ACE1202E(M8)@SOIC8 [(SA602A)]
ACE1202L(dip14)	ACE1202L(dip8)
ACE1202L(M14)@SOIC14 [(SA602)]	ACE1202L(M8)@SOIC8 [(SA602A)]
ACE1202V(dip8)	ACE1202V(M14)@SOIC14 [(SA602)]
ACE1202V(M8)@SOIC8 [(SA602A)]	ACE1501(EM)@SOIC14 [(SA602)]
ACE1501(EM8)@SOIC8 [(SA602A)]	ACE1501(EM8X)@SOIC8 [(SA602A)]
ACE1501(EMT)@TSOP14 [(SA026)]	ACE1501(EMT8)@TSSOP8 [(SA026)]
ACE1501(EMT8X)@TSSOP8 [(SA026)]	ACE1501(EMTX)@TSOP14 [(SA026)]
ACE1501(EMX)@SOIC14 [(SA602)]	ACE1501(EN)
ACE1501(EN14)	ACE1501(VM)@SOIC14 [(SA602)]
ACE1501(VM8)@SOIC8 [(SA602A)]	ACE1501(VM8X)@SOIC8 [(SA602A)]
ACE1501(VMT)@TSOP14 [(SA026)]	ACE1501(VMT8)@TSSOP8 [(SA026)]
ACE1501(VMT8X)@TSSOP8 [(SA026)]	ACE1501(VMTX)@TSOP14 [(SA026)]
ACE1501(VMX)@SOIC14 [(SA602)]	ACE1501(VN)
ACE1501(VN14)	ACE1502(EM)@SOIC14 [(SA602)]
ACE1502(EM8)@SOIC8 [(SA602A)]	ACE1502(EMT)@TSOP14 [(SA026)]
ACE1502(EMT8)@TSSOP8 [(SA026)]	ACE1502(EN)
ACE1502(EN14)	ACE1502(VM)@SOIC14 [(SA602)]
ACE1502(VM8)@SOIC8 [(SA602A)]	ACE1502(VMT)@TSOP14 [(SA026)]
ACE1502(VMT8)@TSSOP8 [(SA026)]	ACE1502(VN)
ACE1502(VN14)	ACE8000(M8)@SOIC8 [(SA602A)]
ACE8000(M8X)@SOIC8 [(SA602A)]	ACE8000E(M8)@SOIC8 [(SA602A)]
ACE8000E(M8X)@SOIC8 [(SA602A)]	ACE8001(M8)@SOIC8 [(SA602A)]
ACE8001(M8X)@SOIC8 [(SA602A)]	ACE8001(MT8)@TSSOP8 [(SA026)]
ACE8001(MT8X)@TSSOP8 [(SA026)]	ACE8001E(M8)@SOIC8 [(SA602A)]
ACE8001E(M8X)@SOIC8 [(SA602A)]	ACE8001E(MT8)@TSSOP8 [(SA026)]
ACE8001E(MT8X)@TSSOP8 [(SA026)]	FMS7401L(EM8X)@SOIC8 [(SA602A)]
FMS7401L(EMT8X)@TSSOP8 [(SA026)]	FMS7401L(EMTX)@TSSOP14 [(SA026)]
FMS7401L(EMX)@SOIC14 [(SA602)]	FMS7401L(EN)
FMS7401L(EN14)	FMS7401L(VN)
FMS7401L(VN14)	

FORCE TECHNOLOGIES

E(E) PROM/FRAM/NVRAM

FT24C01	FT24C01@SOIC8 [(SA602A)]
FT24C01@TSOP8 [(SA026)]	FT24C01A
FT24C01A@SOIC8 [(SA602A)]	FT24C01A@TSOP8 [(SA026)]
FT24C02	FT24C02@SOP8 [(SA602A)]
FT24C02@TSSOP8 [(SA026)]	FT24C02A

FT24C02A@SOP8 [(SA602A)]	FT24C02A@TSSOP8 [(SA026)]
FT24C04	FT24C04@SOP8 [(SA602A)]
FT24C04@TSSOP8 [(SA026)]	FT24C04A
FT24C04A@SOP8 [(SA602A)]	FT24C04A@TSSOP8 [(SA026)]
FT24C08	FT24C08@SOIC8 [(SA602A)]
FT24C08@TSOP8 [(SA026)]	FT24C08A
FT24C08A@SOIC8 [(SA602A)]	FT24C08A@TSOP8 [(SA026)]
FT24C128	FT24C128@SOIC8 [(SA602A)]
FT24C128@TSOP8 [(SA026)]	FT24C128A
FT24C128A@SOIC8 [(SA602A)]	FT24C128A@TSOP8 [(SA026)]
FT24C16	FT24C16@SOIC8 [(SA602A)]
FT24C16@TSOP8 [(SA026)]	FT24C16A
FT24C16A@SOIC8 [(SA602A)]	FT24C16A@TSOP8 [(SA026)]
FT24C256	FT24C256@SOIC8 [(SA602A)]
FT24C256@TSOP8 [(SA026)]	FT24C256A
FT24C256A@SOIC8 [(SA602A)]	FT24C256A@TSOP8 [(SA026)]
FT24C32	FT24C32@SOIC8 [(SA602A)]
FT24C32@TSOP8 [(SA026)]	FT24C32A
FT24C32A@SOIC8 [(SA602A)]	FT24C32A@TSOP8 [(SA026)]
FT24C64	FT24C64@SOIC8 [(SA602A)]
FT24C64@TSOP8 [(SA026)]	FT24C64A
FT24C64A@SOIC8 [(SA602A)]	FT24C64A@TSOP8 [(SA026)]
FT27C010	FT27C010@PLCC32 [(SA015A1T)]
FT27C010@TSOP32 [(SA410T)]	FT27C020
FT27C020@PLCC32 [(SA015A1T)]	FT27C020@TSOP32 [(SA410T)]
FT27C040	FT27C040@PLCC32 [(SA015A1T)]
FT27C040@TSOP32 [(SA410T)]	FT27C16
FT27C256	FT27C256@PLCC32 [(SA015A1T)]
FT27C64	FT27C64@PLCC32 [(SA015A1T)]
FT27HC256	FT27HC256@PLCC32 [(SA015A1T)]
FT27HC64	FT27HC64@PLCC32 [(SA015A1T)]
FT28C010	FT28C010@JLCC32 [(SA412A)]
FT28C010@PLCC32 [(SA015A1T)]	FT28C010@PLCC44 [(SA244)]
FT28C010@TSOP32 [(SA410T)]	FT28C010E
FT28C010E@JLCC32 [(SA412A)]	FT28C010E@PLCC32 [(SA015A1T)]
FT28C010E@PLCC44 [(SA244)]	FT28C010E@TSOP32 [(SA410T)]
FT28C020	FT28C020@JLCC32 [(SA412A)]
FT28C020@PLCC32 [(SA015A1T)]	FT28C020@PLCC44 [(SA244)]
FT28C020@TSOP32 [(SA410T)]	FT28C040
FT28C040@JLCC32 [(SA412A)]	FT28C040@PLCC32 [(SA015A1T)]
FT28C040@PLCC44 [(SA244)]	FT28C040@TSOP32 [(SA410T)]
FT28C16	FT28C16@PLCC32 [(SA015A1T)]
FT28C256	FT28C256@JLCC32 [(SA412A)]
FT28C256@PLCC32 [(SA015A1T)]	FT28C256@SOIC28 [(SA404)]
FT28C256@TSOP28 [(SA430T)]	FT28C256B
FT28C256B@JLCC32 [(SA412A)]	FT28C256B@PLCC32 [(SA015A1T)]
FT28C256B@SOIC28 [(SA404)]	FT28C256B@TSOP28 [(SA430T)]
FT28C64	FT28C64@PLCC32 [(SA015A1T)]
FT28C64@SOIC28 [(SA404)]	FT28C64@TSOP28 [(SA430T)]
FT28C64B	FT28C64B@JLCC32 [(SA412A)]
FT28C64B@PLCC32 [(SA015A1T)]	FT28C64B@SOIC28 [(SA404)]
FT28C64B@TSOP28 [(SA430T)]	FT28C64X
FT28C64X@PLCC32 [(SA015A1T)]	FT28C64X@SOIC28 [(SA404)]
FT28C64X@TSOP28 [(SA430T)]	FT28HC64
FT28HC64@PLCC32 [(SA015A1T)]	FT28HC64@TSOP28 [(SA430T)]
FT58C1001	FT58C1001@SSOP32 [(SA438T)]
FT58C1001@VSOP32 [(SA620)]	

FORWARD

E(E) PROM/FRAM/NVRAM

24LC01	24LC01@SOIC8 [(SA602A)]
24LC02	24LC02@SOIC8 [(SA602A)]
24LC04	24LC04@SOIC8 [(SA602A)]
24LC08	24LC08@SOIC8 [(SA602A)]
24LC16	24LC16@SOIC8 [(SA602A)]
24LC32	24LC32@SOIC8 [(SA602A)]
24LC64	24LC64@SOIC8 [(SA602A)]

Fremont Micro Devices

E(E) PROM/FRAM/NVRAM

FT24C02	FT24C02@SOP8 [(SA602A)]
FT24C02@TSSOP8 [(SA026)]	FT24C02A
FT24C02A@SOP8 [(SA602A)]	FT24C02A@TSSOP8 [(SA026)]
FT24C04	FT24C04@SOP8 [(SA602A)]
FT24C04@TSSOP8 [(SA026)]	FT24C04A
FT24C04A@SOP8 [(SA602A)]	FT24C04A@TSSOP8 [(SA026)]
FT24C08	FT24C08@SOP8 [(SA602A)]
FT24C08@TSSOP8 [(SA026)]	FT24C08A
FT24C08A@SOP8 [(SA602A)]	FT24C08A@TSSOP8 [(SA026)]
FT24C1024	FT24C1024@SOP8 [(SA023A)]
FT24C1024@TSSOP8 [(SA026)]	FT24C1024A
FT24C1024A@SOP8 [(SA023A)]	FT24C1024A@TSSOP8 [(SA026)]
FT24C128	FT24C128@SOP8 [(SA602A)]
FT24C128@TSSOP8 [(SA026)]	FT24C128A
FT24C128A@SOP8 [(SA602A)]	FT24C128A@TSSOP8 [(SA026)]
FT24C16	FT24C16@SOP8 [(SA602A)]
FT24C16@TSSOP8 [(SA026)]	FT24C16A
FT24C16A@SOP8 [(SA602A)]	FT24C16A@TSSOP8 [(SA026)]
FT24C256	FT24C256@SOP8 [(SA602A)]
FT24C256@TSSOP8 [(SA026)]	FT24C256A
FT24C256A@SOP8 [(SA602A)]	FT24C256A@TSSOP8 [(SA026)]
FT24C32	FT24C32@SOP8 [(SA602A)]
FT24C32@TSSOP8 [(SA026)]	FT24C32A
FT24C32A@SOP8 [(SA602A)]	FT24C32A@TSSOP8 [(SA026)]
FT24C512	FT24C512@SOP8 [(SA602A)]
FT24C512@TSSOP8 [(SA026)]	FT24C512A
FT24C512A@SOP8 [(SA602A)]	FT24C512A@TSSOP8 [(SA026)]
FT24C64	FT24C64@SOP8 [(SA602A)]
FT24C64@TSSOP8 [(SA026)]	FT24C64A
FT24C64A@SOP8 [(SA602A)]	FT24C64A@TSSOP8 [(SA026)]
FT34C02	FT34C02@SOP8 [(SA602A)]
FT34C02@TSSOP8 [(SA026)]	FT34C02A
FT34C02A@SOP8 [(SA602A)]	FT34C02A@TSSOP8 [(SA026)]
FT93C46(08bit)	FT93C46(08bit)@SOP8 [(SA602A)]
FT93C46(08bit)@TSSOP8 [(SA026)]	FT93C46(16bit)
FT93C46(16bit)@SOP8 [(SA602A)]	FT93C46(16bit)@TSSOP8 [(SA026)]
FT93C46A(08bit)	FT93C46A(08bit)@SOP8 [(SA602A)]
FT93C46A(08bit)@TSSOP8 [(SA026)]	FT93C46A(16bit)
FT93C46A(16bit)@SOP8 [(SA602A)]	FT93C46A(16bit)@TSSOP8 [(SA026)]
FT93C56(08bit)	FT93C56(08bit)@SOP8 [(SA602A)]
FT93C56(08bit)@TSSOP8 [(SA026)]	FT93C56(16bit)
FT93C56(16bit)@SOP8 [(SA602A)]	FT93C56(16bit)@TSSOP8 [(SA026)]
FT93C56A(08bit)	FT93C56A(08bit)@SOP8 [(SA602A)]
FT93C56A(08bit)@TSSOP8 [(SA026)]	FT93C56A(16bit)
FT93C56A(16bit)@SOP8 [(SA602A)]	FT93C56A(16bit)@TSSOP8 [(SA026)]
FT93C66(08bit)	FT93C66(08bit)@SOP8 [(SA602A)]
FT93C66(08bit)@TSSOP8 [(SA026)]	FT93C66(16bit)
FT93C66(16bit)@SOP8 [(SA602A)]	FT93C66(16bit)@TSSOP8 [(SA026)]
FT93C66A(08bit)	FT93C66A(08bit)@SOP8 [(SA602A)]
FT93C66A(08bit)@TSSOP8 [(SA026)]	FT93C66A(16bit)
FT93C66A(16bit)@SOP8 [(SA602A)]	FT93C66A(16bit)@TSSOP8 [(SA026)]
FT93C86(08bit)	FT93C86(08bit)@SOP8 [(SA602A)]
FT93C86(08bit)@TSSOP8 [(SA026)]	FT93C86(16bit)
FT93C86(16bit)@SOP8 [(SA602A)]	FT93C86(16bit)@TSSOP8 [(SA026)]
FT93C86A(08bit)	FT93C86A(08bit)@SOP8 [(SA602A)]
FT93C86A(08bit)@TSSOP8 [(SA026)]	FT93C86A(16bit)
FT93C86A(16bit)@SOP8 [(SA602A)]	FT93C86A(16bit)@TSSOP8 [(SA026)]

FUJITSU

E(E) PROM/FRAM/NVRAM

MB85R256@SOP28 [(SA630)]	MB85R256@TSOP28 [(SA430T)]
MB85R256A@SOP28 [(SA630)]	MB85R256A@TSOP28 [(SA430T)]
MBM2212	MBM271001
MBM271001@PLCC32 [(SA015A1T)]	MBM271001@TSOP32 [(SA410T)]
MBM27128	MBM27128@PLCC32 [(SA015A1T)]
MBM2716	MBM2716H
MBM27256	MBM27256@PLCC32 [(SA015A1T)]
MBM2732	MBM2732A
MBM2764	MBM2764@PLCC32 [(SA015A1T)]
MBM27C1000	MBM27C1000@PLCC32 [(SA015A1T)]
MBM27C1000@TSOP32 [(SA410T)]	MBM27C1001
MBM27C1001@PLCC32 [(SA015A1T)]	MBM27C1001@TSOP32 [(SA410T)]
MBM27C1024	MBM27C1024@PLCC44 [(SA244)]
MBM27C1028	MBM27C1028@PLCC32 [(SA015A1T)]
MBM27C128	MBM27C128@PLCC32 [(SA015A1T)]

MBM27C128P		MBM27C128P@PLCC32 [(SA015A1T)]
MBM27C2000		MBM27C2000@PLCC32 [(SA015A1T)]
MBM27C2000@TSOP32 [(SA410T)]		MBM27C2001
MBM27C2001@PLCC32 [(SA015A1T)]		MBM27C2001@TSOP32 [(SA410T)]
MBM27C2048		MBM27C256
MBM27C256@PLCC32 [(SA015A1T)]		MBM27C256A
MBM27C256A@PLCC32 [(SA015A1T)]		MBM27C256AP
MBM27C256AP@PLCC32 [(SA015A1T)]		MBM27C256H
MBM27C256H@PLCC32 [(SA015A1T)]		MBM27C32A
MBM27C4001		MBM27C4001@PLCC32 [(SA015A1T)]
MBM27C4001@TSOP32 [(SA410T)]		MBM27C4096
MBM27C512		MBM27C512@PLCC32 [(SA015A1T)]
MBM27C512P		MBM27C512P@PLCC32 [(SA015A1T)]
MBM27C64		MBM27C64@PLCC32 [(SA015A1T)]
MBM28C64		MBM28C65
MBM28F010		MBM28F010@PLCC32 [(SA015A1T)]
MBM28F010@TSOP32 [(SA410T)]		MBM29F001B
MBM29F001B@PLCC32 [(SA015A1T)]		MBM29F001B@TSOP32 [(SA410T)]
MBM29F001T		MBM29F001T@PLCC32 [(SA015A1T)]
MBM29F001T@TSOP32 [(SA410T)]		MBM29F002B
MBM29F002B@PLCC32 [(SA015A1T)]		MBM29F002B@TSOP32 [(SA410T)]
MBM29F002NB		MBM29F002NB@PLCC32 [(SA015A1T)]
MBM29F002NB@TSOP32 [(SA410T)]		MBM29F002NT
MBM29F002NT@PLCC32 [(SA015A1T)]		MBM29F002NT@TSOP32 [(SA410T)]
MBM29F002T		MBM29F002T@PLCC32 [(SA015A1T)]
MBM29F002T@TSOP32 [(SA410T)]		MBM29F010
MBM29F010@PLCC32 [(SA015A1T)]		MBM29F010@TSOP32 [(SA410T)]
MBM29F010A		MBM29F010A@PLCC32 [(SA015A1T)]
MBM29F010A@TSOP32 [(SA410T)]		MBM29F016@PSOP44 [(SA638)]
MBM29F016@TSOP40 [(SA409T)]		MBM29F016@TSOP48 [(SA247-B005)]
MBM29F016A@PSOP44 [(SA638)]		MBM29F016A@TSOP40 [(SA409T)]
MBM29F016A@TSOP48 [(SA247-B005)]		MBM29F016B@PSOP44 [(SA638)]
MBM29F016B@TSOP40 [(SA409T)]		MBM29F016B@TSOP48 [(SA247-B005)]
MBM29F017B@TSOP48 [(SA247-B005)]		MBM29F017D@TSOP40 [(SA409T)]
MBM29F017D@TSOP48 [(SA247-B005)]		MBM29F032B@PSOP44 [(SA638)]
MBM29F032B@TSOP40 [(SA409T)]		MBM29F033C@TSOP40 [(SA409T)]
MBM29F040		MBM29F040@PLCC32 [(SA015A1T)]
MBM29F040@TSOP32 [(SA410T)]		MBM29F040B
MBM29F040B@PLCC32 [(SA015A1T)]		MBM29F040B@TSOP32 [(SA410T)]
MBM29F040C@PLCC32 [(SA015A1T)]		MBM29F040C@TSOP32 [(SA410T)]
MBM29F080@PSOP44 [(SA638)]		MBM29F080@TSOP40 [(SA409T)]
MBM29F080A@TSOP48 [(SA247-B005)]		MBM29F080B@PSOP44 [(SA638)]
MBM29F080B@TSOP40 [(SA409T)]		MBM29F100B@PSOP44 [(SA638-B006)]
MBM29F100B@TSOP48 [(SA247-B005)]		MBM29F100T@PSOP44 [(SA638-B006)]
MBM29F100T@TSOP48 [(SA247-B005)]		
MBM29F160BE@TSOP48 [(SA247-B005)]		
MBM29F160TE@TSOP48 [(SA247-B005)]		
MBM29F200AB@PSOP44 [(SA638-B006)]		
MBM29F200AB@TSOP48 [(SA247-B005)]		
MBM29F200AT@PSOP44 [(SA638-B006)]		
MBM29F200AT@TSOP48 [(SA247-B005)]		
MBM29F200B@PSOP44 [(SA638-B006)]		MBM29F200B@TSOP48 [(SA247-B005)]
MBM29F200T@PSOP44 [(SA638-B006)]		MBM29F200T@TSOP48 [(SA247-B005)]
MBM29F400AB@PSOP44 [(SA638-B006)]		
MBM29F400AB@TSOP48 [(SA247-B005)]		
MBM29F400AT@PSOP44 [(SA638-B006)]		
MBM29F400AT@TSOP48 [(SA247-B005)]		
MBM29F400B@PSOP44 [(SA638-B006)]		MBM29F400B@TSOP48 [(SA247-B005)]
MBM29F400BB@PSOP44 [(SA638-B006)]		
MBM29F400BB@TSOP48 [(SA247-B005)]		
MBM29F400BT@PSOP44 [(SA638-B006)]		
MBM29F400BT@TSOP48 [(SA247-B005)]		
MBM29F400T@PSOP44 [(SA638-B006)]		MBM29F400T@TSOP48 [(SA247-B005)]
MBM29F800B@PSOP44 [(SA638-B006)]		MBM29F800B@TSOP48 [(SA247-B005)]
MBM29F800BA@PSOP44 [(SA638-B006)]		
MBM29F800BA@TSOP48 [(SA247-B005)]		
MBM29F800BB@PSOP44 [(SA638-B006)]		
MBM29F800BB@TSOP48 [(SA247-B005)]		
MBM29F800BT@PSOP44 [(SA638-B006)]		
MBM29F800BT@TSOP48 [(SA247-B005)]		
MBM29F800T@PSOP44 [(SA638-B006)]		MBM29F800T@TSOP48 [(SA247-B005)]
MBM29F800TA@PSOP44 [(SA638-B006)]		
MBM29F800TA@TSOP48 [(SA247-B005)]		
MBM29LL800B@TSOP48 [(SA247-B005)]		
MBM29LL800BB@TSOP48 [(SA247-B005)]		
MBM29LL800BT@TSOP48 [(SA247-B005)]		
MBM29LL800T@TSOP48 [(SA247-B005)]		
MBM29LV001B@PLCC32 [(SA015A1T)]		MBM29LV001BB@PLCC32 [(SA015A1T)]
MBM29LV001BB@TSOP32 [(SA410T)]		MBM29LV001BC@PLCC32 [(SA015A1T)]
MBM29LV001BC@TSOP32 [(SA410T)]		MBM29LV001BT@PLCC32 [(SA015A1T)]
MBM29LV001BT@TSOP32 [(SA410T)]		MBM29LV001T@TSOP32 [(SA410T)]

MBM29LV001TC@PLCC32 [(SA015A1T)]	MBM29LV001TC@TSOP32 [(SA410T)]
MBM29LV002B@TSOP40 [(SA409T)]	MBM29LV002T@TSOP40 [(SA409T)]
MBM29LV004B@PSOP44 [(SA638)]	MBM29LV004B@TSOP40 [(SA409T)]
MBM29LV004BB@TSOP40 [(SA409T)]	MBM29LV004BT@TSOP40 [(SA409T)]
MBM29LV004T@PSOP44 [(SA638)]	MBM29LV004T@TSOP40 [(SA409T)]
MBM29LV008B@PSOP44 [(SA638)]	MBM29LV008B@TSOP40 [(SA409T)]
MBM29LV008BB@TSOP40 [(SA409T)]	MBM29LV008BT@TSOP40 [(SA409T)]
MBM29LV008T@PSOP44 [(SA638)]	MBM29LV008T@TSOP40 [(SA409T)]
MBM29LV016/B@TSOP40 [(SA409T)]	MBM29LV016/T@TSOP40 [(SA409T)]
MBM29LV016B@TSOP40 [(SA409T)]	MBM29LV017B@TSOP40 [(SA409T)]
MBM29LV017E@TSOP40 [(SA409T)]	MBM29LV033C@TSOP40 [(SA409T)]
MBM29LV080T@TSOP40 [(SA409T)]	MBM29LV081@TSOP40 [(SA409T)]
MBM29LV081B@TSOP40 [(SA409T)]	MBM29LV116B@TSOP40 [(SA409T)]
MBM29LV200B@PSOP44 [(SA638-B006)]	
MBM29LV200B@TSOP48 [(SA247-B005)]	
MBM29LV200BB@PSOP44 [(SA638-B006)]	
MBM29LV200BB@TSOP48 [(SA247-B005)]	
MBM29LV200BC@PSOP44 [(SA638)]	
MBM29LV200BC@TSOP48 [(SA247-B005)]	
MBM29LV200BT@PSOP44 [(SA638-B006)]	
MBM29LV200BT@TSOP48 [(SA247-B005)]	
MBM29LV200T@PSOP44 [(SA638-B006)]	
MBM29LV200T@TSOP48 [(SA247-B005)]	
MBM29LV200TC@PSOP44 [(SA638)]	
MBM29LV200TC@TSOP48 [(SA247-B005)]	
MBM29LV400B@PSOP44 [(SA638-B006)]	
MBM29LV400B@TSOP48 [(SA247-B005)]	
MBM29LV400BB@PSOP44 [(SA638-B006)]	
MBM29LV400BB@TSOP48 [(SA247-B005)]	
MBM29LV400BT@PSOP44 [(SA638-B006)]	
MBM29LV400BT@TSOP48 [(SA247-B005)]	
MBM29LV400T@PSOP44 [(SA638-B006)]	
MBM29LV400T@TSOP48 [(SA247-B005)]	
MBM29LV800B@PSOP44 [(SA638-B006)]	
MBM29LV800B@SON46 [(SA631)]	
MBM29LV800B@TSOP48 [(SA247-B005)]	
MBM29LV800BB@PSOP44 [(SA638-B006)]	
MBM29LV800BB@TSOP48 [(SA247-B005)]	
MBM29LV800BT@PSOP44 [(SA638-B006)]	
MBM29LV800BT@TSOP48 [(SA247-B005)]	
MBM29LV800T@PSOP44 [(SA638-B006)]	
MBM29LV800T@SON46 [(SA631)]	
MBM29LV800T@TSOP48 [(SA247-B005)]	

DRAM & SRAM

MB81C78A	MB81C78A@SOIC28 [(SA630)]
----------	---------------------------

GENCORE

MICROCONTROLLER

GC87C520A0	GC87C520A0@PLCC44 [(SA244)]
GC87C520A0@TQFP44 [(SA245A)]	GC87C520G0
GC87C520G0@PLCC44 [(SA244)]	GC87C520G0@TQFP44 [(SA245A)]

GENERAL(GI)

E(E) PROM/FRAM/NVRAM

27256	27C128
27C128@PLCC32 [(SA015A1T)]	27C256
27C256@PLCC32 [(SA015A1T)]	27C512
27C513	27C64
27C64@PLCC32 [(SA015A1T)]	27HC191
27HC291	27HC64
27HC641	27HC641L
27HC64L	28C04
28C04A	28C04F
28C16	28C16A
28C16F	28C17
28C17F	ER5911
ER5911@SOIC8 [(SA602A)]	GI5911

GI5911@SOIC8 [(SA602A)]
 GI59C11@SOIC8 [(SA602A)]
 GI59C12@SOIC8 [(SA602A)]

GI59C11
 GI59C12
 GR27C513

GENERIC

E(E) PROM/FRAM/NVRAM

27128(21V)	27128A(12.5V)
2716(25V)	27256(12.5V)
2732(25V)	2732A(21V)
2732B(12.5V)	27512(12.5V)
27512(21V)	2764(21V)
2764A(12.5V)	27C128(12.5V)
27C128(21V)	27C16(25V)
27C256(12.5V)	27C32(25V)
27C512(12.5V)	27C64(12.5V)
27C64(21V)	

GIGADEVICE

E(E) PROM/FRAM/NVRAM

GD25D40	GD25D40(ISP) [ISP-HEADER01]
GD25D40@SOP8 [(SA605A)]	GD25D40@SOP8(ISP) [ISP-HEADER01]
GD25D80	GD25D80(ISP) [ISP-HEADER01]
GD25D80@SOP8 [(SA605A)]	GD25D80@SOP8(ISP) [ISP-HEADER01]
GD25F40	GD25F40(ISP) [ISP-HEADER01]
GD25F40@SOP8 [(SA605A)]	GD25F40@SOP8(ISP) [ISP-HEADER01]
GD25F80	GD25F80(ISP) [ISP-HEADER01]
GD25F80@SOP8 [(SA605A)]	GD25F80@SOP8(ISP) [ISP-HEADER01]
GD25Q16	GD25Q16@SOP8 [(SA023A)]
GD25Q80	GD25Q80@SOP8 [(SA023A)]
GD25T80	GD25T80(ISP) [ISP-HEADER01]
GD25T80@SOP8 [(SA605A)]	GD25T80@SOP8(ISP) [ISP-HEADER01]

GOAL

MICROCONTROLLER

VRS1000	VRS1000@PLCC44 [(SA244)]
VRS1000@TQFP44 [(SA245A)]	VRS1050
VRS1050@PLCC44 [(SA244)]	VRS1050@TQFP44 [(SA675)]
VRS1100	VRS1100@PLCC44 [(SA244)]
VRS1100@TQFP44 [(SA245A)]	VRS540
VRS540@PLCC44 [(SA244)]	VRS540@TQFP44 [(SA245A)]
VRS550	VRS550@PLCC44 [(SA244)]
VRS550@TQFP44 [(SA245A)]	VRS560
VRS560@PLCC44 [(SA244)]	VRS560@TQFP44 [(SA245A)]
VRS570	VRS570@PLCC44 [(SA244)]
VRS570@TQFP44 [(SA245A)]	VRS580
VRS580@PLCC44 [(SA244)]	VRS580@TQFP44 [(SA245A)]
VRS700	VRS700@PLCC44 [(SA244)]
VRS700@TQFP44 [(SA245A)]	VRS900
VRS900@PLCC44 [(SA244)]	VRS900@TQFP44 [(SA245A)]

GREENWICH

E(E) PROM/FRAM/NVRAM

GR27128	GR27256
GR27512	GR2764

HAIER

MICROCONTROLLER

HCM87CP311SP@SDIP42 [(SA028)]	HR6P59P2DL
HR6P59P2SL@SOP14 [(SA602)]	HR6P60P2DL
HR6P60P2DL-A	HR6P60P2EL
HR6P60P2EL-A	HR6P60P2SL@SOP20 [(SA404)]
HR6P60P2SL@SSOP20 [(SA626A)]	HR6P60P2SL-A@SOP20 [(SA404)]
HR6P60P2SL-A@SSOP20 [(SA626A)]	HR6P60P2XL@SOP18 [(SA404)]
HR6P60P2XL-A@SOP18 [(SA404)]	HR6P60P2YL@SOP14 [(SA404)]
HR6P60P2YL-A@SOP14 [(SA404)]	HR6P62P4D
HR6P62P4DH	HR6P62P4DHL
HR6P62P4DHL(INTOSC)	HR6P62P4DHL-D
HR6P62P4DHL-D(INTOSC)	
HR6P62P4NHL(INTOSC)@SSOP20 [(SA626A)]	
HR6P62P4NHL@SSOP20 [(SA626A)]	
HR6P62P4NHL-D(INTOSC)@SSOP20 [(SA626A)]	
HR6P62P4NHL-D@SSOP20 [(SA626A)]	
HR6P62P4RHL(INTOSC)@SSOP20 [(SA626A)]	
HR6P62P4RHL@SSOP20 [(SA626A)]	
HR6P62P4RHL-D(INTOSC)@SSOP20 [(SA626A)]	
HR6P62P4RHL-D@SSOP20 [(SA626A)]	HR6P62P4SH@SOP20 [(SA404+B003)]
HR6P62P4SHL(INTOSC)@SOP20 [(SA404)]	
HR6P62P4SHL@SOP20 [(SA404)]	
HR6P62P4SHL-D(INTOSC)@SOP20 [(SA404)]	
HR6P62P4SHL-D@SOP20 [(SA404)]	
HR6P62P4XHL(INTOSC)@SOP18 [(SA404)]	
HR6P62P4XHL@SOP18 [(SA404)]	
HR6P62P4XHL-D(INTOSC)@SOP18 [(SA404)]	
HR6P62P4XHL-D@SOP18 [(SA404)]	HR6P62P4YHL@SOIC14 [(SA602)]
HR6P62P4YHL-D@SOP14 [(SA602)]	HR6P67P4D
HR6P67P4DL	HR6P67P4DL-B
HR6P67P4SL@SOP14 [(SA404+B003)]	
HR6P67P4SL-B@SOP14 [(SA404+B003)]	
HR6P71F8D	HR6P71F8D(REVERSE)
HR6P71F8S(REVERSE)@SOP20 [(SA404)]	
HR6P71F8S@SOP20 [(SA404)]	HR6P72P4D
HR6P72P4DL	HR6P72P4S@SOP28 [(SA404)]
HR6P72P4SL@SOP28 [(SA404+B003)]	HR6P73P8DB
HR6P73P8DBL	HR6P73P8SB@SOP28 [(SA404)]
HR6P73P8SBL@SOP28 [(SA404-B003)]	HR6P73PGD
HR6P73PGDH	HR6P73PGDHL
HR6P73PGS@SOP28 [(SA404+B003)]	HR6P73PGSH@SOP28 [(SA404)]
HR6P73PGSHL@SOP28 [(SA404-B003)]	HR6P76PGD
HR6P76PGDL	HR6P76PGS@SOP28 [(SA404)]
HR6P76PGSL@SOP28 [(SA404-B003)]	HR6P77PGD
HR6P77PGDL	HR6P77PGL@LQFP44 [(SA245-B005)]
HR6P77PGL@LQFP44 [(SA245-B005)]	HR6P78P4SL@SOP32 [(SA715+B006)]
HR6P90FGD	HR6P90FGS@SOP28 [(SA404)]
HR6P90FHD	HR6P90FHS@SOP28 [(SA404)]
HR6P91FGS@SOP32 [(SA715)]	HR6P91FHS@SOP32 [(SA715)]
HR6P92FGD	HR6P92FGL@LQFP44 [(SA245A)]
HR6P92FHD	HR6P92FHL@LQFP44 [(SA245A)]
HR6P95F8D	HR6P95F8S@SOP28 [(SA404)]
HR6P97FGD	HR6P97FGD(EEPROM)
HR6P97FGD(EEPROM)(ISP) [ISP-HEADER01]	
HR6P97FGD(ISP) [ISP-HEADER01]	
HR6P97FGS(EEPROM)@SOP28 [(SA404)]	
HR6P97FGS(EEPROM)@SOP28(ISP) [ISP-HEADER01]	
HR6P97FGS@SOP28 [(SA404)]	
HR6P97FGS@SOP28(ISP) [ISP-HEADER01]	
HR6P98FGD	HR6P98FGD(EEPROM)
HR6P98FGD(EEPROM)(ISP) [ISP-HEADER01]	
HR6P98FGD(ISP) [ISP-HEADER01]	
HR6P98FGL(EEPROM)@LQFP44 [(SA245A)]	
HR6P98FGL(EEPROM)@LQFP44(ISP) [ISP-HEADER01]	
HR6P98FGL@LQFP44 [(SA245A)]	
HR6P98FGL@LQFP44(ISP) [ISP-HEADER01]	
HR7T46P8V@SDIP42 [(SA028)]	HR7T46PGV@SDIP42 [(SA028+B005)]
HR7T47P8L@LQFP44 [(SA245A)]	HR7T47PGL@LQFP44 [(SA245A+B005)]

HARRIS

DRAM & SRAM

HM6516	HM6516@PLCC32 [(SA015A1T)]
HM65162	HM65162@PLCC32 [(SA015A1T)]
HM65642	HM65642@TSOP28 [(SA643)]

HITACHI**E (E) PROM/FRAM/NVRAM**

HN27128AG	HN27128AP
HN27256G	HN27256P
HN27512G	HN27512P
HN27C101AG	HN27C101AP
HN27C101G	HN27C101P
HN27C1024HG	HN27C1024HG@PLCC44 [(SA244)]
HN27C256AG	HN27C256FP
HN27C256G	HN27C256HG
HN27C301AG	HN27C301AP
HN27C301G	HN27C301P
HN27C4000FP	HN27C4000G
HN27C4001	HN27C4001@TSOP32 [(SA410T)]
HN27C4001G	HN27C4096A
HN27C4096A@PLCC44 [(SA244)]	HN27C4096FP
HN27C4096FP@PLCC44 [(SA244)]	HN27C4096G
HN27C4096G@PLCC44 [(SA244)]	HN27C512G
HN27C512G@PLCC32 [(SA015A1T)]	HN27C64G
HN28F101	HN28F101@PLCC32 [(SA015A1T)]
HN28F101@SOP32 [(SA438T)]	HN28F101@TSOP32 [(SA410T)]
HN462716G	HN462732G
HN48016	HN48016P
HN4827128G	HN4827128P
HN482732AG	HN482764G
HN482764P	HN58064(FP)@SOIC28 [(SA404)]
HN58064(P)	HN58C1001(FP)@SSOP32 [(SA438T)]
HN58C1001(P)	HN58C1001(T)@VSOP32 [(SA620)]
HN58C256A(FP)@SOP28 [(SA630)]	HN58C256A(P)
HN58C256A(T)@TSOP28 [(SA643)]	HN58C257A(T)@TSOP32 [(SA620)]
HN58C65(FP)@SOIC28 [(SA404)]	HN58C65(P)
HN58C66	HN58C66@SOP28 [(SA630)]
HN58C66@TSOP28 [(SA430T)]	HN58V24256
HN58V24256@SOIC8 [(SA602A)]	HN58V24256@TSSOP14 [(SA026)]
HN58V24512	HN58V24512@SOIC8 [(SA602A)]
HN58V256A	HN58V256A@TSOP28 [(SA430T)]
HN58V65A	HN58V65A@SOIC28 [(SA630)]
HN58V65A@TSOP28 [(SA430T)]	HN58V66A
HN58V66A@SOIC28 [(SA630)]	HN58V66A@TSOP28 [(SA430T)]
HN58W241000	HN58W241000@SOIC8 [(SA602A)]
HN58X2402	HN58X2402@SOIC8 [(SA602A)]
HN58X2402@TSSOP8 [(SA026)]	HN58X2404
HN58X2404@SOIC8 [(SA602A)]	HN58X2404@TSSOP8 [(SA026)]
HN58X2408	HN58X2408@SOIC8 [(SA602A)]
HN58X2408@TSSOP8 [(SA026)]	HN58X24128
HN58X24128@SOIC8 [(SA602A)]	HN58X2416
HN58X2416@SOIC8 [(SA602A)]	HN58X2416@TSSOP8 [(SA026)]
HN58X24256	HN58X24256@SOIC8 [(SA602A)]
HN58X2432	HN58X2432@SOIC8 [(SA602A)]
HN58X2432@TSSOP8 [(SA026)]	HN58X24512
HN58X24512@SOIC8 [(SA602A)]	HN58X2464
HN58X2464@SOIC8 [(SA602A)]	HN58X2464@TSSOP8 [(SA026)]
HN58X2502@SOIC8 [(SA602A)]	HN58X2502@TSSOP8 [(SA026)]
HN58X2504@SOIC8 [(SA602A)]	HN58X2504@TSSOP8 [(SA026)]
HN58X25128@SOIC8 [(SA602A)]	HN58X25128@TSSOP14 [(SA026)]
HN58X25256@SOIC8 [(SA602A)]	HN58X25256@TSSOP14 [(SA026)]
HN58X2532@SOIC8 [(SA602A)]	HN58X2532@TSSOP8 [(SA026)]
HN58X2564@SOIC8 [(SA602A)]	HN58X2564@TSSOP8 [(SA026)]
HT29VB800@TSOP48 [(SA247-B005)]	HT29VT800@TSOP48 [(SA247-B005)]
HT29WB800@TSOP48 [(SA247-B005)]	HT29WT800@TSOP48 [(SA247-B005)]

DRAM & SRAM

HM6116	HM6116@PLCC32 [(SA015A1T)]
HM6116A	HM6116A@PLCC32 [(SA015A1T)]
HM6208	HM6208@SOJ24 [(SA646)]
HM6208H	HM6208H@SOJ24 [(SA646)]
HM62256	HM62256@TSOP28 [(SA643)]
HM62256B	HM62256B@TSOP28 [(SA643)]
HM624256	HM624256@SOJ28 [(SA646)]
HM6264A	HM6264A@TSOP28 [(SA643)]
HM6267	HM6268
HM628128	HM628128@TSOP32 [(SA410T)]

HM628128A	HM628128A@TSOP32 [(SA410T)]
HM62832	HM62832@TSOP28 [(SA643)]
HM62832H	HM62832H@TSOP28 [(SA643)]
HM628512	HM628512@TSOP32 [(SA729)]
HM6287	HM6287HP
HM6288	HM6288@SOJ22 [(SA646)]
HM65256B	HM65256B@TSOP28 [(SA643)]
HM658128	HM658128@TSOP32 [(SA410T)]
HM66204	HM66204@TSOP32 [(SA410T)]
HM6707	HM6707@SOJ24 [(SA646)]
HM6707A	HM6707A@SOJ24 [(SA646)]
HM6708	HM6708@SOJ24 [(SA646)]
HM6708A	HM6708A@SOJ24 [(SA646)]
HM6716	HM6716@PLCC32 [(SA015A1T)]
HM6787	HM6787HP
HM6788	HM6788@SOJ22 [(SA646)]
HM6788H	HM6788H@SOJ22 [(SA646)]
HM6788HA	HM6788HA@SOJ22 [(SA646)]

MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)]	HD4074344@SOIC28 [(SA404)]
HD4074394@SDIP28 [(SA022A)]	HD4074394@SOIC28 [(SA404)]

HOLTEK**E(E) PROM/FRAM/NVRAM**

HT24C01	HT24C01@SOIC8 [(SA602A)]
HT24C02	HT24C02@SOIC8 [(SA602A)]
HT24C04	HT24C04@SOIC8 [(SA602A)]
HT24C08	HT24C16
HT24LC01	HT24LC01@SOIC8 [(SA602A)]
HT24LC01@TSSOP8 [(SA026)]	HT24LC02
HT24LC02@SOIC8 [(SA602A)]	HT24LC02@TSSOP8 [(SA026)]
HT24LC04	HT24LC04@SOIC8 [(SA602A)]
HT24LC08	HT24LC08@SOIC8 [(SA602A)]
HT24LC16	HT24LC16@SOIC8 [(SA602A)]
HT24LC32	HT24LC32@SOIC8 [(SA602A)]
HT24LC64	HT24LC64@SOIC8 [(SA602A)]
HT25LC512@SOIC8 [(SA602A)]	HT27C010
HT27C010@PLCC32 [(SA015A1T)]	HT27C010@TSOP32 [(SA410T)]
HT27C020	HT27C020@PLCC32 [(SA015A1T)]
HT27C020@TSOP32 [(SA410T)]	HT27C040
HT27C040@PLCC32 [(SA015A1T)]	HT27C040@TSOP32 [(SA410T)]
HT27C4096	HT27C4096@PLCC44 [(SA244)]
HT27C512	HT27C512@PLCC32 [(SA015A1T)]
HT27C512@TSOP28 [(SA430T)]	HT27LC010
HT27LC010@PLCC32 [(SA015A1T)]	HT27LC010@TSOP32 [(SA410T)]
HT27LC020	HT27LC020@PLCC32 [(SA015A1T)]
HT27LC020@TSOP32 [(SA410T)]	HT27LC040
HT27LC040@PLCC32 [(SA015A1T)]	HT27LC040@TSOP32 [(SA410T)]
HT27LC4096	HT27LC4096@PLCC44 [(SA244)]
HT27LC512	HT27LC512@PLCC32 [(SA015A1T)]
HT27LC512@TSOP28 [(SA430T)]	HT93C46(16bit)
HT93C46(16bit)@SOP8-A [(SA602A)]	HT93C46(16bit)@SOP8-B [(SA602A)]
HT93C46(16bit)@TSSOP8 [(SA026)]	HT93C56(16bit)
HT93C56(16bit)@SOP8-A [(SA602A)]	HT93C56(16bit)@SOP8-B [(SA602A)]
HT93C56(16bit)@TSSOP8 [(SA026)]	HT93C66(16bit)
HT93C66(16bit)@SOP8-A [(SA602A)]	HT93C66(16bit)@SOP8-B [(SA602A)]
HT93C66(16bit)@TSSOP8 [(SA026)]	HT93LC46A(08bit)
HT93LC46A(08bit)@SOP8-A [(SA602A)]	
HT93LC46A(08bit)@SOP8-B [(SA602A)]	
HT93LC46A(08bit)@TSSOP8 [(SA026)]	
HT93LC46A(16bit)	
HT93LC46A(16bit)@SOP8-A [(SA602A)]	
HT93LC46A(16bit)@SOP8-B [(SA602A)]	
HT93LC46A(16bit)@TSSOP8 [(SA026)]	
HT93LC46B(08bit)	
HT93LC46B(08bit)@SOP8-A [(SA602A)]	
HT93LC46B(08bit)@SOP8-B [(SA602A)]	
HT93LC46B(08bit)@TSSOP8 [(SA026)]	
HT93LC46B(16bit)	
HT93LC46B(16bit)@SOP8-A [(SA602A)]	
HT93LC46B(16bit)@SOP8-B [(SA602A)]	
HT93LC46B(16bit)@TSSOP8 [(SA026)]	

```

HT93LC56A (08bit)
HT93LC56A (08bit)@SOP8-A [(SA602A)]
HT93LC56A (08bit)@SOP8-B [(SA602A)]
HT93LC56A (08bit)@TSSOP8 [(SA026)]
HT93LC56A (16bit)
HT93LC56A (16bit)@SOP8-A [(SA602A)]
HT93LC56A (16bit)@SOP8-B [(SA602A)]
HT93LC56A (16bit)@TSSOP8 [(SA026)]
HT93LC56B (08bit)
HT93LC56B (08bit)@SOP8-A [(SA602A)]
HT93LC56B (08bit)@SOP8-B [(SA026)]
HT93LC56B (08bit)@TSSOP8 [(SA026)]
HT93LC56B (16bit)
HT93LC56B (16bit)@SOP8-A [(SA602A)]
HT93LC56B (16bit)@SOP8-B [(SA602A)]
HT93LC56B (16bit)@TSSOP8 [(SA026)]
HT93LC66A (08bit)
HT93LC66A (08bit)@SOP8-A [(SA602A)]
HT93LC66A (08bit)@SOP8-B [(SA602A)]
HT93LC66A (08bit)@TSSOP8 [(SA026)]
HT93LC66A (16bit)
HT93LC66A (16bit)@SOP8-A [(SA602A)]
HT93LC66A (16bit)@SOP8-B [(SA602A)]
HT93LC66A (16bit)@TSSOP8 [(SA026)]
HT93LC66B (08bit)
HT93LC66B (08bit)@SOP8-A [(SA602A)]
HT93LC66B (08bit)@SOP8-B [(SA026)]
HT93LC66B (08bit)@TSSOP8 [(SA026)]
HT93LC66B (16bit)
HT93LC66B (16bit)@SOP8-A [(SA602A)]
HT93LC66B (16bit)@SOP8-B [(SA602A)]
HT93LC66B (16bit)@TSSOP8 [(SA026)]
HT93LC76 (08bit)
HT93LC76 (08bit)@SOP8-A [(SA602A)]
HT93LC76 (08bit)@SOP8-B [(SA602A)]
HT93LC76 (08bit)@TSSOP8 [(SA026)]
HT93LC76 (16bit)@SOP8-A [(SA602A)]
HT93LC76 (16bit)@SOP8-B [(SA602A)]
HT93LC76 (16bit)@TSSOP8 [(SA026)]
HT93LC86 (08bit)@SOP8-A [(SA602A)]
HT93LC86 (08bit)@SOP8-B [(SA602A)]
HT93LC86 (08bit)@TSSOP8 [(SA026)]
HT93LC86 (16bit)@SOP8-A [(SA602A)]
HT93LC86 (16bit)@SOP8-B [(SA602A)]
HT93LC86 (16bit)@TSSOP8 [(SA026)]

```

HT93LC76 (16bit)

HT93LC86 (08bit)

HT93LC86 (16bit)

MICROCONTROLLER

```

HT46R22
HT46R23 (dip24)
HT46R23@SOP24 [(SA404)]
HT46R24
HT46R24@SSOP48 [(SA669)]
HT46R46 (dip20)
HT46R46@SOP20 [(SA404)]
HT46R46E@SOP18 [(SA404)]
HT46R46-H@SOP18 [(SA404)]
HT46R47 (dip20)
HT46R47@SOP20 [(SA404)]
HT46R47E (dip18)
HT46R47-H
HT46R48 (dip20)
HT46R48@SOP20 [(SA404)]
HT46R48@SSOP24 [(SA674)]
HT46R48E@SOP24 [(SA404)]
HT46R51A (dip18)
HT46R51A@SSOP20 [(SA674)]
HT46R52A@SOP20 [(SA404)]
HT46R53A (dip28)
HT46R54A (dip28)
HT46R65@PQFP100 [(PEP+S427)]
HT46R71D@SSOP48 [(SA669)]
HT46RB70@SOP28 [(SA404)]
HT46RU22 (dip24)
HT46RU22@SSOP24 [(SA674)]
HT48R05A
HT48R05A@SOP18 [(SA404)]
HT48R06A@SOP16 [(SA026)]
HT48R07A
HT46R22@SOP24 [(SA404)]
HT46R23 (dip28)
HT46R23@SOP28 [(SA404)]
HT46R24@SOP28 [(SA404)]
HT46R46 (dip18)
HT46R46@SOP18 [(SA404)]
HT46R46E (dip18)
HT46R46-H
HT46R47 (dip18)
HT46R47@SOP18 [(SA404)]
HT46R47@SSOP20 [(SA674)]
HT46R47E@SOP18 [(SA404)]
HT46R47-H@SOP18 [(SA404)]
HT46R48 (dip24)
HT46R48@SOP24 [(SA404)]
HT46R48E (dip24)
HT46R48E@SSOP24 [(SA674)]
HT46R51A@SOP20 [(SA404)]
HT46R52A (dip18)
HT46R52A@SSOP20 [(SA674)]
HT46R53A@SOP28 [(SA404)]
HT46R54A@SOP28 [(SA404)]
HT46R65@SSOP56 [(SA669)]
HT46RB70
HT46RB70@SSOP48 [(SA669)]
HT46RU22@SOP24 [(SA404)]
HT47R10A@QFP44 [(SA245)]
HT48R05A@SOP16 [(SA026)]
HT48R06A
HT48R06A@SOP18 [(SA404)]
HT48R07A@SOP24 [(SA404)]

```

HT48R07A@SSOP24 [(SA674)]	HT48R08A
HT48R08A@SOP16 [(SA026)]	HT48R08A@SOP18 [(SA404)]
HT48R09A	HT48R09A@SOP24 [(SA404)]
HT48R09A@SSOP24 [(SA674)]	HT48R10A
HT48R10A@SOP24 [(SA404)]	HT48R30A(dip24)
HT48R30A(dip28)	HT48R30A@SOP24 [(SA404)]
HT48R30A@SOP28 [(SA404)]	HT48R50A
HT48R50A@SOP28 [(SA404)]	HT48R52A@QFP44 [(SA245A)]
HT48RA0-1	HT48RA0-1@SOP24 [(SA404)]
HT48RA0-2	HT48RA0-2@SOP20 [(SA404)]
HT48RA0-2@SSOP20 [(SA674)]	HT48RA0-3
HT48RA0-3@SOP20 [(SA404)]	HT48RA1@SOP28 [(SA404)]
HT48RA1@SSOP28 [(SA626A)]	HT48RA3(dip28)
HT48RA3@SOP28 [(SA404)]	HT48RA3@SSOP28 [(SA626A)]
HT48RA5(dip28)	HT48RA5@SOP28 [(SA404)]
HT48RA5@SSOP28 [(SA626A)]	HT48RB50
HT48RB50@SOP28 [(SA404)]	HT48RB8@SOP28 [(SA404)]
HT49R30A@SSOP48 [(SA669)]	HT82A821R@SOP24 [(SA404)]
HT82A821R@SSOP24 [(SA674)]	HT82A822R@SSOP48 [(SA669)]
HT82A832R@QFP48 [(SA248)]	HT82A832R@SSOP48 [(SA669)]
HT82K68E	HT82K68E@SOP20 [(SA404)]
HT82K68E@SOP28 [(SA404)]	HT82K95E@SOP20 [(SA404)]
HT82K95E@SOP28 [(SA404)]	HT82K96E(dip20)
HT82K96E(dip40)	HT82K96E@SOP20 [(SA404)]
HT82K96E@SOP28 [(SA404)]	HT82M99E(dip18)
HT82M99E(dip20)	HT82M99E@SOP18 [(SA404)]
HT82M99E@SOP20 [(SA404)]	HT82M9AE@SOP20 [(SA404)]
HT82M9AE@SOP24 [(SA404)]	HT82M9AE@SSOP20 [(SA674)]
HT82M9AE@SSOP24 [(SA674)]	HT82M9BE@SOP24 [(SA404)]
HT82M9BE@SOP28 [(SA404)]	HT82M9BE@SSOP24 [(SA674)]
HT82M9BE@SSOP28 [(SA626A)]	

HONGKONG

E(E) PROM/FRAM/NVRAM

HK1215	HK1225
HK1235	HK1245
HK1255	HK1265
HK1275	HK1285
HK1295	HK12A5
HK12B5	OKS1225
OKS1235	OKS1245
OKS1255	OKS1265
OKS1275	OKS1285
OKS1295	OKS12A5
OKS12B5	

HYNIX

E(E) PROM/FRAM/NVRAM

HY2764	HY27C64A
HY29F002T	HY29F002T@PLCC32 [(SA015A1T)]
HY29F002T@TSOP32 [(SA410T)]	HY29F040
HY29F040@PLCC32 [(SA015A1T)]	HY29F040@TSOP32 [(SA410T)]
HY29F040A	HY29F040A@PLCC32 [(SA015A1T)]
HY29F040A@TSOP32 [(SA410T)]	HY29F080@TSOP40 [(SA409T)]
HY29F200B@PSOP44 [(SA638-B006)]	HY29F200B@TSOP48 [(SA247-B005)]
HY29F200T@PSOP44 [(SA638-B006)]	HY29F200T@TSOP48 [(SA247-B005)]
HY29F400ABG@PSOP44 [(SA638)]	
HY29F400ABT@TSOP48 [(SA247-B005)]	
HY29F400ATG@PSOP44 [(SA638)]	
HY29F400ATT@TSOP48 [(SA247-B005)]	
HY29F400BG@PSOP44 [(SA638)]	HY29F400BT@TSOP48 [(SA247-B005)]
HY29F400TG@PSOP44 [(SA638)]	HY29F400TT@TSOP48 [(SA247-B005)]
HY29F800ABG@PSOP44 [(SA638)]	
HY29F800ABT@TSOP48 [(SA247-B005)]	
HY29F800ATG@PSOP44 [(SA638)]	
HY29F800ATT@TSOP48 [(SA247-B005)]	
HY29F800BG@PSOP44 [(SA638)]	HY29F800BT@TSOP48 [(SA247-B005)]
HY29F800TG@PSOP44 [(SA638)]	HY29F800TT@TSOP48 [(SA247-B005)]
HY93C46	HY93C46@SOIC8 [(SA602A)]
HY93C56	HY93C56@SOIC8 [(SA602A)]

HY93C66	HY93C66@SOIC8 [(SA602A)]
HY93C76	HY93C76@SOIC8 [(SA602A)]
HY93C86	HY93C86@SOIC8 [(SA602A)]

DRAM & SRAM

HY62256A	HY62256A@TSOP28 [(SA643)]
HY6264A	HY6264A@TSOP28 [(SA643)]
HY628100A	HY628100A@SOP32 [(SA438T)]
HY628100A@TSOP32 [(SA410T)]	HY628100B
HY628100B@SOP32 [(SA438T)]	HY628100B@TSOP32 [(SA410T)]
HY628400	HY628400@SOP32 [(SA438T)]
HY628400@TSOP32 [(SA410T)]	HY628400A
HY628400A@SOP32 [(SA438T)]	HY628400A@TSOP32 [(SA410T)]
HY62CT08081E	HY62CT08081E@SOP28 [(SA438T)]
HY62CT08081E@TSOP28 [(SA643)]	HY62KT08081E
HY62KT08081E@SOP28 [(SA438T)]	HY62KT08081E@TSOP28 [(SA643)]
HY62U8100B	HY62U8100B@SOP32 [(SA438T)]
HY62U8100B@TSOP32 [(SA410T)]	HY62U8200B
HY62U8200B@SOP32 [(SA438T)]	HY62U8200B@TSOP32 [(SA410T)]
HY62U8400A	HY62U8400A@SOP32 [(SA438T)]
HY62U8400A@TSOP32 [(SA410T)]	HY62UT08081E
HY62UT08081E@SOP28 [(SA438T)]	HY62UT08081E@TSOP28 [(SA643)]
HY62V8100B	HY62V8100B@SOP32 [(SA438T)]
HY62V8100B@TSOP32 [(SA410T)]	HY62V8200B
HY62V8200B@SOP32 [(SA438T)]	HY62V8200B@TSOP32 [(SA410T)]
HY62V8400A	HY62V8400A@SOP32 [(SA438T)]
HY62V8400A@TSOP32 [(SA410T)]	HY62VT08081E
HY62VT08081E@SOP28 [(SA438T)]	HY62VT08081E@TSOP28 [(SA643)]
HY62WT08081E	HY62WT08081E@SOP28 [(SA438T)]
HY62WT08081E@TSOP28 [(SA643)]	

MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20 [(SA404)]
GMS97C2051	GMS97C2051@SOIC20 [(SA404)]
GMS97C51	GMS97C51@PLCC44 [(SA244)]
GMS97C51@TQFP44 [(SA245A)]	GMS97C52
GMS97C52@PLCC44 [(SA244)]	GMS97C52@TQFP44 [(SA245A)]
GMS97C54	GMS97C54@PLCC44 [(SA244)]
GMS97C54@TQFP44 [(SA245A)]	GMS97C56
GMS97C56@PLCC44 [(SA244)]	GMS97C56@TQFP44 [(SA245A)]
GMS97C58	GMS97C58@PLCC44 [(SA244)]
GMS97C58@TQFP44 [(SA245A)]	GMS97L1051
GMS97L1051@SOIC20 [(SA404)]	GMS97L2051
GMS97L2051@SOIC20 [(SA404)]	GMS97L51
GMS97L51@PLCC44 [(SA244)]	GMS97L51@TQFP44 [(SA245A)]
GMS97L52	GMS97L52@PLCC44 [(SA244)]
GMS97L52@TQFP44 [(SA245A)]	GMS97L54
GMS97L54@PLCC44 [(SA244)]	GMS97L54@TQFP44 [(SA245A)]
GMS97L56	GMS97L56@PLCC44 [(SA244)]
GMS97L56@TQFP44 [(SA245A)]	GMS97L58
GMS97L58@PLCC44 [(SA244)]	GMS97L58@TQFP44 [(SA245A)]
GMS99C52	GMS99C52@PLCC44 [(SA244)]
GMS99C52@TQFP44 [(SA245A)]	GMS99C58
GMS99C58@PLCC44 [(SA244)]	GMS99C58@TQFP44 [(SA245A)]
HMS99C52	HMS99C52@PLCC44 [(SA244)]
HMS99C52@TQFP44 [(SA245A)]	HMS99C58
HMS99C58@PLCC44 [(SA244)]	HMS99C58@TQFP44 [(SA245A)]

HYUNDAI**E(E) PROM/FRAM/NVRAM**

HY2764	HY27C64A
HY29F002T	HY29F002T@PLCC32 [(SA015A1T)]
HY29F002T@TSOP32 [(SA410T)]	HY29F040
HY29F040@PLCC32 [(SA015A1T)]	HY29F040@TSOP32 [(SA410T)]
HY29F040A	HY29F040A@PLCC32 [(SA015A1T)]
HY29F040A@TSOP32 [(SA410T)]	HY29F080@TSOP40 [(SA409T)]
HY29F200B@PSOP44 [(SA638-B006)]	HY29F200B@TSOP48 [(SA247-B005)]
HY29F200T@PSOP44 [(SA638-B006)]	HY29F200T@TSOP48 [(SA247-B005)]
HY29F400ABG@PSOP44 [(SA638)]	
HY29F400ABT@TSOP48 [(SA247-B005)]	
HY29F400ATG@PSOP44 [(SA638)]	

HY29F400ATT@TSOP48 [(SA247-B005)]	
HY29F400BG@PSOP44 [(SA638)]	HY29F400BT@TSOP48 [(SA247-B005)]
HY29F400TG@PSOP44 [(SA638)]	HY29F400TT@TSOP48 [(SA247-B005)]
HY29F800ABG@PSOP44 [(SA638)]	
HY29F800ABT@TSOP48 [(SA247-B005)]	
HY29F800ATG@PSOP44 [(SA638)]	
HY29F800ATT@TSOP48 [(SA247-B005)]	
HY29F800BG@PSOP44 [(SA638)]	HY29F800BT@TSOP48 [(SA247-B005)]
HY29F800TG@PSOP44 [(SA638)]	HY29F800TT@TSOP48 [(SA247-B005)]
HY93C46	HY93C46@SOIC8 [(SA602A)]
HY93C56	HY93C56@SOIC8 [(SA602A)]
HY93C66	HY93C66@SOIC8 [(SA602A)]
HY93C76	HY93C76@SOIC8 [(SA602A)]
HY93C86	HY93C86@SOIC8 [(SA602A)]

DRAM & SRAM

HY62256A	HY62256A@TSOP28 [(SA643)]
HY6264A	HY6264A@TSOP28 [(SA643)]
HY628100A	HY628100A@SOP32 [(SA438T)]
HY628100A@TSOP32 [(SA410T)]	HY628100B
HY628100B@SOP32 [(SA438T)]	HY628100B@TSOP32 [(SA410T)]
HY628400	HY628400@SOP32 [(SA438T)]
HY628400@TSOP32 [(SA410T)]	HY628400A
HY628400A@SOP32 [(SA438T)]	HY628400A@TSOP32 [(SA410T)]
HY62CT08081E	HY62CT08081E@SOP28 [(SA438T)]
HY62CT08081E@TSOP28 [(SA643)]	HY62KT08081E
HY62KT08081E@SOP28 [(SA438T)]	HY62KT08081E@TSOP28 [(SA643)]
HY62U8100B	HY62U8100B@SOP32 [(SA438T)]
HY62U8100B@TSOP32 [(SA410T)]	HY62U8200B
HY62U8200B@SOP32 [(SA438T)]	HY62U8200B@TSOP32 [(SA410T)]
HY62U8400A	HY62U8400A@SOP32 [(SA438T)]
HY62U8400A@TSOP32 [(SA410T)]	HY62UT08081E
HY62UT08081E@SOP28 [(SA438T)]	HY62UT08081E@TSOP28 [(SA643)]
HY62V8100B	HY62V8100B@SOP32 [(SA438T)]
HY62V8100B@TSOP32 [(SA410T)]	HY62V8200B
HY62V8200B@SOP32 [(SA438T)]	HY62V8200B@TSOP32 [(SA410T)]
HY62V8400A	HY62V8400A@SOP32 [(SA438T)]
HY62V8400A@TSOP32 [(SA410T)]	HY62VT08081E
HY62VT08081E@SOP28 [(SA438T)]	HY62VT08081E@TSOP28 [(SA643)]
HY62WT08081E	HY62WT08081E@SOP28 [(SA438T)]
HY62WT08081E@TSOP28 [(SA643)]	

MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20 [(SA404)]
GMS97C2051	GMS97C2051@SOIC20 [(SA404)]
GMS97C51	GMS97C51@PLCC44 [(SA244)]
GMS97C51@TQFP44 [(SA245A)]	GMS97C52
GMS97C52@PLCC44 [(SA244)]	GMS97C52@TQFP44 [(SA245A)]
GMS97C54	GMS97C54@PLCC44 [(SA244)]
GMS97C54@TQFP44 [(SA245A)]	GMS97C56
GMS97C56@PLCC44 [(SA244)]	GMS97C56@TQFP44 [(SA245A)]
GMS97C58	GMS97C58@PLCC44 [(SA244)]
GMS97C58@TQFP44 [(SA245A)]	GMS97L1051
GMS97L1051@SOIC20 [(SA404)]	GMS97L2051
GMS97L2051@SOIC20 [(SA404)]	GMS97L51
GMS97L51@PLCC44 [(SA244)]	GMS97L51@TQFP44 [(SA245A)]
GMS97L52	GMS97L52@PLCC44 [(SA244)]
GMS97L52@TQFP44 [(SA245A)]	GMS97L54
GMS97L54@PLCC44 [(SA244)]	GMS97L54@TQFP44 [(SA245A)]
GMS97L56	GMS97L56@PLCC44 [(SA244)]
GMS97L56@TQFP44 [(SA245A)]	GMS97L58
GMS97L58@PLCC44 [(SA244)]	GMS97L58@TQFP44 [(SA245A)]
GMS99C52	GMS99C52@PLCC44 [(SA244)]
GMS99C52@TQFP44 [(SA245A)]	GMS99C58
GMS99C58@PLCC44 [(SA244)]	GMS99C58@TQFP44 [(SA245A)]
HMS99C52	HMS99C52@PLCC44 [(SA244)]
HMS99C52@TQFP44 [(SA245A)]	HMS99C58
HMS99C58@PLCC44 [(SA244)]	HMS99C58@TQFP44 [(SA245A)]

ICE**E(E) PROM/FRAM/NVRAM**

ICE25P05	ICE25P05@SOIC8 [(SA602A)]
ICE27C010	ICE27C010@PLCC32 [(SA015A1T)]
ICE27C010@TSOP32 [(SA410T)]	ICE27C020
ICE27C020@PLCC32 [(SA015A1T)]	ICE27C020@TSOP32 [(SA410T)]
ICE27C512	ICE27C512@PLCC32 [(SA015A1T)]
ICE27C512@TSOP28 [(SA430T)]	ICE27LC010
ICE27LC010@PLCC32 [(SA015A1T)]	ICE27LC010@TSOP32 [(SA410T)]
ICE27LC020	ICE27LC020@PLCC32 [(SA015A1T)]
ICE27LC020@TSOP32 [(SA410T)]	ICE27LC512
ICE27LC512@PLCC32 [(SA015A1T)]	ICE27LC512@TSOP28 [(SA430T)]
ICE28LF010	ICE28LF010@PLCC32 [(SA015A1T)]
ICE37C512	ICE37C512@PLCC32 [(SA015A1T)]
ICE37C512@TSOP32 [(SA410T)]	ICE37LC512
ICE37LC512@PLCC32 [(SA015A1T)]	ICE37LC512@TSOP32 [(SA410T)]

ICMIC

E(E) PROM/FRAM/NVRAM

X76F101	X76F101@SOIC8 [(SA602A)]
X76F400@SOIC8 [(SA602A)]	X76F400@TSSOP8 [(SA026)]

ICSI

MICROCONTROLLER

IC89LV51A	IC89LV51A@PLCC44 [(SA244)]
IC89LV51A@TQFP44 [(SA245A)]	IC89LV52A
IC89LV52A@PLCC44 [(SA244)]	IC89LV52A@TQFP44 [(SA245A)]
IS89C51A	IS89C51A@PLCC44 [(SA244)]
IS89C51A@TQFP44 [(SA245A)]	IS89C52A
IS89C52A@PLCC44 [(SA244)]	IS89C52A@TQFP44 [(SA245A)]
IS89C54	IS89C54@PLCC44 [(SA244)]
IS89C54@TQFP44 [(SA245A)]	IS89C58
IS89C58@PLCC44 [(SA244)]	IS89C58@TQFP44 [(SA245A)]
IS89C64	IS89C64@PLCC44 [(SA244)]
IS89C64@TQFP44 [(SA245A)]	IS89E54
IS89E54@PLCC44 [(SA244)]	IS89E54@TQFP44 [(SA245A)]
IS89E58	IS89E58@PLCC44 [(SA244)]
IS89E58@TQFP44 [(SA245A)]	IS89E64
IS89E64@PLCC44 [(SA244)]	IS89E64@TQFP44 [(SA245A)]

ICT

E(E) PROM/FRAM/NVRAM

27CX010	27CX010@PLCC32 [(SA015A1T)]
27CX010@TSOP32 [(SA410T)]	27CX161
27CX162	27CX256
27CX321	27CX322
27CX641	27CX642
93C46	93C46@SOIC8 [(SA602A)]
93C46A	93C46A@SOIC8 [(SA602A)]
93C56A	93C56A@SOIC8 [(SA602A)]
93C66A	93C66A@SOIC8 [(SA602A)]
93CX46	93CX46@SOIC8 [(SA602A)]
93CX56	93CX56@SOIC8 [(SA602A)]
93CX66	93CX66@SOIC8 [(SA602A)]

PLD

PEEL18CV8Z	PEEL18CV8Z@PLCC20 [(SA001A)]
PEEL18CV8Z@SOIC20 [(SA404)]	PEEL18CV8Z@TSOP20 [(SA026)]
PEEL18LV8Z	PEEL18LV8Z@PLCC20 [(SA001A)]
PEEL18LV8Z@SOIC20 [(SA404)]	PEEL18LV8Z@TSOP20 [(SA026)]
PEEL22CV10	PEEL22CV10@PLCC28 [(SA008A)]
PEEL22CV10A	PEEL22CV10A@PLCC28 [(SA008A)]
PEEL22CV10A@SOIC24 [(SA404)]	PEEL22CV10A@TSOP24 [(SA026)]
PEEL22CV10A+	PEEL22CV10A+@PLCC28 [(SA008A)]
PEEL22CV10A+@SOIC24 [(SA404)]	PEEL22CV10A+@TSOP24 [(SA026)]

PEEL22CV10A++	PEEL22CV10A++@PLCC28 [(SA008A)]
PEEL22CV10A++@SOIC24 [(SA404)]	PEEL22CV10A++@TSOP24 [(SA026)]
PEEL22CV10AZ	PEEL22CV10AZ@PLCC28 [(SA008A)]
PEEL22CV10AZ@SOIC24 [(SA404)]	PEEL22CV10AZ@TSOP24 [(SA026)]
PEEL22CV10AZ+	PEEL22CV10AZ+@PLCC28 [(SA008A)]
PEEL22CV10AZ+@SOIC24 [(SA404)]	PEEL22CV10AZ+@TSOP24 [(SA026)]
PEEL22CV10AZ++	PEEL22CV10AZ++@PLCC28 [(SA008A)]
PEEL22CV10AZ++@SOIC24 [(SA404)]	PEEL22CV10AZ++@TSOP24 [(SA026)]
PEEL22LV10AZ	PEEL22LV10AZ@PLCC28 [(SA008A)]
PEEL22LV10AZ@SOIC24 [(SA404)]	PEEL22LV10AZ@TSOP24 [(SA026)]
PEEL22LV10AZ+	PEEL22LV10AZ+@PLCC28 [(SA008A)]
PEEL22LV10AZ+@SOIC24 [(SA404)]	PEEL22LV10AZ+@TSOP24 [(SA026)]
PEEL22LV10AZ++	PEEL22LV10AZ++@PLCC28 [(SA008A)]
PEEL22LV10AZ++@SOIC24 [(SA404)]	PEEL22LV10AZ++@TSOP24 [(SA026)]

IDT

E(E) PROM/FRAM/NVRAM

ICS280@TSSOP16 [(SA026)]	ICS281@TSSOP16 [(SA026)]
--------------------------	--------------------------

IMT

E(E) PROM/FRAM/NVRAM

IM29F001B	IM29F001B@PLCC32 [(SA015A1T)]
IM29F001B@TSOP32 [(SA410T)]	IM29F001B@VSOP32 [(SA620)]
IM29F001T	IM29F001T@PLCC32 [(SA015A1T)]
IM29F001T@TSOP32 [(SA410T)]	IM29F001T@VSOP32 [(SA620)]
IM29F002B	IM29F002B@PLCC32 [(SA015A1T)]
IM29F002B@TSOP32 [(SA410T)]	IM29F002B@VSOP32 [(SA620)]
IM29F002T	IM29F002T@PLCC32 [(SA015A1T)]
IM29F002T@TSOP32 [(SA410T)]	IM29F002T@VSOP32 [(SA620)]
IM29F004B	IM29F004B@PLCC32 [(SA015A1T)]
IM29F004B@TSOP32 [(SA410T)]	IM29F004B@VSOP32 [(SA620)]
IM29F004T	IM29F004T@PLCC32 [(SA015A1T)]
IM29F004T@TSOP32 [(SA410T)]	IM29F004T@VSOP32 [(SA620)]
IM29LV004B	IM29LV004B@PLCC32 [(SA015A1T)]
IM29LV004B@TSOP32 [(SA410T)]	IM29LV004B@VSOP32 [(SA620)]
IM29LV004T	IM29LV004T@PLCC32 [(SA015A1T)]
IM29LV004T@TSOP32 [(SA410T)]	IM29LV004T@VSOP32 [(SA620)]
IM29LV400B@PSOP44 [(SA638)]	IM29LV400B@TSOP48 [(SA247-B005)]
IM29LV400T@PSOP44 [(SA638)]	IM29LV400T@TSOP48 [(SA247-B005)]

INTEL

E(E) PROM/FRAM/NVRAM

27010	27010@PLCC32 [(SA015A1T)]
27010@TSOP32 [(SA410T)]	27128
27128A	27128B
2716	27210
27256	2732
2732A	27512
2764	2764A
27C010	27C010@PLCC32 [(SA015A1T)]
27C010@TSOP32 [(SA410T)]	27C010A
27C010A@PLCC32 [(SA015A1T)]	27C010A@TSOP32 [(SA410T)]
27C020	27C020@PLCC32 [(SA015A1T)]
27C020@TSOP32 [(SA410T)]	27C040
27C040@PLCC32 [(SA015A1T)]	27C040@TSOP32 [(SA410T)]
27C100	27C100@PLCC32 [(SA015A1T)]
27C100@TSOP32 [(SA410T)]	27C128
27C128@PLCC32 [(SA015A1T)]	27C210
27C210@PLCC44 [(SA244)]	27C220
27C220@PLCC44 [(SA244)]	27C240
27C240@PLCC44 [(SA244)]	27C256
27C256@PLCC32 [(SA015A1T)]	27C400
27C400@PLCC44 [(SA244)]	27C512
27C512@PLCC32 [(SA015A1T)]	27C64
27C64@PLCC32 [(SA015A1T)]	27C800

27S512	2816A
2817A	2864A
68C257	68C257@PLCC32 [(SA015A1T)]
87C256	87C257
87C257@PLCC32 [(SA015A1T)]	87C64
D27011	D27513
D27C011	D27C513
D28F256	D28F256A
D28F512	E28F001BX-B@TSOP32 [(SA410T)]
E28F001BX-T@TSOP32 [(SA410T)]	E28F002BCT@TSOP40 [(SA409T)]
E28F002BEB@TSOP40 [(SA409T)]	E28F002BET@TSOP40 [(SA409T)]
E28F002BLB@TSOP40 [(SA409T)]	E28F002BLT@TSOP40 [(SA409T)]
E28F002BVB@TSOP40 [(SA409T)]	E28F002BVT@TSOP40 [(SA409T)]
E28F002BXB@TSOP40 [(SA409T)]	E28F002BXT@TSOP40 [(SA409T)]
E28F004B5B@TSOP40 [(SA409T)]	E28F004B5T@TSOP40 [(SA409T)]
E28F004BEB@TSOP40 [(SA409T)]	E28F004BET@TSOP40 [(SA409T)]
E28F004BLB@TSOP40 [(SA409T)]	E28F004BLT@TSOP40 [(SA409T)]
E28F004BVB@TSOP40 [(SA409T)]	E28F004BVT@TSOP40 [(SA409T)]
E28F004BXB@TSOP40 [(SA409T)]	E28F004BXT@TSOP40 [(SA409T)]
E28F004S3@TSOP40 [(SA409T)]	E28F004S5@TSOP40 [(SA409T)]
E28F004SC@TSOP40 [(SA409T)]	E28F008BEB@TSOP40 [(SA409T)]
E28F008BET@TSOP40 [(SA409T)]	E28F008BLB@TSOP40 [(SA409T)]
E28F008BLT@TSOP40 [(SA409T)]	E28F008BVB@TSOP40 [(SA409T)]
E28F008BVT@TSOP40 [(SA409T)]	E28F008BXB@TSOP40 [(SA409T)]
E28F008BXT@TSOP40 [(SA409T)]	E28F008S3@TSOP40 [(SA409T)]
E28F008S5@TSOP40 [(SA409T)]	E28F008SA@TSOP40 [(SA409T)]
E28F008SA-L@TSOP40 [(SA409T)]	E28F008SC@TSOP40 [(SA409T)]
E28F010@TSOP32 [(SA410T)]	E28F016S3@TSOP40 [(SA409T)]
E28F016S5@TSOP40 [(SA409T)]	E28F016SC@TSOP40 [(SA409T)]
E28F020@TSOP32 [(SA410T)]	E28F256@TSOP32 [(SA410T)]
E28F256A@TSOP32 [(SA410T)]	E28F512@TSOP32 [(SA410T)]
E82802AA@TSOP40 [(SA409T)]	E82802AB@TSOP40 [(SA409T)]
E82802AC@TSOP40 [(SA409T)]	F28F010@TSOP32 [(SA410T)]
F28F020(REVERSE)@TSOP32 [(SA410T)]	F28F256@TSOP32 [(SA410T)]
F28F020@TSOP32 [(SA410T)]	F28F512@TSOP32 [(SA410T)]
F28F256A@TSOP32 [(SA410T)]	M28F010@PLCC32 [(SA015A1T)]
M28F010	N28F001BN-B@PLCC32 [(SA015A1T)]
M28F010@TSOP32 [(SA410T)]	N28F001BX-B@PLCC32 [(SA015A1T)]
N28F001BN-T@PLCC32 [(SA015A1T)]	N28F010@PLCC32 [(SA015A1T)]
N28F001BX-T@PLCC32 [(SA015A1T)]	N28F256@PLCC32 [(SA015A1T)]
N28F020@PLCC32 [(SA015A1T)]	N28F512@PLCC32 [(SA015A1T)]
N28F256A@PLCC32 [(SA015A1T)]	N82802AB@PLCC32 [(SA015A1T)]
N82802AA@PLCC32 [(SA015A1T)]	P27011
N82802AC@PLCC32 [(SA015A1T)]	P27128A@PLCC32 [(SA015A1T)]
P27128A	P27128B@PLCC32 [(SA015A1T)]
P27128B	P27256@PLCC32 [(SA015A1T)]
P27256	P27513
P27512	P2764A@PLCC32 [(SA015A1T)]
P2764A	P27C128
P27C011	P27C256
P27C128@PLCC32 [(SA015A1T)]	P27C513
P27C256@PLCC32 [(SA015A1T)]	P27C64@PLCC32 [(SA015A1T)]
P27C64	P28F001BX-T
P28F001BX-B	P28F010
P28F002BCT@TSOP40 [(SA409T)]	P28F256
P28F020	P28F512
P28F256A	P87C64@PLCC32 [(SA015A1T)]
P87C64	PA28F004S5@PSOP44 [(SA638)]
PA28F004S3@PSOP44 [(SA638)]	PA28F008S3@PSOP44 [(SA638)]
PA28F004SC@PSOP44 [(SA638)]	PA28F008SA@PSOP44 [(SA638)]
PA28F008S5@PSOP44 [(SA638)]	PA28F008SC@PSOP44 [(SA638)]
PA28F008SA-L@PSOP44 [(SA638)]	PA28F016S5@PSOP44 [(SA638)]
PA28F016S3@PSOP44 [(SA638)]	PA28F200B5B@PSOP44 [(SA638)]
PA28F016SC@PSOP44 [(SA638)]	PA28F200BVB@PSOP44 [(SA638)]
PA28F200B5T@PSOP44 [(SA638)]	PA28F200BXB@PSOP44 [(SA638)]
PA28F200BVT@PSOP44 [(SA638)]	PA28F400B5B@PSOP44 [(SA638)]
PA28F200BXT@PSOP44 [(SA638)]	PA28F400BVB@PSOP44 [(SA638)]
PA28F400B5T@PSOP44 [(SA638)]	PA28F400BXB@PSOP44 [(SA638)]
PA28F400BVT@PSOP44 [(SA638)]	PA28F800B5B@PSOP44 [(SA638)]
PA28F400BXT@PSOP44 [(SA638)]	PA28F800BVB@PSOP44 [(SA638)]
PA28F800B5T@PSOP44 [(SA638)]	QB25F016S33B60@SOIC8 [(SA605A)]
PA28F800BVT@PSOP44 [(SA638)]	QB25F160S33B60@SOIC16 [(SA404)]
QB25F016S33T60@SOIC8 [(SA605A)]	QB25F320S33B60@SOIC16 [(SA404)]
QB25F160S33T60@SOIC16 [(SA404)]	QB25F640S33B60@SOIC16 [(SA404)]
QB25F320S33T60@SOIC16 [(SA404)]	QH25F016S33B60@SOIC8 [(SA605A)]
QB25F640S33T60@SOIC16 [(SA404)]	QH25F160S33B60@SOIC16 [(SA404)]
QH25F016S33T60@SOIC8 [(SA605A)]	QH25F320S33B60@SOIC16 [(SA404)]
QH25F160S33T60@SOIC16 [(SA404)]	QH25F640S33B60@SOIC16 [(SA404)]
QH25F320S33T60@SOIC16 [(SA404)]	TB28F004S3@PSOP44 [(SA638)]
QH25F640S33T60@SOIC16 [(SA404)]	TB28F004SC@PSOP44 [(SA638)]
TB28F004S5@PSOP44 [(SA638)]	

TB28F008S3@PSOP44 [(SA638)]	TB28F008S5@PSOP44 [(SA638)]
TB28F008SA@PSOP44 [(SA638)]	TB28F008SA-L@PSOP44 [(SA638)]
TB28F008SC@PSOP44 [(SA638)]	TB28F016S3@PSOP44 [(SA638)]
TB28F016S5@PSOP44 [(SA638)]	TB28F016SC@PSOP44 [(SA638)]
TB28F200B5B@PSOP44 [(SA638)]	TB28F200B5T@PSOP44 [(SA638)]
TB28F200BVB@PSOP44 [(SA638)]	TB28F200BVT@PSOP44 [(SA638)]
TB28F200BXB@PSOP44 [(SA638)]	TB28F200BXT@PSOP44 [(SA638)]
TB28F400B5B@PSOP44 [(SA638)]	TB28F400B5T@PSOP44 [(SA638)]
TB28F400BVB@PSOP44 [(SA638)]	TB28F400BVT@PSOP44 [(SA638)]
TB28F400BXB@PSOP44 [(SA638)]	TB28F400BXT@PSOP44 [(SA638)]
TB28F800B5B@PSOP44 [(SA638)]	TB28F800B5T@PSOP44 [(SA638)]
TB28F800BVB@PSOP44 [(SA638)]	TB28F800BVT@PSOP44 [(SA638)]
TE28F002BEB@TSOP40 [(SA409T)]	TE28F002BET@TSOP40 [(SA409T)]
TE28F002BVB@TSOP40 [(SA409T)]	TE28F002BVT@TSOP40 [(SA409T)]
TE28F002BXB@TSOP40 [(SA409T)]	TE28F002BXT@TSOP40 [(SA409T)]
TE28F004BEB@TSOP40 [(SA409T)]	TE28F004BET@TSOP40 [(SA409T)]
TE28F004BVB@TSOP40 [(SA409T)]	TE28F004BVT@TSOP40 [(SA409T)]
TE28F004BXB@TSOP40 [(SA409T)]	TE28F004BXT@TSOP40 [(SA409T)]
TE28F004S3@TSOP40 [(SA409T)]	TE28F004S5@TSOP40 [(SA409T)]
TE28F004SC@TSOP40 [(SA409T)]	TE28F008B3B@TSOP40 [(SA409T)]
TE28F008B3BA@TSOP40 [(SA409T)]	TE28F008B3T@TSOP40 [(SA409T)]
TE28F008B3TA@TSOP40 [(SA409T)]	TE28F008BEB@TSOP40 [(SA409T)]
TE28F008BET@TSOP40 [(SA409T)]	TE28F008BVB@TSOP40 [(SA409T)]
TE28F008BVT@TSOP40 [(SA409T)]	TE28F008S3@TSOP40 [(SA409T)]
TE28F008S5@TSOP40 [(SA409T)]	TE28F008SA@TSOP40 [(SA409T)]
TE28F008SA-L@TSOP40 [(SA409T)]	TE28F008SC@TSOP40 [(SA409T)]
TE28F016B3B@TSOP40 [(SA409T)]	TE28F016B3T@TSOP40 [(SA409T)]
TE28F016S3@TSOP40 [(SA409T)]	TE28F016S5@TSOP40 [(SA409T)]
TE28F016SC@TSOP40 [(SA409T)]	

PLD

5C031	5C031@PLCC20 [(SA001A)]
5C032	5C032@PLCC20 [(SA001A)]
5C090	5C090@PLCC44 [(SA244)]
85C090	85C090-P44 [(SA244)]
85C220	85C220@PLCC20 [(SA001A)]
IPLD910	IPLD910-P44 [(SA244)]

MICROCONTROLLER

8751BH	8751BH@PLCC44 [(SA244)]
8752BH	8752BH@PLCC44 [(SA244)]
8796BH@PLCC68(*) [(SA648-B6803)]	8796JF@PLCC68(*) [(SA648-B6803)]
8797BH@PGA68(*) [(SA650-B6804)]	8797BH@PLCC68(*) [(SA648-B6803)]
8797JF@PGA68(*) [(SA650-B6804)]	8797JF@PLCC68(*) [(SA648-B6803)]
87C151SA	87C151SA@PLCC44 [(SA244)]
87C151SB	87C151SB@PLCC44 [(SA244)]
87C196CA@PLCC68(*) [(SA648-B6805)]	
87C196JQ@PLCC52(*) [(SA647-B5201)]	
87C196JR@PLCC52(*) [(SA647-B5201)]	
87C196JT@PLCC52(*) [(SA647-B5201)]	
87C196JV@PLCC52(*) [(SA647-B5201)]	
87C196KB@PLCC68(*) [(SA648-B6801)]	
87C196KC@PLCC68(*) [(SA648-B6801)]	
87C196KD@PLCC68(*) [(SA648-B6801)]	
87C196KQ@PLCC68(*) [(SA648-B6802)]	
87C196KR@PLCC68(*) [(SA648-B6802)]	
87C196KS@PLCC68(*) [(SA648-B6802)]	
87C196KT@PLCC68(*) [(SA648-B6802)]	
87C196LA@PLCC52(*) [(SA647-B5201)]	
87C196MC@PLCC84(*) [(SA649-B8401)]	
87C196MC@PQFP80(*) [(TA026-B006)]	
87C196MC@SDIP64(*) [(SA651)]	
87C196MH@PLCC84(*) [(SA649-B8401)]	
87C196MH@PQFP80(*) [(TA026-B006)]	
87C196MH@SDIP64(*) [(SA651)]	87C251SA
87C251SA@PLCC44 [(SA244)]	87C251SB
87C251SB@PLCC44 [(SA244)]	87C251SP
87C251SP@PLCC44 [(SA244)]	87C251SQ
87C251SQ@PLCC44 [(SA244)]	87C51
87C51@PLCC44 [(SA244)]	87C51@TQFP44 [(SA245A)]
87C51FA	87C51FA@PLCC44 [(SA244)]
87C51FA@TQFP44 [(SA245A)]	87C51FB
87C51FB@PLCC44 [(SA244)]	87C51FB@TQFP44 [(SA245A)]
87C51FC	87C51FC@PLCC44 [(SA244)]
87C51FC@TQFP44 [(SA245A)]	87C51RA
87C51RA@PLCC44 [(SA244)]	87C51RA@TQFP44 [(SA245A)]

87C51RB	87C51RB@PLCC44 [(SA244)]
87C51RB@TQFP44 [(SA245A)]	87C51RC
87C51RC@PLCC44 [(SA244)]	87C51RC@TQFP44 [(SA245A)]
87C52	87C52@PLCC44 [(SA244)]
87C52@TQFP44 [(SA245A)]	87C54
87C54@PLCC44 [(SA244)]	87C54@TQFP44 [(SA245A)]
87C58	87C58@PLCC44 [(SA244)]
87C58@TQFP44 [(SA245A)]	87L51FA@PLCC44 [(SA244)]
87L51FA@TQFP44 [(SA245A)]	87L51FB@PLCC44 [(SA244)]
87L51FB@TQFP44 [(SA245A)]	87L51FC@PLCC44 [(SA244)]
87L51FC@TQFP44 [(SA245A)]	87L52@PLCC44 [(SA244)]
87L52@TQFP44 [(SA245A)]	87L54@PLCC44 [(SA244)]
87L54@TQFP44 [(SA245A)]	87L58@PLCC44 [(SA244)]
87L58@TQFP44 [(SA245A)]	

INTELSIL

E(E) PROM/FRAM/NVRAM

HS-6617RH	HS-6617RH@SOIC24 [(SA404)]
HS-6617RH-T	HS-6617RH-T@SOIC24 [(SA404)]
HS-6883RH	HS-6883RH@SOIC24 [(SA404)]
HS-6883RH-T	HS-6883RH-T@SOIC24 [(SA404)]

ISSI

E(E) PROM/FRAM/NVRAM

IS24C01	IS24C01@MSOP8 [(SA666)]
IS24C01@SOIC8 [(SA602A)]	IS24C01@TSSOP8 [(SA026)]
IS24C01B	IS24C01B@MSOP8 [(SA666)]
IS24C01B@SOIC8 [(SA602A)]	IS24C01B@TSSOP8 [(SA026)]
IS24C02	IS24C02@MSOP8 [(SA666)]
IS24C02@SOIC8 [(SA602A)]	IS24C02@TSSOP8 [(SA026)]
IS24C02A	IS24C02A@DFN8
IS24C02A@MSOP8 [(SA666)]	IS24C02A@SOIC8 [(SA602A)]
IS24C02A@TSSOP8 [(SA026)]	IS24C02B
IS24C02B@DFN8	IS24C02B@MSOP8 [(SA666)]
IS24C02B@SOIC8 [(SA602A)]	IS24C02B@TSSOP8 [(SA026)]
IS24C02C	IS24C02C@DFN8
IS24C02C@MSOP8 [(SA666)]	IS24C02C@SOIC8 [(SA602A)]
IS24C02C@TSSOP8 [(SA026)]	IS24C04
IS24C04@MSOP8 [(SA666)]	IS24C04@SOIC8 [(SA602A)]
IS24C04@TSSOP8 [(SA026)]	IS24C04A
IS24C04A@DFN8	IS24C04A@MSOP8 [(SA666)]
IS24C04A@SOIC8 [(SA602A)]	IS24C04A@TSSOP8 [(SA026)]
IS24C08	IS24C08@MSOP8 [(SA666)]
IS24C08@SOIC8 [(SA602A)]	IS24C08@TSSOP8 [(SA026)]
IS24C08A	IS24C08A@DFN8
IS24C08A@MSOP8 [(SA666)]	IS24C08A@SOIC8 [(SA602A)]
IS24C08A@TSSOP8 [(SA026)]	IS24C128
IS24C128@SOIC8 [(SA602A)]	IS24C128@TSSOP14 [(SA026)]
IS24C16	IS24C16@MSOP8 [(SA666)]
IS24C16@SOIC8 [(SA602A)]	IS24C16@TSSOP8 [(SA026)]
IS24C16A	IS24C16A@MSOP8 [(SA666)]
IS24C16A@SOIC8 [(SA602A)]	IS24C16A@TSSOP8 [(SA026)]
IS24C256	IS24C256@SOIC8 [(SA602A)]
IS24C256@TSSOP14 [(SA026)]	IS24C256A
IS24C256A@SOIC8 [(SA602A)]	IS24C256A@TSSOP14 [(SA026)]
IS24C32	IS24C32@SOIC8 [(SA602A)]
IS24C32@TSSOP8 [(SA026)]	IS24C32A
IS24C32A@MSOP8 [(SA666)]	IS24C32A@SOIC8 [(SA602A)]
IS24C32A@TSSOP8 [(SA026)]	IS24C32B
IS24C32B@SOIC8 [(SA602A)]	IS24C32B@TSSOP8 [(SA026)]
IS24C64	IS24C64@SOIC8 [(SA602A)]
IS24C64@TSSOP8 [(SA026)]	IS24C64A
IS24C64A@MSOP8 [(SA666)]	IS24C64A@SOIC8 [(SA602A)]
IS24C64A@TSSOP8 [(SA026)]	IS24C64B
IS24C64B@SOIC8 [(SA602A)]	IS24C64B@TSSOP8 [(SA026)]
IS24L128	
IS24L128@SOIC8(150mil) [(SA602A)]	
IS24L128@SOIC8(200mil) [(SA605A)]	
IS24L256	
IS24L256@SOIC8(150mil) [(SA602A)]	

IS24L256@SOIC8 (200mil) [(SA605A)]	
IS25C01	IS25C01@SOIC8 [(SA602A)]
IS25C01@TSSOP8 [(SA026)]	IS25C02
IS25C02@SOIC8 [(SA602A)]	IS25C02@TSSOP8 [(SA026)]
IS25C04	IS25C04@SOIC8 [(SA602A)]
IS25C04@TSSOP8 [(SA026)]	IS25C08
IS25C08@SOIC8 [(SA602A)]	IS25C08@TSSOP8 [(SA026)]
IS25C128@SOIC8 [(SA602A)]	IS25C128@TSSOP8 [(SA026)]
IS25C16	IS25C16@SOIC8 [(SA602A)]
IS25C16@TSSOP8 [(SA026)]	IS25C256@SOIC8 [(SA602A)]
IS25C256@TSSOP8 [(SA026)]	IS25C32A
IS25C32A@SOIC8 [(SA602A)]	IS25C32A@TSSOP8 [(SA026)]
IS25C64A	IS25C64A@SOIC8 [(SA602A)]
IS25C64A@TSSOP8 [(SA026)]	IS27C010
IS27C010@PLCC32 [(SA015A1T)]	IS27C010@TSOP32 [(SA410T)]
IS27C020	IS27C020@PLCC32 [(SA015A1T)]
IS27C020@TSOP32 [(SA410T)]	IS27C256
IS27C256@PLCC32 [(SA015A1T)]	IS27C512
IS27C512@PLCC32 [(SA015A1T)]	IS27C512@TSOP28 [(SA430T)]
IS27HC010	IS27HC010@PLCC32 [(SA015A1T)]
IS27HC010@TSOP32 [(SA410T)]	IS27HC020
IS27HC020@PLCC32 [(SA015A1T)]	IS27HC020@TSOP32 [(SA410T)]
IS27HC256	IS27HC256@PLCC32 [(SA015A1T)]
IS27HC512	IS27HC512@PLCC32 [(SA015A1T)]
IS27HC512@TSOP28 [(SA430T)]	IS27LV010
IS27LV010@PLCC32 [(SA015A1T)]	IS27LV010@TSOP32 [(SA410T)]
IS27LV512	IS27LV512@PLCC32 [(SA015A1T)]
IS27LV512@TSOP28 [(SA430T)]	IS28F010
IS28F010@PLCC32 [(SA015A1T)]	IS28F010@TSOP32 [(SA410T)]
IS28F010A	IS28F010A@PLCC32 [(SA015A1T)]
IS28F010A@TSOP32 [(SA410T)]	IS28F020
IS28F020@PLCC32 [(SA015A1T)]	IS28F020@TSOP32 [(SA410T)]
IS29F010	IS29F010@PLCC32 [(SA015A1T)]
IS29F010@TSOP32 [(SA410T)]	IS34C02
IS34C02@MSOP8 [(SA666)]	IS34C02@SOIC8 [(SA602A)]
IS34C02@TSSOP8 [(SA026)]	IS34C02B@DFN8
IS34C02B@TSSOP8 [(SA026)]	IS93C46
IS93C46@SOIC8 [(SA602A)]	IS93C46A(08bit)
IS93C46A(08bit)@SOIC8 [(SA602A)]	IS93C46A(08bit)@TSSOP8 [(SA026)]
IS93C46A(16bit)	IS93C46A(16bit)@SOIC8 [(SA602A)]
IS93C46A(16bit)@TSSOP8 [(SA026)]	IS93C46B
IS93C46B@SOIC8 [(SA602A)]	IS93C46B@TSSOP8 [(SA026)]
IS93C46D(08bit)	IS93C46D(08bit)@SOIC8 [(SA602A)]
IS93C46D(08bit)@TSSOP8 [(SA026)]	IS93C46D(16bit)
IS93C46D(16bit)@SOIC8 [(SA602A)]	IS93C46D(16bit)@TSSOP8 [(SA026)]
IS93C56	IS93C56@SOIC8 [(SA602A)]
IS93C56A(08bit)	IS93C56A(08bit)@SOIC8 [(SA602A)]
IS93C56A(08bit)@TSSOP8 [(SA026)]	IS93C56A(16bit)
IS93C56A(16bit)@SOIC8 [(SA602A)]	IS93C56A(16bit)@TSSOP8 [(SA026)]
IS93C66	IS93C66@SOIC8 [(SA602A)]
IS93C66A(08bit)	IS93C66A(08bit)@SOIC8 [(SA602A)]
IS93C66A(08bit)@TSSOP8 [(SA026)]	IS93C66A(16bit)
IS93C66A(16bit)@SOIC8 [(SA602A)]	IS93C66A(16bit)@TSSOP8 [(SA026)]
IS93C76A(08bit)	IS93C76A(08bit)@SOIC8 [(SA602A)]
IS93C76A(08bit)@TSSOP8 [(SA026)]	IS93C76A(16bit)
IS93C76A(16bit)@SOIC8 [(SA602A)]	IS93C76A(16bit)@TSSOP8 [(SA026)]
IS93C86A(08bit)	IS93C86A(08bit)@SOIC8 [(SA602A)]
IS93C86A(08bit)@TSSOP8 [(SA026)]	IS93C86A(16bit)
IS93C86A(16bit)@SOIC8 [(SA602A)]	IS93C86A(16bit)@TSSOP8 [(SA026)]

DRAM & SRAM

IS61C1024	IS61C1024(300m)@SOJ32 [(SA646)]
IS61C1024(400m)@SOJ32 [(SA661)]	IS61C1024@TSOP32 [(SA410T)]
IS61C1024L	IS61C1024L(300m)@SOJ32 [(SA646)]
IS61C1024L(400m)@SOJ32 [(SA661)]	IS61C1024L@TSOP32 [(SA410T)]
IS61C256AH	IS61C256AH@SOJ28 [(SA646)]
IS61C256AH@TSOP28 [(SA430T)]	IS61C512
IS61C512(300m)@SOJ32 [(SA646)]	IS61C512(400m)@SOJ32 [(SA661)]
IS61C512@TSOP32 [(SA410T)]	IS61C64AH
IS61C64AH@SOJ28 [(SA646)]	IS61C64AH@TSOP28 [(SA430T)]
IS61LV256	IS61LV256@SOJ28 [(SA646)]
IS61LV256@TSOP28 [(SA430T)]	IS61M256
IS61M256@SOJ28 [(SA646)]	IS61M256@TSOP28 [(SA430T)]
IS62C1024	IS62C1024(300m)@SOJ32 [(SA646)]
IS62C1024(400m)@SOJ32 [(SA661)]	IS62C1024@TSOP32 [(SA410T)]
IS62C256	IS62C256@SOJ28 [(SA646)]
IS62C256@TSOP28 [(SA430T)]	IS62C512
IS62C512(300m)@SOJ32 [(SA646)]	IS62C512(400m)@SOJ32 [(SA661)]

IS62C512@TSOP32 [(SA410T)]	IS62C64
IS62C64@SOJ28 [(SA646)]	IS62C64@TSOP28 [(SA430T)]
IS62LV256	IS62LV256@SOJ28 [(SA646)]
IS62LV256@TSOP28 [(SA430T)]	

MICROCONTROLLER

IS89C51A	IS89C51A@PLCC44 [(SA244)]
IS89C51A@TQFP44 [(SA245A)]	IS89C52A
IS89C52A@PLCC44 [(SA244)]	IS89C52A@TQFP44 [(SA245A)]

K-LINE**E(E) PROM/FRAM/NVRAM**

K24C32	K24C32@SOIC8 [(SA602A)]
K24C32@TSSOP8 [(SA026)]	K24C64
K24C64@SOIC8 [(SA602A)]	K24C64@TSSOP8 [(SA026)]

LATTICE**PLD**

GAL16LV8	GAL16LV8@PLCC20 [(SA001A)]
GAL16LV8C	GAL16LV8C@PLCC20 [(SA001A)]
GAL16LV8D	GAL16LV8D@PLCC20 [(SA001A)]
GAL16LV8Z	GAL16LV8Z@PLCC20 [(SA001A)]
GAL16LV8ZD	GAL16LV8ZD@PLCC20 [(SA001A)]
GAL16V8	GAL16V8@PLCC20 [(SA001A)]
GAL16V8@SOIC20 [(SA404)]	GAL16V8A
GAL16V8A@PLCC20 [(SA001A)]	GAL16V8A@SOIC20 [(SA404)]
GAL16V8B	GAL16V8B@PLCC20 [(SA001A)]
GAL16V8B@SOIC20 [(SA404)]	GAL16V8C
GAL16V8C@PLCC20 [(SA001A)]	GAL16V8C@SOIC20 [(SA404)]
GAL16V8D	GAL16V8D@PLCC20 [(SA001A)]
GAL16V8D@SOIC20 [(SA404)]	GAL16V8Z
GAL16V8Z@PLCC20 [(SA001A)]	GAL16V8Z@SOIC20 [(SA404)]
GAL18V10	GAL18V10@PLCC20 [(SA001A)]
GAL18V10B	GAL18V10B@PLCC20 [(SA001A)]
GAL20LV8	GAL20LV8@PLCC28 [(SA008A)]
GAL20LV8Z	GAL20LV8Z@PLCC28 [(SA008A)]
GAL20LV8ZD	GAL20LV8ZD@PLCC28 [(SA008A)]
GAL20RA10	GAL20RA10@PLCC28 [(SA008A)]
GAL20RA10B	GAL20RA10B@PLCC28 [(SA008A)]
GAL20V8	GAL20V8@PLCC28 [(SA008A)]
GAL20V8A	GAL20V8A@PLCC28 [(SA008A)]
GAL20V8B	GAL20V8B@PLCC28 [(SA008A)]
GAL20V8C	GAL20V8C@PLCC28 [(SA008A)]
GAL20V8Z	GAL20V8Z@PLCC28 [(SA008A)]
GAL20XV10	GAL20XV10@PLCC28 [(SA008A)]
GAL20XV10B	GAL20XV10B@PLCC28 [(SA008A)]
GAL22LV10C	GAL22LV10C@PLCC28 [(SA008A)]
GAL22LV10C@SOIC24 [(SA404)]	GAL22LV10C@TSOP24 [(SA643)]
GAL22LV10D	GAL22LV10D@PLCC28 [(SA008A)]
GAL22LV10D@SOIC24 [(SA404)]	GAL22LV10D@TSOP24 [(SA643)]
GAL22LV10Z	GAL22LV10Z@PLCC28 [(SA008A)]
GAL22LV10Z@SOIC24 [(SA404)]	GAL22LV10Z@TSOP24 [(SA643)]
GAL22LV10ZD	GAL22LV10ZD@PLCC28 [(SA008A)]
GAL22LV10ZD@SOIC24 [(SA404)]	GAL22LV10ZD@TSOP24 [(SA643)]
GAL22V10	GAL22V10@PLCC28 [(SA008A)]
GAL22V10@SOIC24 [(SA404)]	GAL22V10A
GAL22V10A@PLCC28 [(SA008A)]	GAL22V10A@SOIC24 [(SA404)]
GAL22V10B	GAL22V10B@PLCC28 [(SA008A)]
GAL22V10B@SOIC24 [(SA404)]	GAL22V10BQ
GAL22V10BQ@PLCC28 [(SA008A)]	GAL22V10BQ@SOIC24 [(SA404)]
GAL22V10C	GAL22V10C@PLCC28 [(SA008A)]
GAL22V10C@SOIC24 [(SA404)]	GAL22V10D
GAL22V10D@PLCC28 [(SA008A)]	GAL22V10D@SOIC24 [(SA404)]
ispGAL22LV10	ispGAL22LV10(ISP) [ISP-HEADER01]
ispGAL22LV10@PLCC28 [(SA008A)]	
ispGAL22LV10@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10@SSOP28 [(SA626A)]	
ispGAL22LV10@SSOP28(ISP) [ISP-HEADER01]	

```

ispGAL22LV10A
ispGAL22LV10A(ISP) [ISP-HEADER01]
ispGAL22LV10A@PLCC28 [(SA008A)]
ispGAL22LV10A@PLCC28(ISP) [ISP-HEADER01]
ispGAL22LV10A@SSOP28 [(SA626A)]
ispGAL22LV10A@SSOP28(ISP) [ISP-HEADER01]
ispGAL22LV10B
ispGAL22LV10B(ISP) [ISP-HEADER01]
ispGAL22LV10B@PLCC28 [(SA008A)]
ispGAL22LV10B@PLCC28(ISP) [ISP-HEADER01]
ispGAL22LV10B@SSOP28 [(SA626A)]
ispGAL22LV10B@SSOP28(ISP) [ISP-HEADER01]
ispGAL22LV10C
ispGAL22LV10C(ISP) [ISP-HEADER01]
ispGAL22LV10C@PLCC28 [(SA008A)]
ispGAL22LV10C@PLCC28(ISP) [ISP-HEADER01]
ispGAL22LV10C@SSOP28 [(SA626A)]
ispGAL22LV10C@SSOP28(ISP) [ISP-HEADER01]
ispGAL22LV10D
ispGAL22LV10D(ISP) [ISP-HEADER01]
ispGAL22LV10D@PLCC28 [(SA008A)]
ispGAL22LV10D@PLCC28(ISP) [ISP-HEADER01]
ispGAL22LV10D@SSOP28 [(SA626A)]
ispGAL22LV10D@SSOP28(ISP) [ISP-HEADER01]
ispGAL22V10AB@PLCC28 [(SA008A)]      ispGAL22V10AB@QFN32 [(SA686)]
ispGAL22V10AC@PLCC28 [(SA008A)]      ispGAL22V10AC@QFN32 [(SA686)]
ispGAL22V10AV@PLCC28 [(SA008A)]      ispGAL22V10AV@QFN32 [(SA686)]
ispGAL22V10C(UES)@PLCC28 [(SA008A)]
ispGAL22V10C@PLCC28 [(SA008A)]
LCMXO1200C-FT256(ISP) [ISP-HEADER01]
LCMXO1200C-FT324(ISP) [ISP-HEADER01]
LCMXO1200C-FTN256(ISP) [ISP-HEADER01]
LCMXO1200C-FTN324(ISP) [ISP-HEADER01]
LCMXO1200C-M100(ISP) [ISP-HEADER01]
LCMXO1200C-M132(ISP) [ISP-HEADER01]
LCMXO1200C-MN100(ISP) [ISP-HEADER01]
LCMXO1200C-MN132(ISP) [ISP-HEADER01]
LCMXO1200C-T100(ISP) [ISP-HEADER01]
LCMXO1200C-T144(ISP) [ISP-HEADER01]
LCMXO1200C-TN100(ISP) [ISP-HEADER01]
LCMXO1200C-TN144(ISP) [ISP-HEADER01]
LCMXO1200E-FT256(ISP) [ISP-HEADER01]
LCMXO1200E-FT324(ISP) [ISP-HEADER01]
LCMXO1200E-FTN256(ISP) [ISP-HEADER01]
LCMXO1200E-FTN324(ISP) [ISP-HEADER01]
LCMXO1200E-M100(ISP) [ISP-HEADER01]
LCMXO1200E-M132(ISP) [ISP-HEADER01]
LCMXO1200E-MN100(ISP) [ISP-HEADER01]
LCMXO1200E-MN132(ISP) [ISP-HEADER01]
LCMXO1200E-T100(ISP) [ISP-HEADER01]
LCMXO1200E-T144(ISP) [ISP-HEADER01]
LCMXO1200E-TN100(ISP) [ISP-HEADER01]
LCMXO1200E-TN144(ISP) [ISP-HEADER01]
LCMXO2280C-FT256(ISP) [ISP-HEADER01]
LCMXO2280C-FT324(ISP) [ISP-HEADER01]
LCMXO2280C-FTN256(ISP) [ISP-HEADER01]
LCMXO2280C-FTN324(ISP) [ISP-HEADER01]
LCMXO2280C-M100(ISP) [ISP-HEADER01]
LCMXO2280C-M132(ISP) [ISP-HEADER01]
LCMXO2280C-MN100(ISP) [ISP-HEADER01]
LCMXO2280C-MN132(ISP) [ISP-HEADER01]
LCMXO2280C-T100(ISP) [ISP-HEADER01]
LCMXO2280C-T144(ISP) [ISP-HEADER01]
LCMXO2280C-TN100(ISP) [ISP-HEADER01]
LCMXO2280C-TN144(ISP) [ISP-HEADER01]
LCMXO2280E-FT256(ISP) [ISP-HEADER01]
LCMXO2280E-FT324(ISP) [ISP-HEADER01]
LCMXO2280E-FTN256(ISP) [ISP-HEADER01]
LCMXO2280E-FTN324(ISP) [ISP-HEADER01]
LCMXO2280E-M100(ISP) [ISP-HEADER01]
LCMXO2280E-M132(ISP) [ISP-HEADER01]
LCMXO2280E-MN100(ISP) [ISP-HEADER01]
LCMXO2280E-MN132(ISP) [ISP-HEADER01]
LCMXO2280E-T100(ISP) [ISP-HEADER01]
LCMXO2280E-T144(ISP) [ISP-HEADER01]
LCMXO2280E-TN100(ISP) [ISP-HEADER01]
LCMXO2280E-TN144(ISP) [ISP-HEADER01]
LCMXO256C-FT256(ISP) [ISP-HEADER01]
LCMXO256C-FT324(ISP) [ISP-HEADER01]
LCMXO256C-FTN256(ISP) [ISP-HEADER01]
LCMXO256C-FTN324(ISP) [ISP-HEADER01]

```

LCMXO256C-M100 (ISP) [ISP-HEADER01]
LCMXO256C-M132 (ISP) [ISP-HEADER01]
LCMXO256C-MN100 (ISP) [ISP-HEADER01]
LCMXO256C-MN132 (ISP) [ISP-HEADER01]
LCMXO256C-T100 (ISP) [ISP-HEADER01]
LCMXO256C-T144 (ISP) [ISP-HEADER01]
LCMXO256C-TN100 (ISP) [ISP-HEADER01]
LCMXO256C-TN144 (ISP) [ISP-HEADER01]
LCMXO256E-FT256 (ISP) [ISP-HEADER01]
LCMXO256E-FT324 (ISP) [ISP-HEADER01]
LCMXO256E-FTN256 (ISP) [ISP-HEADER01]
LCMXO256E-FTN324 (ISP) [ISP-HEADER01]
LCMXO256E-M100 (ISP) [ISP-HEADER01]
LCMXO256E-M132 (ISP) [ISP-HEADER01]
LCMXO256E-MN100 (ISP) [ISP-HEADER01]
LCMXO256E-MN132 (ISP) [ISP-HEADER01]
LCMXO256E-T100 (ISP) [ISP-HEADER01]
LCMXO256E-T144 (ISP) [ISP-HEADER01]
LCMXO256E-TN100 (ISP) [ISP-HEADER01]
LCMXO256E-TN144 (ISP) [ISP-HEADER01]
LCMXO640C-FT256 (ISP) [ISP-HEADER01]
LCMXO640C-FT324 (ISP) [ISP-HEADER01]
LCMXO640C-FTN256 (ISP) [ISP-HEADER01]
LCMXO640C-FTN324 (ISP) [ISP-HEADER01]
LCMXO640C-M100 (ISP) [ISP-HEADER01]
LCMXO640C-M132 (ISP) [ISP-HEADER01]
LCMXO640C-MN100 (ISP) [ISP-HEADER01]
LCMXO640C-MN132 (ISP) [ISP-HEADER01]
LCMXO640C-T100 (ISP) [ISP-HEADER01]
LCMXO640C-T144 (ISP) [ISP-HEADER01]
LCMXO640C-TN100 (ISP) [ISP-HEADER01]
LCMXO640C-TN144 (ISP) [ISP-HEADER01]
LCMXO640E-FT256 (ISP) [ISP-HEADER01]
LCMXO640E-FT324 (ISP) [ISP-HEADER01]
LCMXO640E-FTN256 (ISP) [ISP-HEADER01]
LCMXO640E-FTN324 (ISP) [ISP-HEADER01]
LCMXO640E-M100 (ISP) [ISP-HEADER01]
LCMXO640E-M132 (ISP) [ISP-HEADER01]
LCMXO640E-MN100 (ISP) [ISP-HEADER01]
LCMXO640E-MN132 (ISP) [ISP-HEADER01]
LCMXO640E-T100 (ISP) [ISP-HEADER01]
LCMXO640E-T144 (ISP) [ISP-HEADER01]
LCMXO640E-TN100 (ISP) [ISP-HEADER01]
LCMXO640E-TN144 (ISP) [ISP-HEADER01]
LFXP10C-3F256C (ISP) [ISP-HEADER01]
LFXP10C-3F256I (ISP) [ISP-HEADER01]
LFXP10C-3F388C (ISP) [ISP-HEADER01]
LFXP10C-3F388I (ISP) [ISP-HEADER01]
LFXP10C-3FN256C (ISP) [ISP-HEADER01]
LFXP10C-3FN256I (ISP) [ISP-HEADER01]
LFXP10C-3FN388C (ISP) [ISP-HEADER01]
LFXP10C-3FN388I (ISP) [ISP-HEADER01]
LFXP10C-4F256C (ISP) [ISP-HEADER01]
LFXP10C-4F256I (ISP) [ISP-HEADER01]
LFXP10C-4F388C (ISP) [ISP-HEADER01]
LFXP10C-4F388I (ISP) [ISP-HEADER01]
LFXP10C-4FN256C (ISP) [ISP-HEADER01]
LFXP10C-4FN256I (ISP) [ISP-HEADER01]
LFXP10C-4FN388C (ISP) [ISP-HEADER01]
LFXP10C-4FN388I (ISP) [ISP-HEADER01]
LFXP10C-5F256C (ISP) [ISP-HEADER01]
LFXP10C-5F256I (ISP) [ISP-HEADER01]
LFXP10C-5F388C (ISP) [ISP-HEADER01]
LFXP10C-5F388I (ISP) [ISP-HEADER01]
LFXP10C-5FN256C (ISP) [ISP-HEADER01]
LFXP10C-5FN256I (ISP) [ISP-HEADER01]
LFXP10C-5FN388C (ISP) [ISP-HEADER01]
LFXP10C-5FN388I (ISP) [ISP-HEADER01]
LFXP10E-3F256C (ISP) [ISP-HEADER01]
LFXP10E-3F256I (ISP) [ISP-HEADER01]
LFXP10E-3F388C (ISP) [ISP-HEADER01]
LFXP10E-3F388I (ISP) [ISP-HEADER01]
LFXP10E-3FN256C (ISP) [ISP-HEADER01]
LFXP10E-3FN256I (ISP) [ISP-HEADER01]
LFXP10E-3FN388C (ISP) [ISP-HEADER01]
LFXP10E-3FN388I (ISP) [ISP-HEADER01]
LFXP10E-4F256C (ISP) [ISP-HEADER01]
LFXP10E-4F256I (ISP) [ISP-HEADER01]
LFXP10E-4F388C (ISP) [ISP-HEADER01]
LFXP10E-4F388I (ISP) [ISP-HEADER01]
LFXP10E-4FN256C (ISP) [ISP-HEADER01]

LFXP10E-4FN256I (ISP) [ISP-HEADER01]
LFXP10E-4FN388C (ISP) [ISP-HEADER01]
LFXP10E-4FN388I (ISP) [ISP-HEADER01]
LFXP10E-5F256C (ISP) [ISP-HEADER01]
LFXP10E-5F256I (ISP) [ISP-HEADER01]
LFXP10E-5F388C (ISP) [ISP-HEADER01]
LFXP10E-5F388I (ISP) [ISP-HEADER01]
LFXP10E-5FN256C (ISP) [ISP-HEADER01]
LFXP10E-5FN256I (ISP) [ISP-HEADER01]
LFXP10E-5FN388C (ISP) [ISP-HEADER01]
LFXP10E-5FN388I (ISP) [ISP-HEADER01]
LFXP15C-3F256C (ISP) [ISP-HEADER01]
LFXP15C-3F256I (ISP) [ISP-HEADER01]
LFXP15C-3F388C (ISP) [ISP-HEADER01]
LFXP15C-3F388I (ISP) [ISP-HEADER01]
LFXP15C-3F484C (ISP) [ISP-HEADER01]
LFXP15C-3F484I (ISP) [ISP-HEADER01]
LFXP15C-3FN256C (ISP) [ISP-HEADER01]
LFXP15C-3FN256I (ISP) [ISP-HEADER01]
LFXP15C-3FN388C (ISP) [ISP-HEADER01]
LFXP15C-3FN388I (ISP) [ISP-HEADER01]
LFXP15C-3FN484C (ISP) [ISP-HEADER01]
LFXP15C-3FN484I (ISP) [ISP-HEADER01]
LFXP15C-4F256C (ISP) [ISP-HEADER01]
LFXP15C-4F256I (ISP) [ISP-HEADER01]
LFXP15C-4F388C (ISP) [ISP-HEADER01]
LFXP15C-4F388I (ISP) [ISP-HEADER01]
LFXP15C-4F484C (ISP) [ISP-HEADER01]
LFXP15C-4F484I (ISP) [ISP-HEADER01]
LFXP15C-4FN256C (ISP) [ISP-HEADER01]
LFXP15C-4FN256I (ISP) [ISP-HEADER01]
LFXP15C-4FN388C (ISP) [ISP-HEADER01]
LFXP15C-4FN388I (ISP) [ISP-HEADER01]
LFXP15C-4FN484C (ISP) [ISP-HEADER01]
LFXP15C-4FN484I (ISP) [ISP-HEADER01]
LFXP15C-5F256C (ISP) [ISP-HEADER01]
LFXP15C-5F256I (ISP) [ISP-HEADER01]
LFXP15C-5F388C (ISP) [ISP-HEADER01]
LFXP15C-5F388I (ISP) [ISP-HEADER01]
LFXP15C-5F484C (ISP) [ISP-HEADER01]
LFXP15C-5F484I (ISP) [ISP-HEADER01]
LFXP15C-5FN256C (ISP) [ISP-HEADER01]
LFXP15C-5FN256I (ISP) [ISP-HEADER01]
LFXP15C-5FN388C (ISP) [ISP-HEADER01]
LFXP15C-5FN388I (ISP) [ISP-HEADER01]
LFXP15C-5FN484C (ISP) [ISP-HEADER01]
LFXP15C-5FN484I (ISP) [ISP-HEADER01]
LFXP15E-3F256C (ISP) [ISP-HEADER01]
LFXP15E-3F256I (ISP) [ISP-HEADER01]
LFXP15E-3F388C (ISP) [ISP-HEADER01]
LFXP15E-3F388I (ISP) [ISP-HEADER01]
LFXP15E-3F484C (ISP) [ISP-HEADER01]
LFXP15E-3F484I (ISP) [ISP-HEADER01]
LFXP15E-3FN256C (ISP) [ISP-HEADER01]
LFXP15E-3FN256I (ISP) [ISP-HEADER01]
LFXP15E-3FN388C (ISP) [ISP-HEADER01]
LFXP15E-3FN388I (ISP) [ISP-HEADER01]
LFXP15E-3FN484C (ISP) [ISP-HEADER01]
LFXP15E-3FN484I (ISP) [ISP-HEADER01]
LFXP15E-4F256C (ISP) [ISP-HEADER01]
LFXP15E-4F256I (ISP) [ISP-HEADER01]
LFXP15E-4F388C (ISP) [ISP-HEADER01]
LFXP15E-4F388I (ISP) [ISP-HEADER01]
LFXP15E-4F484C (ISP) [ISP-HEADER01]
LFXP15E-4F484I (ISP) [ISP-HEADER01]
LFXP15E-4FN256C (ISP) [ISP-HEADER01]
LFXP15E-4FN256I (ISP) [ISP-HEADER01]
LFXP15E-4FN388C (ISP) [ISP-HEADER01]
LFXP15E-4FN388I (ISP) [ISP-HEADER01]
LFXP15E-4FN484C (ISP) [ISP-HEADER01]
LFXP15E-4FN484I (ISP) [ISP-HEADER01]
LFXP15E-5F256C (ISP) [ISP-HEADER01]
LFXP15E-5F256I (ISP) [ISP-HEADER01]
LFXP15E-5F388C (ISP) [ISP-HEADER01]
LFXP15E-5F388I (ISP) [ISP-HEADER01]
LFXP15E-5F484C (ISP) [ISP-HEADER01]
LFXP15E-5F484I (ISP) [ISP-HEADER01]
LFXP15E-5FN256C (ISP) [ISP-HEADER01]
LFXP15E-5FN256I (ISP) [ISP-HEADER01]
LFXP15E-5FN388C (ISP) [ISP-HEADER01]
LFXP15E-5FN388I (ISP) [ISP-HEADER01]

LFXP15E-5FN484C(ISP) [ISP-HEADER01]
LFXP15E-5FN484I(ISP) [ISP-HEADER01]
LFXP20C-3F256C(ISP) [ISP-HEADER01]
LFXP20C-3F256I(ISP) [ISP-HEADER01]
LFXP20C-3F388C(ISP) [ISP-HEADER01]
LFXP20C-3F388I(ISP) [ISP-HEADER01]
LFXP20C-3F484C(ISP) [ISP-HEADER01]
LFXP20C-3F484I(ISP) [ISP-HEADER01]
LFXP20C-3FN256C(ISP) [ISP-HEADER01]
LFXP20C-3FN256I(ISP) [ISP-HEADER01]
LFXP20C-3FN388C(ISP) [ISP-HEADER01]
LFXP20C-3FN388I(ISP) [ISP-HEADER01]
LFXP20C-3FN484C(ISP) [ISP-HEADER01]
LFXP20C-3FN484I(ISP) [ISP-HEADER01]
LFXP20C-4F256C(ISP) [ISP-HEADER01]
LFXP20C-4F256I(ISP) [ISP-HEADER01]
LFXP20C-4F388C(ISP) [ISP-HEADER01]
LFXP20C-4F388I(ISP) [ISP-HEADER01]
LFXP20C-4F484C(ISP) [ISP-HEADER01]
LFXP20C-4F484I(ISP) [ISP-HEADER01]
LFXP20C-4FN256C(ISP) [ISP-HEADER01]
LFXP20C-4FN256I(ISP) [ISP-HEADER01]
LFXP20C-4FN388C(ISP) [ISP-HEADER01]
LFXP20C-4FN388I(ISP) [ISP-HEADER01]
LFXP20C-4FN484C(ISP) [ISP-HEADER01]
LFXP20C-4FN484I(ISP) [ISP-HEADER01]
LFXP20C-5F256C(ISP) [ISP-HEADER01]
LFXP20C-5F256I(ISP) [ISP-HEADER01]
LFXP20C-5F388C(ISP) [ISP-HEADER01]
LFXP20C-5F388I(ISP) [ISP-HEADER01]
LFXP20C-5F484C(ISP) [ISP-HEADER01]
LFXP20C-5F484I(ISP) [ISP-HEADER01]
LFXP20C-5FN256C(ISP) [ISP-HEADER01]
LFXP20C-5FN256I(ISP) [ISP-HEADER01]
LFXP20C-5FN388C(ISP) [ISP-HEADER01]
LFXP20C-5FN388I(ISP) [ISP-HEADER01]
LFXP20C-5FN484C(ISP) [ISP-HEADER01]
LFXP20C-5FN484I(ISP) [ISP-HEADER01]
LFXP20E-3F256C(ISP) [ISP-HEADER01]
LFXP20E-3F256I(ISP) [ISP-HEADER01]
LFXP20E-3F388C(ISP) [ISP-HEADER01]
LFXP20E-3F388I(ISP) [ISP-HEADER01]
LFXP20E-3F484C(ISP) [ISP-HEADER01]
LFXP20E-3F484I(ISP) [ISP-HEADER01]
LFXP20E-3FN256C(ISP) [ISP-HEADER01]
LFXP20E-3FN256I(ISP) [ISP-HEADER01]
LFXP20E-3FN388C(ISP) [ISP-HEADER01]
LFXP20E-3FN388I(ISP) [ISP-HEADER01]
LFXP20E-3FN484C(ISP) [ISP-HEADER01]
LFXP20E-3FN484I(ISP) [ISP-HEADER01]
LFXP20E-4F256C(ISP) [ISP-HEADER01]
LFXP20E-4F256I(ISP) [ISP-HEADER01]
LFXP20E-4F388C(ISP) [ISP-HEADER01]
LFXP20E-4F388I(ISP) [ISP-HEADER01]
LFXP20E-4F484C(ISP) [ISP-HEADER01]
LFXP20E-4F484I(ISP) [ISP-HEADER01]
LFXP20E-4FN256C(ISP) [ISP-HEADER01]
LFXP20E-4FN256I(ISP) [ISP-HEADER01]
LFXP20E-4FN388C(ISP) [ISP-HEADER01]
LFXP20E-4FN388I(ISP) [ISP-HEADER01]
LFXP20E-4FN484C(ISP) [ISP-HEADER01]
LFXP20E-4FN484I(ISP) [ISP-HEADER01]
LFXP20E-5F256C(ISP) [ISP-HEADER01]
LFXP20E-5F256I(ISP) [ISP-HEADER01]
LFXP20E-5F388C(ISP) [ISP-HEADER01]
LFXP20E-5F388I(ISP) [ISP-HEADER01]
LFXP20E-5F484C(ISP) [ISP-HEADER01]
LFXP20E-5F484I(ISP) [ISP-HEADER01]
LFXP20E-5FN256C(ISP) [ISP-HEADER01]
LFXP20E-5FN256I(ISP) [ISP-HEADER01]
LFXP20E-5FN388C(ISP) [ISP-HEADER01]
LFXP20E-5FN388I(ISP) [ISP-HEADER01]
LFXP20E-5FN484C(ISP) [ISP-HEADER01]
LFXP20E-5FN484I(ISP) [ISP-HEADER01]
LFXP3C-3Q208C(ISP) [ISP-HEADER01]
LFXP3C-3Q208I(ISP) [ISP-HEADER01]
LFXP3C-3QN208C(ISP) [ISP-HEADER01]
LFXP3C-3QN208I(ISP) [ISP-HEADER01]
LFXP3C-3T100C(ISP) [ISP-HEADER01]
LFXP3C-3T100I(ISP) [ISP-HEADER01]
LFXP3C-3T144C(ISP) [ISP-HEADER01]

LFXP3C-3T144I (ISP) [ISP-HEADER01]
LFXP3C-3TN100C (ISP) [ISP-HEADER01]
LFXP3C-3TN100I (ISP) [ISP-HEADER01]
LFXP3C-3TN144C (ISP) [ISP-HEADER01]
LFXP3C-3TN144I (ISP) [ISP-HEADER01]
LFXP3C-4Q208C (ISP) [ISP-HEADER01]
LFXP3C-4Q208I (ISP) [ISP-HEADER01]
LFXP3C-4QN208C (ISP) [ISP-HEADER01]
LFXP3C-4QN208I (ISP) [ISP-HEADER01]
LFXP3C-4T100C (ISP) [ISP-HEADER01]
LFXP3C-4T100I (ISP) [ISP-HEADER01]
LFXP3C-4T144C (ISP) [ISP-HEADER01]
LFXP3C-4T144I (ISP) [ISP-HEADER01]
LFXP3C-4TN100C (ISP) [ISP-HEADER01]
LFXP3C-4TN100I (ISP) [ISP-HEADER01]
LFXP3C-4TN144C (ISP) [ISP-HEADER01]
LFXP3C-4TN144I (ISP) [ISP-HEADER01]
LFXP3C-5Q208C (ISP) [ISP-HEADER01]
LFXP3C-5Q208I (ISP) [ISP-HEADER01]
LFXP3C-5QN208C (ISP) [ISP-HEADER01]
LFXP3C-5QN208I (ISP) [ISP-HEADER01]
LFXP3C-5T100C (ISP) [ISP-HEADER01]
LFXP3C-5T100I (ISP) [ISP-HEADER01]
LFXP3C-5T144C (ISP) [ISP-HEADER01]
LFXP3C-5T144I (ISP) [ISP-HEADER01]
LFXP3C-5TN100C (ISP) [ISP-HEADER01]
LFXP3C-5TN100I (ISP) [ISP-HEADER01]
LFXP3C-5TN144C (ISP) [ISP-HEADER01]
LFXP3C-5TN144I (ISP) [ISP-HEADER01]
LFXP3E-3Q208C (ISP) [ISP-HEADER01]
LFXP3E-3Q208I (ISP) [ISP-HEADER01]
LFXP3E-3QN208C (ISP) [ISP-HEADER01]
LFXP3E-3QN208I (ISP) [ISP-HEADER01]
LFXP3E-3T100C (ISP) [ISP-HEADER01]
LFXP3E-3T100I (ISP) [ISP-HEADER01]
LFXP3E-3T144C (ISP) [ISP-HEADER01]
LFXP3E-3T144I (ISP) [ISP-HEADER01]
LFXP3E-3TN100C (ISP) [ISP-HEADER01]
LFXP3E-3TN100I (ISP) [ISP-HEADER01]
LFXP3E-3TN144C (ISP) [ISP-HEADER01]
LFXP3E-3TN144I (ISP) [ISP-HEADER01]
LFXP3E-4Q208C (ISP) [ISP-HEADER01]
LFXP3E-4Q208I (ISP) [ISP-HEADER01]
LFXP3E-4QN208C (ISP) [ISP-HEADER01]
LFXP3E-4QN208I (ISP) [ISP-HEADER01]
LFXP3E-4T100C (ISP) [ISP-HEADER01]
LFXP3E-4T100I (ISP) [ISP-HEADER01]
LFXP3E-4T144C (ISP) [ISP-HEADER01]
LFXP3E-4T144I (ISP) [ISP-HEADER01]
LFXP3E-4TN100C (ISP) [ISP-HEADER01]
LFXP3E-4TN100I (ISP) [ISP-HEADER01]
LFXP3E-4TN144C (ISP) [ISP-HEADER01]
LFXP3E-4TN144I (ISP) [ISP-HEADER01]
LFXP3E-5Q208C (ISP) [ISP-HEADER01]
LFXP3E-5Q208I (ISP) [ISP-HEADER01]
LFXP3E-5QN208C (ISP) [ISP-HEADER01]
LFXP3E-5QN208I (ISP) [ISP-HEADER01]
LFXP3E-5T100C (ISP) [ISP-HEADER01]
LFXP3E-5T100I (ISP) [ISP-HEADER01]
LFXP3E-5T144C (ISP) [ISP-HEADER01]
LFXP3E-5T144I (ISP) [ISP-HEADER01]
LFXP3E-5TN100C (ISP) [ISP-HEADER01]
LFXP3E-5TN100I (ISP) [ISP-HEADER01]
LFXP3E-5TN144C (ISP) [ISP-HEADER01]
LFXP3E-5TN144I (ISP) [ISP-HEADER01]
LFXP6C-3F256C (ISP) [ISP-HEADER01]
LFXP6C-3F256I (ISP) [ISP-HEADER01]
LFXP6C-3FN256C (ISP) [ISP-HEADER01]
LFXP6C-3FN256I (ISP) [ISP-HEADER01]
LFXP6C-3Q208C (ISP) [ISP-HEADER01]
LFXP6C-3Q208I (ISP) [ISP-HEADER01]
LFXP6C-3QN208C (ISP) [ISP-HEADER01]
LFXP6C-3QN208I (ISP) [ISP-HEADER01]
LFXP6C-3T144C (ISP) [ISP-HEADER01]
LFXP6C-3T144I (ISP) [ISP-HEADER01]
LFXP6C-3TN144C (ISP) [ISP-HEADER01]
LFXP6C-3TN144I (ISP) [ISP-HEADER01]
LFXP6C-4F256C (ISP) [ISP-HEADER01]
LFXP6C-4F256I (ISP) [ISP-HEADER01]
LFXP6C-4FN256C (ISP) [ISP-HEADER01]
LFXP6C-4FN256I (ISP) [ISP-HEADER01]

LFXP6C-4Q208C(ISP) [ISP-HEADER01]
 LFXP6C-4Q208I(ISP) [ISP-HEADER01]
 LFXP6C-4QN208C(ISP) [ISP-HEADER01]
 LFXP6C-4QN208I(ISP) [ISP-HEADER01]
 LFXP6C-4T144C(ISP) [ISP-HEADER01]
 LFXP6C-4T144I(ISP) [ISP-HEADER01]
 LFXP6C-4TN144C(ISP) [ISP-HEADER01]
 LFXP6C-4TN144I(ISP) [ISP-HEADER01]
 LFXP6C-5F256C(ISP) [ISP-HEADER01]
 LFXP6C-5F256I(ISP) [ISP-HEADER01]
 LFXP6C-5FN256C(ISP) [ISP-HEADER01]
 LFXP6C-5FN256I(ISP) [ISP-HEADER01]
 LFXP6C-5Q208C(ISP) [ISP-HEADER01]
 LFXP6C-5Q208I(ISP) [ISP-HEADER01]
 LFXP6C-5QN208C(ISP) [ISP-HEADER01]
 LFXP6C-5QN208I(ISP) [ISP-HEADER01]
 LFXP6C-5T144C(ISP) [ISP-HEADER01]
 LFXP6C-5T144I(ISP) [ISP-HEADER01]
 LFXP6C-5TN144C(ISP) [ISP-HEADER01]
 LFXP6C-5TN144I(ISP) [ISP-HEADER01]
 LFXP6E-3F256C(ISP) [ISP-HEADER01]
 LFXP6E-3F256I(ISP) [ISP-HEADER01]
 LFXP6E-3FN256C(ISP) [ISP-HEADER01]
 LFXP6E-3FN256I(ISP) [ISP-HEADER01]
 LFXP6E-3Q208C(ISP) [ISP-HEADER01]
 LFXP6E-3Q208I(ISP) [ISP-HEADER01]
 LFXP6E-3QN208C(ISP) [ISP-HEADER01]
 LFXP6E-3QN208I(ISP) [ISP-HEADER01]
 LFXP6E-3T144C(ISP) [ISP-HEADER01]
 LFXP6E-3T144I(ISP) [ISP-HEADER01]
 LFXP6E-3TN144C(ISP) [ISP-HEADER01]
 LFXP6E-3TN144I(ISP) [ISP-HEADER01]
 LFXP6E-4F256C(ISP) [ISP-HEADER01]
 LFXP6E-4F256I(ISP) [ISP-HEADER01]
 LFXP6E-4FN256C(ISP) [ISP-HEADER01]
 LFXP6E-4FN256I(ISP) [ISP-HEADER01]
 LFXP6E-4Q208C(ISP) [ISP-HEADER01]
 LFXP6E-4Q208I(ISP) [ISP-HEADER01]
 LFXP6E-4QN208C(ISP) [ISP-HEADER01]
 LFXP6E-4QN208I(ISP) [ISP-HEADER01]
 LFXP6E-4T144C(ISP) [ISP-HEADER01]
 LFXP6E-4T144I(ISP) [ISP-HEADER01]
 LFXP6E-4TN144C(ISP) [ISP-HEADER01]
 LFXP6E-4TN144I(ISP) [ISP-HEADER01]
 LFXP6E-5F256C(ISP) [ISP-HEADER01]
 LFXP6E-5F256I(ISP) [ISP-HEADER01]
 LFXP6E-5FN256C(ISP) [ISP-HEADER01]
 LFXP6E-5FN256I(ISP) [ISP-HEADER01]
 LFXP6E-5Q208C(ISP) [ISP-HEADER01]
 LFXP6E-5Q208I(ISP) [ISP-HEADER01]
 LFXP6E-5QN208C(ISP) [ISP-HEADER01]
 LFXP6E-5QN208I(ISP) [ISP-HEADER01]
 LFXP6E-5T144C(ISP) [ISP-HEADER01]
 LFXP6E-5T144I(ISP) [ISP-HEADER01]
 LFXP6E-5TN144C(ISP) [ISP-HEADER01]
 LFXP6E-5TN144I(ISP) [ISP-HEADER01]

LG Semicon

DRAM & SRAM

GM76C256CL	GM76C256CL@SSOP28 [(SA430T)]
GM76C256CL@TSOP28 [(SA630)]	GM76C256CLL
GM76C256CLL@SSOP28 [(SA430T)]	GM76C256CLL@TSOP28 [(SA630)]
GM76C8128CL	GM76C8128CL@SSOP32 [(SA438T)]
GM76C8128CL@TSOP32 [(SA410T)]	GM76C8128CL@VSOP32 [(SA620)]
GM76C8128CLL	GM76C8128CLL@SSOP32 [(SA438T)]
GM76C8128CLL@TSOP32 [(SA410T)]	GM76C8128CLL@VSOP32 [(SA620)]
GM76C888AL	GM76C888AL@SSOP28 [(SA430T)]
GM76C888AL@TSOP28 [(SA643)]	GM76U256CL
GM76U256CL@SSOP28 [(SA430T)]	GM76U256CL@TSOP28 [(SA643)]
GM76U256CLL	GM76U256CLL@SSOP28 [(SA430T)]
GM76U256CLL@TSOP28 [(SA643)]	GM76U8128CL
GM76U8128CL@SSOP32 [(SA438T)]	GM76U8128CL@TSOP32 [(SA410T)]
GM76U8128CL@VSOP32 [(SA620)]	GM76U8128CLL
GM76U8128CLL@SSOP32 [(SA438T)]	GM76U8128CLL@TSOP32 [(SA410T)]
GM76U8128CLL@VSOP32 [(SA620)]	GM76U8128DL
GM76U8128DL@SSOP32 [(SA438T)]	GM76U8128DL@TSOP32 [(SA410T)]

GM76U8128DL@VSOP32 [(SA620)]	GM76U8128DLL
GM76U8128DLL@SSOP32 [(SA438T)]	GM76U8128DLL@TSOP32 [(SA410T)]
GM76U8128DLL@VSOP32 [(SA620)]	GM76U8512L
GM76U8512L@SSOP32 [(SA438T)]	GM76U8512L@TSOP32 [(SA410T)]
GM76U8512L@VSOP32 [(SA620)]	GM76U8512LL
GM76U8512LL@SSOP32 [(SA438T)]	GM76U8512LL@TSOP32 [(SA410T)]
GM76U8512LL@VSOP32 [(SA620)]	GM76V256CL
GM76V256CL@SSOP28 [(SA430T)]	GM76V256CL@TSOP28 [(SA630)]
GM76V256CLL	GM76V256CLL@SSOP28 [(SA430T)]
GM76V256CLL@TSOP28 [(SA630)]	GM76V8128CL
GM76V8128CL@SSOP32 [(SA438T)]	GM76V8128CL@TSOP32 [(SA410T)]
GM76V8128CL@VSOP32 [(SA620)]	GM76V8128CLL
GM76V8128CLL@SSOP32 [(SA438T)]	GM76V8128CLL@TSOP32 [(SA410T)]
GM76V8128CLL@VSOP32 [(SA620)]	GM76V8128DL
GM76V8128DL@SSOP32 [(SA438T)]	GM76V8128DL@TSOP32 [(SA410T)]
GM76V8128DL@VSOP32 [(SA620)]	GM76V8128DLL
GM76V8128DLL@SSOP32 [(SA438T)]	GM76V8128DLL@TSOP32 [(SA410T)]
GM76V8128DLL@VSOP32 [(SA620)]	GM76V8512L
GM76V8512L@SSOP32 [(SA438T)]	GM76V8512L@TSOP32 [(SA410T)]
GM76V8512L@VSOP32 [(SA620)]	GM76V8512LL
GM76V8512LL@SSOP32 [(SA438T)]	GM76V8512LL@TSOP32 [(SA410T)]
GM76V8512LL@VSOP32 [(SA620)]	GM77C8128A
GM77C8128A@SSOP32 [(SA438T)]	GM77C8128A@TSOP32 [(SA410T)]
GM77C8128A@VSOP32 [(SA620)]	

MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20 [(SA404)]
GMS97C2051	GMS97C2051@SOIC20 [(SA404)]
GMS97C51	GMS97C51@PLCC44 [(SA244)]
GMS97C51@TQFP44 [(SA245A)]	GMS97C52
GMS97C52@PLCC44 [(SA244)]	GMS97C52@TQFP44 [(SA245A)]
GMS97C54	GMS97C54@PLCC44 [(SA244)]
GMS97C54@TQFP44 [(SA245A)]	GMS97C56
GMS97C56@PLCC44 [(SA244)]	GMS97C56@TQFP44 [(SA245A)]
GMS97C58	GMS97C58@PLCC44 [(SA244)]
GMS97C58@TQFP44 [(SA245A)]	GMS97L1051
GMS97L1051@SOIC20 [(SA404)]	GMS97L2051
GMS97L2051@SOIC20 [(SA404)]	GMS97L51
GMS97L51@PLCC44 [(SA244)]	GMS97L51@TQFP44 [(SA245A)]
GMS97L52	GMS97L52@PLCC44 [(SA244)]
GMS97L52@TQFP44 [(SA245A)]	GMS97L54
GMS97L54@PLCC44 [(SA244)]	GMS97L54@TQFP44 [(SA245A)]
GMS97L56	GMS97L56@PLCC44 [(SA244)]
GMS97L56@TQFP44 [(SA245A)]	GMS97L58
GMS97L58@PLCC44 [(SA244)]	GMS97L58@TQFP44 [(SA245A)]
GMS99C52	GMS99C52@PLCC44 [(SA244)]
GMS99C52@TQFP44 [(SA245A)]	GMS99C58
GMS99C58@PLCC44 [(SA244)]	GMS99C58@TQFP44 [(SA245A)]

LINKSMART

E(E) PROM/FRAM/NVRAM

L24C02	L24C02@SSOP8 [(SA602A)]
L24C02@TSOP8 [(SA026)]	L24C04
L24C04@SSOP8 [(SA602A)]	L24C04@TSOP8 [(SA026)]
L29004C	L29004C@PLCC32 [(SA015A1T)]
L29004C@TSOP32 [(SA620)]	L29S160F@TSOP48 [(SA247-B005)]
L29S160F-B@TSOP48 [(SA247-B005)]	L29S400F@PSOP44 [(SA638)]
L29S400F@TSOP48 [(SA247-B005)]	L29S400F-B@PSOP44 [(SA638)]
L29S400F-B@TSOP48 [(SA247-B005)]	L29S800F@TSOP48 [(SA247-B005)]
L29S800F-B@TSOP48 [(SA247-B005)]	L29W800E@TSOP48 [(SA247-B005)]
L29W800E-B@TSOP48 [(SA247-B005)]	LST28001
LST28001@PLCC32 [(SA015A1T)]	LST28001@TSOP32 [(SA620)]
LST28002	LST28002@PLCC32 [(SA015A1T)]
LST28002@TSOP32 [(SA620)]	LST28004
LST28004@PLCC32 [(SA015A1T)]	LST28004@TSOP32 [(SA620)]

MACRONIX

E(E) PROM/FRAM/NVRAM

```

KH25L1005                                KH25L1005(ISP) [ISP-HEADER01]
KH25L1005@SON8 [(SA683)]
KH25L1005@SON8(ISP) [ISP-HEADER01]
KH25L1005@SOP8 [(SA602A)]
KH25L1005@SOP8(ISP) [ISP-HEADER01]
KH25L1005A                                KH25L1005A@SON8 [(SA683)]
KH25L1005A@SOP8 [(SA602A)]
KH25L12805D@SON8(Fast Mode) [(SA684)]
KH25L12805D@SOP16(Fast Mode) [(SA404)]
KH25L12805N@SOP16 [(SA404)]
KH25L12805N@SOP16(Fast Mode) [(SA404)]
KH25L1602@SOP28 [(SA630)]                KH25L1605@SON8 [(SA684)]
KH25L1605@SON8(Fast Mode) [(SA684)]
KH25L1605@SOP16 [(SA404)]
KH25L1605@SOP16(Fast Mode) [(SA404)]
KH25L1605A@SON8 [(SA684)]
KH25L1605A@SON8(Fast Mode) [(SA684)]
KH25L1605A@SOP16 [(SA404)]
KH25L1605A@SOP16(Fast Mode) [(SA404)]
KH25L1605A@SOP8 [(SA023A)]
KH25L1605A@SOP8(Fast Mode) [(SA023A)]
KH25L1605D@SON8 [(SA684)]
KH25L1605D@SON8(Fast Mode) [(SA683)]
KH25L1605D@SOP16 [(SA404)]
KH25L1605D@SOP16(Fast Mode) [(SA404)]
KH25L1605D@SOP8(150)(Fast Mode) [(SA602A)]
KH25L1605D@SOP8(200)(Fast Mode) [(SA605B)]
KH25L1636DMI@SOP8 [(SA602A)]             KH25L1636DM2I@SOP8 [(SA605B)]
KH25L1636DMI@SOP16 [(SA404)]             KH25L1636DZNI@WSON8 [(SA683)]
KH25L2005                                KH25L2005(ISP) [ISP-HEADER01]
KH25L2005@SON8 [(SA683)]
KH25L2005@SON8(ISP) [ISP-HEADER01]
KH25L2005@SOP8 [(SA602A)]
KH25L2005@SOP8(ISP) [ISP-HEADER01]
KH25L2025                                KH25L2025@SON8 [(SA683)]
KH25L2025@SOP8 [(SA602A)]                KH25L3202@SOP32 [(SA438T)]
KH25L3205@SOP16 [(SA404)]
KH25L3205@SOP16(Fast Mode) [(SA404)]
KH25L3205@SOP8 [(SA023A)]
KH25L3205@SOP8(Fast Mode) [(SA023A)]
KH25L3205A@SON8 [(SA684)]
KH25L3205A@SON8(Fast Mode) [(SA684)]
KH25L3205A@SOP16 [(SA404)]
KH25L3205A@SOP16(Fast Mode) [(SA404)]
KH25L3205A@SOP8 [(SA023A)]
KH25L3205A@SOP8(Fast Mode) [(SA023A)]
KH25L3205D@SON8(Fast Mode) [(SA683)]
KH25L3205D@SOP16 [(SA404)]
KH25L3205D@SOP16(Fast Mode) [(SA404)]
KH25L3205D@SOP8 [(SA023A)]
KH25L3205D@SOP8(Fast Mode) [(SA605B)]
KH25L3236DM2I@SOP8 [(SA605B)]             KH25L3236DMI@SOP16 [(SA404)]
KH25L3236DZNI@WSON8 [(SA683)]            KH25L4005
KH25L4005(150mil)@SOP8 [(SA602A)]
KH25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]
KH25L4005(209mil)@SOP8 [(SA023A)]
KH25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]
KH25L4005(ISP) [ISP-HEADER01]             KH25L4005@SON8 [(SA683)]
KH25L4005@SON8(ISP) [ISP-HEADER01]
KH25L4005A
KH25L4005A(150mil)@SOP8 [(SA602A)]
KH25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]
KH25L4005A(209mil)@SOP8 [(SA023A)]
KH25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]
KH25L4005A(ISP) [ISP-HEADER01]           KH25L4005A@SON8 [(SA683)]
KH25L4005A@SON8(ISP) [ISP-HEADER01]
KH25L4025A
KH25L4025A(150mil)@SOP8 [(SA602A)]
KH25L4025A(209mil)@SOP8 [(SA023A)]
KH25L4025A@SON8 [(SA683)]                KH25L512@SON8 [(SA683)]
KH25L512@SOP8 [(SA602A)]                 KH25L512A
KH25L512A@SON8 [(SA683)]                 KH25L512A@SOP8 [(SA602A)]
KH25L6402@SOP32 [(SA438T)]               KH25L6402A@SOP28 [(SA630)]
KH25L6405@SOP16 [(SA404)]
KH25L6405@SOP16(Fast Mode) [(SA404)]
KH25L6405@SOP8 [(SA023A)]
KH25L6405@SOP8(Fast Mode) [(SA023A)]
KH25L6405D@SON8(Fast Mode) [(SA684)]
KH25L6405D@SOP16 [(SA404)]
KH25L6405D@SOP16(Fast Mode) [(SA404)]
KH25L6405D@SOP8 [(SA023A)]              KH25L8005

```

KH25L8005(150mil)@SOP8 [(SA602A)]
 KH25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]
 KH25L8005(209mil)@SOP8 [(SA023A)]
 KH25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]
 KH25L8005(ISP) [ISP-HEADER01] KH25L8005@SON8 [(SA683)]
 KH25L8005@SON8(ISP) [ISP-HEADER01]
 KH25L802@SOP28 [(SA630)] KH25L8025
 KH25L8025(150mil)@SOP8 [(SA602A)]
 KH25L8025(209mil)@SOP8 [(SA023A)]
 KH25L8025@SON8 [(SA683)] KH25L8036D
 KH25L8036D@SOP16 [(SA404)]
 KH25L8036D@SOP8[150 mil] [(SA602A)]
 KH25L8036D@SOP8[200 mil] [(SA023A)]
 KH25L8036D@WSON8 [(SA683)] KH29LV004CB@PLCC32 [(SA015A1T)]
 KH29LV004CB@TSOP40 [(SA409T)] KH29LV004CT@PLCC32 [(SA015A1T)]
 KH29LV004CT@TSOP40 [(SA409T)] KH29LV008CB@TSOP40 [(SA409T)]
 KH29LV008CT@TSOP40 [(SA409T)] KH29LV040C
 KH29LV040C@PLCC32 [(SA015A1T)] MX25L1005
 MX25L1005(ISP) [ISP-HEADER01] MX25L1005@SON8 [(SA683)]
 MX25L1005@SON8(ISP) [ISP-HEADER01]
 MX25L1005@SOP8 [(SA602A)]
 MX25L1005@SOP8(ISP) [ISP-HEADER01]
 MX25L1005A MX25L1005A@SON8 [(SA683)]
 MX25L1005A@SOP8 [(SA602A)]
 MX25L12805D@SON8(512bit OTP) [(SA684)]
 MX25L12805D@SON8(Fast Mode) [(SA684)]
 MX25L12805D@SOP16(512bit OTP) [(SA404)]
 MX25L12805D@SOP16(Fast Mode) [(SA404)]
 MX25L12805N@SOP16 [(SA404)]
 MX25L12805N@SOP16(Fast Mode) [(SA404)]
 MX25L12845E@SOP16 [(SA404)] MX25L12845E@WSON8 [(SA684)]
 MX25L12855E@SOP16 [(SA404)] MX25L12855E@TFBGA24 [(TA088)]
 MX25L1602@SOP28 [(SA630)] MX25L1605@SON8 [(SA684)]
 MX25L1605@SON8(Fast Mode) [(SA684)]
 MX25L1605@SOP16 [(SA404)]
 MX25L1605@SOP16(Fast Mode) [(SA404)]
 MX25L1605A@SON8 [(SA684)]
 MX25L1605A@SON8(Fast Mode) [(SA684)]
 MX25L1605A@SOP16 [(SA404)]
 MX25L1605A@SOP16(Fast Mode) [(SA404)]
 MX25L1605A@SOP8 [(SA023A)]
 MX25L1605A@SOP8(Fast Mode) [(SA023A)]
 MX25L1605D@SON8 [(SA684)]
 MX25L1605D@SON8(512bit OTP) [(SA683)]
 MX25L1605D@SON8(Fast Mode) [(SA683)]
 MX25L1605D@SOP16 [(SA404)]
 MX25L1605D@SOP16(512bit OTP) [(SA404)]
 MX25L1605D@SOP16(Fast Mode) [(SA404)]
 MX25L1605D@SOP8(150)(512bit OTP) [(SA602A)]
 MX25L1605D@SOP8(150)(Fast Mode) [(SA602A)]
 MX25L1605D@SOP8(200)(512bit OTP) [(SA605B)]
 MX25L1605D@SOP8(200)(Fast Mode) [(SA605B)]
 MX25L1605D@USON8 [(SA744)]
 MX25L1605D@USON8(Fast Mode) [(SA744)]
 MX25L1615D@SOP16 [(SA404)] MX25L1615D@SOP8 [(SA023A)]
 MX25L1635DMI@SOP8 [(SA602A)] MX25L1635DM2I@SOP8 [(SA605B)]
 MX25L1635DMI@SOP16 [(SA404)] MX25L1635DZNI@WSON8 [(SA683)]
 MX25L1636DMI@SOP8 [(SA602A)] MX25L1636DM2I@SOP8 [(SA605B)]
 MX25L1636DMI@SOP16 [(SA404)] MX25L1636DZNI@WSON8 [(SA683)]
 MX25L2005 MX25L2005(ISP) [ISP-HEADER01]
 MX25L2005@SON8 [(SA683)]
 MX25L2005@SON8(ISP) [ISP-HEADER01]
 MX25L2005@SOP8 [(SA602A)]
 MX25L2005@SOP8(ISP) [ISP-HEADER01]
 MX25L2025 MX25L2025@SON8 [(SA683)]
 MX25L2025@SOP8 [(SA602A)] MX25L2026C@SOP8 [(SA602A)]
 MX25L3202@SOP32 [(SA438T)] MX25L3205@SOP16 [(SA404)]
 MX25L3205@SOP16(Fast Mode) [(SA404)]
 MX25L3205@SOP8 [(SA023A)]
 MX25L3205@SOP8(Fast Mode) [(SA023A)]
 MX25L3205A@SON8 [(SA684)]
 MX25L3205A@SON8(Fast Mode) [(SA684)]
 MX25L3205A@SOP16 [(SA404)]
 MX25L3205A@SOP16(Fast Mode) [(SA404)]
 MX25L3205A@SOP16(Parallel Mode) [(SA404)]
 MX25L3205A@SOP8 [(SA023A)]
 MX25L3205A@SOP8(Fast Mode) [(SA023A)]
 MX25L3205D@SON8(512bit OTP) [(SA683)]
 MX25L3205D@SON8(Fast Mode) [(SA683)]
 MX25L3205D@SOP16 [(SA404)]
 MX25L3205D@SOP16(512bit OTP) [(SA404)]

MX25L3205D@SOP16(Fast Mode) [(SA404)]
 MX25L3205D@SOP8 [(SA023A)]
 MX25L3205D@SOP8(512bit OTP) [(SA605B)]
 MX25L3205D@SOP8(Fast Mode) [(SA605B)]
 MX25L3205D@USON8 [(SA744)]
 MX25L3205D@USON8(Fast Mode) [(SA744)]
 MX25L3215D@SOP16 [(SA404)]
 MX25L3215D@SOP8 [(SA023A)]
 MX25L3235DMI@SOP8 [(SA605B)]
 MX25L3235DMI@SOP16 [(SA404)]
 MX25L3235DZNI@WSON8 [(SA683)]
 MX25L3236DMI@SOP16 [(SA404)]
 MX25L3236DMI@SOP8 [(SA605B)]
 MX25L3236DZNI@WSON8 [(SA683)]
 MX25L3237D@SOP16 [(SA404)]
 MX25L3237D@WSON8 [(SA683)]
 MX25L4005
 MX25L4005(150mil)@SOP8 [(SA602A)]
 MX25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L4005(209mil)@SOP8 [(SA023A)]
 MX25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L4005(ISP) [ISP-HEADER01]
 MX25L4005@SON8 [(SA683)]
 MX25L4005@SON8(ISP) [ISP-HEADER01]
 MX25L4005A
 MX25L4005A(150mil)@SOP8 [(SA602A)]
 MX25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L4005A(209mil)@SOP8 [(SA023A)]
 MX25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L4005A(ISP) [ISP-HEADER01]
 MX25L4005A@SON8 [(SA683)]
 MX25L4005A@SON8(ISP) [ISP-HEADER01]
 MX25L4025@SOP8 [(SA602A)]
 MX25L4025A
 MX25L4025A(150mil)@SOP8 [(SA602A)]
 MX25L4025A(209mil)@SOP8 [(SA023A)]
 MX25L4025A@SON8 [(SA683)]
 MX25L512@SOP8 [(SA602A)]
 MX25L512A@SON8 [(SA683)]
 MX25L512A@SOP8 [(SA602A)]
 MX25L6402@SOP32 [(SA438T)]
 MX25L6402A@SOP28 [(SA630)]
 MX25L6405@SOP16 [(SA404)]
 MX25L6405@SOP16(Fast Mode) [(SA404)]
 MX25L6405@SOP8 [(SA023A)]
 MX25L6405@SOP8(Fast Mode) [(SA023A)]
 MX25L6405D@SON8(512bit OTP) [(SA684)]
 MX25L6405D@SON8(Fast Mode) [(SA684)]
 MX25L6405D@SOP16 [(SA404)]
 MX25L6405D@SOP16(512bit OTP) [(SA404)]
 MX25L6405D@SOP16(Fast Mode) [(SA404)]
 MX25L6405D@SOP8 [(SA023A)]
 MX25L6415D@SOP16 [(SA404)]
 MX25L6415D@SOP8 [(SA023A)]
 MX25L6445E@SOP8 [(SA023A)]
 MX25L6445E@WSON8 [(SA684)]
 MX25L6446E@SOP16 [(SA404)]
 MX25L6446E@SOP8 [(SA023A)]
 MX25L6446E@WSON8 [(SA684)]
 MX25L6455E@SOP16 [(SA404)]
 MX25L6455E@SOP8 [(SA023A)]
 MX25L6455E@TFBGA24 [(TA088)]
 MX25L8005
 MX25L8005(150mil)@SOP8 [(SA602A)]
 MX25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L8005(209mil)@SOP8 [(SA023A)]
 MX25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]
 MX25L8005(ISP) [ISP-HEADER01]
 MX25L8005@SON8 [(SA683)]
 MX25L8005@SON8(ISP) [ISP-HEADER01]
 MX25L802@SOP28 [(SA630)]
 MX25L8025
 MX25L8025(150mil)@SOP8 [(SA602A)]
 MX25L8025(209mil)@SOP8 [(SA023A)]
 MX25L8025@SON8 [(SA683)]
 MX25L8036D
 MX25L8036D@SOP16 [(SA602A)]
 MX25L8036D@SOP8[150 mil] [(SA602A)]
 MX25L8036D@SOP8[200 mil] [(SA023A)]
 MX25L8036D@WSON8 [(SA683)]
 MX25U1635@USON8 [(SA602A)]
 MX25U1635@USON8(4*4mm) [(SA744)]
 MX25U1635@USON8(6*5mm) [(SA683)]
 MX25U4035@SOIC8 [(SA602A)]
 MX25U4035@USON8(4*4mm) [(SA744)]
 MX25U8035@SOIC8 [(SA602A)]
 MX25U8035@USON8(4*4mm) [(SA744)]
 MX25U8035@USON8(6*5mm) [(SA683)]
 MX25V512@USON8 [(SA724)]
 MX26C1000B
 MX26C1000B@PLCC32 [(SA015A1T)]
 MX26C1000B@SOIC32 [(SA603)]
 MX26C1000B@TSOP32 [(SA410T)]
 MX26C2000B
 MX26C2000B@PLCC32 [(SA015A1T)]
 MX26C2000B@SOIC32 [(SA603)]
 MX26C2000B@TSOP32 [(SA410T)]
 MX26C512A
 MX26C512A@PLCC32 [(SA015A1T)]
 MX26C512A@SOIC28 [(SA630)]
 MX26C512A@TSOP28 [(SA430T)]
 MX26LV004B@PLCC32 [(SA015A1T)]
 MX26LV004B@TSOP40 [(SA409T)]
 MX26LV004T@PLCC32 [(SA015A1T)]
 MX26LV004T@TSOP40 [(SA409T)]
 MX26LV008B@TSOP40 [(SA409T)]
 MX26LV008T@TSOP40 [(SA409T)]
 MX26LV040(QC)@PLCC32 [(SA015A1T)]
 MX26LV040(TC)@TSOP32 [(SA410T)]
 MX27C1000
 MX27C1000@PLCC32 [(SA015A1T)]
 MX27C1000@SOIC32 [(SA603)]
 MX27C1000@TSOP32 [(SA410T)]
 MX27C1000A
 MX27C1000A@SOIC32 [(SA603)]

MX27C1000A@TSOP32 [(SA410T)]	MX27C1001
MX27C1001@PLCC32 [(SA015A1T)]	MX27C1001@SOIC32 [(SA603)]
MX27C1001@TSOP32 [(SA410T)]	MX27C1024
MX27C1024@PLCC44 [(SA244)]	MX27C1024@TSOP40 [(SA409T)]
MX27C1024A	MX27C1024A@PLCC44 [(SA244)]
MX27C1024A@TSOP40 [(SA409T)]	MX27C1024B
MX27C1024B@PLCC44 [(SA244)]	MX27C1024B@TSOP40 [(SA409T)]
MX27C1100	MX27C2000
MX27C2000@PLCC32 [(SA015A1T)]	MX27C2000@SOIC32 [(SA603)]
MX27C2000@TSOP32 [(SA410T)]	MX27C2000A
MX27C2000A@PLCC32 [(SA015A1T)]	MX27C2000A@SOIC32 [(SA603)]
MX27C2000A@TSOP32 [(SA410T)]	MX27C2048
MX27C2048@PLCC44 [(SA244)]	MX27C2048@TSOP40 [(SA409T)]
MX27C2100	MX27C256
MX27C256@PLCC32 [(SA015A1T)]	MX27C4000
MX27C4000@PLCC32 [(SA015A1T)]	MX27C4000@SOIC32 [(SA603)]
MX27C4000@TSOP32 [(SA410T)]	MX27C4000A
MX27C4000A@PLCC32 [(SA015A1T)]	MX27C4000A@SOIC32 [(SA603)]
MX27C4000A@TSOP32 [(SA410T)]	MX27C4096
MX27C4096@PLCC44 [(SA244)]	MX27C4100
MX27C4111	MX27C512
MX27C512@PLCC32 [(SA015A1T)]	MX27C516
MX27C516@PLCC44 [(SA244)]	MX27C516@TSOP40 [(SA409T)]
MX27C8000	MX27C8000@PLCC32 [(SA015A1T)]
MX27C8000@SOIC32 [(SA603)]	MX27C8000@TSOP32 [(SA410T)]
MX27C8000A	MX27C8000A@PLCC32 [(SA015A1T)]
MX27C8000A@SOIC32 [(SA603)]	MX27C8000A@TSOP32 [(SA410T)]
MX27C8100	MX27C8100@PSOP44 [(SA638)]
MX27C8111	MX27C8111@PSOP44 [(SA638)]
MX27L1000	MX27L1000@PLCC32 [(SA015A1T)]
MX27L1000@TSOP32 [(SA410T)]	MX27L2000
MX27L2000@PLCC32 [(SA015A1T)]	MX27L2000@TSOP32 [(SA410T)]
MX27L256	MX27L256@PLCC32 [(SA015A1T)]
MX27L256@TSOP32 [(SA430T)]	MX27L4000
MX27L4000@PLCC32 [(SA015A1T)]	MX27L4000@TSOP32 [(SA410T)]
MX27L4096	MX27L4096@PLCC44 [(SA244)]
MX27L512	MX27L512@PLCC32 [(SA015A1T)]
MX27L512@TSOP28 [(SA430T)]	MX28F002B@TSOP40 [(SA409T)]
MX28F002T@TSOP40 [(SA409T)]	MX28F1000
MX28F1000@PLCC32 [(SA015A1T)]	MX28F1000@SOP32 [(SA603)]
MX28F1000@TSOP32 [(SA410T)]	MX28F1000P
MX28F1000P@PLCC32 [(SA015A1T)]	MX28F1000P@TSOP32 [(SA410T)]
MX28F2000	MX28F2000@PLCC32 [(SA015A1T)]
MX28F2000@TSOP32 [(SA410T)]	MX28F2000P
MX28F2000P@PLCC32 [(SA015A1T)]	MX28F2000P@TSOP32 [(SA410T)]
MX28F2100B@PSOP44 [(SA638)]	MX28F2100B@TSOP48 [(SA247-B005)]
MX28F2100T@PSOP44 [(SA638)]	MX28F2100T@TSOP48 [(SA247-B005)]
MX28F4000	MX28F4000@PLCC32 [(SA015A1T)]
MX28F4000@TSOP32 [(SA410T)]	MX29F001B
MX29F001B@PLCC32 [(SA015A1T)]	MX29F001B@TSOP32 [(SA410T)]
MX29F001T	MX29F001T@PLCC32 [(SA015A1T)]
MX29F001T@TSOP32 [(SA410T)]	MX29F002B
MX29F002B@PLCC32 [(SA015A1T)]	MX29F002B@TSOP32 [(SA410T)]
MX29F002NB	MX29F002NB@PLCC32 [(SA015A1T)]
MX29F002NB@TSOP32 [(SA410T)]	MX29F002NT
MX29F002NT@PLCC32 [(SA015A1T)]	MX29F002NT@TSOP32 [(SA410T)]
MX29F002T	MX29F002T@PLCC32 [(SA015A1T)]
MX29F002T@TSOP32 [(SA410T)]	MX29F004B
MX29F004B@PLCC32 [(SA015A1T)]	MX29F004B@TSOP32 [(SA410T)]
MX29F004T	MX29F004T@PLCC32 [(SA015A1T)]
MX29F004T@TSOP32 [(SA410T)]	MX29F016@PSOP44 [(SA638)]
MX29F016@TSOP40 [(SA409T)]	MX29F016@TSOP48 [(SA247-B005)]
MX29F022B	MX29F022B@PLCC32 [(SA015A1T)]
MX29F022B@TSOP32 [(SA410T)]	MX29F022NB
MX29F022NB@PLCC32 [(SA015A1T)]	MX29F022NB@TSOP32 [(SA410T)]
MX29F022NT	MX29F022NT@PLCC32 [(SA015A1T)]
MX29F022NT@TSOP32 [(SA410T)]	MX29F022T
MX29F022T@PLCC32 [(SA015A1T)]	MX29F022T@TSOP32 [(SA410T)]
MX29F040	MX29F040@PLCC32 [(SA015A1T)]
MX29F040@TSOP32 [(SA410T)]	MX29F040C
MX29F040C@PLCC32 [(SA015A1T)]	MX29F040C@TSOP32 [(SA410T)]
MX29F080@PSOP44 [(SA638)]	MX29F080@TSOP40 [(SA409T)]
MX29F100B@PSOP44 [(SA638-B006)]	MX29F100B@TSOP48 [(SA247-B005)]
MX29F100T@PSOP44 [(SA638-B006)]	MX29F100T@TSOP48 [(SA247-B005)]
MX29F1610@PSOP44 [(SA638)]	MX29F1610@TSOP48 [(SA247-B005)]
MX29F1610A@PSOP44 [(SA638)]	MX29F1610A@TSOP48 [(SA247-B005)]
MX29F1610B@TSOP48 [(SA247-B005)]	MX29F1611@PSOP44 [(SA638)]
MX29F1615	MX29F200B@PSOP44 [(SA638-B006)]
MX29F200B@TSOP48 [(SA247-B005)]	MX29F200CB@PSOP44 [(SA638)]
MX29F200CB@TSOP48 [(SA247-B005)]	MX29F200CT@PSOP44 [(SA638)]
MX29F200CT@TSOP48 [(SA247-B005)]	MX29F200T@PSOP44 [(SA638-B006)]

MX29F200T@TSOP48 [(SA247-B005)]	MX29F4000
MX29F400B@PSOP44 [(SA638-B006)]	MX29F400B@TSOP48 [(SA247-B005)]
MX29F400CB@PSOP44 [(SA638)]	MX29F400CB@TSOP48 [(SA247-B005)]
MX29F400CT@PSOP44 [(SA638)]	MX29F400CT@TSOP48 [(SA247-B005)]
MX29F400T@PSOP44 [(SA638-B006)]	MX29F400T@TSOP48 [(SA247-B005)]
MX29F800B@PSOP44 [(SA638-B006)]	MX29F800B@TSOP48 [(SA247-B005)]
MX29F800CBM@PSOP44 [(SA638)]	
MX29F800CBT@TSOP48 [(SA247-B005)]	
MX29F800CTM@PSOP44 [(SA638)]	
MX29F800CTT@TSOP48 [(SA247-B005)]	
MX29F800T@PSOP44 [(SA638-B006)]	MX29F800T@TSOP48 [(SA247-B005)]
MX29L1611@PSOP44 [(SA638)]	MX29L1611@TSOP48 [(SA247-B005)]
MX29L1611G	MX29L3211@PSOP44 [(SA638)]
MX29L3211@TSOP48 [(SA247-B005)]	MX29LV004B@PLCC32 [(SA015A1T)]
MX29LV004B@TSOP40 [(SA409T)]	MX29LV004CB@PLCC32 [(SA015A1T)]
MX29LV004CB@TSOP40 [(SA409T)]	MX29LV004CT@PLCC32 [(SA015A1T)]
MX29LV004CT@TSOP40 [(SA409T)]	MX29LV004T@PLCC32 [(SA015A1T)]
MX29LV004T@TSOP40 [(SA409T)]	MX29LV008B@TSOP40 [(SA409T)]
MX29LV008BB@TSOP40 [(SA409T)]	MX29LV008BT@TSOP40 [(SA409T)]
MX29LV008CB@TSOP40 [(SA409T)]	MX29LV008CT@TSOP40 [(SA409T)]
MX29LV008T@TSOP40 [(SA409T)]	MX29LV033T@TSOP40 [(SA409T)]
MX29LV040@PLCC32 [(SA015A1T)]	MX29LV040@TSOP32 [(SA410T)]
MX29LV040C@PLCC32 [(SA015A1T)]	MX29LV040C@TSOP32 [(SA410T)]
MX29LV081@TSOP40 [(SA409T)]	

MICROCONTROLLER

MX10E8050I	MX10E8050I@PLCC44 [(SA244)]
MX10E8050I@TQFP44 [(SA245A)]	MX10EXA@PLCC44 [(SA244)]
MX10EXA@TQFP44 [(SA245A)]	MX10FLCD
MX10FMAXD	MX10FMAXD@PLCC44 [(SA244)]
MX10FMAXD@TQFP44 [(SA245A)]	

MAXIM

E (E) PROM / FRAM / NVRAM

DS1220AB	DS1220AD
DS1220Y	DS1225AB
DS1225AD	DS1225D
DS1225E	DS1225Y
DS1230AB	DS1230W
DS1230Y	DS1235AB
DS1235Y	DS1243Y
DS1244	DS1244Y
DS1245AB	DS1245EE
DS1245P	DS1245W
DS1245Y	DS1248P
DS1248W	DS1248Y
DS1249AB	DS1249W
DS1249Y	DS1250AB
DS1250W	DS1250Y
DS1251AB	DS1251W
DS1251Y	DS1256P
DS1256W	DS1256Y
DS1258AB	DS1258W
DS1258Y	DS1265AB
DS1265W	DS1265Y
DS1270AB	DS1270W
DS1270Y	DS1284
DS1284N	DS1284Q@PLCC28 [(SA008A)]
DS1284QN@PLCC28 [(SA008A)]	DS1286
DS1286I	DS1287
DS1287A	DS12887
DS12887A	DS12C887
DS12C887A	DS1386 (32K)
DS1386 (8K)	DS1485
DS1485@SOIC28 [(SA630)]	DS1488
DS1501	DS1511
DS1553	DS1553W
DS1554	DS1554W
DS1556	DS1642
DS1643	DS1644
DS1644P	DS1645AB
DS1645EE	DS1645Y
DS1646	DS1647

DS1647LPM	DS1650AB
DS1650Y	DS1687-3
DS1687-5	DS17287-3
DS17287-5	DS1742
DS1742W	DS1743
DS1743P	DS1743W
DS1743WP	DS1744
DS1744P	DS1744W
DS1744WP	DS1746
DS1747	DS1747P
DS1747W	DS1747WP
DS17487-3	DS17487-5
DS17887-3	DS17887-5
DS2430A@TO-92	DS2430AP@TSOC6 [(SA602A)]
DS2431@TO-92	DS2431P@TSOC6 [(SA602A)]
DS2432P@TSOC6 [(SA602A)]	DS2433@PR-35
DS2433S(3.9)@SOIC8 [(SA602A)]	DS2433S(5.5)@SOIC8 [(SA605A)]
DS2502	DS2502P@TSOC6 [(SA602A)]
DS2502S@SOIC8 [(SA602A)]	DS2502UNW
DS2502UNW@SOIC8 [(SA602A)]	DS2502UNW@TSOC6 [(SA602A)]
DS2506	DS2506S@SOIC8 [(SA023A)]
DS4510@uSOP10	DS4520@TSSOP16 [(SA026)]
DS4550@TSSOP20 [(SA026)]	

MICROCONTROLLER

DS87C520	DS87C520@PLCC44 [(SA244)]
DS87C520@TQFP44 [(SA245A)]	DS89C420(rev.A)
DS89C420(rev.A)@PLCC44 [(SA244)]	
DS89C420(rev.A)@TQFP44 [(SA245A)]	

MAXWELL**E(E) PROM/FRAM/NVRAM**

27C010T@LDFFP32 [(SA438T)]	28C010
28C010@PLCC32 [(SA015A1T)]	28C010@TSOP32 [(SA438T)]
28C010T	28C010T@PLCC32 [(SA015A1T)]
28C010T@TSOP32 [(SA438T)]	28C011
28C011@PLCC32 [(SA015A1T)]	28C011@TSOP32 [(SA438T)]
28C011T	28C011T@PLCC32 [(SA015A1T)]
28C011T@TSOP32 [(SA438T)]	

MEGAWIN**E(E) PROM/FRAM/NVRAM**

MM25SB512@SOIC8 [(SA602A)]	MM29F040
MM29F040@PLCC32 [(SA015A1T)]	MM29F040@TSOP32 [(SA410T)]
MM29LF040	MM29LF040@PLCC32 [(SA015A1T)]
MM29LF040@TSOP32 [(SA410T)]	

MICROCONTROLLER

MPC82G516AD@LQFP48 [(SA248)]	MPC82G516AE
MPC82G516AF@PLCC44 [(SA244)]	MPC82G516AF@PQFP44 [(SA675)]
MPC89E515AE	MPC89E515AF@PQFP44 [(SA675)]
MPC89E515AP@PLCC44 [(SA244)]	MPC89E51AE
MPC89E51AF@PQFP44 [(SA675)]	MPC89E51AP@PLCC44 [(SA244)]
MPC89E52AE	MPC89E52AF@PQFP44 [(SA675)]
MPC89E52AP@PLCC44 [(SA244)]	MPC89E53AE
MPC89E53AF@PQFP44 [(SA675)]	MPC89E53AP@PLCC44 [(SA244)]
MPC89E54AE	MPC89E54AF@PQFP44 [(SA675)]
MPC89E54AP@PLCC44 [(SA244)]	MPC89E58AE
MPC89E58AF@PQFP44 [(SA675)]	MPC89E58AP@PLCC44 [(SA244)]
MPC89L515AE	MPC89L515AF@PQFP44 [(SA675)]
MPC89L515AP@PLCC44 [(SA244)]	MPC89L516X2
MPC89L516X2@PLCC44 [(SA244)]	MPC89L516X2@TQFP44 [(SA245A)]
MPC89L51AE	MPC89L51AF@PQFP44 [(SA675)]
MPC89L51AP@PLCC44 [(SA244)]	MPC89L52AE
MPC89L52AF@PQFP44 [(SA675)]	MPC89L52AP@PLCC44 [(SA244)]
MPC89L53AE	MPC89L53AF@PQFP44 [(SA675)]

```

MPC89L53AP@PLCC44 [(SA244)]
MPC89L54AF@PQFP44 [(SA675)]
MPC89L556X2
MPC89L556X2@TQFP44 [(SA245A)]
MPC89L58AF@PQFP44 [(SA675)]
MPC89L54AE
MPC89L54AP@PLCC44 [(SA244)]
MPC89L556X2@PLCC44 [(SA244)]
MPC89L58AE
MPC89L58AP@PLCC44 [(SA244)]

```

MICON

MICROCONTROLLER

```

MDT10P21(dip18)
MDT10P21(dip22)
MDT10P21@SOP20 [(SA404A)]
MDT10P22(dip18)
MDT10P22(dip22)
MDT10P22@SOP20 [(SA404A)]
MDT10P23(dip18)
MDT10P23(dip22)
MDT10P23@SOP20 [(SA404A)]
MDT10P61
MDT10P61@SSOP20 [(SA626A)]
MDT2005@SOP18 [(SA404A)]
MDT2010
MDT2010@SSOP20 [(SA626A)]
MDT2020@SOP28 [(SA404A)]
MDT2030
MDT2030@SSOP20 [(SA626A)]
MDT2050@SOP18 [(SA404A)]
MDT2051
MDT2051@SSOP20 [(SA626A)]
MDT2060@SOP18 [(SA404A)]
MDT10P21(dip20)
MDT10P21@SOP18 [(SA404A)]
MDT10P21@SOP24 [(SA404A)]
MDT10P22(dip20)
MDT10P22@SOP18 [(SA404A)]
MDT10P22@SOP24 [(SA404A)]
MDT10P23(dip20)
MDT10P23@SOP18 [(SA404A)]
MDT10P23@SOP24 [(SA404A)]
MDT10P61@SOP18 [(SA404A)]
MDT2005
MDT2005@SSOP20 [(SA626A)]
MDT2010@SOP18 [(SA404A)]
MDT2020
MDT2020@SSOP28 [(SA626A)]
MDT2030@SOP18 [(SA404A)]
MDT2050
MDT2050@SSOP20 [(SA626A)]
MDT2051@SOP18 [(SA404A)]
MDT2060
MDT2060@SSOP20 [(SA626A)]

```

MICROCHIP

E (E) PROM/FRAM/NVRAM

```

24AA00
24AA00@SOT-23 [(SA717)]
24AA01
24AA01@TSSOP8 [(SA026)]
24AA014@SOIC8 [(SA602A)]
24AA02
24AA02@MSOP8 [(SA666)]
24AA02@SOT-23-5 [(SA717)]
24AA024
24AA024@MSOP8 [(SA666)]
24AA024@TSSOP8 [(SA026)]
24AA025@DFN8 [(SA694)]
24AA025@SOIC8 [(SA602A)]
24AA04
24AA04@TSSOP8 [(SA026)]
24AA08@SOIC8 [(SA602A)]
24AA1025
24AA1025@TSSOP8 [(SA026)]
24AA128@MSOP8 [(SA666)]
24AA128@TSSOP14 [(SA026)]
24AA16
24AA16@TSSOP8 [(SA026)]
24AA164@SOIC8 [(SA602A)]
24AA174
24AA174@TSSOP8 [(SA026)]
24AA256@MSOP8 [(SA666)]
24AA256@TSSOP14 [(SA026)]
24AA32
24AA32@MSOP8 [(SA666)]
24AA32@TSSOP8 [(SA026)]
24AA32A(Rotated)@TSSOP8 [(SA026)]
24AA32A@MSOP8 [(SA666)]
24AA32A@TSSOP8 [(SA026)]
24AA512@DFN8 [(SA683)]
24AA512@TSSOP14 [(SA602)]
24AA515@SOIC8 [(SA605A)]
24AA52@DFN8 [(SA694)]
24AA52@SOIC8 [(SA602A)]
24AA00@SOIC8 [(SA602A)]
24AA00@TSSOP8 [(SA026)]
24AA01@SOIC8 [(SA602A)]
24AA014
24AA014@TSSOP8 [(SA026)]
24AA02@DFN8 [(SA694)]
24AA02@SOIC8 [(SA602A)]
24AA02@TSSOP8 [(SA026)]
24AA024@DFN8 [(SA694)]
24AA024@SOIC8 [(SA602A)]
24AA025
24AA025@MSOP8 [(SA666)]
24AA025@TSSOP8 [(SA026)]
24AA04@SOIC8 [(SA602A)]
24AA08
24AA08@TSSOP8 [(SA026)]
24AA1025@SOIC8 [(SA602A)]
24AA128
24AA128@SOIC8 [(SA602A)]
24AA128@TSSOP8 [(SA026)]
24AA16@SOIC8 [(SA602A)]
24AA164
24AA164@TSSOP8 [(SA026)]
24AA174@SOIC8 [(SA602A)]
24AA256
24AA256@SOIC8 [(SA605A)]
24AA256@TSSOP8 [(SA026)]
24AA32(Rotated)@TSSOP8 [(SA026)]
24AA32@SOIC8 [(SA602A)]
24AA32A
24AA32A@SOIC8 [(SA602A)]
24AA512
24AA512@SOIC8 [(SA605A)]
24AA515
24AA52
24AA52@MSOP8 [(SA666)]
24AA52@TSSOP8 [(SA026)]

```

24AA64	24AA64(Rotated)@TSSOP8 [(SA026)]
24AA64@MSOP8 [(SA666)]	24AA64@SOIC8 [(SA602A)]
24AA64@TSSOP8 [(SA026)]	24AA65
24AA65@SOIC8 [(SA602A)]	24AA65@TSSOP8 [(SA026)]
24C00	24C00@SOIC8 [(SA602A)]
24C00@SOT-23 [(SA717)]	24C00@TSSOP8 [(SA026)]
24C01	24C01A
24C01A@SOIC8 [(SA602A)]	24C01C
24C01C@SOIC8 [(SA602A)]	24C01C@TSSOP8 [(SA026)]
24C02	24C02A
24C02A@SOIC8 [(SA602A)]	24C02C
24C02C@SOIC8 [(SA602A)]	24C02C@TSSOP8 [(SA026)]
24C04	24C04A
24C04A@SOIC8 [(SA602A)]	24C04A@TSSOP8 [(SA026)]
24C08	24C08@SOIC8 [(SA602A)]
24C08B	24C08B@SOIC8 [(SA602A)]
24C16	24C16@SOIC8 [(SA602A)]
24C16B	24C16B@SOIC8 [(SA602A)]
24C32	24C32@SOIC8 [(SA602A)]
24C64	24C64@SOIC8 [(SA602A)]
24C64@TSSOP8 [(SA026)]	24C65
24C65@SOIC8 [(SA602A)]	24FC1025
24FC1025@SOIC8 [(SA602A)]	24FC1025@TSSOP8 [(SA026)]
24FC128	24FC128@MSOP8 [(SA666)]
24FC128@SOIC8 [(SA602A)]	24FC128@TSSOP14 [(SA026)]
24FC128@TSSOP8 [(SA026)]	24FC256
24FC256@MSOP8 [(SA666)]	24FC256@SOIC8 [(SA605A)]
24FC256@TSSOP14 [(SA026)]	24FC256@TSSOP8 [(SA026)]
24FC32	24FC32@SOIC8 [(SA602A)]
24FC512	24FC512@DFN8 [(SA683)]
24FC512@SOIC8 [(SA605A)]	24FC512@TSSOP14 [(SA602)]
24FC515	24FC515@SOIC8 [(SA605A)]
24FC65	24FC65@SOIC8 [(SA605A)]
24LC00	24LC00@SOIC8 [(SA602A)]
24LC00@SOT-23 [(SA717)]	24LC00@TSSOP8 [(SA026)]
24LC01	24LC014
24LC014@SOIC8 [(SA602A)]	24LC014@TSSOP8 [(SA026)]
24LC01B	24LC01B@SOIC8 [(SA602A)]
24LC01B@TSSOP8 [(SA026)]	24LC02
24LC024	24LC024@SOIC8 [(SA602A)]
24LC024@TSSOP8 [(SA026)]	24LC025
24LC025@SOIC8 [(SA602A)]	24LC025@TSSOP8 [(SA026)]
24LC02B	24LC02B@DFN8 [(SA694)]
24LC02B@MSOP8 [(SA666)]	24LC02B@SOIC8 [(SA602A)]
24LC02B@SOT-23-5 [(SA717)]	24LC02B@TSSOP8 [(SA026)]
24LC04	24LC04B
24LC04B@SOIC8 [(SA602A)]	24LC04B@TSSOP8 [(SA026)]
24LC08	24LC08B
24LC08B@SOIC8 [(SA602A)]	24LC08B@TSSOP8 [(SA026)]
24LC1025	24LC1025@SOIC8 [(SA602A)]
24LC1025@TSSOP8 [(SA026)]	24LC128
24LC128@MSOP8 [(SA666)]	24LC128@SOIC8 [(SA605A)]
24LC128@TSSOP14 [(SA026)]	24LC128@TSSOP8 [(SA026)]
24LC16	24LC16@MSOP8 [(SA605A)]
24LC16@SOIC8 [(SA602A)]	24LC164
24LC164@SOIC8 [(SA602A)]	24LC16B
24LC16B@SOIC8 [(SA602A)]	24LC16B@TSSOP8 [(SA026)]
24LC174	24LC174@SOIC8 [(SA602A)]
24LC21	24LC21@SOIC8 [(SA602A)]
24LC21A	24LC21A@SOIC8 [(SA602A)]
24LC22A	24LC22A@SOIC8 [(SA602A)]
24LC256	24LC256@MSOP8 [(SA666)]
24LC256@SOIC8 [(SA605A)]	24LC256@TSSOP14 [(SA026)]
24LC256@TSSOP8 [(SA026)]	24LC32
24LC32@SOIC8 [(SA602A)]	24LC32A
24LC32A@SOIC8 [(SA602A)]	24LC32A@TSSOP8 [(SA026)]
24LC512	24LC512@DFN8 [(SA683)]
24LC512@SOIC8 [(SA605A)]	24LC512@TSSOP14 [(SA602)]
24LC515	24LC515@SOIC8 [(SA605A)]
24LC64	24LC64(Rotated)@TSSOP8 [(SA026)]
24LC64@MSOP8 [(SA605A)]	24LC64@SOIC8 [(SA602A)]
24LC64@TSSOP8 [(SA026)]	24LC65
24LC65@SOIC8 [(SA602A)]	24LCS21
24LCS21@SOIC8 [(SA602A)]	24LCS21A
24LCS21A@SOIC8 [(SA602A)]	24LCS22
24LCS22@SOIC8 [(SA602A)]	24LCS22A
24LCS22A@SOIC8 [(SA602A)]	24LCS52
24LCS52@DFN8 [(SA694)]	24LCS52@MSOP8 [(SA666)]
24LCS52@SOIC8 [(SA602A)]	24LCS52@TSSOP8 [(SA026)]
25AA010A	25AA010A@DFN8 [(SA683)]
25AA010A@MSOP8 [(SA605A)]	25AA010A@SOIC8 [(SA602A)]

25AA010A@SOT-23 [(SA698)]	25AA010A@TSSOP8 [(SA026)]
25AA010A[X-Rotated]@TSSOP8 [(SA026)]	
25AA020A	25AA020A@DFN8 [(SA683)]
25AA020A@MSOP8 [(SA605A)]	25AA020A@SOIC8 [(SA602A)]
25AA020A@SOT-23 [(SA698)]	25AA020A@TSSOP8 [(SA026)]
25AA020A[X-Rotated]@TSSOP8 [(SA026)]	
25AA040	25AA040@SOIC8 [(SA602A)]
25AA040@TSSOP8 [(SA026)]	25AA040A
25AA040A@DFN8 [(SA683)]	25AA040A@MSOP8 [(SA605A)]
25AA040A@SOIC8 [(SA602A)]	25AA040A@SOT-23 [(SA698)]
25AA040A@TSSOP8 [(SA026)]	
25AA040A[X-Rotated]@TSSOP8 [(SA026)]	
25AA080	25AA080@SOIC8 [(SA602A)]
25AA080A	25AA080A@MSOP8 [(SA605A)]
25AA080A@SOIC8 [(SA602A)]	25AA080A@TSSOP8 [(SA026)]
25AA080B	25AA080B@MSOP8 [(SA605A)]
25AA080B@SOIC8 [(SA602A)]	25AA080B@TSSOP8 [(SA026)]
25AA1024	25AA1024@DFN8 [(SA683)]
25AA1024@SOIC8 [(SA602A)]	25AA1024@SOIJ8 [(SA605)]
25AA128	25AA128@DFN8 [(SA683)]
25AA128@SOIC8(4.0) [(SA602A)]	25AA128@SOIC8(5.4) [(SA605A)]
25AA128@TSSOP8 [(SA026)]	
25AA128[X-Rotated]@TSSOP8 [(SA026)]	
25AA160	25AA160@SOIC8 [(SA602A)]
25AA160A	25AA160A@MSOP8 [(SA605A)]
25AA160A@SOIC8 [(SA602A)]	25AA160A@TSSOP8 [(SA026)]
25AA160B	25AA160B@MSOP8 [(SA605A)]
25AA160B@SOIC8 [(SA602A)]	25AA160B@TSSOP8 [(SA026)]
25AA256	25AA256@DFN8 [(SA683)]
25AA256@SOIC8(4.0) [(SA602A)]	25AA256@SOIC8(5.4) [(SA605A)]
25AA256@TSSOP8 [(SA026)]	
25AA256[X-Rotated]@TSSOP8 [(SA026)]	
25AA320	25AA320@SOIC8 [(SA602A)]
25AA320@TSSOP14 [(SA026)]	25AA320@TSSOP8 [(SA026)]
25AA512	25AA512@DFN8 [(SA683)]
25AA512@SOIC8 [(SA602A)]	25AA512@SOIJ8 [(SA605)]
25AA640	25AA640@SOIC8 [(SA602A)]
25AA640@TSSOP8 [(SA026)]	
25C040@SOIC8 [(SA602A)]	25C040
25C080	25C040@TSSOP8 [(SA026)]
25C160	25C080@SOIC8 [(SA602A)]
25C320	25C160@SOIC8 [(SA602A)]
25C320@TSSOP14 [(SA026)]	25C320@SOIC8 [(SA602A)]
25C640	25C320@TSSOP8 [(SA026)]
25C640@TSSOP8 [(SA026)]	25C640@SOIC8 [(SA602A)]
25LC010A@DFN8 [(SA683)]	25LC010A
25LC010A@SOIC8 [(SA602A)]	25LC010A@MSOP8 [(SA605A)]
25LC010A@TSSOP8 [(SA026)]	25LC010A@SOT-23 [(SA698)]
25LC010A[X-Rotated]@TSSOP8 [(SA026)]	
25LC020A	25LC020A@DFN8 [(SA683)]
25LC020A@MSOP8 [(SA605A)]	25LC020A@SOIC8 [(SA602A)]
25LC020A@SOT-23 [(SA698)]	25LC020A@TSSOP8 [(SA026)]
25LC020A[X-Rotated]@TSSOP8 [(SA026)]	
25LC040	25LC040@SOIC8 [(SA602A)]
25LC040@TSSOP8 [(SA026)]	25LC040A
25LC040A@DFN8 [(SA683)]	25LC040A@MSOP8 [(SA605A)]
25LC040A@SOIC8 [(SA602A)]	25LC040A@SOT-23 [(SA698)]
25LC040A@TSSOP8 [(SA026)]	
25LC040A[X-Rotated]@TSSOP8 [(SA026)]	
25LC080	25LC080@SOIC8 [(SA602A)]
25LC080A	25LC080A@MSOP8 [(SA605A)]
25LC080A@SOIC8 [(SA602A)]	25LC080A@TSSOP8 [(SA026)]
25LC080B	25LC080B@MSOP8 [(SA605A)]
25LC080B@SOIC8 [(SA602A)]	25LC080B@TSSOP8 [(SA026)]
25LC1024	25LC1024@DFN8 [(SA683)]
25LC1024@SOIC8 [(SA602A)]	25LC1024@SOIJ8 [(SA605)]
25LC128	25LC128@DFN8 [(SA683)]
25LC128@SOIC8(4.0) [(SA602A)]	25LC128@SOIC8(5.4) [(SA605A)]
25LC128@TSSOP8 [(SA026)]	
25LC128[X-Rotated]@TSSOP8 [(SA026)]	
25LC160	25LC160@SOIC8 [(SA602A)]
25LC160A	25LC160A@MSOP8 [(SA605A)]
25LC160A@SOIC8 [(SA602A)]	25LC160A@TSSOP8 [(SA026)]
25LC160B	25LC160B@MSOP8 [(SA605A)]
25LC160B@SOIC8 [(SA602A)]	25LC160B@TSSOP8 [(SA026)]
25LC256	25LC256@DFN8 [(SA683)]
25LC256@SOIC8(4.0) [(SA602A)]	25LC256@SOIC8(5.4) [(SA605A)]
25LC256@TSSOP8 [(SA026)]	
25LC256[X-Rotated]@TSSOP8 [(SA026)]	
25LC320	
25LC320@TSSOP14 [(SA026)]	25LC320(SN)@SOIC8 [(SA602A)]
	25LC320@TSSOP8 [(SA026)]

25LC512	25LC512@DFN8 [(SA683)]
25LC512@SOIC8 [(SA602A)]	25LC512@SOIJ8 [(SA605)]
25LC640	25LC640@SOIC8 [(SA602A)]
25LC640@TSSOP8 [(SA026)]	27256
27256@PLCC32 [(SA015A1T)]	27C128
27C128@PLCC32 [(SA015A1T)]	27C128A
27C128A@PLCC32 [(SA015A1T)]	27C256
27C256@PLCC32 [(SA015A1T)]	27C32A
27C512	27C512@PLCC32 [(SA015A1T)]
27C512A	27C512A@PLCC32 [(SA015A1T)]
27C513	27C64
27C64@PLCC32 [(SA015A1T)]	27C64@SOIC28 [(SA404)]
27HC1616	27HC1616@PLCC44 [(SA244)]
27HC1616L	27HC1616L@PLCC44 [(SA244)]
27HC191	27HC191@PLCC28 [(SA008A)]
27HC191@SOIC24 [(SA404)]	27HC256
27HC256@PLCC32 [(SA015A1T)]	27HC256L
27HC256L@PLCC32 [(SA015A1T)]	27HC291
27HC291@PLCC28 [(SA008A)]	27HC291@SOIC24 [(SA404)]
27HC416	27HC64
27HC64@PLCC32 [(SA015A1T)]	27HC64@SOIC28 [(SA404)]
27HC641	27HC641@PLCC28 [(SA008A)]
27HC641@SOIC24 [(SA404)]	27HC641L
27HC641L@PLCC28 [(SA008A)]	27HC641L@SOIC24 [(SA404)]
27HC64L	27HC64L@PLCC32 [(SA015A1T)]
27HC64L@SOIC28 [(SA404)]	27LV256
27LV256@PLCC32 [(SA015A1T)]	27LV64
2817	2864
2864@PLCC32 [(SA015A1T)]	28C04
28C04@PLCC32 [(SA015A1T)]	28C04@SOIC24 [(SA404)]
28C04A	28C04A@PLCC32 [(SA015A1T)]
28C04A@SOIC24 [(SA404)]	28C04AF
28C04AF@PLCC32 [(SA015A1T)]	28C04AF@SOIC24 [(SA404)]
28C04F	28C04F@PLCC32 [(SA015A1T)]
28C04F@SOIC24 [(SA404)]	28C16
28C16@PLCC32 [(SA015A1T)]	28C16@SOIC24 [(SA404)]
28C16A	28C16A@PLCC32 [(SA015A1T)]
28C16A@SOIC24 [(SA404)]	28C16AF
28C16AF@PLCC32 [(SA015A1T)]	28C16AF@SOIC24 [(SA404)]
28C16F	28C16F@PLCC32 [(SA015A1T)]
28C16F@SOIC24 [(SA404)]	28C17
28C17@PLCC32 [(SA015A1T)]	28C17@SOIC28 [(SA404)]
28C17A	28C17A@PLCC32 [(SA015A1T)]
28C17A@SOIC28 [(SA404)]	28C17AF
28C17AF@PLCC32 [(SA015A1T)]	28C17AF@SOIC28 [(SA404)]
28C17F	28C17F@PLCC32 [(SA015A1T)]
28C17F@SOIC28 [(SA404)]	28C256
28C256@PLCC32 [(SA015A1T)]	28C256F
28C256F@PLCC32 [(SA015A1T)]	28C64A
28C64A@PLCC32 [(SA015A1T)]	28C64A@SOIC28 [(SA404)]
28C64A@TSOP32 [(SA410T)]	28C64AF
28C64AF@PLCC32 [(SA015A1T)]	28C64AF@SOIC28 [(SA404)]
28LV64A	28LV64A@PLCC32 [(SA015A1T)]
28LV64A@SOIC28 [(SA404)]	28PC64
28PC64@PLCC32 [(SA015A1T)]	59C11
59C11@SOIC8 [(SA602A)]	85C72
85C72@SOIC8 [(SA602A)]	85C82
85C82@SOIC8 [(SA602A)]	85C92
85C92@SOIC8 [(SA602A)]	93AA46(08bit)
93AA46(08bit)@SOIC8 [(SA602A)]	93AA46(16bit)
93AA46(16bit)@SOIC8 [(SA602A)]	93AA46A(08bit)
93AA46A(08bit)@DFN8 [(BBBB)]	93AA46A(08bit)@MSOP8 [(SA666)]
93AA46A(08bit)@SOIC8 [(SA602A)]	93AA46A(08bit)@SOT-23 [(SA717)]
93AA46A(08bit)@TSSOP8 [(SA026)]	93AA46B(16bit)
93AA46B(16bit)@DFN8 [(BBBB)]	93AA46B(16bit)@MSOP8 [(SA666)]
93AA46B(16bit)@SOIC8 [(SA602A)]	93AA46B(16bit)@SOT-23 [(SA717)]
93AA46B(16bit)@TSSOP8 [(SA026)]	93AA46C(08bit)
93AA46C(08bit)@DFN8 [(BBBB)]	93AA46C(08bit)@MSOP8 [(SA666)]
93AA46C(08bit)@SOIC8 [(SA602A)]	93AA46C(08bit)@TSSOP8 [(SA026)]
93AA46C(08bit)@TSSOP8 [(SA026)]	93AA46C(16bit)@DFN8 [(BBBB)]
93AA46C(16bit)	93AA46C(16bit)@SOIC8 [(SA602A)]
93AA46C(16bit)@MSOP8 [(SA666)]	93AA56(08bit)
93AA46C(16bit)@TSSOP8 [(SA026)]	93AA56(16bit)
93AA56(08bit)@SOIC8 [(SA602A)]	93AA56A(08bit)
93AA56(16bit)@SOIC8 [(SA602A)]	93AA56A(08bit)@MSOP8 [(SA666)]
93AA56A(08bit)@DFN8 [(BBBB)]	93AA56A(08bit)@SOT-23 [(SA717)]
93AA56A(08bit)@SOIC8 [(SA602A)]	93AA56B(16bit)
93AA56A(08bit)@TSSOP8 [(SA026)]	93AA56B(16bit)@MSOP8 [(SA666)]
93AA56B(16bit)@DFN8 [(BBBB)]	93AA56B(16bit)@SOT-23 [(SA717)]
93AA56B(16bit)@SOIC8 [(SA602A)]	93AA56C(08bit)
93AA56B(16bit)@TSSOP8 [(SA026)]	93AA56C(08bit)@MSOP8 [(SA666)]
93AA56C(08bit)@SOIC8 [(SA602A)]	
93AA56C(08bit)@TSSOP8 [(SA026)]	
93AA56C(08bit)@DFN8 [(BBBB)]	

93AA56C(08bit)@SOIC8 [(SA602A)]	93AA56C(08bit)@TSSOP8 [(SA026)]
93AA56C(16bit)	93AA56C(16bit)@DFN8 [(BBBB)]
93AA56C(16bit)@MSOP8 [(SA666)]	93AA56C(16bit)@SOIC8 [(SA602A)]
93AA56C(16bit)@TSSOP8 [(SA026)]	93AA66(08bit)
93AA66(08bit)@SOIC8 [(SA602A)]	93AA66(16bit)
93AA66(16bit)@SOIC8 [(SA602A)]	93AA66A(08bit)
93AA66A(08bit)@DFN8 [(BBBB)]	93AA66A(08bit)@MSOP8 [(SA666)]
93AA66A(08bit)@SOIC8 [(SA602A)]	93AA66A(08bit)@SOT-23 [(SA717)]
93AA66A(08bit)@TSSOP8 [(SA026)]	93AA66B(16bit)
93AA66B(16bit)@DFN8 [(BBBB)]	93AA66B(16bit)@MSOP8 [(SA666)]
93AA66B(16bit)@SOIC8 [(SA602A)]	93AA66B(16bit)@SOT-23 [(SA717)]
93AA66B(16bit)@TSSOP8 [(SA026)]	93AA66C(08bit)
93AA66C(08bit)@DFN8 [(BBBB)]	93AA66C(08bit)@MSOP8 [(SA666)]
93AA66C(08bit)@SOIC8 [(SA602A)]	93AA66C(08bit)@TSSOP8 [(SA026)]
93AA66C(16bit)	93AA66C(16bit)@DFN8 [(BBBB)]
93AA66C(16bit)@MSOP8 [(SA666)]	93AA66C(16bit)@SOIC8 [(SA602A)]
93AA66C(16bit)@TSSOP8 [(SA026)]	93AA76(08bit)
93AA76(08bit)@SOIC8 [(SA602A)]	93AA76(16bit)
93AA76(16bit)@SOIC8 [(SA602A)]	93AA76A(08bit)
93AA76A(08bit)@DFN8 [(BBBB)]	93AA76A(08bit)@MSOP8 [(SA666)]
93AA76A(08bit)@SOIC8 [(SA602A)]	93AA76A(08bit)@SOT-23 [(SA717)]
93AA76A(08bit)@TSSOP8 [(SA026)]	93AA76B(16bit)
93AA76B(16bit)@DFN8 [(BBBB)]	93AA76B(16bit)@MSOP8 [(SA666)]
93AA76B(16bit)@SOIC8 [(SA602A)]	93AA76B(16bit)@SOT-23 [(SA717)]
93AA76B(16bit)@TSSOP8 [(SA026)]	93AA76C(08bit)
93AA76C(08bit)@DFN8 [(BBBB)]	93AA76C(08bit)@MSOP8 [(SA666)]
93AA76C(08bit)@SOIC8 [(SA602A)]	93AA76C(08bit)@TSSOP8 [(SA026)]
93AA76C(16bit)	93AA76C(16bit)@DFN8 [(BBBB)]
93AA76C(16bit)@MSOP8 [(SA666)]	93AA76C(16bit)@SOIC8 [(SA602A)]
93AA76C(16bit)@TSSOP8 [(SA026)]	93AA86(08bit)
93AA86(08bit)@SOIC8 [(SA602A)]	93AA86(16bit)
93AA86(16bit)@SOIC8 [(SA602A)]	93AA86A(08bit)
93AA86A(08bit)@DFN8 [(BBBB)]	93AA86A(08bit)@MSOP8 [(SSA666)]
93AA86A(08bit)@SOIC8 [(SA602A)]	93AA86A(08bit)@SOT-23 [(SA717)]
93AA86A(08bit)@TSSOP8 [(SA026)]	93AA86B(16bit)
93AA86B(16bit)@DFN8 [(BBBB)]	93AA86B(16bit)@MSOP8 [(SA666)]
93AA86B(16bit)@SOIC8 [(SA602A)]	93AA86B(16bit)@SOT-23 [(SA717)]
93AA86B(16bit)@TSSOP8 [(SA026)]	93AA86C(08bit)
93AA86C(08bit)@DFN8 [(BBBB)]	93AA86C(08bit)@MSOP8 [(SA666)]
93AA86C(08bit)@SOIC8 [(SA602A)]	93AA86C(08bit)@TSSOP8 [(SA026)]
93AA86C(16bit)	93AA86C(16bit)@DFN8 [(BBBB)]
93AA86C(16bit)@MSOP8 [(SA666)]	93AA86C(16bit)@SOIC8 [(SA602A)]
93AA86C(16bit)@TSSOP8 [(SA026)]	93C06(08bit)
93C06(08bit)@SOIC8 [(SA602A)]	93C06(16bit)
93C06(16bit)@SOIC8 [(SA602A)]	93C46(08bit)
93C46(08bit)@SOIC8 [(SA602A)]	93C46(16bit)
93C46(16bit)@SOIC8 [(SA602A)]	93C46A(08bit)
93C46A(08bit)@DFN8 [(BBBB)]	93C46A(08bit)@MSOP8 [(SA666)]
93C46A(08bit)@SOIC8 [(SA602A)]	93C46A(08bit)@SOT-23 [(SA717)]
93C46A(08bit)@TSSOP8 [(SA026)]	93C46B(16bit)
93C46B(16bit)@DFN8 [(BBBB)]	93C46B(16bit)@MSOP8 [(SA666)]
93C46B(16bit)@SOIC8 [(SA602A)]	93C46B(16bit)@SOT-23 [(SA717)]
93C46B(16bit)@TSSOP8 [(SA026)]	93C46C(08bit)
93C46C(08bit)@DFN8 [(BBBB)]	93C46C(08bit)@MSOP8 [(SA666)]
93C46C(08bit)@SOIC8 [(SA602A)]	93C46C(08bit)@TSSOP8 [(SA026)]
93C46C(16bit)	93C46C(16bit)@DFN8 [(BBBB)]
93C46C(16bit)@MSOP8 [(SA666)]	93C46C(16bit)@SOIC8 [(SA602A)]
93C46C(16bit)@TSSOP8 [(SA026)]	93C56(08bit)
93C56(08bit)@SOIC8 [(SA602A)]	93C56(16bit)
93C56(16bit)@SOIC8 [(SA602A)]	93C56A(08bit)
93C56A(08bit)@DFN8 [(BBBB)]	93C56A(08bit)@MSOP8 [(SA666)]
93C56A(08bit)@SOIC8 [(SA602A)]	93C56A(08bit)@SOT-23 [(SA717)]
93C56A(08bit)@TSSOP8 [(SA026)]	93C56B(16bit)
93C56B(16bit)@DFN8 [(BBBB)]	93C56B(16bit)@MSOP8 [(SA666)]
93C56B(16bit)@SOIC8 [(SA602A)]	93C56B(16bit)@SOT-23 [(SA717)]
93C56B(16bit)@TSSOP8 [(SA026)]	93C56C(08bit)
93C56C(08bit)@DFN8 [(BBBB)]	93C56C(08bit)@MSOP8 [(SA666)]
93C56C(08bit)@SOIC8 [(SA602A)]	93C56C(08bit)@TSSOP8 [(SA026)]
93C56C(16bit)	93C56C(16bit)@DFN8 [(BBBB)]
93C56C(16bit)@MSOP8 [(SA666)]	93C56C(16bit)@SOIC8 [(SA602A)]
93C56C(16bit)@TSSOP8 [(SA026)]	93C66(08bit)
93C66(08bit)@SOIC8 [(SA602A)]	93C66(16bit)
93C66(16bit)@SOIC8 [(SA602A)]	93C66A(08bit)
93C66A(08bit)@DFN8 [(BBBB)]	93C66A(08bit)@MSOP8 [(SA666)]
93C66A(08bit)@SOIC8 [(SA602A)]	93C66A(08bit)@SOT-23 [(SA717)]
93C66A(08bit)@TSSOP8 [(SA026)]	93C66B(16bit)
93C66B(16bit)@DFN8 [(BBBB)]	93C66B(16bit)@MSOP8 [(SA666)]
93C66B(16bit)@SOIC8 [(SA602A)]	93C66B(16bit)@SOT-23 [(SA717)]
93C66B(16bit)@TSSOP8 [(SA026)]	93C66C(08bit)
93C66C(08bit)@DFN8 [(BBBB)]	93C66C(08bit)@MSOP8 [(SA666)]
93C66C(08bit)@SOIC8 [(SA602A)]	93C66C(08bit)@TSSOP8 [(SA026)]

```

93C66C(16bit)
93C66C(16bit)@MSOP8 [(SA666)]
93C66C(16bit)@TSSOP8 [(SA026)]
93C76(08bit)@SOIC8 [(SA602A)]
93C76(16bit)@SOIC8 [(SA602A)]
93C76A(08bit)@DFN8 [(BBBB)]
93C76A(08bit)@SOIC8 [(SA602A)]
93C76A(08bit)@TSSOP8 [(SA026)]
93C76B(16bit)@DFN8 [(BBBB)]
93C76B(16bit)@SOIC8 [(SA602A)]
93C76B(16bit)@TSSOP8 [(SA026)]
93C76C(08bit)@DFN8 [(BBBB)]
93C76C(08bit)@SOIC8 [(SA602A)]
93C76C(16bit)
93C76C(16bit)@MSOP8 [(SA666)]
93C76C(16bit)@TSSOP8 [(SA026)]
93C86(08bit)@SOIC8 [(SA602A)]
93C86(16bit)@SOIC8 [(SA602A)]
93C86A(08bit)@DFN8 [(BBBB)]
93C86A(08bit)@SOIC8 [(SA602A)]
93C86A(08bit)@TSSOP8 [(SA026)]
93C86B(16bit)@DFN8 [(BBBB)]
93C86B(16bit)@SOIC8 [(SA602A)]
93C86B(16bit)@TSSOP8 [(SA026)]
93C86C(08bit)@DFN8 [(BBBB)]
93C86C(08bit)@SOIC8 [(SA602A)]
93C86C(16bit)
93C86C(16bit)@MSOP8 [(SA666)]
93C86C(16bit)@TSSOP8 [(SA026)]
93LC46(08bit)@SOIC8 [(SA602A)]
93LC46(16bit)@SOIC8 [(SA602A)]
93LC46A(08bit)@DFN8 [(BBBB)]
93LC46A(08bit)@SOIC8 [(SA602A)]
93LC46A(08bit)@TSSOP8 [(SA026)]
93LC46B(16bit)@DFN8 [(BBBB)]
93LC46B(16bit)@SOIC8 [(SA602A)]
93LC46B(16bit)@TSSOP8 [(SA026)]
93LC46BX@SOIC8 [(SA602A)]
93LC46C(08bit)@DFN8 [(BBBB)]
93LC46C(08bit)@SOIC8 [(SA602A)]
93LC46C(16bit)
93LC46C(16bit)@MSOP8 [(SA666)]
93LC46C(16bit)@TSSOP8 [(SA026)]
93LC46C(16bit)@SOIC8 [(SA602A)]
93LC56(08bit)@SOIC8 [(SA602A)]
93LC56(16bit)@SOIC8 [(SA602A)]
93LC56A(08bit)@DFN8 [(BBBB)]
93LC56A(08bit)@SOIC8 [(SA602A)]
93LC56A(08bit)@TSSOP8 [(SA026)]
93LC56B(16bit)@DFN8 [(BBBB)]
93LC56B(16bit)@SOIC8 [(SA602A)]
93LC56B(16bit)@TSSOP8 [(SA026)]
93LC56BX@SOIC8 [(SA602A)]
93LC56C(08bit)@DFN8 [(BBBB)]
93LC56C(08bit)@SOIC8 [(SA602A)]
93LC56C(16bit)
93LC56C(16bit)@MSOP8 [(SA666)]
93LC56C(16bit)@TSSOP8 [(SA026)]
93LC66(08bit)@SOIC8 [(SA602A)]
93LC66(16bit)@SOIC8 [(SA602A)]
93LC66A(08bit)@DFN8 [(BBBB)]
93LC66A(08bit)@SOIC8 [(SA602A)]
93LC66A(08bit)@TSSOP8 [(SA026)]
93LC66B(16bit)@DFN8 [(BBBB)]
93LC66B(16bit)@SOIC8 [(SA602A)]
93LC66B(16bit)@TSSOP8 [(SA026)]
93LC66BX@SOIC8 [(SA602A)]
93LC66C(08bit)@DFN8 [(BBBB)]
93LC66C(08bit)@SOIC8 [(SA602A)]
93LC66C(16bit)
93LC66C(16bit)@MSOP8 [(SA666)]
93LC66C(16bit)@TSSOP8 [(SA026)]
93LC76(08bit)@SOIC8 [(SA602A)]
93LC76(16bit)@SOIC8 [(SA602A)]
93LC76A(08bit)@DFN8 [(BBBB)]
93LC76A(08bit)@SOIC8 [(SA602A)]
93LC76A(08bit)@TSSOP8 [(SA026)]
93LC76B(16bit)@DFN8 [(BBBB)]
93LC76B(16bit)@SOIC8 [(SA602A)]
93LC76B(16bit)@TSSOP8 [(SA026)]
93LC76C(08bit)@DFN8 [(BBBB)]
93LC76C(08bit)@SOIC8 [(SA602A)]
93C66C(16bit)@DFN8 [(BBBB)]
93C66C(16bit)@SOIC8 [(SA602A)]
93C76(08bit)
93C76(16bit)
93C76A(08bit)
93C76A(08bit)@MSOP8 [(SA666)]
93C76A(08bit)@SOT-23 [(SA717)]
93C76B(16bit)
93C76B(16bit)@MSOP8 [(SA666)]
93C76B(16bit)@SOT-23 [(SA717)]
93C76C(08bit)
93C76C(08bit)@MSOP8 [(SA666)]
93C76C(08bit)@TSSOP8 [(SA026)]
93C76C(16bit)@DFN8 [(BBBB)]
93C76C(16bit)@SOIC8 [(SA602A)]
93C86(08bit)
93C86(16bit)
93C86A(08bit)
93C86A(08bit)@MSOP8 [(SSA666)]
93C86A(08bit)@SOT-23 [(SA717)]
93C86B(16bit)
93C86B(16bit)@MSOP8 [(SA666)]
93C86B(16bit)@SOT-23 [(SA717)]
93C86C(08bit)
93C86C(08bit)@MSOP8 [(SA666)]
93C86C(08bit)@TSSOP8 [(SA026)]
93C86C(16bit)@DFN8 [(BBBB)]
93C86C(16bit)@SOIC8 [(SA602A)]
93LC46(08bit)
93LC46(16bit)
93LC46A(08bit)
93LC46A(08bit)@MSOP8 [(SA666)]
93LC46A(08bit)@SOT-23 [(SA717)]
93LC46B(16bit)
93LC46B(16bit)@MSOP8 [(SA666)]
93LC46B(16bit)@SOT-23 [(SA717)]
93LC46BX
93LC46C(08bit)
93LC46C(08bit)@MSOP8 [(SA666)]
93LC46C(08bit)@TSSOP8 [(SA026)]
93LC46C(16bit)@DFN8 [(BBBB)]
93LC46C(16bit)@SOIC8 [(SA602A)]
93LC56(08bit)
93LC56(16bit)
93LC56A(08bit)
93LC56A(08bit)@MSOP8 [(SA666)]
93LC56A(08bit)@SOT-23 [(SA717)]
93LC56B(16bit)
93LC56B(16bit)@MSOP8 [(SA666)]
93LC56B(16bit)@SOT-23 [(SA717)]
93LC56BX
93LC56C(08bit)
93LC56C(08bit)@MSOP8 [(SA666)]
93LC56C(08bit)@TSSOP8 [(SA026)]
93LC56C(16bit)@DFN8 [(BBBB)]
93LC56C(16bit)@SOIC8 [(SA602A)]
93LC66(08bit)
93LC66(16bit)
93LC66A(08bit)
93LC66A(08bit)@MSOP8 [(SA666)]
93LC66A(08bit)@SOT-23 [(SA717)]
93LC66B(16bit)
93LC66B(16bit)@MSOP8 [(SA666)]
93LC66B(16bit)@SOT-23 [(SA717)]
93LC66BX
93LC66C(08bit)
93LC66C(08bit)@MSOP8 [(SA666)]
93LC66C(08bit)@TSSOP8 [(SA026)]
93LC66C(16bit)@DFN8 [(BBBB)]
93LC66C(16bit)@SOIC8 [(SA602A)]
93LC76(08bit)
93LC76(16bit)
93LC76A(08bit)
93LC76A(08bit)@MSOP8 [(SA666)]
93LC76A(08bit)@SOT-23 [(SA717)]
93LC76B(16bit)
93LC76B(16bit)@MSOP8 [(SA666)]
93LC76B(16bit)@SOT-23 [(SA717)]
93LC76C(08bit)
93LC76C(08bit)@MSOP8 [(SA666)]
93LC76C(08bit)@TSSOP8 [(SA026)]

```

93LC76C(16bit)	93LC76C(16bit)@DFN8 [(BBBB)]
93LC76C(16bit)@MSOP8 [(SA666)]	93LC76C(16bit)@SOIC8 [(SA602A)]
93LC76C(16bit)@TSSOP8 [(SA026)]	93LC86(08bit)
93LC86(08bit)@SOIC8 [(SA602A)]	93LC86(16bit)
93LC86(16bit)@SOIC8 [(SA602A)]	93LC86A(08bit)
93LC86A(08bit)@DFN8 [(BBBB)]	93LC86A(08bit)@MSOP8 [(SSA666)]
93LC86A(08bit)@SOIC8 [(SA602A)]	93LC86A(08bit)@SOT-23 [(SA717)]
93LC86A(08bit)@TSSOP8 [(SA026)]	93LC86B(16bit)
93LC86B(16bit)@DFN8 [(BBBB)]	93LC86B(16bit)@MSOP8 [(SA666)]
93LC86B(16bit)@SOIC8 [(SA602A)]	93LC86B(16bit)@SOT-23 [(SA717)]
93LC86B(16bit)@TSSOP8 [(SA026)]	93LC86C(08bit)
93LC86C(08bit)@DFN8 [(BBBB)]	93LC86C(08bit)@MSOP8 [(SA666)]
93LC86C(08bit)@SOIC8 [(SA602A)]	93LC86C(08bit)@TSSOP8 [(SA026)]
93LC86C(16bit)	93LC86C(16bit)@DFN8 [(BBBB)]
93LC86C(16bit)@MSOP8 [(SA666)]	93LC86C(16bit)@SOIC8 [(SA602A)]
93LC86C(16bit)@TSSOP8 [(SA026)]	93LCS46
93LCS46@SOIC14 [(SA026)]	93LCS46@SOIC8 [(SA602A)]
93LCS56	93LCS56@SOIC14 [(SA026)]
93LCS56@SOIC8 [(SA602A)]	93LCS66
93LCS66@SOIC14 [(SA026)]	93LCS66@SOIC8 [(SA602A)]
ER5911	ER5911@SOIC8 [(SA602A)]
HCS101	HCS101SN@SOIC8 [(SA602A)]
HCS200	HCS200SN@SOIC8 [(SA602A)]
HCS300	HCS300SN@SOIC8 [(SA602A)]
HCS301	HCS301SN@SOIC8 [(SA602A)]
HCS320	HCS320SN@SOIC8 [(SA602A)]
HCS360	HCS360SN@SOIC8 [(SA602A)]
HCS361	HCS361SN@SOIC8 [(SA602A)]

MICROCONTROLLER

MCP25020(150mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25020(208mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25020(ISP) [ISP-HEADER01]	
MCP25025(150mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25025(208mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25025(ISP) [ISP-HEADER01]	
MCP25050(150mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25050(208mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25050(ISP) [ISP-HEADER01]	
MCP25055(150mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25055(208mil)@SOIC14(ISP) [ISP-HEADER01]	
MCP25055(ISP) [ISP-HEADER01]	PIC10F200
PIC10F200(ISP) [ISP-HEADER01]	PIC10F200@SOT6 [(SA717)]
PIC10F200@SOT6(ISP) [ISP-HEADER01]	
PIC10F202	PIC10F202(ISP) [ISP-HEADER01]
PIC10F202@SOT6 [(SA717)]	
PIC10F202@SOT6(ISP) [ISP-HEADER01]	
PIC10F204	PIC10F204(ISP) [ISP-HEADER01]
PIC10F204@SOT6 [(SA717)]	
PIC10F204@SOT6(ISP) [ISP-HEADER01]	
PIC10F206	PIC10F206(ISP) [ISP-HEADER01]
PIC10F206@SOT6 [(SA717)]	
PIC10F206@SOT6(ISP) [ISP-HEADER01]	
PIC10F220	PIC10F220(ISP) [ISP-HEADER01]
PIC10F220@SOT6 [(SA717)]	
PIC10F220@SOT6(ISP) [ISP-HEADER01]	
PIC10F222	PIC10F222(ISP) [ISP-HEADER01]
PIC10F222@SOT6 [(SA717)]	
PIC10F222@SOT6(ISP) [ISP-HEADER01]	
PIC12C508	PIC12C508(ISP) [ISP-HEADER01]
PIC12C508@SOIC8 [(SA605A)]	
PIC12C508@SOIC8(ISP) [ISP-HEADER01]	
PIC12C508A	PIC12C508A(ISP) [ISP-HEADER01]
PIC12C508A(SM)@SOIC8 [(SA605A)]	
PIC12C508A(SM)@SOIC8(ISP) [ISP-HEADER01]	
PIC12C508A(SN)@SOIC8 [(SA602A)]	
PIC12C508A(SN)@SOIC8(ISP) [ISP-HEADER01]	
PIC12C509	PIC12C509(ISP) [ISP-HEADER01]
PIC12C509(SM)@SOIC8 [(SA605A)]	
PIC12C509(SM)@SOIC8(ISP) [ISP-HEADER01]	
PIC12C509(SN)@SOIC8 [(SA602A)]	
PIC12C509(SN)@SOIC8(ISP) [ISP-HEADER01]	
PIC12C509A	PIC12C509A(ISP) [ISP-HEADER01]
PIC12C509A(SM)@SOIC8 [(SA605A)]	
PIC12C509A(SM)@SOIC8(ISP) [ISP-HEADER01]	
PIC12C509A(SN)@SOIC8 [(SA602A)]	
PIC12C509A(SN)@SOIC8(ISP) [ISP-HEADER01]	
PIC12C509A@DFN8 [(SA683)]	

```

PIC12C509A@DFN8 (ISP) [ISP-HEADER01]
PIC12C671 PIC12C671 (ISP) [ISP-HEADER01]
PIC12C671@DFN8 [(SA683)]
PIC12C671@DFN8 (ISP) [ISP-HEADER01]
PIC12C671@SOIC8 [(SA605A)]
PIC12C671@SOIC8 (ISP) [ISP-HEADER01]
PIC12C672 PIC12C672 (ISP) [ISP-HEADER01]
PIC12C672@DFN8 [(SA683)]
PIC12C672@DFN8 (ISP) [ISP-HEADER01]
PIC12C672@SOIC8 [(SA605A)]
PIC12C672@SOIC8 (ISP) [ISP-HEADER01]
PIC12CE518 PIC12CE518 (ISP) [ISP-HEADER01]
PIC12CE518@SOIC8 [(SA605A)]
PIC12CE518@SOIC8 (ISP) [ISP-HEADER01]
PIC12CE519 PIC12CE519 (ISP) [ISP-HEADER01]
PIC12CE519 (SM)@SOIC8 [(SA605A)]
PIC12CE519 (SM)@SOIC8 (ISP) [ISP-HEADER01]
PIC12CE519 (SN)@SOIC8 [(SA602A)]
PIC12CE519 (SN)@SOIC8 (ISP) [ISP-HEADER01]
PIC12CE673 PIC12CE673 (ISP) [ISP-HEADER01]
PIC12CE673@SOIC8 [(SA605A)]
PIC12CE673@SOIC8 (ISP) [ISP-HEADER01]
PIC12CE674 PIC12CE674 (ISP) [ISP-HEADER01]
PIC12CE674@SOIC8 [(SA605A)]
PIC12CE674@SOIC8 (ISP) [ISP-HEADER01]
PIC12F508 PIC12F508 (ISP) [ISP-HEADER01]
PIC12F508@MSOP8 [(SA666)]
PIC12F508@MSOP8 (ISP) [ISP-HEADER01]
PIC12F508@SOIC8 [(SA602)]
PIC12F508@SOIC8 (ISP) [ISP-HEADER01]
PIC12F509 PIC12F509 (ISP) [ISP-HEADER01]
PIC12F509@MSOP8 [(SA666)]
PIC12F509@MSOP8 (ISP) [ISP-HEADER01]
PIC12F509@SOIC8 [(SA602)]
PIC12F509@SOIC8 (ISP) [ISP-HEADER01]
PIC12F510 PIC12F510 (ISP) [ISP-HEADER01]
PIC12F510@MSOP8 [(SA666)]
PIC12F510@MSOP8 (ISP) [ISP-HEADER01]
PIC12F510@SOIC8 [(SA605A)]
PIC12F510@SOIC8 (ISP) [ISP-HEADER01]
PIC12F519 PIC12F519@DFN8 [(SA724)]
PIC12F519@MSOP8 [(SA666)] PIC12F519@SOIC8 [(SA602)]
PIC12F609 PIC12F609 (ISP) [ISP-HEADER01]
PIC12F609@DFN8 [(BBBB)]
PIC12F609@DFN8 (ISP) [ISP-HEADER01]
PIC12F609@SOIC8 [(SA602A)]
PIC12F609@SOIC8 (ISP) [ISP-HEADER01]
PIC12F615 PIC12F615 (ISP) [ISP-HEADER01]
PIC12F615@DFN8 [(BBBB)]
PIC12F615@DFN8 (ISP) [ISP-HEADER01]
PIC12F615@SOIC8 [(SA602A)]
PIC12F615@SOIC8 (ISP) [ISP-HEADER01]
PIC12F629 PIC12F629 (ISP) [ISP-HEADER01]
PIC12F629 (SM)@SOIC8 [(SA605A)]
PIC12F629 (SM)@SOIC8 (ISP) [ISP-HEADER01]
PIC12F629 (SN)@SOIC8 [(SA602A)]
PIC12F629 (SN)@SOIC8 (ISP) [ISP-HEADER01]
PIC12F629@DFN8 [(SA683)]
PIC12F629@DFN8 (ISP) [ISP-HEADER01]
PIC12F635 PIC12F635 (ISP) [ISP-HEADER01]
PIC12F635 (MD)@DFN8 [(SA744)]
PIC12F635 (MD)@DFN8 (ISP) [ISP-HEADER01]
PIC12F635 (MF)@DFN8 [(SA683)]
PIC12F635 (MF)@DFN8 (ISP) [ISP-HEADER01]
PIC12F635 (SM)@SOIC8 [(SA605A)]
PIC12F635 (SM)@SOIC8 (ISP) [ISP-HEADER01]
PIC12F635 (SN)@SOIC8 [(SA602A)]
PIC12F635 (SN)@SOIC8 (ISP) [ISP-HEADER01]
PIC12F675 PIC12F675 (ISP) [ISP-HEADER01]
PIC12F675 (SM)@SOIC8 [(SA605A)]
PIC12F675 (SM)@SOIC8 (ISP) [ISP-HEADER01]
PIC12F675 (SN)@SOIC8 [(SA602A)]
PIC12F675 (SN)@SOIC8 (ISP) [ISP-HEADER01]
PIC12F675@DFN8 [(SA683)]
PIC12F675@DFN8 (ISP) [ISP-HEADER01]
PIC12F675@SSOP20 [(SA626A)]
PIC12F675@SSOP20 (ISP) [ISP-HEADER01]
PIC12F683 PIC12F683 (ISP) [ISP-HEADER01]
PIC12F683 (MD)@DFN8 [(SA744)]
PIC12F683 (MD)@DFN8 (ISP) [ISP-HEADER01]
PIC12F683 (MF)@DFN8 [(SA683)]

```

```

PIC12F683(MF)@DFN8(ISP) [ISP-HEADER01]
PIC12F683(SM)@SOIC8 [(SA605A)]
PIC12F683(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12F683(SN)@SOIC8 [(SA602A)]
PIC12F683(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12HV609 PIC12HV609(ISP) [ISP-HEADER01]
PIC12HV609@DFN8 [(BBBB)]
PIC12HV609@DFN8(ISP) [ISP-HEADER01]
PIC12HV609@SOIC8 [(SA602A)]
PIC12HV609@SOIC8(ISP) [ISP-HEADER01]
PIC12HV615 PIC12HV615(ISP) [ISP-HEADER01]
PIC12HV615@DFN8 [(BBBB)]
PIC12HV615@DFN8(ISP) [ISP-HEADER01]
PIC12HV615@SOIC8 [(SA602A)]
PIC12HV615@SOIC8(ISP) [ISP-HEADER01]
PIC12LC508 PIC12LC508(ISP) [ISP-HEADER01]
PIC12LC508@SOIC8 [(SA605A)]
PIC12LC508@SOIC8(ISP) [ISP-HEADER01]
PIC12LC508A PIC12LC508A(ISP) [ISP-HEADER01]
PIC12LC508A(SM)@SOIC8 [(SA605A)]
PIC12LC508A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC508A(SN)@SOIC8 [(SA602A)]
PIC12LC508A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509 PIC12LC509(ISP) [ISP-HEADER01]
PIC12LC509(SM)@SOIC8 [(SA605A)]
PIC12LC509(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509(SN)@SOIC8 [(SA602A)]
PIC12LC509(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509A PIC12LC509A(ISP) [ISP-HEADER01]
PIC12LC509A(SM)@SOIC8 [(SA605A)]
PIC12LC509A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509A(SN)@SOIC8 [(SA602A)]
PIC12LC509A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC671 PIC12LC671(ISP) [ISP-HEADER01]
PIC12LC671@DFN8 [(SA683)]
PIC12LC671@DFN8(ISP) [ISP-HEADER01]
PIC12LC671@SOIC8 [(SA605A)]
PIC12LC671@SOIC8(ISP) [ISP-HEADER01]
PIC12LC672 PIC12LC672(ISP) [ISP-HEADER01]
PIC12LC672@DFN8 [(SA683)]
PIC12LC672@DFN8(ISP) [ISP-HEADER01]
PIC12LC672@SOIC8 [(SA605A)]
PIC12LC672@SOIC8(ISP) [ISP-HEADER01]
PIC12LF508 PIC12LF508(ISP) [ISP-HEADER01]
PIC12LF508@MSOP8 [(SA666)]
PIC12LF508@MSOP8(ISP) [ISP-HEADER01]
PIC12LF508@SOIC8 [(SA602)]
PIC12LF508@SOIC8(ISP) [ISP-HEADER01]
PIC12LF509 PIC12LF509(ISP) [ISP-HEADER01]
PIC12LF509@MSOP8 [(SA666)]
PIC12LF509@MSOP8(ISP) [ISP-HEADER01]
PIC12LF509@SOIC8 [(SA602)]
PIC12LF509@SOIC8(ISP) [ISP-HEADER01]
PIC12LF519 PIC12LF519@DFN8 [(SA724)]
PIC12LF519@MSOP8 [(SA666)] PIC12LF519@SOIC8 [(SA602)]
PIC14000 PIC14000(ISP) [ISP-HEADER01]
PIC14000@SOIC28 [(SA404)]
PIC14000@SOIC28(ISP) [ISP-HEADER01]
PIC14000@SSOP28 [(SA626A)]
PIC14000@SSOP28(ISP) [ISP-HEADER01]
PIC16C432 PIC16C432(ISP) [ISP-HEADER01]
PIC16C432@SSOP20 [(SA626A)]
PIC16C432@SSOP20(ISP) [ISP-HEADER01]
PIC16C433 PIC16C433(ISP) [ISP-HEADER01]
PIC16C433@SOIC18 [(SA404)]
PIC16C433@SOIC18(ISP) [ISP-HEADER01]
PIC16C505 PIC16C505@SOIC14 [(SA602)]
PIC16C52 PIC16C52@SOIC18 [(SA404)]
PIC16C54 PIC16C54@SOIC18 [(SA404)]
PIC16C54A PIC16C54A@SOIC18 [(SA404)]
PIC16C54A@SSOP20 [(SA626A)] PIC16C54B
PIC16C54B@SOIC18 [(SA404)] PIC16C54B@SSOP20 [(SA626A)]
PIC16C54C PIC16C54C@SOIC18 [(SA404)]
PIC16C54C@SSOP20 [(SA626A)] PIC16C55
PIC16C55@SOIC28 [(SA404)] PIC16C554
PIC16C554(ISP) [ISP-HEADER01] PIC16C554@SOIC18 [(SA404)]
PIC16C554@SOIC18(ISP) [ISP-HEADER01]
PIC16C554@SSOP20 [(SA626A)]
PIC16C554@SSOP20(ISP) [ISP-HEADER01]
PIC16C556 PIC16C556(ISP) [ISP-HEADER01]
PIC16C556@SOIC18 [(SA404)]

```

```

PIC16C556@SOIC18(ISP) [ISP-HEADER01]
PIC16C558 PIC16C558(ISP) [ISP-HEADER01]
PIC16C558@SOIC18 [(SA404)]
PIC16C558@SOIC18(ISP) [ISP-HEADER01]
PIC16C558@SSOP20 [(SA626A)]
PIC16C558@SSOP20(ISP) [ISP-HEADER01]
PIC16C55A PIC16C55A@SOIC28 [(SA404)]
PIC16C55A@SSOP28 [(SA626A)] PIC16C56
PIC16C56@SOIC18 [(SA404)] PIC16C56A
PIC16C56A@SOIC18 [(SA404)] PIC16C56A@SSOP20 [(SA626A)]
PIC16C57 PIC16C57@SOIC28 [(SA404)]
PIC16C57@SSOP28 [(SA626A)] PIC16C57C
PIC16C57C@SOIC28 [(SA404)] PIC16C57C@SSOP28 [(SA626A)]
PIC16C58 PIC16C58@SOIC18 [(SA404)]
PIC16C58A PIC16C58A@SOIC18 [(SA404)]
PIC16C58A@SSOP20 [(SA626A)] PIC16C58B
PIC16C58B@SOIC18 [(SA404)] PIC16C58B@SSOP20 [(SA626A)]
PIC16C61 PIC16C61(ISP) [ISP-HEADER01]
PIC16C61@SOIC18 [(SA404)]
PIC16C61@SOIC18(ISP) [ISP-HEADER01]
PIC16C62 PIC16C62(ISP) [ISP-HEADER01]
PIC16C62@SOIC28 [(SA404)]
PIC16C62@SOIC28(ISP) [ISP-HEADER01]
PIC16C62@SSOP28 [(SA626A)]
PIC16C62@SSOP28(ISP) [ISP-HEADER01]
PIC16C620 PIC16C620(ISP) [ISP-HEADER01]
PIC16C620@SOIC18 [(SA404)]
PIC16C620@SOIC18(ISP) [ISP-HEADER01]
PIC16C620A PIC16C620A(ISP) [ISP-HEADER01]
PIC16C620A@SOIC18 [(SA404)]
PIC16C620A@SOIC18(ISP) [ISP-HEADER01]
PIC16C620A@SSOP20 [(SA626A)]
PIC16C620A@SSOP20(ISP) [ISP-HEADER01]
PIC16C621 PIC16C621(ISP) [ISP-HEADER01]
PIC16C621@SOIC18 [(SA404)]
PIC16C621@SOIC18(ISP) [ISP-HEADER01]
PIC16C621A PIC16C621A(ISP) [ISP-HEADER01]
PIC16C621A@SOIC18 [(SA404)]
PIC16C621A@SOIC18(ISP) [ISP-HEADER01]
PIC16C621A@SSOP20 [(SA626A)]
PIC16C621A@SSOP20(ISP) [ISP-HEADER01]
PIC16C622 PIC16C622(ISP) [ISP-HEADER01]
PIC16C622@SOIC18 [(SA404)]
PIC16C622@SOIC18(ISP) [ISP-HEADER01]
PIC16C622A PIC16C622A(ISP) [ISP-HEADER01]
PIC16C622A@SOIC18 [(SA404)]
PIC16C622A@SOIC18(ISP) [ISP-HEADER01]
PIC16C622A@SSOP20 [(SA626A)]
PIC16C622A@SSOP20(ISP) [ISP-HEADER01]
PIC16C625 PIC16C625(ISP) [ISP-HEADER01]
PIC16C625@SOIC18 [(SA404)]
PIC16C625@SOIC18(ISP) [ISP-HEADER01]
PIC16C62A PIC16C62A(ISP) [ISP-HEADER01]
PIC16C62A@SOIC28 [(SA404)]
PIC16C62A@SOIC28(ISP) [ISP-HEADER01]
PIC16C62A@SSOP28 [(SA626A)]
PIC16C62A@SSOP28(ISP) [ISP-HEADER01]
PIC16C62B PIC16C62B(ISP) [ISP-HEADER01]
PIC16C62B@SOIC28 [(SA404)]
PIC16C62B@SOIC28(ISP) [ISP-HEADER01]
PIC16C62B@SSOP28 [(SA626A)]
PIC16C62B@SSOP28(ISP) [ISP-HEADER01]
PIC16C63 PIC16C63(ISP) [ISP-HEADER01]
PIC16C63@SOIC28 [(SA404)]
PIC16C63@SOIC28(ISP) [ISP-HEADER01]
PIC16C63A PIC16C63A(ISP) [ISP-HEADER01]
PIC16C63A@SOIC28 [(SA404)]
PIC16C63A@SOIC28(ISP) [ISP-HEADER01]
PIC16C63A@SSOP28 [(SA626A)]
PIC16C63A@SSOP28(ISP) [ISP-HEADER01]
PIC16C64 PIC16C64(ISP) [ISP-HEADER01]
PIC16C64@PLCC44 [(SA244)]
PIC16C64@PLCC44(ISP) [ISP-HEADER01]
PIC16C64@TQFP44 [(SA245A)]
PIC16C64@TQFP44(ISP) [ISP-HEADER01]
PIC16C641 PIC16C641@SOIC28 [(SA404)]
PIC16C641@SSOP28 [(SA626A)] PIC16C642
PIC16C642@SOIC28 [(SA404)] PIC16C642@SSOP28 [(SA626A)]
PIC16C64A PIC16C64A(ISP) [ISP-HEADER01]
PIC16C64A@PLCC44 [(SA244)]
PIC16C64A@PLCC44(ISP) [ISP-HEADER01]

```

```

PIC16C64A@TQFP44 [(SA245A)]
PIC16C64A@TQFP44(ISP) [ISP-HEADER01]
PIC16C65
PIC16C65@PLCC44 [(SA244)]
PIC16C65@PLCC44(ISP) [ISP-HEADER01]
PIC16C65@TQFP44 [(SA245A)]
PIC16C65@TQFP44(ISP) [ISP-HEADER01]
PIC16C65A
PIC16C65A@PLCC44 [(SA244)]
PIC16C65A@PLCC44(ISP) [ISP-HEADER01]
PIC16C65A@TQFP44 [(SA245A)]
PIC16C65A@TQFP44(ISP) [ISP-HEADER01]
PIC16C65B
PIC16C65B@PLCC44 [(SA244)]
PIC16C65B@PLCC44(ISP) [ISP-HEADER01]
PIC16C65B@TQFP44 [(SA245A)]
PIC16C65B@TQFP44(ISP) [ISP-HEADER01]
PIC16C66
PIC16C66@SOIC28 [(SA404)]
PIC16C66@SOIC28(ISP) [ISP-HEADER01]
PIC16C661
PIC16C661@TQFP44 [(SA245A)]
PIC16C662@PLCC44 [(SA244)]
PIC16C67
PIC16C67@PLCC44 [(SA244)]
PIC16C67@PLCC44(ISP) [ISP-HEADER01]
PIC16C67@TQFP44 [(SA245A)]
PIC16C67@TQFP44(ISP) [ISP-HEADER01]
PIC16C70
PIC16C70@SOIC18 [(SA404)]
PIC16C70@SOIC18(ISP) [ISP-HEADER01]
PIC16C71
PIC16C71@SOIC18 [(SA404)]
PIC16C71@SOIC18(ISP) [ISP-HEADER01]
PIC16C710
PIC16C710@SOIC18 [(SA404)]
PIC16C710@SOIC18(ISP) [ISP-HEADER01]
PIC16C710@SSOP20 [(SA626A)]
PIC16C710@SSOP20(ISP) [ISP-HEADER01]
PIC16C711
PIC16C711@SOIC18 [(SA404)]
PIC16C711@SOIC18(ISP) [ISP-HEADER01]
PIC16C711@SSOP20 [(SA626A)]
PIC16C711@SSOP20(ISP) [ISP-HEADER01]
PIC16C712
PIC16C712@SOIC18 [(SA404)]
PIC16C712@SOIC18(ISP) [ISP-HEADER01]
PIC16C712@SSOP20 [(SA626A)]
PIC16C712@SSOP20(ISP) [ISP-HEADER01]
PIC16C715
PIC16C715@SSOP20 [(SA626A)]
PIC16C716(ISP) [ISP-HEADER01]
PIC16C716@SOIC18(ISP) [ISP-HEADER01]
PIC16C716@SSOP20 [(SA626A)]
PIC16C716@SSOP20(ISP) [ISP-HEADER01]
PIC16C717
PIC16C717@SOIC18 [(SA404)]
PIC16C717@SOIC18(ISP) [ISP-HEADER01]
PIC16C717@SSOP20 [(SA626A)]
PIC16C717@SSOP20(ISP) [ISP-HEADER01]
PIC16C71A
PIC16C71A@SOIC18 [(SA404)]
PIC16C71A@SOIC18(ISP) [ISP-HEADER01]
PIC16C72
PIC16C72@SOIC28 [(SA404)]
PIC16C72@SOIC28(ISP) [ISP-HEADER01]
PIC16C72@SSOP28 [(SA626A)]
PIC16C72@SSOP28(ISP) [ISP-HEADER01]
PIC16C72A
PIC16C72A@SOIC28 [(SA404)]
PIC16C72A@SOIC28(ISP) [ISP-HEADER01]
PIC16C72A@SSOP28 [(SA626A)]
PIC16C72A@SSOP28(ISP) [ISP-HEADER01]
PIC16C73
PIC16C73@SOIC28 [(SA404)]
PIC16C73@SOIC28(ISP) [ISP-HEADER01]
PIC16C73A
PIC16C73A@SOIC28 [(SA404)]
PIC16C73A@SOIC28(ISP) [ISP-HEADER01]
PIC16C73B
PIC16C73B@SOIC28 [(SA404)]

```

PIC16C65(ISP) [ISP-HEADER01]

PIC16C65A(ISP) [ISP-HEADER01]

PIC16C65B(ISP) [ISP-HEADER01]

PIC16C66(ISP) [ISP-HEADER01]

PIC16C661@PLCC44 [(SA244)]

PIC16C662

PIC16C662@TQFP44 [(SA245A)]

PIC16C67(ISP) [ISP-HEADER01]

PIC16C70(ISP) [ISP-HEADER01]

PIC16C71(ISP) [ISP-HEADER01]

PIC16C710(ISP) [ISP-HEADER01]

PIC16C711(ISP) [ISP-HEADER01]

PIC16C712(ISP) [ISP-HEADER01]

PIC16C715@SOIC18 [(SA404)]

PIC16C716

PIC16C716@SOIC18 [(SA404)]

PIC16C717(ISP) [ISP-HEADER01]

PIC16C71A(ISP) [ISP-HEADER01]

PIC16C72(ISP) [ISP-HEADER01]

PIC16C72A(ISP) [ISP-HEADER01]

PIC16C73(ISP) [ISP-HEADER01]

PIC16C73A(ISP) [ISP-HEADER01]

PIC16C73B(ISP) [ISP-HEADER01]


```

PIC16C73B@SOIC28 (ISP) [ISP-HEADER01]
PIC16C73B@SSOP28 [(SA626A)]
PIC16C73B@SSOP28 (ISP) [ISP-HEADER01]
PIC16C74 PIC16C74 (ISP) [ISP-HEADER01]
PIC16C74@PLCC44 [(SA244)]
PIC16C74@PLCC44 (ISP) [ISP-HEADER01]
PIC16C74@TQFP44 [(SA245A)]
PIC16C74@TQFP44 (ISP) [ISP-HEADER01]
PIC16C745 PIC16C745 (ISP) [ISP-HEADER01]
PIC16C745@SOIC28 [(SA404)]
PIC16C745@SOIC28 (ISP) [ISP-HEADER01]
PIC16C74A PIC16C74A (ISP) [ISP-HEADER01]
PIC16C74A@PLCC44 [(SA244)]
PIC16C74A@PLCC44 (ISP) [ISP-HEADER01]
PIC16C74A@TQFP44 [(SA245A)]
PIC16C74A@TQFP44 (ISP) [ISP-HEADER01]
PIC16C74B PIC16C74B (ISP) [ISP-HEADER01]
PIC16C74B@MQFP44 [(SA675)]
PIC16C74B@MQFP44 (ISP) [ISP-HEADER01]
PIC16C74B@PLCC44 [(SA244)]
PIC16C74B@PLCC44 (ISP) [ISP-HEADER01]
PIC16C74B@TQFP44 [(SA245A)]
PIC16C74B@TQFP44 (ISP) [ISP-HEADER01]
PIC16C76 PIC16C76 (ISP) [ISP-HEADER01]
PIC16C76@SOIC28 [(SA404)]
PIC16C76@SOIC28 (ISP) [ISP-HEADER01]
PIC16C765 PIC16C765 (ISP) [ISP-HEADER01]
PIC16C765@PLCC44 [(SA244)]
PIC16C765@PLCC44 (ISP) [ISP-HEADER01]
PIC16C765@TQFP44 [(SA245A)]
PIC16C765@TQFP44 (ISP) [ISP-HEADER01]
PIC16C77 PIC16C77 (ISP) [ISP-HEADER01]
PIC16C77@PLCC44 [(SA244)]
PIC16C77@PLCC44 (ISP) [ISP-HEADER01]
PIC16C77@TQFP44 [(SA245A)]
PIC16C77@TQFP44 (ISP) [ISP-HEADER01]
PIC16C770 PIC16C770 (ISP) [ISP-HEADER01]
PIC16C770@SOIC20 [(SA404)]
PIC16C770@SOIC20 (ISP) [ISP-HEADER01]
PIC16C770@SSOP20 [(SA626A)]
PIC16C770@SSOP20 (ISP) [ISP-HEADER01]
PIC16C771 PIC16C771 (ISP) [ISP-HEADER01]
PIC16C771@SOIC20 [(SA404)]
PIC16C771@SOIC20 (ISP) [ISP-HEADER01]
PIC16C771@SSOP20 [(SA626A)]
PIC16C771@SSOP20 (ISP) [ISP-HEADER01]
PIC16C773 PIC16C773 (ISP) [ISP-HEADER01]
PIC16C773@SOIC28 [(SA404)]
PIC16C773@SOIC28 (ISP) [ISP-HEADER01]
PIC16C773@SSOP28 [(SA626A)]
PIC16C773@SSOP28 (ISP) [ISP-HEADER01]
PIC16C774 PIC16C774 (ISP) [ISP-HEADER01]
PIC16C774@PLCC44 [(SA244)]
PIC16C774@PLCC44 (ISP) [ISP-HEADER01]
PIC16C774@TQFP44 [(SA675)]
PIC16C774@TQFP44 (ISP) [ISP-HEADER01]
PIC16C781 PIC16C781 (ISP) [ISP-HEADER01]
PIC16C781@SOIC20 [(SA404)]
PIC16C781@SOIC20 (ISP) [ISP-HEADER01]
PIC16C781@SSOP20 [(SA626A)]
PIC16C781@SSOP20 (ISP) [ISP-HEADER01]
PIC16C782 PIC16C782 (ISP) [ISP-HEADER01]
PIC16C782@SOIC20 [(SA404)]
PIC16C782@SOIC20 (ISP) [ISP-HEADER01]
PIC16C782@SSOP20 [(SA626A)]
PIC16C782@SSOP20 (ISP) [ISP-HEADER01]
PIC16C84 PIC16C84 (ISP) [ISP-HEADER01]
PIC16C84@SOIC18 [(SA404)]
PIC16C84@SOIC18 (ISP) [ISP-HEADER01]
PIC16C923@PLCC68(*) [(SA648-B6807)]
PIC16C923@PLCC68 (ISP) [ISP-HEADER01]
PIC16C923@SDIP64 (ISP) [ISP-HEADER01]
PIC16C923@TQFP64 (ISP) [ISP-HEADER01]
PIC16C924@PLCC68(*) [(SA648-B6807)]
PIC16C924@PLCC68 (ISP) [ISP-HEADER01]
PIC16C924@SDIP64 (ISP) [ISP-HEADER01]
PIC16C924@TQFP64 (ISP) [ISP-HEADER01]
PIC16C925@PLCC68(*) [(SA648-B6807)]
PIC16C925@PLCC68 (ISP) [ISP-HEADER01]
PIC16C925@TQFP64 (ISP) [ISP-HEADER01]
PIC16C926@PLCC68(*) [(SA648-B6807)]

```

```

PIC16C926@PLCC68(ISP) [ISP-HEADER01]
PIC16C926@TQFP64(ISP) [ISP-HEADER01]
PIC16CE623 PIC16CE623(ISP) [ISP-HEADER01]
PIC16CE623@SOIC18 [(SA404)]
PIC16CE623@SOIC18(ISP) [ISP-HEADER01]
PIC16CE624 PIC16CE624(ISP) [ISP-HEADER01]
PIC16CE624@SOIC18 [(SA404)]
PIC16CE624@SOIC18(ISP) [ISP-HEADER01]
PIC16CE625 PIC16CE625(ISP) [ISP-HEADER01]
PIC16CE625@SOIC18 [(SA404)]
PIC16CE625@SOIC18(ISP) [ISP-HEADER01]
PIC16CE625@SSOP20 [(SA626A)]
PIC16CE625@SSOP20(ISP) [ISP-HEADER01]
PIC16CR83 PIC16CR83(ISP) [ISP-HEADER01]
PIC16CR83@SOIC18 [(SA404)]
PIC16CR83@SOIC18(ISP) [ISP-HEADER01]
PIC16CR84 PIC16CR84(ISP) [ISP-HEADER01]
PIC16CR84@SOIC18 [(SA404)]
PIC16CR84@SOIC18(ISP) [ISP-HEADER01]
PIC16F505 PIC16F505(ISP) [ISP-HEADER01]
PIC16F505@SOIC14 [(SA602)]
PIC16F505@SOIC14(ISP) [ISP-HEADER01]
PIC16F505@TSSOP14 [(SA026)]
PIC16F505@TSSOP14(ISP) [ISP-HEADER01]
PIC16F506 PIC16F506(ISP) [ISP-HEADER01]
PIC16F506@SOIC14 [(SA602)]
PIC16F506@SOIC14(ISP) [ISP-HEADER01]
PIC16F506@TSSOP14 [(SA026)]
PIC16F506@TSSOP14(ISP) [ISP-HEADER01]
PIC16F526 PIC16F526@SOIC14 [(SA602)]
PIC16F54(ISP) [ISP-HEADER01]
PIC16F54@SOIC18(ISP) [ISP-HEADER01]
PIC16F54@SSOP20 [(SA626A)]
PIC16F54@SSOP20(ISP) [ISP-HEADER01]
PIC16F57 PIC16F57(ISP) [ISP-HEADER01]
PIC16F57@SOIC28 [(SA404)]
PIC16F57@SOIC28(ISP) [ISP-HEADER01]
PIC16F57@SSOP28 [(SA626A)]
PIC16F57@SSOP28(ISP) [ISP-HEADER01]
PIC16F59 PIC16F59(ISP) [ISP-HEADER01]
PIC16F59@PLCC44 [(SA244)]
PIC16F59@PLCC44(ISP) [ISP-HEADER01]
PIC16F59@TQFP44 [(SA245A)]
PIC16F59@TQFP44(ISP) [ISP-HEADER01]
PIC16F610 PIC16F610(ISP) [ISP-HEADER01]
PIC16F610@QFN16 [(SA727)]
PIC16F610@QFN16(ISP) [ISP-HEADER01]
PIC16F610@SOIC14 [(SA602)]
PIC16F610@SOIC14(ISP) [ISP-HEADER01]
PIC16F610@TSSOP14 [(SA026)]
PIC16F610@TSSOP14(ISP) [ISP-HEADER01]
PIC16F616 PIC16F616(ISP) [ISP-HEADER01]
PIC16F616@QFN16 [(SA727)]
PIC16F616@QFN16(ISP) [ISP-HEADER01]
PIC16F616@SOIC14 [(SA602)]
PIC16F616@SOIC14(ISP) [ISP-HEADER01]
PIC16F616@TSSOP14 [(SA026)]
PIC16F616@TSSOP14(ISP) [ISP-HEADER01]
PIC16F627 PIC16F627(ISP) [ISP-HEADER01]
PIC16F627@SOIC18 [(SA404)]
PIC16F627@SOIC18(ISP) [ISP-HEADER01]
PIC16F627@SSOP20 [(SA626A)]
PIC16F627@SSOP20(ISP) [ISP-HEADER01]
PIC16F627A PIC16F627A(ISP) [ISP-HEADER01]
PIC16F627A@SOIC18 [(SA404)]
PIC16F627A@SOIC18(ISP) [ISP-HEADER01]
PIC16F627A@SSOP20 [(SA626A)]
PIC16F627A@SSOP20(ISP) [ISP-HEADER01]
PIC16F628 PIC16F628(ISP) [ISP-HEADER01]
PIC16F628@SOIC18 [(SA404)]
PIC16F628@SOIC18(ISP) [ISP-HEADER01]
PIC16F628@SSOP20 [(SA626A)]
PIC16F628@SSOP20(ISP) [ISP-HEADER01]
PIC16F628A PIC16F628A(ISP) [ISP-HEADER01]
PIC16F628A@SOIC18 [(SA404)]
PIC16F628A@SOIC18(ISP) [ISP-HEADER01]
PIC16F628A@SSOP20 [(SA626A)]
PIC16F628A@SSOP20(ISP) [ISP-HEADER01]
PIC16F630 PIC16F630(ISP) [ISP-HEADER01]
PIC16F630@SOIC14 [(SA602)]

```

```

PIC16F630@SOIC14(ISP) [ISP-HEADER01]
PIC16F630@TSSOP14 [(SA026)]
PIC16F630@TSSOP14(ISP) [ISP-HEADER01]
PIC16F631 PIC16F631(ISP) [ISP-HEADER01]
PIC16F631@QFN20 [(SA692)]
PIC16F631@QFN20(ISP) [ISP-HEADER01]
PIC16F631@SOIC20 [(SA404)]
PIC16F631@SOIC20(ISP) [ISP-HEADER01]
PIC16F631@SSOP20 [(SA626A)]
PIC16F631@SSOP20(ISP) [ISP-HEADER01]
PIC16F636 PIC16F636(ISP) [ISP-HEADER01]
PIC16F636@QFN16 [(SA727)]
PIC16F636@QFN16(ISP) [ISP-HEADER01]
PIC16F636@SOIC14 [(SA602)]
PIC16F636@SOIC14(ISP) [ISP-HEADER01]
PIC16F636@TSSOP14 [(SA026)]
PIC16F636@TSSOP14(ISP) [ISP-HEADER01]
PIC16F639 PIC16F639(ISP) [ISP-HEADER01]
PIC16F639@QFN20 [(SA692)]
PIC16F639@QFN20(ISP) [ISP-HEADER01]
PIC16F639@SOIC20 [(SA404)]
PIC16F639@SOIC20(ISP) [ISP-HEADER01]
PIC16F639@SSOP20 [(SA626A)]
PIC16F639@SSOP20(ISP) [ISP-HEADER01]
PIC16F648A PIC16F648A(ISP) [ISP-HEADER01]
PIC16F648A@SOIC18 [(SA404)]
PIC16F648A@SOIC18(ISP) [ISP-HEADER01]
PIC16F648A@SSOP20 [(SA626A)]
PIC16F648A@SSOP20(ISP) [ISP-HEADER01]
PIC16F676 PIC16F676(ISP) [ISP-HEADER01]
PIC16F676@SOIC14 [(SA602)]
PIC16F676@SOIC14(ISP) [ISP-HEADER01]
PIC16F676@TSSOP14 [(SA026)]
PIC16F676@TSSOP14(ISP) [ISP-HEADER01]
PIC16F677 PIC16F677(ISP) [ISP-HEADER01]
PIC16F677@QFN20 [(SA692)]
PIC16F677@QFN20(ISP) [ISP-HEADER01]
PIC16F677@SOIC20 [(SA404)]
PIC16F677@SOIC20(ISP) [ISP-HEADER01]
PIC16F677@SSOP20 [(SA626A)]
PIC16F677@SSOP20(ISP) [ISP-HEADER01]
PIC16F684 PIC16F684(ISP) [ISP-HEADER01]
PIC16F684@QFN16 [(SA727)]
PIC16F684@QFN16(ISP) [ISP-HEADER01]
PIC16F684@SOIC14 [(SA602)]
PIC16F684@SOIC14(ISP) [ISP-HEADER01]
PIC16F684@TSSOP14 [(SA026)]
PIC16F684@TSSOP14(ISP) [ISP-HEADER01]
PIC16F685 PIC16F685(ISP) [ISP-HEADER01]
PIC16F685@QFN20 [(SA692)]
PIC16F685@QFN20(ISP) [ISP-HEADER01]
PIC16F685@SOIC20 [(SA404)]
PIC16F685@SOIC20(ISP) [ISP-HEADER01]
PIC16F685@SSOP20 [(SA626A)]
PIC16F685@SSOP20(ISP) [ISP-HEADER01]
PIC16F687 PIC16F687(ISP) [ISP-HEADER01]
PIC16F687@QFN20 [(SA692)]
PIC16F687@QFN20(ISP) [ISP-HEADER01]
PIC16F687@SOIC20 [(SA404)]
PIC16F687@SOIC20(ISP) [ISP-HEADER01]
PIC16F687@SSOP20 [(SA626A)]
PIC16F687@SSOP20(ISP) [ISP-HEADER01]
PIC16F688 PIC16F688(ISP) [ISP-HEADER01]
PIC16F688@QFN16 [(SA727)]
PIC16F688@QFN16(ISP) [ISP-HEADER01]
PIC16F688@SOIC14 [(SA602)]
PIC16F688@SOIC14(ISP) [ISP-HEADER01]
PIC16F688@TSSOP14 [(SA026)]
PIC16F688@TSSOP14(ISP) [ISP-HEADER01]
PIC16F689 PIC16F689(ISP) [ISP-HEADER01]
PIC16F689@QFN20 [(SA692)]
PIC16F689@QFN20(ISP) [ISP-HEADER01]
PIC16F689@SOIC20 [(SA404)]
PIC16F689@SOIC20(ISP) [ISP-HEADER01]
PIC16F689@SSOP20 [(SA626A)]
PIC16F689@SSOP20(ISP) [ISP-HEADER01]
PIC16F690 PIC16F690(ISP) [ISP-HEADER01]
PIC16F690@QFN20 [(SA692)]
PIC16F690@QFN20(ISP) [ISP-HEADER01]
PIC16F690@SOIC20 [(SA404)]
PIC16F690@SOIC20(ISP) [ISP-HEADER01]

```

```

PIC16F690@SSOP20 [(SA626A)]
PIC16F690@SSOP20(ISP) [ISP-HEADER01]
PIC16F716 PIC16F716(ISP) [ISP-HEADER01]
PIC16F716@SOIC18 [(SA404)]
PIC16F716@SOIC18(ISP) [ISP-HEADER01]
PIC16F716@SSOP20 [(SA626A)]
PIC16F716@SSOP20(ISP) [ISP-HEADER01]
PIC16F72 PIC16F72(ISP) [ISP-HEADER01]
PIC16F72@QFN28 [(SA685-B006)]
PIC16F72@QFN28(ISP) [ISP-HEADER01]
PIC16F72@SOIC28 [(SA404)]
PIC16F72@SOIC28(ISP) [ISP-HEADER01]
PIC16F72@SSOP28 [(SA626A)]
PIC16F72@SSOP28(ISP) [ISP-HEADER01]
PIC16F722 PIC16F722@QFN28 [(SA685-B006)]
PIC16F722@SOIC28 [(SA404)] PIC16F722@SSOP28 [(SA626A)]
PIC16F723 PIC16F723@QFN28 [(SA685-B006)]
PIC16F723@SOIC28 [(SA404)] PIC16F723@SSOP28 [(SA626A)]
PIC16F724 PIC16F724@QFN44 [(SA737)]
PIC16F724@TQFP44 [(SA245A)] PIC16F726
PIC16F726@QFN28 [(SA685-B006)] PIC16F726@SOIC28 [(SA404)]
PIC16F726@SSOP28 [(SA626A)] PIC16F727
PIC16F727@QFN44 [(SA737)] PIC16F727@TQFP44 [(SA245A)]
PIC16F73 PIC16F73(ISP) [ISP-HEADER01]
PIC16F73@QFN28 [(SA685-B006)] PIC16F73@SOIC28 [(SA404)]
PIC16F73@SOIC28(ISP) [ISP-HEADER01]
PIC16F73@SSOP28 [(SA626A)]
PIC16F73@SSOP28(ISP) [ISP-HEADER01]
PIC16F737 PIC16F737(ISP) [ISP-HEADER01]
PIC16F737@SOIC28 [(SA404)]
PIC16F737@SOIC28(ISP) [ISP-HEADER01]
PIC16F737@SSOP28 [(SA626A)]
PIC16F737@SSOP28(ISP) [ISP-HEADER01]
PIC16F74 PIC16F74(ISP) [ISP-HEADER01]
PIC16F74@PLCC44 [(SA244)]
PIC16F74@PLCC44(ISP) [ISP-HEADER01]
PIC16F74@TQFP44 [(SA245A)]
PIC16F74@TQFP44(ISP) [ISP-HEADER01]
PIC16F747 PIC16F747(ISP) [ISP-HEADER01]
PIC16F747@TQFP44 [(SA245A)]
PIC16F747@TQFP44(ISP) [ISP-HEADER01]
PIC16F76 PIC16F76(ISP) [ISP-HEADER01]
PIC16F76@QFN28 [(SA685-B006)] PIC16F76@SOIC28 [(SA404)]
PIC16F76@SOIC28(ISP) [ISP-HEADER01]
PIC16F76@SSOP28 [(SA626A)]
PIC16F76@SSOP28(ISP) [ISP-HEADER01]
PIC16F767 PIC16F767(ISP) [ISP-HEADER01]
PIC16F767@SOIC28 [(SA404)]
PIC16F767@SOIC28(ISP) [ISP-HEADER01]
PIC16F767@SSOP28 [(SA626A)]
PIC16F767@SSOP28(ISP) [ISP-HEADER01]
PIC16F77 PIC16F77(ISP) [ISP-HEADER01]
PIC16F77@PLCC44 [(SA244)]
PIC16F77@PLCC44(ISP) [ISP-HEADER01]
PIC16F77@TQFP44 [(SA245A)]
PIC16F77@TQFP44(ISP) [ISP-HEADER01]
PIC16F777 PIC16F777(ISP) [ISP-HEADER01]
PIC16F777@TQFP44 [(SA245A)]
PIC16F777@TQFP44(ISP) [ISP-HEADER01]
PIC16F785 PIC16F785(ISP) [ISP-HEADER01]
PIC16F785@QFN20 [(SA692)]
PIC16F785@QFN20(ISP) [ISP-HEADER01]
PIC16F785@SOIC20 [(SA404)]
PIC16F785@SOIC20(ISP) [ISP-HEADER01]
PIC16F785@SSOP20 [(SA626A)]
PIC16F785@SSOP20(ISP) [ISP-HEADER01]
PIC16F818 PIC16F818(ISP) [ISP-HEADER01]
PIC16F818(LV)
PIC16F818(LV)@QFN28 [(SA685-B006)]
PIC16F818(LV)@SOIC18 [(SA404)] PIC16F818(LV)@SSOP20 [(SA626A)]
PIC16F818@QFN28 [(SA685-B006)]
PIC16F818@QFN28(ISP) [ISP-HEADER01]
PIC16F818@SOIC18 [(SA404)]
PIC16F818@SOIC18(ISP) [ISP-HEADER01]
PIC16F818@SSOP20 [(SA626A)]
PIC16F818@SSOP20(ISP) [ISP-HEADER01]
PIC16F819 PIC16F819(ISP) [ISP-HEADER01]
PIC16F819(LV)
PIC16F819(LV)@QFN28 [(SA685-B006)]
PIC16F819(LV)@SOIC18 [(SA404)] PIC16F819(LV)@SSOP20 [(SA626A)]
PIC16F819@QFN28 [(SA685-B006)]

```

```

PIC16F819@QFN28(ISP) [ISP-HEADER01]
PIC16F819@SOIC18 [(SA404)]
PIC16F819@SOIC18(ISP) [ISP-HEADER01]
PIC16F819@SSOP20 [(SA626A)]
PIC16F819@SSOP20(ISP) [ISP-HEADER01]
PIC16F83 PIC16F83(ISP) [ISP-HEADER01]
PIC16F83@SOIC18 [(SA404)]
PIC16F83@SOIC18(ISP) [ISP-HEADER01]
PIC16F84 PIC16F84(ISP) [ISP-HEADER01]
PIC16F84@SOIC18 [(SA404)]
PIC16F84@SOIC18(ISP) [ISP-HEADER01]
PIC16F84A PIC16F84A(ISP) [ISP-HEADER01]
PIC16F84A@SOIC18 [(SA404)]
PIC16F84A@SOIC18(ISP) [ISP-HEADER01]
PIC16F84A@SSOP20 [(SA626A)]
PIC16F84A@SSOP20(ISP) [ISP-HEADER01]
PIC16F87 PIC16F87(ISP) [ISP-HEADER01]
PIC16F87@QFN28 [(SA685-B006)]
PIC16F87@QFN28(ISP) [ISP-HEADER01]
PIC16F87@SOIC18 [(SA404)]
PIC16F87@SOIC18(ISP) [ISP-HEADER01]
PIC16F87@SSOP20 [(SA626A)]
PIC16F87@SSOP20(ISP) [ISP-HEADER01]
PIC16F870 PIC16F870(ISP) [ISP-HEADER01]
PIC16F870@SOIC28 [(SA404)]
PIC16F870@SOIC28(ISP) [ISP-HEADER01]
PIC16F870@SSOP28 [(SA626A)]
PIC16F870@SSOP28(ISP) [ISP-HEADER01]
PIC16F871 PIC16F871(ISP) [ISP-HEADER01]
PIC16F871@MQFP44 [(SA675)]
PIC16F871@MQFP44(ISP) [ISP-HEADER01]
PIC16F871@PLCC44 [(SA244)]
PIC16F871@PLCC44(ISP) [ISP-HEADER01]
PIC16F871@TQFP44 [(SA245A)]
PIC16F871@TQFP44(ISP) [ISP-HEADER01]
PIC16F872 PIC16F872(ISP) [ISP-HEADER01]
PIC16F872@SOIC28 [(SA404)]
PIC16F872@SOIC28(ISP) [ISP-HEADER01]
PIC16F872@SSOP28 [(SA626A)]
PIC16F872@SSOP28(ISP) [ISP-HEADER01]
PIC16F873 PIC16F873(ISP) [ISP-HEADER01]
PIC16F873@SOIC28 [(SA404)]
PIC16F873@SOIC28(ISP) [ISP-HEADER01]
PIC16F873A
PIC16F873A(ISP)(High-V) [ISP-HEADER01]
PIC16F873A(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@QFN28 [(SA697-B006)]
PIC16F873A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@SOIC28 [(SA404)]
PIC16F873A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@SSOP28 [(SA626A)]
PIC16F873A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874 PIC16F874(ISP) [ISP-HEADER01]
PIC16F874@MQFP44 [(SA675)]
PIC16F874@MQFP44(ISP) [ISP-HEADER01]
PIC16F874@PLCC44 [(SA244)]
PIC16F874@PLCC44(ISP) [ISP-HEADER01]
PIC16F874@TQFP44 [(SA245A)]
PIC16F874@TQFP44(ISP) [ISP-HEADER01]
PIC16F874A
PIC16F874A(ISP)(High-V) [ISP-HEADER01]
PIC16F874A(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874A@PLCC44 [(SA244)]
PIC16F874A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874A@TQFP44 [(SA245A)]

```

```

PIC16F874A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876 PIC16F876(ISP) [ISP-HEADER01]
PIC16F876@SOIC28 [(SA404)]
PIC16F876@SOIC28(ISP) [ISP-HEADER01]
PIC16F876A
PIC16F876A(ISP)(High-V) [ISP-HEADER01]
PIC16F876A(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876A@QFN28 [(SA697-B006)]
PIC16F876A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F876A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876A@SOIC28 [(SA404)]
PIC16F876A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876A@SSOP28 [(SA626A)]
PIC16F876A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F877 PIC16F877(ISP) [ISP-HEADER01]
PIC16F877@MQFP44 [(SA675)]
PIC16F877@MQFP44(ISP) [ISP-HEADER01]
PIC16F877@PLCC44 [(SA244)]
PIC16F877@PLCC44(ISP) [ISP-HEADER01]
PIC16F877@TQFP44 [(SA245A)]
PIC16F877@TQFP44(ISP) [ISP-HEADER01]
PIC16F877A
PIC16F877A(ISP)(High-V) [ISP-HEADER01]
PIC16F877A(ISP)(Low-V) [ISP-HEADER01]
PIC16F877A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F877A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F877A@PLCC44 [(SA244)]
PIC16F877A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16F877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16F877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F877A@TQFP44 [(SA245A)]
PIC16F877A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F88 PIC16F88(ISP) [ISP-HEADER01]
PIC16F88@QFN28 [(SA685-B006)]
PIC16F88@QFN28(ISP) [ISP-HEADER01]
PIC16F88@SOIC18 [(SA404)]
PIC16F88@SOIC18(ISP) [ISP-HEADER01]
PIC16F88@SSOP20 [(SA626A)]
PIC16F88@SSOP20(ISP) [ISP-HEADER01]
PIC16F882
PIC16F882(ISP)(High-V) [ISP-HEADER01]
PIC16F882(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@QFN28 [(SA685-B005)]
PIC16F882@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@SOIC28 [(SA404)]
PIC16F882@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@SSOP28 [(SA626A)]
PIC16F882@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883
PIC16F883(ISP)(High-V) [ISP-HEADER01]
PIC16F883(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@QFN28 [(SA685-B005)]
PIC16F883@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@SOIC28 [(SA404)]
PIC16F883@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@SSOP28 [(SA626A)]
PIC16F883@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F884

```

```

PIC16F884(ISP)(High-V) [ISP-HEADER01]
PIC16F884(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@QFN44 [(SA712)]
PIC16F884@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC16F884@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@QFN44(ML) [(SA737)]
PIC16F884@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]
PIC16F884@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@TQFP44 [(SA245A)]
PIC16F884@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F884@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F886
PIC16F886(ISP)(High-V) [ISP-HEADER01]
PIC16F886(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@QFN28 [(SA685-B005)]
PIC16F886@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@SOIC28 [(SA404)]
PIC16F886@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@SSOP28 [(SA626A)]
PIC16F886@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F887
PIC16F887(ISP)(High-V) [ISP-HEADER01]
PIC16F887(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@QFN44 [(SA712)]
PIC16F887@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC16F887@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@QFN44(ML) [(SA737)]
PIC16F887@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]
PIC16F887@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@TQFP44 [(SA245A)]
PIC16F887@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F887@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F913 PIC16F913(ISP) [ISP-HEADER01]
PIC16F913@QFN28 [(SA685-B006)]
PIC16F913@QFN28(ISP) [ISP-HEADER01]
PIC16F913@SOIC28 [(SA404)]
PIC16F913@SOIC28(ISP) [ISP-HEADER01]
PIC16F913@SSOP28 [(SA626A)]
PIC16F913@SSOP28(ISP) [ISP-HEADER01]
PIC16F914 PIC16F914(ISP) [ISP-HEADER01]
PIC16F914@QFN44 [(SA712)]
PIC16F914@QFN44(ISP) [ISP-HEADER01]
PIC16F914@QFN44(ML) [(SA737)]
PIC16F914@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16F914@TQFP44 [(SA245A)]
PIC16F914@TQFP44(ISP) [ISP-HEADER01]
PIC16F916 PIC16F916(ISP) [ISP-HEADER01]
PIC16F916@QFN28 [(SA685-B006)]
PIC16F916@QFN28(ISP) [ISP-HEADER01]
PIC16F916@SOIC28 [(SA404)]
PIC16F916@SOIC28(ISP) [ISP-HEADER01]
PIC16F916@SSOP28 [(SA626A)]
PIC16F916@SSOP28(ISP) [ISP-HEADER01]
PIC16F917 PIC16F917(ISP) [ISP-HEADER01]
PIC16F917@QFN44 [(SA712)]
PIC16F917@QFN44(ISP) [ISP-HEADER01]
PIC16F917@QFN44(ML) [(SA737)]
PIC16F917@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16F917@TQFP44 [(SA245A)]
PIC16F917@TQFP44(ISP) [ISP-HEADER01]
PIC16F946@TQFP64(ISP) [ISP-HEADER01]
PIC16HV540 PIC16HV540@SOIC18 [(SA404)]
PIC16HV540@SSOP20 [(SA626A)] PIC16HV610
PIC16HV610(ISP) [ISP-HEADER01] PIC16HV610@QFN16 [(SA727)]
PIC16HV610@QFN16(ISP) [ISP-HEADER01]
PIC16HV610@SOIC14 [(SA602)]
PIC16HV610@SOIC14(ISP) [ISP-HEADER01]
PIC16HV610@TSSOP14 [(SA026)]
PIC16HV610@TSSOP14(ISP) [ISP-HEADER01]
PIC16HV616 PIC16HV616(ISP) [ISP-HEADER01]
PIC16HV616@QFN16 [(SA727)]
PIC16HV616@QFN16(ISP) [ISP-HEADER01]
PIC16HV616@SOIC14 [(SA602)]
PIC16HV616@SOIC14(ISP) [ISP-HEADER01]
PIC16HV616@TSSOP14 [(SA026)]
PIC16HV616@TSSOP14(ISP) [ISP-HEADER01]
PIC16HV785 PIC16HV785(ISP) [ISP-HEADER01]
PIC16HV785@QFN20 [(SA692)]

```



```

PIC16HV785@QFN20 (ISP) [ISP-HEADER01]
PIC16HV785@SOIC20 [(SA404)]
PIC16HV785@SOIC20 (ISP) [ISP-HEADER01]
PIC16HV785@SSOP20 [(SA626A)]
PIC16HV785@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC505 PIC16LC505@SOIC14 [(SA602)]
PIC16LC54A PIC16LC54A@SOIC18 [(SA404)]
PIC16LC54A@SSOP20 [(SA626A)] PIC16LC54C
PIC16LC54C@SOIC18 [(SA404)] PIC16LC54C@SSOP20 [(SA626A)]
PIC16LC554 PIC16LC554 (ISP) [ISP-HEADER01]
PIC16LC554@SOIC18 [(SA404)]
PIC16LC554@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC558 PIC16LC558 (ISP) [ISP-HEADER01]
PIC16LC558@SOIC18 [(SA404)]
PIC16LC558@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC56A PIC16LC56A@SOIC18 [(SA404)]
PIC16LC56A@SSOP20 [(SA626A)] PIC16LC58A
PIC16LC58A@SOIC18 [(SA404)] PIC16LC58A@SSOP20 [(SA626A)]
PIC16LC58B PIC16LC58B@SOIC18 [(SA404)]
PIC16LC58B@SSOP20 [(SA626A)] PIC16LC620
PIC16LC620 (ISP) [ISP-HEADER01] PIC16LC620@SOIC18 [(SA404)]
PIC16LC620@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC620A PIC16LC620A (ISP) [ISP-HEADER01]
PIC16LC620A@SOIC18 [(SA404)]
PIC16LC620A@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC620A@SSOP20 [(SA626A)]
PIC16LC620A@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC621A PIC16LC621A (ISP) [ISP-HEADER01]
PIC16LC621A@SOIC18 [(SA404)]
PIC16LC621A@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC621A@SSOP20 [(SA626A)]
PIC16LC621A@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC622 PIC16LC622 (ISP) [ISP-HEADER01]
PIC16LC622@SOIC18 [(SA404)]
PIC16LC622@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC62A PIC16LC62A (ISP) [ISP-HEADER01]
PIC16LC62A@SOIC28 [(SA404)]
PIC16LC62A@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC62A@SSOP28 [(SA626A)]
PIC16LC62A@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC62B PIC16LC62B (ISP) [ISP-HEADER01]
PIC16LC62B@SOIC28 [(SA404)]
PIC16LC62B@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC62B@SSOP28 [(SA626A)]
PIC16LC62B@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC63 PIC16LC63 (ISP) [ISP-HEADER01]
PIC16LC63@SOIC28 [(SA404)]
PIC16LC63@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC63A PIC16LC63A (ISP) [ISP-HEADER01]
PIC16LC63A@SOIC28 [(SA404)]
PIC16LC63A@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC63A@SSOP28 [(SA626A)]
PIC16LC63A@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC64A PIC16LC64A (ISP) [ISP-HEADER01]
PIC16LC64A@PLCC44 [(SA244)]
PIC16LC64A@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC64A@TQFP44 [(SA245A)]
PIC16LC64A@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC65A PIC16LC65A (ISP) [ISP-HEADER01]
PIC16LC65A@PLCC44 [(SA244)]
PIC16LC65A@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC65A@TQFP44 [(SA245A)]
PIC16LC65A@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC65B PIC16LC65B (ISP) [ISP-HEADER01]
PIC16LC65B@PLCC44 [(SA244)]
PIC16LC65B@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC65B@TQFP44 [(SA245A)]
PIC16LC65B@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC66 PIC16LC66 (ISP) [ISP-HEADER01]
PIC16LC66@SOIC28 [(SA404)]
PIC16LC66@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC67 PIC16LC67 (ISP) [ISP-HEADER01]
PIC16LC67@PLCC44 [(SA244)]
PIC16LC67@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC67@TQFP44 [(SA245A)]
PIC16LC67@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC71 PIC16LC71 (ISP) [ISP-HEADER01]
PIC16LC71@SOIC18 [(SA404)]
PIC16LC71@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC710 PIC16LC710 (ISP) [ISP-HEADER01]
PIC16LC710@SOIC18 [(SA404)]

```

```

PIC16LC710@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC710@SSOP20 [(SA626A)]
PIC16LC710@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC711                                     PIC16LC711 (ISP) [ISP-HEADER01]
PIC16LC711@SOIC18 [(SA404)]
PIC16LC711@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC711@SSOP20 [(SA626A)]
PIC16LC711@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC712                                     PIC16LC712 (ISP) [ISP-HEADER01]
PIC16LC712@SOIC18 [(SA404)]
PIC16LC712@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC712@SSOP20 [(SA626A)]
PIC16LC712@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC715                                     PIC16LC715@SOIC18 [(SA404)]
PIC16LC716                                     PIC16LC716 (ISP) [ISP-HEADER01]
PIC16LC716@SOIC18 [(SA404)]
PIC16LC716@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC716@SSOP20 [(SA626A)]
PIC16LC716@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC717                                     PIC16LC717 (ISP) [ISP-HEADER01]
PIC16LC717@SOIC18 [(SA404)]
PIC16LC717@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC717@SSOP20 [(SA626A)]
PIC16LC717@SSOP20 (ISP) [ISP-HEADER01]
PIC16LC72                                     PIC16LC72 (ISP) [ISP-HEADER01]
PIC16LC72@SOIC28 [(SA404)]
PIC16LC72@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC72@SSOP28 [(SA626A)]
PIC16LC72@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC72A                                     PIC16LC72A (ISP) [ISP-HEADER01]
PIC16LC72A@SOIC28 [(SA404)]
PIC16LC72A@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC72A@SSOP28 [(SA626A)]
PIC16LC72A@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC73A                                     PIC16LC73A (ISP) [ISP-HEADER01]
PIC16LC73A@SOIC28 [(SA404)]
PIC16LC73A@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC73B                                     PIC16LC73B (ISP) [ISP-HEADER01]
PIC16LC73B@SOIC28 [(SA404)]
PIC16LC73B@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC73B@SSOP28 [(SA626A)]
PIC16LC73B@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC74                                     PIC16LC74 (ISP) [ISP-HEADER01]
PIC16LC74@PLCC44 [(SA244)]
PIC16LC74@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC74@TQFP44 [(SA245A)]
PIC16LC74@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC74A                                     PIC16LC74A (ISP) [ISP-HEADER01]
PIC16LC74A@PLCC44 [(SA244)]
PIC16LC74A@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC74A@TQFP44 [(SA245A)]
PIC16LC74A@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC74B                                     PIC16LC74B (ISP) [ISP-HEADER01]
PIC16LC74B@MQFP44 [(SA675)]
PIC16LC74B@MQFP44 (ISP) [ISP-HEADER01]
PIC16LC74B@PLCC44 [(SA244)]
PIC16LC74B@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC74B@TQFP44 [(SA245A)]
PIC16LC74B@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC76                                     PIC16LC76 (ISP) [ISP-HEADER01]
PIC16LC76@SOIC28 [(SA404)]
PIC16LC76@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC77                                     PIC16LC77 (ISP) [ISP-HEADER01]
PIC16LC77@PLCC44 [(SA244)]
PIC16LC77@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC773                                     PIC16LC773 (ISP) [ISP-HEADER01]
PIC16LC773@SOIC28 [(SA404)]
PIC16LC773@SOIC28 (ISP) [ISP-HEADER01]
PIC16LC773@SSOP28 [(SA626A)]
PIC16LC773@SSOP28 (ISP) [ISP-HEADER01]
PIC16LC774                                     PIC16LC774 (ISP) [ISP-HEADER01]
PIC16LC774@PLCC44 [(SA244)]
PIC16LC774@PLCC44 (ISP) [ISP-HEADER01]
PIC16LC774@TQFP44 [(SA675)]
PIC16LC774@TQFP44 (ISP) [ISP-HEADER01]
PIC16LC84                                     PIC16LC84 (ISP) [ISP-HEADER01]
PIC16LC84@SOIC18 [(SA404)]
PIC16LC84@SOIC18 (ISP) [ISP-HEADER01]
PIC16LC923@PLCC68 (*) [(SA648-B6807)]
PIC16LC923@PLCC68 (ISP) [ISP-HEADER01]
PIC16LC923@SDIP64 (ISP) [ISP-HEADER01]

```

```

PIC16LC923@TQFP64(ISP) [ISP-HEADER01]
PIC16LC924@PLCC68(*) [(SA648-B6807)]
PIC16LC924@PLCC68(ISP) [ISP-HEADER01]
PIC16LC924@SDIP64(ISP) [ISP-HEADER01]
PIC16LC924@TQFP64(ISP) [ISP-HEADER01]
PIC16LC925@PLCC68(*) [(SA648-B6807)]
PIC16LC925@PLCC68(ISP) [ISP-HEADER01]
PIC16LC925@TQFP64(ISP) [ISP-HEADER01]
PIC16LC926@PLCC68(*) [(SA648-B6807)]
PIC16LC926@PLCC68(ISP) [ISP-HEADER01]
PIC16LC926@TQFP64(ISP) [ISP-HEADER01]
PIC16LCE623@SOIC18 [(SA404)]
PIC16LCE623@SOIC18(ISP) [ISP-HEADER01]
PIC16LCE623@SSOP20 [(SA626A)]
PIC16LCE623@SSOP20(ISP) [ISP-HEADER01]
PIC16LF505 PIC16LF505(ISP) [ISP-HEADER01]
PIC16LF505@SOIC14 [(SA602)]
PIC16LF505@SOIC14(ISP) [ISP-HEADER01]
PIC16LF505@TSSOP14 [(SA026)]
PIC16LF505@TSSOP14(ISP) [ISP-HEADER01]
PIC16LF506 PIC16LF506(ISP) [ISP-HEADER01]
PIC16LF506@SOIC14 [(SA602)]
PIC16LF506@SOIC14(ISP) [ISP-HEADER01]
PIC16LF506@TSSOP14 [(SA026)]
PIC16LF506@TSSOP14(ISP) [ISP-HEADER01]
PIC16LF526 PIC16LF526@SOIC14 [(SA602)]
PIC16LF526@TSSOP14 [(SA026)]
PIC16LF54(ISP) [ISP-HEADER01] PIC16LF54
PIC16LF54@SOIC18(ISP) [ISP-HEADER01] PIC16LF54@SOIC18 [(SA404)]
PIC16LF54@SSOP20 [(SA626A)]
PIC16LF54@SSOP20(ISP) [ISP-HEADER01]
PIC16LF57 PIC16LF57(ISP) [ISP-HEADER01]
PIC16LF57@SOIC28 [(SA404)]
PIC16LF57@SOIC28(ISP) [ISP-HEADER01]
PIC16LF57@SSOP28 [(SA626A)]
PIC16LF57@SSOP28(ISP) [ISP-HEADER01]
PIC16LF59 PIC16LF59(ISP) [ISP-HEADER01]
PIC16LF59@PLCC44 [(SA244)]
PIC16LF59@PLCC44(ISP) [ISP-HEADER01]
PIC16LF59@TQFP44 [(SA245A)]
PIC16LF59@TQFP44(ISP) [ISP-HEADER01]
PIC16LF627 PIC16LF627(ISP) [ISP-HEADER01]
PIC16LF627@SOIC18 [(SA404)]
PIC16LF627@SOIC18(ISP) [ISP-HEADER01]
PIC16LF627@SSOP20 [(SA626A)]
PIC16LF627@SSOP20(ISP) [ISP-HEADER01]
PIC16LF627A PIC16LF627A(ISP) [ISP-HEADER01]
PIC16LF627A@SOIC18 [(SA404)]
PIC16LF627A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF627A@SSOP20 [(SA626A)]
PIC16LF627A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF628 PIC16LF628(ISP) [ISP-HEADER01]
PIC16LF628@SOIC18 [(SA404)]
PIC16LF628@SOIC18(ISP) [ISP-HEADER01]
PIC16LF628@SSOP20 [(SA626A)]
PIC16LF628@SSOP20(ISP) [ISP-HEADER01]
PIC16LF628A PIC16LF628A(ISP) [ISP-HEADER01]
PIC16LF628A@SOIC18 [(SA404)]
PIC16LF628A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF628A@SSOP20 [(SA626A)]
PIC16LF628A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF631 PIC16LF631(ISP) [ISP-HEADER01]
PIC16LF631@QFN20 [(SA692)]
PIC16LF631@QFN20(ISP) [ISP-HEADER01]
PIC16LF631@SOIC20 [(SA404)]
PIC16LF631@SOIC20(ISP) [ISP-HEADER01]
PIC16LF631@SSOP20 [(SA626A)]
PIC16LF631@SSOP20(ISP) [ISP-HEADER01]
PIC16LF639 PIC16LF639(ISP) [ISP-HEADER01]
PIC16LF639@QFN20 [(SA692)]
PIC16LF639@QFN20(ISP) [ISP-HEADER01]
PIC16LF639@SOIC20 [(SA404)]
PIC16LF639@SOIC20(ISP) [ISP-HEADER01]
PIC16LF639@SSOP20 [(SA626A)]
PIC16LF639@SSOP20(ISP) [ISP-HEADER01]
PIC16LF648A PIC16LF648A(ISP) [ISP-HEADER01]
PIC16LF648A@SOIC18 [(SA404)]
PIC16LF648A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF648A@SSOP20 [(SA626A)]
PIC16LF648A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF677 PIC16LF677(ISP) [ISP-HEADER01]

```

```

PIC16LF677@QFN20 [(SA692)]
PIC16LF677@QFN20(ISP) [ISP-HEADER01]
PIC16LF677@SOIC20 [(SA404)]
PIC16LF677@SOIC20(ISP) [ISP-HEADER01]
PIC16LF677@SSOP20 [(SA626A)]
PIC16LF677@SSOP20(ISP) [ISP-HEADER01]
PIC16LF685 PIC16LF685(ISP) [ISP-HEADER01]
PIC16LF685@QFN20 [(SA692)]
PIC16LF685@QFN20(ISP) [ISP-HEADER01]
PIC16LF685@SOIC20 [(SA404)]
PIC16LF685@SOIC20(ISP) [ISP-HEADER01]
PIC16LF685@SSOP20 [(SA626A)]
PIC16LF685@SSOP20(ISP) [ISP-HEADER01]
PIC16LF687 PIC16LF687(ISP) [ISP-HEADER01]
PIC16LF687@QFN20 [(SA692)]
PIC16LF687@QFN20(ISP) [ISP-HEADER01]
PIC16LF687@SOIC20 [(SA404)]
PIC16LF687@SOIC20(ISP) [ISP-HEADER01]
PIC16LF687@SSOP20 [(SA626A)]
PIC16LF687@SSOP20(ISP) [ISP-HEADER01]
PIC16LF689 PIC16LF689(ISP) [ISP-HEADER01]
PIC16LF689@QFN20 [(SA692)]
PIC16LF689@QFN20(ISP) [ISP-HEADER01]
PIC16LF689@SOIC20 [(SA404)]
PIC16LF689@SOIC20(ISP) [ISP-HEADER01]
PIC16LF689@SSOP20 [(SA626A)]
PIC16LF689@SSOP20(ISP) [ISP-HEADER01]
PIC16LF690 PIC16LF690(ISP) [ISP-HEADER01]
PIC16LF690@QFN20 [(SA692)]
PIC16LF690@QFN20(ISP) [ISP-HEADER01]
PIC16LF690@SOIC20 [(SA404)]
PIC16LF690@SOIC20(ISP) [ISP-HEADER01]
PIC16LF690@SSOP20 [(SA626A)]
PIC16LF690@SSOP20(ISP) [ISP-HEADER01]
PIC16LF716 PIC16LF716(ISP) [ISP-HEADER01]
PIC16LF716@SOIC18 [(SA404)]
PIC16LF716@SOIC18(ISP) [ISP-HEADER01]
PIC16LF716@SSOP20 [(SA626A)]
PIC16LF716@SSOP20(ISP) [ISP-HEADER01]
PIC16LF72 PIC16LF72(ISP) [ISP-HEADER01]
PIC16LF72@QFN28 [(SA685-B006)]
PIC16LF72@QFN28(ISP) [ISP-HEADER01]
PIC16LF72@SOIC28 [(SA404)]
PIC16LF72@SOIC28(ISP) [ISP-HEADER01]
PIC16LF72@SSOP28 [(SA626A)]
PIC16LF72@SSOP28(ISP) [ISP-HEADER01]
PIC16LF722 PIC16LF722@QFN28 [(SA685-B006)]
PIC16LF722@SOIC28 [(SA404)] PIC16LF722@SSOP28 [(SA626A)]
PIC16LF723 PIC16LF723@QFN28 [(SA685-B006)]
PIC16LF723@SOIC28 [(SA404)] PIC16LF723@SSOP28 [(SA626A)]
PIC16LF724 PIC16LF724@QFN44 [(SA737)]
PIC16LF724@TQFP44 [(SA245A)] PIC16LF726
PIC16LF726@QFN28 [(SA685-B006)] PIC16LF726@SOIC28 [(SA404)]
PIC16LF726@SSOP28 [(SA626A)] PIC16LF727
PIC16LF727@QFN44 [(SA737)] PIC16LF727@TQFP44 [(SA245A)]
PIC16LF73 PIC16LF73(ISP) [ISP-HEADER01]
PIC16LF73@QFN28 [(SA685-B006)] PIC16LF73@SOIC28 [(SA404)]
PIC16LF73@SOIC28(ISP) [ISP-HEADER01]
PIC16LF73@SSOP28 [(SA626A)]
PIC16LF73@SSOP28(ISP) [ISP-HEADER01]
PIC16LF737 PIC16LF737(ISP) [ISP-HEADER01]
PIC16LF737@SOIC28 [(SA404)]
PIC16LF737@SOIC28(ISP) [ISP-HEADER01]
PIC16LF737@SSOP28 [(SA626A)]
PIC16LF737@SSOP28(ISP) [ISP-HEADER01]
PIC16LF74 PIC16LF74(ISP) [ISP-HEADER01]
PIC16LF74@PLCC44 [(SA244)]
PIC16LF74@PLCC44(ISP) [ISP-HEADER01]
PIC16LF74@TQFP44 [(SA245A)]
PIC16LF74@TQFP44(ISP) [ISP-HEADER01]
PIC16LF747 PIC16LF747(ISP) [ISP-HEADER01]
PIC16LF747@TQFP44 [(SA245A)]
PIC16LF747@TQFP44(ISP) [ISP-HEADER01]
PIC16LF76 PIC16LF76(ISP) [ISP-HEADER01]
PIC16LF76@QFN28 [(SA685-B006)] PIC16LF76@SOIC28 [(SA404)]
PIC16LF76@SOIC28(ISP) [ISP-HEADER01]
PIC16LF76@SSOP28 [(SA626A)]
PIC16LF76@SSOP28(ISP) [ISP-HEADER01]
PIC16LF767 PIC16LF767(ISP) [ISP-HEADER01]
PIC16LF767@SOIC28 [(SA404)]
PIC16LF767@SOIC28(ISP) [ISP-HEADER01]

```

```

PIC16LF767@SSOP28 [(SA626A)]
PIC16LF767@SSOP28(ISP) [ISP-HEADER01]
PIC16LF77 PIC16LF77(ISP) [ISP-HEADER01]
PIC16LF77@PLCC44 [(SA244)]
PIC16LF77@PLCC44(ISP) [ISP-HEADER01]
PIC16LF77@TQFP44 [(SA245A)]
PIC16LF77@TQFP44(ISP) [ISP-HEADER01]
PIC16LF777 PIC16LF777(ISP) [ISP-HEADER01]
PIC16LF777@TQFP44 [(SA245A)]
PIC16LF777@TQFP44(ISP) [ISP-HEADER01]
PIC16LF818 PIC16LF818(ISP) [ISP-HEADER01]
PIC16LF818(LV)
PIC16LF818(LV)@QFN28 [(SA685-B006)]
PIC16LF818(LV)@SOIC18 [(SA404)] PIC16LF818(LV)@SSOP20 [(SA626A)]
PIC16LF818@QFN28 [(SA685-B006)]
PIC16LF818@QFN28(ISP) [ISP-HEADER01]
PIC16LF818@SOIC18 [(SA404)]
PIC16LF818@SOIC18(ISP) [ISP-HEADER01]
PIC16LF818@SSOP20 [(SA626A)]
PIC16LF818@SSOP20(ISP) [ISP-HEADER01]
PIC16LF819 PIC16LF819(ISP) [ISP-HEADER01]
PIC16LF819(LV)
PIC16LF819(LV)@QFN28 [(SA685-B006)]
PIC16LF819(LV)@SOIC18 [(SA404)] PIC16LF819(LV)@SSOP20 [(SA626A)]
PIC16LF819@QFN28 [(SA685-B006)]
PIC16LF819@QFN28(ISP) [ISP-HEADER01]
PIC16LF819@SOIC18 [(SA404)]
PIC16LF819@SOIC18(ISP) [ISP-HEADER01]
PIC16LF819@SSOP20 [(SA626A)]
PIC16LF819@SSOP20(ISP) [ISP-HEADER01]
PIC16LF83 PIC16LF83(ISP) [ISP-HEADER01]
PIC16LF83@SOIC18 [(SA404)]
PIC16LF83@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84 PIC16LF84(ISP) [ISP-HEADER01]
PIC16LF84@SOIC18 [(SA404)]
PIC16LF84@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84A PIC16LF84A(ISP) [ISP-HEADER01]
PIC16LF84A@SOIC18 [(SA404)]
PIC16LF84A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84A@SSOP20 [(SA626A)]
PIC16LF84A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF87 PIC16LF87(ISP) [ISP-HEADER01]
PIC16LF87@QFN28 [(SA685-B006)]
PIC16LF87@QFN28(ISP) [ISP-HEADER01]
PIC16LF87@SOIC18 [(SA404)]
PIC16LF87@SOIC18(ISP) [ISP-HEADER01]
PIC16LF87@SSOP20 [(SA626A)]
PIC16LF87@SSOP20(ISP) [ISP-HEADER01]
PIC16LF870 PIC16LF870(ISP) [ISP-HEADER01]
PIC16LF870@SOIC28 [(SA404)]
PIC16LF870@SOIC28(ISP) [ISP-HEADER01]
PIC16LF870@SSOP28 [(SA626A)]
PIC16LF870@SSOP28(ISP) [ISP-HEADER01]
PIC16LF871 PIC16LF871(ISP) [ISP-HEADER01]
PIC16LF871@MQFP44 [(SA245A)]
PIC16LF871@MQFP44(ISP) [ISP-HEADER01]
PIC16LF871@PLCC44 [(SA244)]
PIC16LF871@PLCC44(ISP) [ISP-HEADER01]
PIC16LF871@TQFP44 [(SA245A)]
PIC16LF871@TQFP44(ISP) [ISP-HEADER01]
PIC16LF872 PIC16LF872(ISP) [ISP-HEADER01]
PIC16LF872@SOIC28 [(SA404)]
PIC16LF872@SOIC28(ISP) [ISP-HEADER01]
PIC16LF872@SSOP28 [(SA626A)]
PIC16LF872@SSOP28(ISP) [ISP-HEADER01]
PIC16LF873 PIC16LF873(ISP) [ISP-HEADER01]
PIC16LF873@SOIC28 [(SA404)]
PIC16LF873@SOIC28(ISP) [ISP-HEADER01]
PIC16LF873A
PIC16LF873A(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@QFN28 [(SA697-B006)]
PIC16LF873A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@SOIC28 [(SA404)]
PIC16LF873A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]

```

```

PIC16LF873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@SSOP28 [(SA626A)]
PIC16LF873A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874
PIC16LF874(ISP) [ISP-HEADER01]
PIC16LF874@MQFP44 [(SA675)]
PIC16LF874@MQFP44(ISP) [ISP-HEADER01]
PIC16LF874@PLCC44 [(SA244)]
PIC16LF874@PLCC44(ISP) [ISP-HEADER01]
PIC16LF874@TQFP44 [(SA245A)]
PIC16LF874@TQFP44(ISP) [ISP-HEADER01]
PIC16LF874A
PIC16LF874A(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874A@PLCC44 [(SA244)]
PIC16LF874A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874A@TQFP44 [(SA245A)]
PIC16LF874A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876
PIC16LF876(ISP) [ISP-HEADER01]
PIC16LF876@SOIC28 [(SA404)]
PIC16LF876@SOIC28(ISP) [ISP-HEADER01]
PIC16LF876A
PIC16LF876A(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876A@QFN28 [(SA697-B006)]
PIC16LF876A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876A@SOIC28 [(SA404)]
PIC16LF876A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876A@SSOP28 [(SA626A)]
PIC16LF876A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF877
PIC16LF877(ISP) [ISP-HEADER01]
PIC16LF877@MQFP44 [(SA675)]
PIC16LF877@MQFP44(ISP) [ISP-HEADER01]
PIC16LF877@PLCC44 [(SA244)]
PIC16LF877@PLCC44(ISP) [ISP-HEADER01]
PIC16LF877@TQFP44 [(SA245A)]
PIC16LF877@TQFP44(ISP) [ISP-HEADER01]
PIC16LF877A
PIC16LF877A(ISP)(High-V) [ISP-HEADER01]
PIC16LF877A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF877A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF877A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF877A@PLCC44 [(SA244)]
PIC16LF877A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16LF877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF877A@TQFP44 [(SA245A)]
PIC16LF877A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16LF877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF88
PIC16LF88(ISP) [ISP-HEADER01]
PIC16LF88@QFN28 [(SA685-B006)]
PIC16LF88@QFN28(ISP) [ISP-HEADER01]
PIC16LF88@SOIC18 [(SA404)]
PIC16LF88@SOIC18(ISP) [ISP-HEADER01]
PIC16LF88@SSOP20 [(SA626A)]
PIC16LF88@SSOP20(ISP) [ISP-HEADER01]

```

```

PIC16LF913 PIC16LF913(ISP) [ISP-HEADER01]
PIC16LF913@QFN28 [(SA685-B006)]
PIC16LF913@QFN28(ISP) [ISP-HEADER01]
PIC16LF913@SOIC28 [(SA404)]
PIC16LF913@SOIC28(ISP) [ISP-HEADER01]
PIC16LF913@SSOP28 [(SA626A)]
PIC16LF913@SSOP28(ISP) [ISP-HEADER01]
PIC16LF914 PIC16LF914(ISP) [ISP-HEADER01]
PIC16LF914@QFN44 [(SA712)]
PIC16LF914@QFN44(ISP) [ISP-HEADER01]
PIC16LF914@QFN44(ML) [(SA737)]
PIC16LF914@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16LF914@TQFP44 [(SA245A)]
PIC16LF914@TQFP44(ISP) [ISP-HEADER01]
PIC16LF916 PIC16LF916(ISP) [ISP-HEADER01]
PIC16LF916@QFN28 [(SA685-B006)]
PIC16LF916@QFN28(ISP) [ISP-HEADER01]
PIC16LF916@SOIC28 [(SA404)]
PIC16LF916@SOIC28(ISP) [ISP-HEADER01]
PIC16LF916@SSOP28 [(SA626A)]
PIC16LF916@SSOP28(ISP) [ISP-HEADER01]
PIC16LF917 PIC16LF917(ISP) [ISP-HEADER01]
PIC16LF917@QFN44 [(SA712)]
PIC16LF917@QFN44(ISP) [ISP-HEADER01]
PIC16LF917@QFN44(ML) [(SA737)]
PIC16LF917@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16LF917@TQFP44 [(SA245A)]
PIC16LF917@TQFP44(ISP) [ISP-HEADER01]
PIC16LF946@TQFP64(ISP) [ISP-HEADER01]
PIC16LV54A PIC16LV54A@SOIC18 [(SA404)]
PIC16LV54A@SSOP20 [(SA626A)] PIC16LV58A
PIC16LV58A@SOIC18 [(SA404)] PIC16LV58A@SSOP20 [(SA626A)]
PIC18C242 PIC18C242@SOIC28 [(SA404)]
PIC18C252 PIC18C252@SOIC28 [(SA404)]
PIC18C442 PIC18C442@PLCC44 [(SA244)]
PIC18C442@TQFP44 [(SA245A)] PIC18C452
PIC18C452@PLCC44 [(SA244)] PIC18C452@TQFP44 [(SA245A)]
PIC18F1220 PIC18F1220(ISP) [ISP-HEADER01]
PIC18F1220@SOIC18 [(SA404)]
PIC18F1220@SOIC18(ISP) [ISP-HEADER01]
PIC18F1220@SSOP20 [(SA626A)]
PIC18F1220@SSOP20(ISP) [ISP-HEADER01]
PIC18F1230 PIC18F1230(ISP) [ISP-HEADER01]
PIC18F1230@QFN28 [(SA685-B006)]
PIC18F1230@QFN28(ISP) [ISP-HEADER01]
PIC18F1230@SOIC18 [(SA404)]
PIC18F1230@SOIC18(ISP) [ISP-HEADER01]
PIC18F1230@SSOP20 [(SA626A)]
PIC18F1230@SSOP20(ISP) [ISP-HEADER01]
PIC18F1320 PIC18F1320(ISP) [ISP-HEADER01]
PIC18F1320@SOIC18 [(SA404)]
PIC18F1320@SOIC18(ISP) [ISP-HEADER01]
PIC18F1320@SSOP20 [(SA626A)]
PIC18F1320@SSOP20(ISP) [ISP-HEADER01]
PIC18F1330 PIC18F1330(ISP) [ISP-HEADER01]
PIC18F1330@QFN28 [(SA685-B006)]
PIC18F1330@QFN28(ISP) [ISP-HEADER01]
PIC18F1330@SOIC18 [(SA404)]
PIC18F1330@SOIC18(ISP) [ISP-HEADER01]
PIC18F1330@SSOP20 [(SA626A)]
PIC18F1330@SSOP20(ISP) [ISP-HEADER01]
PIC18F1330-ICD@QFN28 [(SA685-B006)]
PIC18F1330-ICD@QFN28(ISP) [ISP-HEADER01]
PIC18F2220 PIC18F2220(ISP) [ISP-HEADER01]
PIC18F2220@SOIC28 [(SA404)]
PIC18F2220@SOIC28(ISP) [ISP-HEADER01]
PIC18F2221
PIC18F2221(ISP)(Low-V) [ISP-HEADER01]
PIC18F2221@QFN28 [(SA685-B006)]
PIC18F2221@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2221@SOIC28 [(SA404)]
PIC18F2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2320 PIC18F2320(ISP) [ISP-HEADER01]
PIC18F2320@SOIC28 [(SA404)]
PIC18F2320@SOIC28(ISP) [ISP-HEADER01]
PIC18F2321
PIC18F2321(ISP)(Low-V) [ISP-HEADER01]
PIC18F2321@QFN28 [(SA685-B006)]
PIC18F2321@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2321@SOIC28 [(SA404)]
PIC18F2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]

```



```

PIC18F2331                                PIC18F2331(ISP) [ISP-HEADER01]
PIC18F2331@SOIC28 [(SA404)]
PIC18F2331@SOIC28(ISP) [ISP-HEADER01]
PIC18F23K20
PIC18F23K20(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@QFN28 [(SA685-B006)]
PIC18F23K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@SOIC28 [(SA404)]
PIC18F23K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@SSOP28 [(SA626A)]
PIC18F23K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410
PIC18F2410(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410@QFN28 [(SA685-B006)]
PIC18F2410@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410@SOIC28 [(SA404)]
PIC18F2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F242                                PIC18F242(ISP) [ISP-HEADER01]
PIC18F242@SOIC28 [(SA404)]
PIC18F242@SOIC28(ISP) [ISP-HEADER01]
PIC18F2420
PIC18F2420(ISP)(High-V) [ISP-HEADER01]
PIC18F2420(ISP)(Low-V) [ISP-HEADER01]
PIC18F2420@SOIC28 [(SA404)]
PIC18F2420@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423
PIC18F2423(ISP)(High-V) [ISP-HEADER01]
PIC18F2423(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423@QFN28 [(SA685-B006)]
PIC18F2423@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2423@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423@SOIC28 [(SA404)]
PIC18F2423@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2423@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2431                                PIC18F2431(ISP) [ISP-HEADER01]
PIC18F2431@SOIC28 [(SA404)]
PIC18F2431@SOIC28(ISP) [ISP-HEADER01]
PIC18F2439                                PIC18F2439(ISP) [ISP-HEADER01]
PIC18F2439@SOIC28 [(SA404)]
PIC18F2439@SOIC28(ISP) [ISP-HEADER01]
PIC18F2450
PIC18F2450(ISP)(Low-V) [ISP-HEADER01]
PIC18F2450@QFN28 [(SA685-B006)]
PIC18F2450@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2450@SOIC28 [(SA404)]
PIC18F2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2455
PIC18F2455(ISP)(High-V) [ISP-HEADER01]
PIC18F2455(ISP)(Low-V) [ISP-HEADER01]
PIC18F2455@SOIC28 [(SA404)]
PIC18F2455@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2458
PIC18F2458(ISP)(High-V) [ISP-HEADER01]
PIC18F2458(ISP)(Low-V) [ISP-HEADER01]
PIC18F2458@SOIC28 [(SA404)]
PIC18F2458@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2458@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2458@SSOP28 [(SA626A)]
PIC18F2458@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2458@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F248                                PIC18F248(ISP) [ISP-HEADER01]
PIC18F248@SOIC28 [(SA404)]
PIC18F248@SOIC28(ISP) [ISP-HEADER01]
PIC18F2480
PIC18F2480(ISP)(High-V) [ISP-HEADER01]
PIC18F2480(ISP)(Low-V) [ISP-HEADER01]
PIC18F2480@QFN28 [(SA685-B006)]
PIC18F2480@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2480@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2480@SOIC28 [(SA404)]
PIC18F2480@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F24J10                                PIC18F24J10(ISP) [ISP-HEADER01]
PIC18F24J10@QFN28 [(SA685-B006)]
PIC18F24J10@QFN28(ISP) [ISP-HEADER01]

```

```

PIC18F24J10@SOIC28 [(SA404)]
PIC18F24J10@SOIC28(ISP) [ISP-HEADER01]
PIC18F24J10@SSOP28 [(SA626A)]
PIC18F24J10@SSOP28(ISP) [ISP-HEADER01]
PIC18F24K20
PIC18F24K20(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F24K20@QFN28 [(SA685-B006)]
PIC18F24K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F24K20@SOIC28 [(SA404)]
PIC18F24K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F24K20@SSOP28 [(SA626A)]
PIC18F24K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F24K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2510 PIC18F2510(ISP) [ISP-HEADER01]
PIC18F2510@QFN28 [(SA685-B006)]
PIC18F2510@QFN28(ISP) [ISP-HEADER01]
PIC18F2510@SOIC28 [(SA404)]
PIC18F2510@SOIC28(ISP) [ISP-HEADER01]
PIC18F2515
PIC18F2515(ISP)(Low-V) [ISP-HEADER01]
PIC18F2515@SOIC28 [(SA404)]
PIC18F2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F252 PIC18F252(ISP) [ISP-HEADER01]
PIC18F252@SOIC28 [(SA404)]
PIC18F252@SOIC28(ISP) [ISP-HEADER01]
PIC18F2520
PIC18F2520(ISP)(High-V) [ISP-HEADER01]
PIC18F2520(ISP)(Low-V) [ISP-HEADER01]
PIC18F2520@SOIC28 [(SA404)]
PIC18F2520@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523
PIC18F2523(ISP)(High-V) [ISP-HEADER01]
PIC18F2523(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523@QFN28 [(SA685-B006)]
PIC18F2523@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2523@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523@SOIC28 [(SA404)]
PIC18F2523@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2523@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2525
PIC18F2525(ISP)(Low-V) [ISP-HEADER01]
PIC18F2525@SOIC28 [(SA404)]
PIC18F2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2539 PIC18F2539(ISP) [ISP-HEADER01]
PIC18F2539@SOIC28 [(SA404)]
PIC18F2539@SOIC28(ISP) [ISP-HEADER01]
PIC18F2550
PIC18F2550(ISP)(High-V) [ISP-HEADER01]
PIC18F2550(ISP)(Low-V) [ISP-HEADER01]
PIC18F2550@SOIC28 [(SA404)]
PIC18F2550@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553
PIC18F2553(ISP)(High-V) [ISP-HEADER01]
PIC18F2553(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553@SOIC28 [(SA404)]
PIC18F2553@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2553@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553@SSOP28 [(SA626A)]
PIC18F2553@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2553@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F258 PIC18F258(ISP) [ISP-HEADER01]
PIC18F258@SOIC28 [(SA404)]
PIC18F258@SOIC28(ISP) [ISP-HEADER01]
PIC18F2580
PIC18F2580(ISP)(High-V) [ISP-HEADER01]
PIC18F2580(ISP)(Low-V) [ISP-HEADER01]
PIC18F2580@QFN28 [(SA685-B006)]
PIC18F2580@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2580@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2580@SOIC28 [(SA404)]
PIC18F2580@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585
PIC18F2585(ISP)(High-V) [ISP-HEADER01]
PIC18F2585(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585@SDIP28 [(SA022A)]

```

```

PIC18F2585@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585@SOIC28 [(SA404)]
PIC18F2585@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25J10 PIC18F25J10(ISP) [ISP-HEADER01]
PIC18F25J10@QFN28 [(SA685-B006)]
PIC18F25J10@QFN28(ISP) [ISP-HEADER01]
PIC18F25J10@SOIC28 [(SA404)]
PIC18F25J10@SOIC28(ISP) [ISP-HEADER01]
PIC18F25J10@SSOP28 [(SA626A)]
PIC18F25J10@SSOP28(ISP) [ISP-HEADER01]
PIC18F25K20
PIC18F25K20(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@QFN28 [(SA685-B006)]
PIC18F25K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@SOIC28 [(SA404)]
PIC18F25K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@SSOP28 [(SA626A)]
PIC18F25K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2610
PIC18F2610(ISP)(Low-V) [ISP-HEADER01]
PIC18F2610@SOIC28 [(SA404)]
PIC18F2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2620
PIC18F2620(ISP)(Low-V) [ISP-HEADER01]
PIC18F2620@SOIC28 [(SA404)]
PIC18F2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680
PIC18F2680(ISP)(High-V) [ISP-HEADER01]
PIC18F2680(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680@SDIP28 [(SA022A)]
PIC18F2680@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680@SOIC28 [(SA404)]
PIC18F2680@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682
PIC18F2682(ISP)(High-V) [ISP-HEADER01]
PIC18F2682(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682@QFN28 [(SA685)]
PIC18F2682@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2682@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682@SOIC28 [(SA404)]
PIC18F2682@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685
PIC18F2685(ISP)(High-V) [ISP-HEADER01]
PIC18F2685(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685@QFN28 [(SA685)]
PIC18F2685@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2685@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685@SOIC28 [(SA404)]
PIC18F2685@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20
PIC18F26K20(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20@QFN28 [(SA685-B006)]
PIC18F26K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20@SOIC28 [(SA404)]
PIC18F26K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F26K20@SSOP28 [(SA626A)]
PIC18F26K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F26K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F4220 PIC18F4220(ISP) [ISP-HEADER01]
PIC18F4220@QFN44 [(SA712)]
PIC18F4220@QFN44(ISP) [ISP-HEADER01]
PIC18F4220@QFN44(ML) [(SA737)]
PIC18F4220@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4220@TQFP44 [(SA245A)]
PIC18F4220@TQFP44(ISP) [ISP-HEADER01]
PIC18F4221
PIC18F4221(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@QFN44 [(SA712)]

```

```
PIC18F4221@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@QFN44(ML) [(SA737)]
PIC18F4221@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@TQFP44 [(SA245A)]
PIC18F4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4320 PIC18F4320(ISP) [ISP-HEADER01]
PIC18F4320@QFN44 [(SA712)]
PIC18F4320@QFN44(ISP) [ISP-HEADER01]
PIC18F4320@QFN44(ML) [(SA737)]
PIC18F4320@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4320@TQFP44 [(SA245A)]
PIC18F4320@TQFP44(ISP) [ISP-HEADER01]
PIC18F4321
PIC18F4321(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@QFN44 [(SA712)]
PIC18F4321@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@QFN44(ML) [(SA737)]
PIC18F4321@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@TQFP44 [(SA245A)]
PIC18F4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4331(ISP) [ISP-HEADER01]
PIC18F4331@TQFP44(ISP) [ISP-HEADER01]
PIC18F43K20
PIC18F43K20(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F43K20@QFN44 [(SA712)]
PIC18F43K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ML) [(SA737)]
PIC18F43K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F43K20@TQFP44 [(SA245A)]
PIC18F43K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410
PIC18F4410(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@QFN44 [(SA712)]
PIC18F4410@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@QFN44(ML) [(SA737)]
PIC18F4410@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@TQFP44 [(SA245A)]
PIC18F4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F442 PIC18F442(ISP) [ISP-HEADER01]
PIC18F442@PLCC44 [(SA244)]
PIC18F442@PLCC44(ISP) [ISP-HEADER01]
PIC18F442@QFN44 [(SA737)] PIC18F442@TQFP44 [(SA245A)]
PIC18F442@TQFP44(ISP) [ISP-HEADER01]
PIC18F4420
PIC18F4420(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@QFN44 [(SA712)]
PIC18F4420@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@QFN44(ML) [(SA737)]
PIC18F4420@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@TQFP44 [(SA245A)]
PIC18F4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423
PIC18F4423(ISP)(High-V) [ISP-HEADER01]
PIC18F4423(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@QFN44 [(SA712)]
PIC18F4423@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4423@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@QFN44(ML) [(SA737)]
PIC18F4423@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4423@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@TQFP44 [(SA245A)]
PIC18F4423@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4423@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4431 PIC18F4431(ISP) [ISP-HEADER01]
PIC18F4431@TQFP44 [(SA245A)]
PIC18F4431@TQFP44(ISP) [ISP-HEADER01]
PIC18F4439 PIC18F4439(ISP) [ISP-HEADER01]
PIC18F4439@TQFP44 [(SA245A)]
PIC18F4439@TQFP44(ISP) [ISP-HEADER01]
PIC18F4450
PIC18F4450(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@QFN44 [(SA712)]
PIC18F4450@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@QFN44(ML) [(SA737)]
PIC18F4450@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@TQFP44 [(SA245A)]
PIC18F4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]
```

```

PIC18F4455
PIC18F4455(ISP)(High-V) [ISP-HEADER01]
PIC18F4455(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@QFN44 [(SA712)]
PIC18F4455@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4455@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@QFN44(ML) [(SA737)]
PIC18F4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4455@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@TQFP44 [(SA245A)]
PIC18F4455@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458
PIC18F4458(ISP)(High-V) [ISP-HEADER01]
PIC18F4458(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458@QFN44 [(SA737)]
PIC18F4458@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4458@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458@TQFP44 [(SA245A)]
PIC18F4458@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4458@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F448 PIC18F448(ISP) [ISP-HEADER01]
PIC18F448@PLCC44 [(SA244)]
PIC18F448@PLCC44(ISP) [ISP-HEADER01]
PIC18F448@QFN44 [(SA737)] PIC18F448@TQFP44 [(SA245A)]
PIC18F448@TQFP44(ISP) [ISP-HEADER01]
PIC18F4480
PIC18F4480(ISP)(High-V) [ISP-HEADER01]
PIC18F4480(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@QFN44 [(SA712)]
PIC18F4480@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4480@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@QFN44(ML) [(SA737)]
PIC18F4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4480@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@TQFP44 [(SA245A)]
PIC18F4480@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F44J10(ISP) [ISP-HEADER01]
PIC18F44J10@QFN44(ISP) [ISP-HEADER01]
PIC18F44J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F44J10@TQFP44(ISP) [ISP-HEADER01]
PIC18F44K20
PIC18F44K20(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F44K20@QFN44 [(SA712)]
PIC18F44K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ML) [(SA737)]
PIC18F44K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F44K20@TQFP44 [(SA245A)]
PIC18F44K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4510 PIC18F4510(ISP) [ISP-HEADER01]
PIC18F4510@QFN44 [(SA712)]
PIC18F4510@QFN44(ISP) [ISP-HEADER01]
PIC18F4510@QFN44(ML) [(SA737)]
PIC18F4510@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4510@TQFP44 [(SA245A)]
PIC18F4510@TQFP44(ISP) [ISP-HEADER01]
PIC18F4515
PIC18F4515(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@QFN44 [(SA712)]
PIC18F4515@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@QFN44(ML) [(SA737)]
PIC18F4515@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@TQFP44 [(SA245A)]
PIC18F4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F452 PIC18F452(ISP) [ISP-HEADER01]
PIC18F452@PLCC44 [(SA244)]
PIC18F452@PLCC44(ISP) [ISP-HEADER01]
PIC18F452@QFN44 [(SA737)] PIC18F452@TQFP44 [(SA245A)]
PIC18F452@TQFP44(ISP) [ISP-HEADER01]
PIC18F4520 PIC18F4520(ISP) [ISP-HEADER01]
PIC18F4520@QFN44 [(SA712)]
PIC18F4520@QFN44(ISP) [ISP-HEADER01]
PIC18F4520@QFN44(ML) [(SA737)]
PIC18F4520@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4520@TQFP44 [(SA245A)]
PIC18F4520@TQFP44(ISP) [ISP-HEADER01]

```

```
PIC18F4523
PIC18F4523(ISP)(High-V) [ISP-HEADER01]
PIC18F4523(ISP)(Low-V) [ISP-HEADER01]
PIC18F4523@QFN44 [(SA712)]
PIC18F4523@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4523@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4523@QFN44(ML) [(SA737)]
PIC18F4523@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4523@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4523@TQFP44 [(SA245A)]
PIC18F4523@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4523@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525
PIC18F4525(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525@QFN44 [(SA712)]
PIC18F4525@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525@QFN44(ML) [(SA737)]
PIC18F4525@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4525@TQFP44 [(SA245A)]
PIC18F4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4539(ISP) [ISP-HEADER01]
PIC18F4539@TQFP44(ISP) [ISP-HEADER01]
PIC18F4550
PIC18F4550(ISP)(High-V) [ISP-HEADER01]
PIC18F4550(ISP)(Low-V) [ISP-HEADER01]
PIC18F4550@QFN44 [(SA712)]
PIC18F4550@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4550@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4550@QFN44(ML) [(SA737)]
PIC18F4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4550@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4550@TQFP44 [(SA245A)]
PIC18F4550@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553
PIC18F4553(ISP)(High-V) [ISP-HEADER01]
PIC18F4553(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553@QFN44 [(SA737)]
PIC18F4553@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4553@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553@TQFP44 [(SA245A)]
PIC18F4553@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4553@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F458
PIC18F458@PLCC44 [(SA244)]
PIC18F458@PLCC44(ISP) [ISP-HEADER01]
PIC18F458@QFN44 [(SA737)]
PIC18F458@TQFP44(ISP) [ISP-HEADER01]
PIC18F458@TQFP44(ISP) [ISP-HEADER01]
PIC18F458(ISP) [ISP-HEADER01]
PIC18F4580
PIC18F4580(ISP)(High-V) [ISP-HEADER01]
PIC18F4580(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@QFN44 [(SA712)]
PIC18F4580@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4580@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@QFN44(ML) [(SA737)]
PIC18F4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4580@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@TQFP44 [(SA245A)]
PIC18F4580@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585
PIC18F4585(ISP)(High-V) [ISP-HEADER01]
PIC18F4585(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@QFN44 [(SA712)]
PIC18F4585@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4585@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@QFN44(ML) [(SA737)]
PIC18F4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4585@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@TQFP44 [(SA245A)]
PIC18F4585@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F45J10(ISP) [ISP-HEADER01]
PIC18F45J10@QFN44(ISP) [ISP-HEADER01]
PIC18F45J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F45J10@TQFP44(ISP) [ISP-HEADER01]
PIC18F45K20
PIC18F45K20(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F45K20@QFN44 [(SA712)]
PIC18F45K20@QFN44(ISP)(High-V) [ISP-HEADER01]
```

```
PIC18F45K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ML) [(SA737)]
PIC18F45K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F45K20@TQFP44 [(SA245A)]
PIC18F45K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610
PIC18F4610(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@QFN44 [(SA712)]
PIC18F4610@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@QFN44(ML) [(SA737)]
PIC18F4610@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@TQFP44 [(SA245A)]
PIC18F4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620
PIC18F4620(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@QFN44 [(SA712)]
PIC18F4620@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@QFN44(ML) [(SA737)]
PIC18F4620@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@TQFP44 [(SA245A)]
PIC18F4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680
PIC18F4680(ISP)(High-V) [ISP-HEADER01]
PIC18F4680(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@QFN44 [(SA712)]
PIC18F4680@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4680@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@QFN44(ML) [(SA737)]
PIC18F4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4680@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@TQFP44 [(SA245A)]
PIC18F4680@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682
PIC18F4682(ISP)(High-V) [ISP-HEADER01]
PIC18F4682(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@QFN44 [(SA712)]
PIC18F4682@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4682@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@QFN44(ML) [(SA737)]
PIC18F4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4682@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@TQFP44 [(SA245A)]
PIC18F4682@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685
PIC18F4685(ISP)(High-V) [ISP-HEADER01]
PIC18F4685(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@QFN44 [(SA712)]
PIC18F4685@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4685@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@QFN44(ML) [(SA737)]
PIC18F4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4685@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@TQFP44 [(SA245A)]
PIC18F4685@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F46K20
PIC18F46K20(ISP)(High-V) [ISP-HEADER01]
PIC18F46K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F46K20@QFN44 [(SA712)]
PIC18F46K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F46K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F46K20@QFN44(ML) [(SA737)]
PIC18F46K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F46K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F46K20@TQFP44 [(SA245A)]
PIC18F46K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F46K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F6310@TQFP64(ISP) [ISP-HEADER01]
PIC18F6390@TQFP64(ISP) [ISP-HEADER01]
PIC18F6393@TQFP64(ISP) [ISP-HEADER01]
PIC18F63J11@TQFP64(*) [(SA732+B340)]
PIC18F63J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F63J90@TQFP64(*) [(SA732+B340)]
PIC18F63J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F6410@TQFP64(ISP) [ISP-HEADER01]
PIC18F6490@TQFP64(ISP) [ISP-HEADER01]
PIC18F6493@TQFP64(ISP) [ISP-HEADER01]
```



```
PIC18F64J11@TQFP64(*) [(SA732+B340)]
PIC18F64J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F64J90@TQFP64(*) [(SA732+B340)]
PIC18F64J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F6520@TQFP64(ISP) [ISP-HEADER01]
PIC18F6525@TQFP64(ISP) [ISP-HEADER01]
PIC18F6527@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F6585@PLCC68(ISP) [ISP-HEADER01]
PIC18F6585@TQFP64(ISP) [ISP-HEADER01]
PIC18F65J10@TQFP64(*) [(SA732+B340)]
PIC18F65J10@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F65J10@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F65J11@TQFP64(*) [(SA732+B340)]
PIC18F65J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F65J15@TQFP64(*) [(SA732+B340)]
PIC18F65J15@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F65J15@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F65J50@TQFP64(*) [(SA732+B340)]
PIC18F65J50@TQFP64(ISP) [ISP-HEADER01]
PIC18F65J90@TQFP64(*) [(SA732+B340)]
PIC18F65J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F6620@TQFP64(ISP) [ISP-HEADER01]
PIC18F6621@TQFP64(ISP) [ISP-HEADER01]
PIC18F6622@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F6627@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F6680@PLCC68(ISP) [ISP-HEADER01]
PIC18F6680@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J10@TQFP64(*) [(SA732+B340)]
PIC18F66J10@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F66J10@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F66J11@TQFP64(*) [(SA732+B340)]
PIC18F66J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J15@TQFP64(*) [(SA732+B340)]
PIC18F66J15@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F66J15@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F66J16@TQFP64(*) [(SA732+B340)]
PIC18F66J16@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J50@TQFP64(*) [(SA732+B340)]
PIC18F66J50@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J55@TQFP64(*) [(SA732+B340)]
PIC18F66J55@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J60@TQFP64(*) [(SA732+B340)]
PIC18F66J60@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J65@TQFP64(*) [(SA732+B340)]
PIC18F66J65@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J93@TQFP64(ISP) [ISP-HEADER01]
PIC18F6720@TQFP64(ISP) [ISP-HEADER01]
PIC18F6722@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F67J10@TQFP64(*) [(SA732+B340)]
PIC18F67J10@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F67J10@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F67J11@TQFP64(*) [(SA732+B340)]
PIC18F67J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J50@TQFP64(*) [(SA732+B340)]
PIC18F67J50@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J60@TQFP64(*) [(SA732+B340)]
PIC18F67J60@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J93@TQFP64(ISP) [ISP-HEADER01]
PIC18F8310@TQFP80(ISP) [ISP-HEADER01]
PIC18F8390@TQFP80(ISP) [ISP-HEADER01]
PIC18F8393@TQFP80(ISP) [ISP-HEADER01]
PIC18F83J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F83J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8410@TQFP80(ISP) [ISP-HEADER01]
PIC18F8490@TQFP80(ISP) [ISP-HEADER01]
PIC18F8493@TQFP80(ISP) [ISP-HEADER01]
PIC18F84J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F84J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8520@TQFP80(ISP) [ISP-HEADER01]
PIC18F8525@TQFP80(ISP) [ISP-HEADER01]
PIC18F8527@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8585@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F85J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
```

```

PIC18F85J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J15@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F85J15@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F85J50@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8620@TQFP80(ISP) [ISP-HEADER01]
PIC18F8621@TQFP80(ISP) [ISP-HEADER01]
PIC18F8622@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8627@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8680@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F86J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F86J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J15@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F86J15@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F86J16@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J50@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J55@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J60@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J65@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J93@TQFP80(ISP) [ISP-HEADER01]
PIC18F8720@TQFP80(ISP) [ISP-HEADER01]
PIC18F8722@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F87J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F87J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F87J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F87J50@TQFP80(ISP) [ISP-HEADER01]
PIC18F87J60@TQFP80(ISP) [ISP-HEADER01]
PIC18F87J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F87J93@TQFP80(ISP) [ISP-HEADER01]
PIC18F96J60@TQFP100(ISP) [ISP-HEADER01]
PIC18F96J65@TQFP100(ISP) [ISP-HEADER01]
PIC18F97J60@TQFP100(ISP) [ISP-HEADER01]
PIC18LC452 PIC18LC452@PLCC44 [(SA244)]
PIC18LC452@TQFP44 [(SA245A)] PIC18LF1220
PIC18LF1220(ISP) [ISP-HEADER01] PIC18LF1220@SOIC18 [(SA404)]
PIC18LF1220@SOIC18(ISP) [ISP-HEADER01]
PIC18LF1220@SSOP20 [(SA626A)]
PIC18LF1220@SSOP20(ISP) [ISP-HEADER01]
PIC18LF1320 PIC18LF1320(ISP) [ISP-HEADER01]
PIC18LF1320@SOIC18 [(SA404)]
PIC18LF1320@SOIC18(ISP) [ISP-HEADER01]
PIC18LF1320@SSOP20 [(SA626A)]
PIC18LF1320@SSOP20(ISP) [ISP-HEADER01]
PIC18LF2220 PIC18LF2220(ISP) [ISP-HEADER01]
PIC18LF2220@SOIC28 [(SA404)]
PIC18LF2220@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2221
PIC18LF2221(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2221@QFN28 [(SA685-B006)]
PIC18LF2221@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2221@SOIC28 [(SA404)]
PIC18LF2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2320 PIC18LF2320(ISP) [ISP-HEADER01]
PIC18LF2320@SOIC28 [(SA404)]
PIC18LF2320@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2321
PIC18LF2321(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2321@QFN28 [(SA685-B006)]
PIC18LF2321@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2321@SOIC28 [(SA404)]
PIC18LF2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2331 PIC18LF2331(ISP) [ISP-HEADER01]
PIC18LF2331@SOIC28 [(SA404)]
PIC18LF2331@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2410
PIC18LF2410(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2410@QFN28 [(SA685-B006)]
PIC18LF2410@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2410@SOIC28 [(SA404)]
PIC18LF2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF242 PIC18LF242(ISP) [ISP-HEADER01]
PIC18LF242@SOIC28 [(SA404)]
PIC18LF242@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2420
PIC18LF2420(ISP)(High-V) [ISP-HEADER01]
PIC18LF2420(ISP)(Low-V) [ISP-HEADER01]

```

```
PIC18LF2420@SOIC28 [(SA404)]
PIC18LF2420@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2431
PIC18LF2431@SOIC28 [(SA404)]
PIC18LF2431@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2439
PIC18LF2439@SOIC28 [(SA404)]
PIC18LF2439@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2450
PIC18LF2450(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2450@QFN28 [(SA685-B006)]
PIC18LF2450@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2450@SOIC28 [(SA404)]
PIC18LF2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2455
PIC18LF2455(ISP)(High-V) [ISP-HEADER01]
PIC18LF2455(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2455@SOIC28 [(SA404)]
PIC18LF2455@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF248
PIC18LF248@SOIC28 [(SA404)]
PIC18LF248@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2480
PIC18LF2480(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2480@QFN28 [(SA685-B006)]
PIC18LF2480@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2480@SOIC28 [(SA404)]
PIC18LF2480@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF24J10
PIC18LF24J10@QFN28 [(SA685-B006)]
PIC18LF24J10@QFN28(ISP) [ISP-HEADER01]
PIC18LF24J10@SOIC28 [(SA404)]
PIC18LF24J10@SOIC28(ISP) [ISP-HEADER01]
PIC18LF24J10@SSOP28 [(SA626A)]
PIC18LF24J10@SSOP28(ISP) [ISP-HEADER01]
PIC18LF2510
PIC18LF2510@QFN28 [(SA685-B006)]
PIC18LF2510@QFN28(ISP) [ISP-HEADER01]
PIC18LF2510@SOIC28 [(SA404)]
PIC18LF2510@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2515
PIC18LF2515(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2515@SOIC28 [(SA404)]
PIC18LF2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF252
PIC18LF252@SOIC28 [(SA404)]
PIC18LF252@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2520
PIC18LF2520(ISP)(High-V) [ISP-HEADER01]
PIC18LF2520(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2520@SOIC28 [(SA404)]
PIC18LF2520@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2525
PIC18LF2525(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2525@SOIC28 [(SA404)]
PIC18LF2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2539
PIC18LF2539@SOIC28 [(SA404)]
PIC18LF2539@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2550
PIC18LF2550(ISP)(High-V) [ISP-HEADER01]
PIC18LF2550(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2550@SOIC28 [(SA404)]
PIC18LF2550@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF258
PIC18LF258@SOIC28 [(SA404)]
PIC18LF258@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2580
PIC18LF2580(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2580@QFN28 [(SA685-B006)]
PIC18LF2580@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2580@SOIC28 [(SA404)]
```

```
PIC18LF2580@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2585
PIC18LF2585(ISP)(High-V) [ISP-HEADER01]
PIC18LF2585(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2585@SDIP28 [(SA022A)]
PIC18LF2585@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2585@SOIC28 [(SA404)]
PIC18LF2585@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF25J10 PIC18LF25J10(ISP) [ISP-HEADER01]
PIC18LF25J10@QFN28 [(SA685-B006)]
PIC18LF25J10@QFN28(ISP) [ISP-HEADER01]
PIC18LF25J10@SOIC28 [(SA404)]
PIC18LF25J10@SOIC28(ISP) [ISP-HEADER01]
PIC18LF25J10@SSOP28 [(SA626A)]
PIC18LF25J10@SSOP28(ISP) [ISP-HEADER01]
PIC18LF2610
PIC18LF2610(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2610@SOIC28 [(SA404)]
PIC18LF2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2620
PIC18LF2620(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2620@SOIC28 [(SA404)]
PIC18LF2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2680
PIC18LF2680(ISP)(High-V) [ISP-HEADER01]
PIC18LF2680(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2680@SDIP28 [(SA022A)]
PIC18LF2680@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2680@SOIC28 [(SA404)]
PIC18LF2680@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2682
PIC18LF2682(ISP)(High-V) [ISP-HEADER01]
PIC18LF2682(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2682@QFN28 [(SA685)]
PIC18LF2682@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2682@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2682@SOIC28 [(SA404)]
PIC18LF2682@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2685
PIC18LF2685(ISP)(High-V) [ISP-HEADER01]
PIC18LF2685(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2685@QFN28 [(SA685)]
PIC18LF2685@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2685@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2685@SOIC28 [(SA404)]
PIC18LF2685@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4220 PIC18LF4220(ISP) [ISP-HEADER01]
PIC18LF4220@QFN44 [(SA712)]
PIC18LF4220@QFN44(ISP) [ISP-HEADER01]
PIC18LF4220@QFN44(ML) [(SA737)]
PIC18LF4220@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4220@TQFP44 [(SA245A)]
PIC18LF4220@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4221
PIC18LF4221(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4221@QFN44 [(SA712)]
PIC18LF4221@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4221@QFN44(ML) [(SA737)]
PIC18LF4221@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4221@TQFP44 [(SA245A)]
PIC18LF4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4320 PIC18LF4320(ISP) [ISP-HEADER01]
PIC18LF4320@QFN44 [(SA712)]
PIC18LF4320@QFN44(ISP) [ISP-HEADER01]
PIC18LF4320@QFN44(ML) [(SA737)]
PIC18LF4320@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4320@TQFP44 [(SA245A)]
PIC18LF4320@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4321
PIC18LF4321(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4321@QFN44 [(SA712)]
PIC18LF4321@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4321@QFN44(ML) [(SA737)]
PIC18LF4321@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
```

```

PIC18LF4321@TQFP44 [(SA245A)]
PIC18LF4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4331(ISP) [ISP-HEADER01]
PIC18LF4331@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4410
PIC18LF4410(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4410@QFN44 [(SA712)]
PIC18LF4410@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4410@QFN44(ML) [(SA737)]
PIC18LF4410@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4410@TQFP44 [(SA245A)]
PIC18LF4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF442 PIC18LF442(ISP) [ISP-HEADER01]
PIC18LF442@PLCC44 [(SA244)]
PIC18LF442@PLCC44(ISP) [ISP-HEADER01]
PIC18LF442@QFN44 [(SA737)] PIC18LF442@TQFP44 [(SA245A)]
PIC18LF442@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4420
PIC18LF4420(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4420@QFN44 [(SA712)]
PIC18LF4420@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4420@QFN44(ML) [(SA737)]
PIC18LF4420@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4420@TQFP44 [(SA245A)]
PIC18LF4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4431 PIC18LF4431(ISP) [ISP-HEADER01]
PIC18LF4431@TQFP44 [(SA245A)]
PIC18LF4431@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4439 PIC18LF4439(ISP) [ISP-HEADER01]
PIC18LF4439@TQFP44 [(SA245A)]
PIC18LF4439@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4450
PIC18LF4450(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4450@QFN44 [(SA712)]
PIC18LF4450@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4450@QFN44(ML) [(SA737)]
PIC18LF4450@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4450@TQFP44 [(SA245A)]
PIC18LF4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455
PIC18LF4455(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455@QFN44 [(SA712)]
PIC18LF4455@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ML) [(SA737)]
PIC18LF4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4455@TQFP44 [(SA245A)]
PIC18LF4455@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF448 PIC18LF448(ISP) [ISP-HEADER01]
PIC18LF448@PLCC44 [(SA244)]
PIC18LF448@PLCC44(ISP) [ISP-HEADER01]
PIC18LF448@QFN44 [(SA737)] PIC18LF448@TQFP44 [(SA245A)]
PIC18LF448@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4480
PIC18LF4480(ISP)(High-V) [ISP-HEADER01]
PIC18LF4480(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4480@QFN44 [(SA712)]
PIC18LF4480@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4480@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4480@QFN44(ML) [(SA737)]
PIC18LF4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4480@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4480@TQFP44 [(SA245A)]
PIC18LF4480@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF44J10(ISP) [ISP-HEADER01]
PIC18LF44J10@QFN44(ISP) [ISP-HEADER01]
PIC18LF44J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF44J10@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4510 PIC18LF4510(ISP) [ISP-HEADER01]
PIC18LF4510@QFN44 [(SA712)]
PIC18LF4510@QFN44(ISP) [ISP-HEADER01]
PIC18LF4510@QFN44(ML) [(SA737)]
PIC18LF4510@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4510@TQFP44 [(SA245A)]
PIC18LF4510@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4515
PIC18LF4515(ISP)(Low-V) [ISP-HEADER01]

```

```
PIC18LF4515@QFN44 [(SA712)]
PIC18LF4515@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4515@QFN44(ML) [(SA737)]
PIC18LF4515@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4515@TQFP44 [(SA245A)]
PIC18LF4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF452                                PIC18LF452(ISP) [ISP-HEADER01]
PIC18LF452@PLCC44 [(SA244)]
PIC18LF452@PLCC44(ISP) [ISP-HEADER01]
PIC18LF452@QFN44 [(SA737)]                PIC18LF452@TQFP44 [(SA245A)]
PIC18LF452@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4520                                PIC18LF4520(ISP) [ISP-HEADER01]
PIC18LF4520@QFN44 [(SA712)]
PIC18LF4520@QFN44(ISP) [ISP-HEADER01]
PIC18LF4520@QFN44(ML) [(SA737)]
PIC18LF4520@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4520@TQFP44 [(SA245A)]
PIC18LF4520@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4525
PIC18LF4525(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4525@QFN44 [(SA712)]
PIC18LF4525@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4525@QFN44(ML) [(SA737)]
PIC18LF4525@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4525@TQFP44 [(SA245A)]
PIC18LF4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4539(ISP) [ISP-HEADER01]
PIC18LF4539@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4550
PIC18LF4550(ISP)(High-V) [ISP-HEADER01]
PIC18LF4550(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4550@QFN44 [(SA712)]
PIC18LF4550@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4550@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4550@QFN44(ML) [(SA737)]
PIC18LF4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4550@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4550@TQFP44 [(SA245A)]
PIC18LF4550@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF458                                PIC18LF458(ISP) [ISP-HEADER01]
PIC18LF458@PLCC44 [(SA244)]
PIC18LF458@PLCC44(ISP) [ISP-HEADER01]
PIC18LF458@QFN44 [(SA737)]                PIC18LF458@TQFP44 [(SA245A)]
PIC18LF458@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4580
PIC18LF4580(ISP)(High-V) [ISP-HEADER01]
PIC18LF4580(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4580@QFN44 [(SA712)]
PIC18LF4580@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4580@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4580@QFN44(ML) [(SA737)]
PIC18LF4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4580@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4580@TQFP44 [(SA245A)]
PIC18LF4580@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585
PIC18LF4585(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585@QFN44 [(SA712)]
PIC18LF4585@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ML) [(SA737)]
PIC18LF4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4585@TQFP44 [(SA245A)]
PIC18LF4585@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF45J10(ISP) [ISP-HEADER01]
PIC18LF45J10@QFN44(ISP) [ISP-HEADER01]
PIC18LF45J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF45J10@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4610
PIC18LF4610(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4610@QFN44 [(SA712)]
PIC18LF4610@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4610@QFN44(ML) [(SA737)]
PIC18LF4610@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4610@TQFP44 [(SA245A)]
PIC18LF4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]
```

PIC18LF4620
PIC18LF4620(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620@QFN44 [(SA712)]
PIC18LF4620@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620@QFN44(ML) [(SA737)]
PIC18LF4620@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4620@TQFP44 [(SA245A)]
PIC18LF4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680
PIC18LF4680(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680@QFN44 [(SA712)]
PIC18LF4680@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ML) [(SA737)]
PIC18LF4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4680@TQFP44 [(SA245A)]
PIC18LF4680@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682
PIC18LF4682(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682@QFN44 [(SA712)]
PIC18LF4682@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ML) [(SA737)]
PIC18LF4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4682@TQFP44 [(SA245A)]
PIC18LF4682@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685
PIC18LF4685(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685@QFN44 [(SA712)]
PIC18LF4685@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ML) [(SA737)]
PIC18LF4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4685@TQFP44 [(SA245A)]
PIC18LF4685@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6310@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6390@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6393@TQFP64(ISP) [ISP-HEADER01]
PIC18LF63J11@TQFP64(*) [(SA732+B340)]
PIC18LF63J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF63J90@TQFP64(*) [(SA732+B340)]
PIC18LF63J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6410@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6490@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6493@TQFP64(ISP) [ISP-HEADER01]
PIC18LF64J11@TQFP64(*) [(SA732+B340)]
PIC18LF64J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF64J90@TQFP64(*) [(SA732+B340)]
PIC18LF64J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6520@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6525@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6527@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6585@PLCC68(ISP) [ISP-HEADER01]
PIC18LF6585@TQFP64(ISP) [ISP-HEADER01]
PIC18LF65J11@TQFP64(*) [(SA732+B340)]
PIC18LF65J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF65J90@TQFP64(*) [(SA732+B340)]
PIC18LF65J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6620@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6621@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6622@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6627@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6680@PLCC68(ISP) [ISP-HEADER01]
PIC18LF6680@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6720@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6722@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8310@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8390@TQFP80(ISP) [ISP-HEADER01]


```
PIC18LF8393@TQFP80(ISP) [ISP-HEADER01]
PIC18LF83J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF83J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8410@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8490@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8493@TQFP80(ISP) [ISP-HEADER01]
PIC18LF84J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF84J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8520@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8525@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8527@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8585@TQFP80(ISP) [ISP-HEADER01]
PIC18LF85J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF85J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8620@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8621@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8622@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8627@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8680@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8720@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8722@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC30F2010 PIC30F2010(ISP) [ISP-HEADER01]
PIC30F2010@SDIP28 [(SA022A)]
PIC30F2010@SDIP28(ISP) [ISP-HEADER01]
PIC30F2010@SOIC28 [(SA404)]
PIC30F2010@SOIC28(ISP) [ISP-HEADER01]
PIC30F2011(ISP) [ISP-HEADER01]
PIC30F2011@QFN28(ISP) [ISP-HEADER01]
PIC30F2011@SDIP18(ISP) [ISP-HEADER01]
PIC30F2011@SOIC18(ISP) [ISP-HEADER01]
PIC30F2012(ISP) [ISP-HEADER01]
PIC30F2012@QFN28(ISP) [ISP-HEADER01]
PIC30F2012@SDIP28(ISP) [ISP-HEADER01]
PIC30F2012@SOIC28(ISP) [ISP-HEADER01]
PIC30F3010(ISP) [ISP-HEADER01]
PIC30F3010@QFN44(ISP) [ISP-HEADER01]
PIC30F3010@SDIP28(ISP) [ISP-HEADER01]
PIC30F3010@SOIC28(ISP) [ISP-HEADER01]
PIC30F3011(ISP) [ISP-HEADER01]
PIC30F3011@QFN44(ISP) [ISP-HEADER01]
PIC30F3011@QFP44(ISP) [ISP-HEADER01]
PIC30F3012(ISP) [ISP-HEADER01]
PIC30F3012@QFN44(ISP) [ISP-HEADER01]
PIC30F3012@QFP44(ISP) [ISP-HEADER01]
PIC30F3012@SDIP18(ISP) [ISP-HEADER01]
PIC30F3012@SOIC18(ISP) [ISP-HEADER01]
PIC30F3013(ISP) [ISP-HEADER01]
PIC30F3013@QFN44(ISP) [ISP-HEADER01]
PIC30F3013@QFP44(ISP) [ISP-HEADER01]
PIC30F3013@SDIP28(ISP) [ISP-HEADER01]
PIC30F3013@SOIC28(ISP) [ISP-HEADER01]
PIC30F3014(ISP) [ISP-HEADER01]
PIC30F3014@QFN44(ISP) [ISP-HEADER01]
PIC30F3014@QFP44(ISP) [ISP-HEADER01]
PIC30F4011(ISP) [ISP-HEADER01]
PIC30F4011@QFN44(ISP) [ISP-HEADER01]
PIC30F4011@QFP44(ISP) [ISP-HEADER01]
PIC30F4012(ISP) [ISP-HEADER01]
PIC30F4012@QFN44(ISP) [ISP-HEADER01]
PIC30F4012@SDIP28(ISP) [ISP-HEADER01]
PIC30F4012@SOIC28(ISP) [ISP-HEADER01]
PIC30F4013(ISP) [ISP-HEADER01]
PIC30F4013@QFN44(ISP) [ISP-HEADER01]
PIC30F4013@QFP44(ISP) [ISP-HEADER01]
PIC30F5011@QFP64(ISP) [ISP-HEADER01]
PIC30F5013@QFP80(ISP) [ISP-HEADER01]
PIC30F5015@QFP64(ISP) [ISP-HEADER01]
PIC30F5016@QFP80(ISP) [ISP-HEADER01]
PIC30F6010@QFP80(ISP) [ISP-HEADER01]
PIC30F6010@TQFP80(ISP) [ISP-HEADER01]
PIC30F6010A@QFP80(ISP) [ISP-HEADER01]
PIC30F6010A@TQFP80(ISP) [ISP-HEADER01]
PIC30F6011@LQFP64(ISP) [ISP-HEADER01]
PIC30F6011@QFP64(ISP) [ISP-HEADER01]
PIC30F6011A@QFP64(ISP) [ISP-HEADER01]
PIC30F6012@QFP64(ISP) [ISP-HEADER01]
PIC30F6012A@QFP64(ISP) [ISP-HEADER01]
```

```

PIC30F6013@QFP80(ISP) [ISP-HEADER01]
PIC30F6013A@QFP80(ISP) [ISP-HEADER01]
PIC30F6014@QFP80(ISP) [ISP-HEADER01]
PIC30F6014@TQFP80(ISP) [ISP-HEADER01]
PIC30F6014A@QFP80(ISP) [ISP-HEADER01]
PIC30F6014A@TQFP80(ISP) [ISP-HEADER01]
PIC30F6015@QFP64(ISP) [ISP-HEADER01]
PS200 PS200(ISP) [ISP-HEADER01]
PS200@SOIC20 [(SA404)] PS200@SOIC20(ISP) [ISP-HEADER01]
PS200@SSOP20 [(SA626A)] PS200@SSOP20(ISP) [ISP-HEADER01]
rfPIC12C509AF@SSOP20 [(SA626A)]
rfPIC12C509AF@SSOP20(ISP) [ISP-HEADER01]
rfPIC12C509AG@SOIC18 [(SA404)]
rfPIC12C509AG@SOIC18(ISP) [ISP-HEADER01]
rfPIC12LC509AF@SSOP20 [(SA626A)]
rfPIC12LC509AF@SSOP20(ISP) [ISP-HEADER01]
rfPIC12LC509AG@SOIC18 [(SA404)]
rfPIC12LC509AG@SOIC18(ISP) [ISP-HEADER01]

```

MICRON

E(E) PROM/FRAM/NVRAM

```

MT28F002B1VG-B@TSOP40 [(SA409T)] MT28F002B1VG-T@TSOP40 [(SA409T)]
MT28F002B3VG-B@TSOP40 [(SA409T)] MT28F002B3VG-T@TSOP40 [(SA409T)]
MT28F002B5VG-B@TSOP40 [(SA409T)] MT28F002B5VG-T@TSOP40 [(SA409T)]
MT28F002C1VG-T@TSOP40 [(SA409T)] MT28F002C5VG-T@TSOP40 [(SA409T)]
MT28F002VG-B@TSOP40 [(SA409T)] MT28F002VG-T@TSOP40 [(SA409T)]
MT28F004B1VG-B@TSOP40 [(SA409T)] MT28F004B1VG-T@TSOP40 [(SA409T)]
MT28F004B3VG-B@TSOP40 [(SA409T)] MT28F004B3VG-T@TSOP40 [(SA409T)]
MT28F004B5VG-B@TSOP40 [(SA409T)] MT28F004B5VG-T@TSOP40 [(SA409T)]
MT28F004VG-B@TSOP40 [(SA409T)] MT28F004VG-T@TSOP40 [(SA409T)]
MT28F008B1VG-B@TSOP40 [(SA409T)] MT28F008B1VG-T@TSOP40 [(SA409T)]
MT28F008B3VG-B@TSOP40 [(SA409T)] MT28F008B3VG-T@TSOP40 [(SA409T)]
MT28F008B5VG-B@TSOP40 [(SA409T)] MT28F008B5VG-T@TSOP40 [(SA409T)]
MT28F016S3VG@TSOP40 [(SA409T)] MT28F016S5VG@TSOP40 [(SA409T)]
MT28F200B1SGB@PSOP44 [(SA638)] MT28F200B1SGT@PSOP44 [(SA638)]
MT28F200B1WGB@TSOP48 [(SA247-B005)]
MT28F200B1WGT@TSOP48 [(SA247-B005)]
MT28F200B3SGB@PSOP44 [(SA638)] MT28F200B3SGT@PSOP44 [(SA638)]
MT28F200B3WGB@TSOP48 [(SA247-B005)]
MT28F200B3WGT@TSOP48 [(SA247-B005)]
MT28F200B5SGB@PSOP44 [(SA638)] MT28F200B5SGT@PSOP44 [(SA638)]
MT28F200B5WGB@TSOP48 [(SA247-B005)]
MT28F200B5WGT@TSOP48 [(SA247-B005)]
MT28F400B1SGB@PSOP44 [(SA638)] MT28F400B1SGT@PSOP44 [(SA638)]
MT28F400B1WGB@TSOP48 [(SA247-B005)]
MT28F400B1WGT@TSOP48 [(SA247-B005)]
MT28F400B3SGB@PSOP44 [(SA638)] MT28F400B3SGT@PSOP44 [(SA638)]
MT28F400B3WGB@TSOP48 [(SA247-B005)]
MT28F400B3WGT@TSOP48 [(SA247-B005)]
MT28F400B5SGB@PSOP44 [(SA638)] MT28F400B5SGT@PSOP44 [(SA638)]
MT28F400B5WGB@TSOP48 [(SA247-B005)]
MT28F400B5WGT@TSOP48 [(SA247-B005)]
MT28F800B1SGB@PSOP44 [(SA638)] MT28F800B1SGT@PSOP44 [(SA638)]
MT28F800B1WGB@TSOP48 [(SA247-B005)]
MT28F800B1WGT@TSOP48 [(SA247-B005)]
MT28F800B3SGB@PSOP44 [(SA638)] MT28F800B3SGT@PSOP44 [(SA638)]
MT28F800B3WGB@TSOP48 [(SA247-B005)]
MT28F800B3WGT@TSOP48 [(SA247-B005)]
MT28F800B5SGB@PSOP44 [(SA638)] MT28F800B5SGT@PSOP44 [(SA638)]
MT28F800B5WGB@TSOP48 [(SA247-B005)]
MT28F800B5WGT@TSOP48 [(SA247-B005)]

```

MICRONAS

MICROCONTROLLER

```
SDA555XFL@SDIP52(*) [(SA627-B5603)]
```

MITSUBISHI

E (E) PROM/FRAM/NVRAM

M5L27128K	M5L2716
M5L27256K	M5L2732
M5L2732A	M5L27512
M5L27512K	M5L2764K
M5L27C512A	M5M27128P
M5M27256P	M5M27512P
M5M2764P	M5M27C100K
M5M27C100K@PLCC32 [(SA015A1T)]	M5M27C100K@TSOP32 [(SA410T)]
M5M27C100P	M5M27C100P@PLCC32 [(SA015A1T)]
M5M27C100P@TSOP32 [(SA410T)]	M5M27C101JK
M5M27C101JK@PLCC32 [(SA015A1T)]	M5M27C101JK@TSOP32 [(SA410T)]
M5M27C101K	M5M27C101K@PLCC32 [(SA015A1T)]
M5M27C101K@TSOP32 [(SA410T)]	M5M27C101P
M5M27C101P@PLCC32 [(SA015A1T)]	M5M27C101P@TSOP32 [(SA410T)]
M5M27C102K	M5M27C102K@PLCC44 [(SA244)]
M5M27C102P	M5M27C102P@PLCC44 [(SA244)]
M5M27C128K	M5M27C201K
M5M27C201K@PLCC32 [(SA015A1T)]	M5M27C201K@TSOP32 [(SA410T)]
M5M27C202K	M5M27C202K@PLCC44 [(SA244)]
M5M27C256(K)	M5M27C256(P)
M5M27C256A(FP)	M5M27C256A(K)
M5M27C256A(P)	M5M27C401K
M5M27C401K@PLCC32 [(SA015A1T)]	M5M27C401K@TSOP32 [(SA410T)]
M5M27C402K	M5M27C512(FP)
M5M27C512A(FP)	M5M27C512A(K)
M5M27C512A(P)	M5M28F101
M5M28F101@PLCC32 [(SA015A1T)]	M5M28F101@SOP32 [(SA438T)]
M5M28F101@TSOP32 [(SA410T)]	M5M28F101A
M5M28F101A@PLCC32 [(SA015A1T)]	M5M28F101A@SOIC32 [(SA438T)]
M5M28F101A@TSOP32 [(SA410T)]	
M5M29FB160A@TSOP48 [(SA247-B005)]	
M5M29FB800(FP)@PSOP44 [(SA638)]	
M5M29FB800(VP)@TSOP48 [(SA247-B005)]	
M5M29FT160A@TSOP48 [(SA247-B005)]	
M5M29FT800(FP)@PSOP44 [(SA638)]	
M5M29FT800(VP)@TSOP48 [(SA247-B005)]	
M6M80011A	M6M80011A@SOIC10 [(SA023A)]
M6M80011A@SOIC16 [(SA023A)]	M6M80021
M6M80021@SOIC10 [(SA023A)]	M6M80021@SOIC16 [(SA023A)]
M6M80041	M6M80041@SOIC10 [(SA023A)]

MICROCONTROLLER

M30240ECFP@QFP80(Renesas) [(PCA7302E1F-80)]
M30620ECFP@QFP100(Renesas) [(PCA7412F-100)]
M30620ECFS@QFN100(Renesas) [(PCA7412L-100)]
M30620ECGP@LQFP100(Renesas) [(PCA7412G-100)]
M30621ECGP@QFP80(Renesas) [(PCA7413F-80)]
M30622ECTFP@QFP100(Renesas) [(PCA7412F-100)]
M30623ECTGP@QFP80(Renesas) [(PCA7413F-80)]
M306V0EEFFP@QFP100(Renesas) [(PCA7412F-100)]
M306V0EEFS@QFN100(Renesas) [(PCA7412L-100)]
M306V2EEFFP@QFP100(Renesas) [(PCA7412F-100)]
M306V2EEFS@QFN100(Renesas) [(PCA7412L-100)]
M34513E4FP@LQFP32(Renesas) [(PCA7442FPG02)]
M34513E4SP@SDIP32(Renesas) [(PCA7442SP)]
M34513E8FP@LQFP32(Renesas) [(PCA7442FPG02)]
M34514E8FP@SSOP42(Renesas) [(PCA7441)]
M34518E8FP@LQFP32(Renesas) [(PCA7442FPG02)]
M34518E8SP@SDIP32(Renesas) [(PCA7442SP)]
M34519E8FP@SSOP42(Renesas) [(PCA7441)]
M34524EDFP@QFP64(Renesas) [(PCA7448)]
M34551E8FP@QFP48(Renesas) [(PCA7414)]
M34554EDFP@QFP64(Renesas) [(PCA7448)]
M34570E8FP@SSOP36(Renesas) [(PCA7425)]
M34570EDFP@SSOP36(Renesas) [(PCA7425)]
M34583EDFP@LQFP32(Renesas) [(PCA7442FPG02)]
M34584EDFP@SSOP42(Renesas) [(PCA7441)]
M37150EFFF@SSOP42(Renesas) [(PCA7450FP)]
M37151EFFF@SSOP42(Renesas) [(PCA7450FP)]
M37160EFFF@SSOP42(Renesas) [(PCA7450FP)]
M37161EFFF@SSOP42(Renesas) [(PCA7450FP)]
M37516E6HKP@QFN44(Renesas) [(PCA7446)]
M37516E6HP@LQFP48(Renesas) [(PCA7419)]
M37540E2FP@SSOP36(Renesas) [(PCA7435FPG02)]
M37540E2GP@LQFP32(Renesas) [(PCA7435GPG03)]
M37540E2SP@SDIP32(Renesas) [(PCA7435SPG02)]

M37540E8FP@SSOP36 (Renesas) [(PCA7435FPG02)]
M37540E8GP@LQFP32 (Renesas) [(PCA7435GPG03)]
M37540E8SP@SDIP32 (Renesas) [(PCA7435SPG02)]
M37560E8DFP@QFP100 (Renesas) [(PCA4738F-100A)]
M37560E8FFP@QFN100 (Renesas) [(PCA4738L-100A)]
M37560E8FFP@QFP100 (Renesas) [(PCA4738F-100A)]
M37560E8FGP@LQFP100 (Renesas) [(PCA4738G-100A)]
M37630E4FFP@QFP44 (Renesas) [(PCA7430)]
M37630E4FS@QFN80 (Renesas) [(PCA7431)]
M37640E8FP@QFP80 (Renesas) [(PCA7440FP)]
M37640E8FS@QFN80 (Renesas) [(PCA7440FS)]
M37733E8BFP@QFP80 (Renesas) [(PCA4774G05)]
M37733E8BFS@QFN80 (Renesas) [(PCA4708G05)]
M37735E8BFP@QFP80 (Renesas) [(PCA4774G05)]
M37735E8BFS@QFN80 (Renesas) [(PCA4708G05)]
M37736E8BGP@QFP100 (Renesas) [(PCA7422GPG02)]
M37736E8BGS@QFN100 (Renesas) [(PCA7422GSG02)]
M37751E6CFP@QFP80 (Renesas) [(PCA4774G05)]
M37751E6CFS@QFN80 (Renesas) [(PCA4708G05)]
M37751F6CFP@QFP80 (Renesas) [(PCA4774G05)]
M38027E8DFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]
M38027E8DSP@DIP64 (Mitsubishi) [(BBBB)]
M38027E8DXXFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]
M38027E8DXXSP@DIP64 (Mitsubishi) [(BBBB)]
M38027E8FS@LCC64 (Mitsubishi) [(BBBB)]
M38027E8SP@DIP64 (Mitsubishi) [(BBBB)]
M38027E8SS@DIP64 (Mitsubishi) [(BBBB)]
M38027E8-XXXFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]
M38027E8-XXXSP@DIP64 (Mitsubishi) [(BBBB)]
M38027M8-XXXFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]
M38039FFFP@QFP64 (Renesas) [(PCA4738FF-64)]
M38039FFHP@LQFP64 (Renesas) [(PCA4738HF-64)]
M38039FFSP@SDIP64 (Renesas) [(PCA4738SF-64)]
M38049FFFP@QFP64 (Renesas) [(PCA4738FF-64)]
M38049FFHP@LQFP64 (Renesas) [(PCA4738HF-64)]
M38049FFSP@SDIP64 (Renesas) [(PCA4738SF-64)]
M38223E4FFP@QFP80 (Renesas) [(PCA4738F-80A)]
M38223E4FS@QFN80 (Renesas) [(PCA4738L-80A)]
M38223E4GP@QFP80 (Renesas) [(PCA4738G-80A)]
M38223E4HP@LQFP80 (Renesas) [(PCA4738H-80A)]
M38227ECFP@QFP80 (Renesas) [(PCA4738F-80A)]
M38227ECFS@QFN80 (Renesas) [(PCA4738L-80A)]
M38227ECHP@LQFP80 (Renesas) [(PCA4738H-80A)]
M38267E8FP@QFP100 (Renesas) [(PCA4738F-100A)]
M38267E8GP@LQFP100 (Renesas) [(PCA4738G-100A)]
M3826AEFFP@QFP100 (Renesas) [(PCA4738F-100A)]
M3826AEFFS@QFN100 (Renesas) [(PCA4738L-100A)]
M3826AEFGP@LQFP100 (Renesas) [(PCA4738G-100A)]
M38504E6FP@SSOP42 (Renesas) [(PCA4738F-42A)]
M38504E6SP@SDIP42 (Renesas) [(PCA4738S-42A)]
M38504E6SS@SDIP42 (Renesas) [(PCA4738S-42A)]
M38514E6FP@SSOP42 (Renesas) [(PCA4738F-42A)]
M38514E6SP@SDIP42 (Renesas) [(PCA4738S-42A)]
M38514E6SS@SDIP42 (Renesas) [(PCA4738S-42A)]
M38867E8AFS@QFN80 (Renesas) [(PCA4738L-80A)]
M38867E8AHP@LQFP80 (Renesas) [(PCA4738H-80A)]
M38869FFAGP@QFP80 (Renesas) [(PCA4738GF-80)]
M38869FFAHP@LQFP80 (Renesas) [(PCA4738HF-80)]
M38B79FFFP@QFP100 (Renesas) [(PCA7438FF-100)]
M38C13E6FP@LQFP64 (Renesas) [(PCA7438F-64A)]
M38C13E6HP@QFP64 (Renesas) [(PCA7438H-64A)]
M38C89EFP@LQFP144 (Renesas) [(PCA7447FP)]
R5F21102DFP@TQFP32 [(SA663+B005)]
R5F21102DFP@TQFP32 (ISP) [ISP-HEADER01]
R5F21102FFP@TQFP32 [(SA663+B005)]
R5F21102FFP@TQFP32 (ISP) [ISP-HEADER01]
R5F21103DFP@TQFP32 [(SA663+B005)]
R5F21103DFP@TQFP32 (ISP) [ISP-HEADER01]
R5F21103FFP@TQFP32 [(SA663+B005)]
R5F21103FFP@TQFP32 (ISP) [ISP-HEADER01]
R5F21104DFP@TQFP32 [(SA663+B005)]
R5F21104DFP@TQFP32 (ISP) [ISP-HEADER01]
R5F21104FFP@TQFP32 [(SA663+B005)]
R5F21104FFP@TQFP32 (ISP) [ISP-HEADER01]
R5F21112DFP@TQFP32 [(SA663+B005)]
R5F21112DFP@TQFP32 (ISP) [ISP-HEADER01]
R5F21112FFP@TQFP32 [(SA663+B005)]
R5F21112FFP@TQFP32 (ISP) [ISP-HEADER01]
R5F21113DFP@TQFP32 [(SA663+B005)]
R5F21113DFP@TQFP32 (ISP) [ISP-HEADER01]
R5F21113FFP@TQFP32 [(SA663+B005)]

```
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]
R5F21114DFP@TQFP32 [(SA663+B005)]
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21114FP@TQFP32 [(SA663+B005)]
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]
R5F21122DFP@TQFP32 [(SA663+B005)]
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21122FP@TQFP32 [(SA663+B005)]
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]
R5F21123DFP@TQFP32 [(SA663+B005)]
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21123FP@TQFP32 [(SA663+B005)]
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]
R5F21124DFP@TQFP32 [(SA663+B005)]
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21124FP@TQFP32 [(SA663+B005)]
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]
R5F21132DFP@TQFP32 [(SA663+B005)]
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21132FP@TQFP32 [(SA663+B005)]
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]
R5F21133DFP@TQFP32 [(SA663+B005)]
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21133FP@TQFP32 [(SA663+B005)]
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]
R5F21134DFP@TQFP32 [(SA663+B005)]
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21134FP@TQFP32 [(SA663+B005)]
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]
R5F21181DD@SDIP20 [(SA725-B005)]
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(single wire) [(SA725-B005)]
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]
R5F21181DSP@TSSOP20 [(SA026-B001)]
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21181SP@TSSOP20 [(SA026-B001)]
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182DD@SDIP20 [(SA725-B005)]
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(single wire) [(SA725-B005)]
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]
R5F21182DSP@TSSOP20 [(SA026-B001)]
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182NP@QFN28 [(SA697-B006)]
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]
R5F21182NP@QFN28(single wire) [(SA697-B006)]
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21182NP@QFN28(UART mode) [(SA697+B006)]
R5F21182SP@TSSOP20 [(SA026-B001)]
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183DD@SDIP20 [(SA725-B005)]
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(single wire) [(SA725-B005)]
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]
R5F21183DSP@TSSOP20 [(SA026-B001)]
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183NP@QFN28 [(SA697-B006)]
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]
R5F21183NP@QFN28(single wire) [(SA697-B006)]
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21183NP@QFN28(UART mode) [(SA697+B006)]
R5F21183SP@TSSOP20 [(SA026-B001)]
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]
```

```
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184DD@SDIP20 [(SA725-B005)]
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(single wire) [(SA725-B005)]
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]
R5F21184DSP@TSSOP20 [(SA026-B001)]
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184NP@QFN28 [(SA697-B006)]
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]
R5F21184NP@QFN28(single wire) [(SA697-B006)]
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21184NP@QFN28(UART mode) [(SA697+B006)]
R5F21184SP@TSSOP20 [(SA026-B001)]
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191DD@SDIP20 [(SA725-B005)]
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(single wire) [(SA725+B005)]
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]
R5F21191DSP@TSSOP20 [(SA026-B001)]
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191SP@TSSOP20 [(SA026-B001)]
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192DD@SDIP20 [(SA725-B005)]
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(single wire) [(SA725+B005)]
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]
R5F21192DSP@TSSOP20 [(SA026-B001)]
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192NP@QFN28 [(SA697-B006)]
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]
R5F21192NP@QFN28(single wire) [(SA697+B006)]
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21192NP@QFN28(UART mode) [(SA697+B006)]
R5F21192SP@TSSOP20 [(SA026-B001)]
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193DD@SDIP20 [(SA725-B005)]
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(single wire) [(SA725+B005)]
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]
R5F21193DSP@TSSOP20 [(SA026-B001)]
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193NP@QFN28 [(SA697-B006)]
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]
R5F21193NP@QFN28(single wire) [(SA697+B006)]
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21193NP@QFN28(UART mode) [(SA697+B006)]
R5F21193SP@TSSOP20 [(SA026-B001)]
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194DD@SDIP20 [(SA725-B005)]
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(single wire) [(SA725+B005)]
```

R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]
R5F21194DSP@TSSOP20 [(SA026-B001)]
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194NP@QFN28 [(SA697-B006)]
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]
R5F21194NP@QFN28(single wire) [(SA697+B006)]
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21194NP@QFN28(UART mode) [(SA697+B006)]
R5F21194SP@TSSOP20 [(SA026-B001)]
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1DD@SDIP20 [(SA725-B005)]
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A1DSP@TSSOP20 [(SA026-B001)]
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1SP@TSSOP20 [(SA026-B001)]
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2DD@SDIP20 [(SA725-B005)]
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A2DSP@TSSOP20 [(SA026-B001)]
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2NP@QFN28 [(SA697-B006)]
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(single wire) [(SA697-B006)]
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]
R5F211A2SP@TSSOP20 [(SA026-B001)]
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3DD@SDIP20 [(SA725-B005)]
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A3DSP@TSSOP20 [(SA026-B001)]
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3NP@QFN28 [(SA697-B006)]
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(single wire) [(SA697-B006)]
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]
R5F211A3SP@TSSOP20 [(SA026-B001)]
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4DD@SDIP20 [(SA725-B005)]
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A4DSP@TSSOP20 [(SA026-B001)]
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]


```
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4NP@QFN28 [(SA697-B006)]
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(single wire) [(SA697-B006)]
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]
R5F211A4SP@TSSOP20 [(SA026-B001)]
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1DD@SDIP20 [(SA725-B005)]
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B1DSP@TSSOP20 [(SA026-B001)]
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1SP@TSSOP20 [(SA026-B001)]
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2DD@SDIP20 [(SA725-B005)]
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B2DSP@TSSOP20 [(SA026-B001)]
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2NP@QFN28 [(SA697-B006)]
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(single wire) [(SA697+B006)]
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]
R5F211B2SP@TSSOP20 [(SA026-B001)]
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3DD@SDIP20 [(SA725-B005)]
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B3DSP@TSSOP20 [(SA026-B001)]
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3NP@QFN28 [(SA697-B006)]
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(single wire) [(SA697+B006)]
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]
R5F211B3SP@TSSOP20 [(SA026-B001)]
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4DD@SDIP20 [(SA725-B005)]
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B4DSP@TSSOP20 [(SA026-B001)]
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4NP@QFN28 [(SA697-B006)]
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(single wire) [(SA697+B006)]
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]
```

```
R5F211B4SP@TSSOP20 [(SA026-B001)]
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21206JFP@TQFP48 [(SA248-B005)]
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]
R5F21206KFP@TQFP48 [(SA248-B005)]
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]
R5F21207JFP@TQFP48 [(SA248-B005)]
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]
R5F21207KFP@TQFP48 [(SA248-B005)]
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]
R5F21208JFP@TQFP48 [(SA248-B005)]
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]
R5F21208KFP@TQFP48 [(SA248-B005)]
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AJFP@TQFP48 [(SA248-B005)]
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AKFP@TQFP48 [(SA248-B005)]
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CJFP@TQFP48 [(SA248-B005)]
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CKFP@TQFP48 [(SA248-B005)]
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21216JFP@TQFP48 [(SA248-B005)]
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]
R5F21216KFP@TQFP48 [(SA248-B005)]
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]
R5F21217JFP@TQFP48 [(SA248-B005)]
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]
R5F21217KFP@TQFP48 [(SA248-B005)]
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]
R5F21218JFP@TQFP48 [(SA248-B005)]
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]
R5F21218KFP@TQFP48 [(SA248-B005)]
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AJFP@TQFP48 [(SA248-B005)]
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AKFP@TQFP48 [(SA248-B005)]
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CJFP@TQFP48 [(SA248-B005)]
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CKFP@TQFP48 [(SA248-B005)]
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21226JFP@TQFP48 [(SA248-B005)]
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]
R5F21226KFP@TQFP48 [(SA248-B005)]
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]
R5F21227JFP@TQFP48 [(SA248-B005)]
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]
R5F21227KFP@TQFP48 [(SA248-B005)]
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]
R5F21228JFP@TQFP48 [(SA248-B005)]
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]
R5F21228KFP@TQFP48 [(SA248-B005)]
```

R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AJFP@TQFP48 [(SA248-B005)]
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AKFP@TQFP48 [(SA248-B005)]
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CJFP@TQFP48 [(SA248-B005)]
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CKFP@TQFP48 [(SA248-B005)]
R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21236JFP@TQFP48 [(SA248-B005)]
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]
R5F21236KFP@TQFP48 [(SA248-B005)]
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]
R5F21237JFP@TQFP48 [(SA248-B005)]
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]
R5F21237KFP@TQFP48 [(SA248-B005)]
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]
R5F21238JFP@TQFP48 [(SA248-B005)]
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]
R5F21238KFP@TQFP48 [(SA248-B005)]
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AJFP@TQFP48 [(SA248-B005)]
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AKFP@TQFP48 [(SA248-B005)]
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CJFP@TQFP48 [(SA248-B005)]
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CKFP@TQFP48 [(SA248-B005)]
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]

R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(single ISPf© [ISP-HEADER01]
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]

R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]

R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20 [(SA026-B001)]
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212H1SNSP@TSSOP20 [(SA026-B001)]
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212H2SDSP@TSSOP20 [(SA725-B005)]
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212H2SNSP@TSSOP20 [(SA725-B005)]
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212J0SDSP@TSSOP20 [(SA026-B001)]
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212J0SNSP@TSSOP20 [(SA026-B001)]
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212J1SDSP@TSSOP20 [(SA026-B001)]
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212J1SNSP@TSSOP20 [(SA026-B001)]
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212K2SDFP@QFP32 [(SA663-B005)]
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SDFP@QFP32(single wire [(SA663-B005)])
R5F212K2SNFP@QFP32 [(SA663-B005)]
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SNFP@QFP32(single wire [(SA663-B005)])
R5F212K4SDFP@QFP32 [(SA663-B005)]

```
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SDFP@QFP32(single wire) [(SA663-B005)]
R5F212K4SNFP@QFP32 [(SA663-B005)]
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SNFP@QFP32(single wire) [(SA663-B005)]
R5F212L2SDFP@QFP32 [(SA663-B005)]
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]
R5F212L2SNFP@QFP32 [(SA663-B005)]
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]
R5F212L4SDFP@QFP32 [(SA663-B005)]
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]
R5F212L4SNFP@QFP32 [(SA663-B005)]
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]
```

MOSEL-VITELIC

E(E) PROM/FRAM/NVRAM

```
V29C31004B V29C31004B@PLCC32 [(SA015A1T)]
V29C31004B@TSOP32 [(SA410T)] V29C31004T
V29C31004T@PLCC32 [(SA015A1T)] V29C31004T@TSOP32 [(SA410T)]
V29C51000B V29C51000B@PLCC32 [(SA015A1T)]
V29C51000T V29C51000T@PLCC32 [(SA015A1T)]
V29C51001B V29C51001B@PLCC32 [(SA015A1T)]
V29C51001B@TSOP32 [(SA410T)] V29C51001T
V29C51001T@PLCC32 [(SA015A1T)] V29C51001T@TSOP32 [(SA410T)]
V29C51002B V29C51002B@PLCC32 [(SA015A1T)]
V29C51002B@TSOP32 [(SA410T)] V29C51002T
V29C51002T@PLCC32 [(SA015A1T)] V29C51002T@TSOP32 [(SA410T)]
V29C51004B V29C51004B@PLCC32 [(SA015A1T)]
V29C51004B@TSOP32 [(SA410T)] V29C51004T
V29C51004T@PLCC32 [(SA015A1T)] V29C51004T@TSOP32 [(SA410T)]
V29LC51000 V29LC51000@PLCC32 [(SA015A1T)]
V29LC51001 V29LC51001@PLCC32 [(SA015A1T)]
V29LC51002 V29LC51002@PLCC32 [(SA015A1T)]
```

MICROCONTROLLER

```
MSU1958 MSU1958@PLCC44 [(SA244)]
MSU1958@TQFP44 [(SA245A)] MSU2952
MSU2952@PLCC44 [(SA244)] MSU2952@TQFP44 [(SA245A)]
MSU2958 MSU2958@PLCC44 [(SA244)]
MSU2958@TQFP44 [(SA245A)] MSU2964
MSU2964@PLCC44 [(SA244)] MSU2964@TQFP44 [(SA245A)]
```

MOSTEK

E(E) PROM/FRAM/NVRAM

```
ET2716 ETC2716
ETC2732 MK2716
MK2764 MK48C02
MK48C12 MK48T02
MK48T08 MK48T12
MK48T12B MK48T18
MK48Z02 MK48Z08
MK48Z12 MK48Z12B
MK48Z18
```

MOTOROLA

E(E) PROM/FRAM/NVRAM

```
MC68764 MC68766
MCM2716
```


DRAM & SRAM

MCM2018A	MCM2018A@PLCC32 [(SA015A1T)]
MCM60256A	MCM60256A@SOIC28 [(SA630)]
MCM60256AC	MCM60256AC@SOIC28 [(SA630)]
MCM60256AV	MCM60256AV@SOIC28 [(SA630)]
MCM60L256A	MCM60L256A@SOIC28 [(SA630)]
MCM60L256AC	MCM60L256AC@SOIC28 [(SA630)]
MCM60L256AV	MCM60L256AV@SOIC28 [(SA630)]
MCM6206	MCM6206@SOIC28 [(SA630)]
MCM6206C	MCM6206C@SOIC28 [(SA630)]
MCM6207	MCM6207@SOJ24 [(SA646)]
MCM6207C	MCM6207C@SOJ24 [(SA646)]
MCM6208	MCM6208@SOJ24 [(SA646)]
MCM6208C	MCM6208C@SOJ24 [(SA646)]
MCM6209	MCM6209@SOJ28 [(SA646)]
MCM6209C	MCM6209C@SOJ28 [(SA646)]
MCM6229	MCM6229(300m)@SOJ28 [(SA646)]
MCM6229(400m)@SOJ28 [(SA661)]	MCM6229A
MCM6229A(300m)@SOJ28 [(SA646)]	MCM6229A(400m)@SOJ28 [(SA661)]
MCM6264	MCM6264@SOIC28 [(SA630)]
MCM6264C	MCM6264C@SOIC28 [(SA630)]
MCM6268	MCM6269
MCM6287	MCM6287@SOJ24 [(SA646)]
MCM6288	MCM6288@SOJ22 [(SA646)]
MCM6288B	MCM6288B@SOJ22 [(SA646)]
MCM6288C	MCM6288C@SOJ22 [(SA646)]
MCM6290	MCM6290@SOJ24 [(SA646)]
MCM6290B	MCM6290B@SOJ24 [(SA646)]
MCM6290C	MCM6290C@SOJ24 [(SA646)]
MCM62L07	MCM62L07@SOJ24 [(SA646)]
MCM62L08	MCM62L08@SOJ24 [(SA646)]
MCM62L09	MCM62L09@SOJ28 [(SA646)]
MCM6706	MCM6706@SOIC28 [(SA630)]
MCM6706A	MCM6706A@SOJ28 [(SA646)]
MCM6708A	MCM6708A@SOJ24 [(SA646)]
MCM6709A	MCM6709A@SOJ28 [(SA646)]

NANTRONICS**E(E) PROM/FRAM/NVRAM**

NS29LV032FB@FBGA48 [(SA642G-B026A-T048F001Y)]
NS29LV032FB@TSOP48 [(SA247-B005)]
NS29LV032FT@FBGA48 [(SA642G-B026A-T048F001Y)]
NS29LV032FT@TSOP48 [(SA247-B005)]

NEC**E(E) PROM/FRAM/NVRAM**

D2716D	uPD271000
uPD271000@PLCC32 [(SA015A1T)]	uPD271000@TSOP32 [(SA410T)]
uPD27128	uPD27128(C)
uPD27128(D)	uPD2716
uPD27256	uPD27256(C)
uPD27256(D)	uPD27256A
uPD27256A(C)	uPD27256A(D)
uPD2732	uPD2732A
uPD27512	uPD27512ACT
uPD27512AD	uPD2764
uPD2764C	uPD2764D
uPD27C1000	uPD27C1000@PLCC32 [(SA015A1T)]
uPD27C1000@TSOP32 [(SA410T)]	uPD27C1000A
uPD27C1000A@PLCC32 [(SA015A1T)]	uPD27C1000A@TSOP32 [(SA410T)]
uPD27C1000AD	uPD27C1000AD@PLCC32 [(SA015A1T)]
uPD27C1000AD@TSOP32 [(SA410T)]	uPD27C1001
uPD27C1001@PLCC32 [(SA015A1T)]	uPD27C1001@TSOP32 [(SA410T)]
uPD27C1001A	uPD27C1001A@PLCC32 [(SA015A1T)]
uPD27C1001A@TSOP32 [(SA410T)]	uPD27C1001D
uPD27C1001D@PLCC32 [(SA015A1T)]	uPD27C1001D@TSOP32 [(SA410T)]
uPD27C1024	uPD27C1024A
uPD27C2001	uPD27C2001@PLCC32 [(SA015A1T)]
uPD27C2001@TSOP32 [(SA410T)]	uPD27C2001D

uPD27C2001D@PLCC32 [(SA015A1T)]	uPD27C2001D@TSOP32 [(SA410T)]
uPD27C210	uPD27C256
uPD27C256A	uPD27C400
uPD27C4001	uPD27C4001@PLCC32 [(SA015A1T)]
uPD27C4001@TSOP32 [(SA410T)]	uPD27C4096
uPD27C512	uPD27C64(C)
uPD27C64(D)	uPD27C8000
uPD27C8001	uPD27C8001@PLCC32 [(SA015A1T)]
uPD27C8001@TSOP32 [(SA410T)]	uPD28C04
uPD28C04@SOIC24 [(SA404)]	uPD28C05
uPD28C05@SOIC24 [(SA404)]	uPD28C256
uPD28C64	uPD28C64@SOIC28 [(SA404)]
uPD29F008CB@TSOP40 [(SA409T)]	uPD29F008CT@TSOP40 [(SA409T)]

DRAM & SRAM

PD4361B	PD4361B@SOJ24 [(SA646)]
---------	-------------------------

NEXFLASH**E(E) PROM/FRAM/NVRAM**

NX25B40(Bottom Boot)@MLP8 [(SA683)]	
NX25B40(Bottom Boot)@SOIC8 [(SA602A)]	
NX25B40(Top Boot)@MLP8 [(SA683)]	
NX25B40(Top Boot)@SOIC8 [(SA602A)]	
NX25P10@MLP8 [(SA683)]	NX25P10@SOIC8 [(SA602A)]
NX25P16@MLP8 [(SA683)]	NX25P16@MLP8(ISP) [ISP-HEADER01]
NX25P16@SOIC16 [(SA404)]	
NX25P16@SOIC16(ISP) [ISP-HEADER01]	
NX25P16@SOIC8 [(SA023A)]	
NX25P16@SOIC8(ISP) [ISP-HEADER01]	
NX25P20@MLP8 [(SA683)]	NX25P20@SOIC8 [(SA602A)]
NX25P32@MLP8 [(SA683)]	NX25P32@MLP8(ISP) [ISP-HEADER01]
NX25P32@SOIC16 [(SA404)]	
NX25P32@SOIC16(ISP) [ISP-HEADER01]	
NX25P40@MLP8 [(SA683)]	NX25P40@SOIC8 [(SA602A)]
NX25P64@MLP8 [(SA683)]	NX25P64@MLP8(ISP) [ISP-HEADER01]
NX25P64@SOIC16 [(SA404)]	
NX25P64@SOIC16(ISP) [ISP-HEADER01]	
NX25P80@MLP8 [(SA683)]	NX25P80@SOIC8 [(SA602A)]
NX29F010	NX29F010@PLCC32 [(SA015A1T)]
NX29F010@TSOP32 [(SA410T)]	

NJRC**E(E) PROM/FRAM/NVRAM**

NJU26040V	NJU26040V@SSOP32 [(SA626A)]
-----------	-----------------------------

NSC**E(E) PROM/FRAM/NVRAM**

2864	MM2716
MM2716E	NM24C02
NM24C02@SOIC8 [(SA602A)]	NM24C02@TSOP8 [(SA026)]
NM24C02L	NM24C02L@SOIC8 [(SA602A)]
NM24C02L@TSOP8 [(SA026)]	NM24C03
NM24C03@SOIC8 [(SA602A)]	NM24C03@TSOP8 [(SA026)]
NM24C04	NM24C04@SOIC8 [(SA602A)]
NM24C04@TSOP8 [(SA026)]	NM24C05
NM24C05@SOIC8 [(SA602A)]	NM24C05@TSOP8 [(SA026)]
NM24C08	NM24C08@SOIC8 [(SA602A)]
NM24C09	NM24C09@SOIC8 [(SA602A)]
NM24C16	NM24C16@SOIC8 [(SA602A)]
NM24C17	NM24C17@SOIC8 [(SA602A)]
NM25C04	NM25C04@SOIC16 [(SA602)]
NM25C04@SOIC8 [(SA602A)]	NM25C04@TSSOP14 [(SA026)]
NM25C04@TSSOP8 [(SA026)]	NM27C010

NM27C010@PLCC32 [(SA015A1T)]	NM27C010@TSOP32 [(SA410T)]
NM27C010Q	NM27C010Q@PLCC32 [(SA015A1T)]
NM27C010Q@TSOP32 [(SA410T)]	NM27C020
NM27C020@PLCC32 [(SA015A1T)]	NM27C020@TSOP32 [(SA410T)]
NM27C020Q	NM27C020Q@PLCC32 [(SA015A1T)]
NM27C020Q@TSOP32 [(SA410T)]	NM27C040
NM27C040@PLCC32 [(SA015A1T)]	NM27C040@TSOP32 [(SA410T)]
NM27C1023	NM27C128
NM27C128@PLCC32 [(SA015A1T)]	NM27C210
NM27C210@PLCC44 [(SA244)]	NM27C210Q
NM27C210Q@PLCC44 [(SA244)]	NM27C240
NM27C240@PLCC44 [(SA244)]	NM27C256
NM27C256@PLCC32 [(SA015A1T)]	NM27C400
NM27C512	NM27C512@PLCC32 [(SA015A1T)]
NM27C512Q	NM27C512Q@PLCC32 [(SA015A1T)]
NM27C64Q	NM27C64Q@PLCC32 [(SA015A1T)]
NM27CP256	NM27CP256@PLCC32 [(SA015A1T)]
NM27LC010	NM27LC010@PLCC32 [(SA015A1T)]
NM27LC010@TSOP32 [(SA410T)]	NM27LC256
NM27LC256@PLCC32 [(SA015A1T)]	NM27LC512
NM27LC512@PLCC32 [(SA015A1T)]	NM27LC64
NM27LC64@PLCC32 [(SA015A1T)]	NM27LV010
NM27LV010@PLCC32 [(SA015A1T)]	NM27LV010@TSOP32 [(SA410T)]
NM27LV210	NM27LV210@PLCC44 [(SA244)]
NM27LV512	NM27LV512@PLCC32 [(SA015A1T)]
NM27LV512@TSOP32 [(SA410T)]	NM27P040
NM27P040@PLCC32 [(SA015A1T)]	NM27P040@TSOP32 [(SA410T)]
NM27P210	NM27P210@PLCC44 [(SA244)]
NM27P512	NM27P512@PLCC32 [(SA015A1T)]
NM59C11	NM59C11@SOIC8 [(SA602A)]
NM93C06(08bit)	NM93C06(08bit)@SOIC8 [(SA602A)]
NM93C06(16bit)	NM93C06(16bit)@SOIC8 [(SA602A)]
NM93C46	NM93C46@SOIC8 [(SA602A)]
NM93C46A(08bit)	NM93C46A(08bit)@SOIC8 [(SA602A)]
NM93C46A(16bit)	NM93C46A(16bit)@SOIC8 [(SA602A)]
NM93C46AL(08bit)	
NM93C46AL(08bit)@SOIC8 [(SA602A)]	
NM93C46AL(16bit)	
NM93C46AL(16bit)@SOIC8 [(SA602A)]	
NM93C46ALZ(08bit)	
NM93C46ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C46ALZ(16bit)	
NM93C46ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C46L	NM93C46L@SOIC8 [(SA602A)]
NM93C46LZ	NM93C46LZ@SOIC8 [(SA602A)]
NM93C56	NM93C56@SOIC8 [(SA602A)]
NM93C56A(08bit)	NM93C56A(08bit)@SOIC8 [(SA602A)]
NM93C56A(16bit)	NM93C56A(16bit)@SOIC8 [(SA602A)]
NM93C56AL(08bit)	
NM93C56AL(08bit)@SOIC8 [(SA602A)]	
NM93C56AL(16bit)	
NM93C56AL(16bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(08bit)	
NM93C56ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(16bit)	
NM93C56ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C56L	NM93C56L@SOIC8 [(SA602A)]
NM93C56LZ	NM93C56LZ@SOIC8 [(SA602A)]
NM93C66	NM93C66@SOIC8 [(SA602A)]
NM93C66A	NM93C66A(08bit)
NM93C66A(08bit)@SOIC8 [(SA602A)]	NM93C66A@SOIC8 [(SA602A)]
NM93C66AL(08bit)	
NM93C66AL(08bit)@SOIC8 [(SA602A)]	
NM93C66AL(16bit)	
NM93C66AL(16bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(08bit)	
NM93C66ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(16bit)	
NM93C66ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C66L	NM93C66L@SOIC8 [(SA602A)]
NM93C66LZ	NM93C66LZ@SOIC8 [(SA602A)]
NM93C86(16bit)	NM93C86(16bit)@SOIC8 [(SA602A)]
NM93C86A	NM93C86A(08bit)
NM93C86A(08bit)@SOIC8 [(SA602A)]	NM93C86A@SOIC8 [(SA602A)]
NM93C86AL(08bit)	
NM93C86AL(08bit)@SOIC8 [(SA602A)]	
NM93C86AL(16bit)	
NM93C86AL(16bit)@SOIC8 [(SA602A)]	
NM93C86ALZ(08bit)	
NM93C86ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C86ALZ(16bit)	

NM93C86ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C86L	NM93C86L@SOIC8 [(SA602A)]
NM93C86LZ	NM93C86LZ@SOIC8 [(SA602A)]
NM93CS06(M8)@SOIC8 [(SA602A)]	NM93CS06(MT8)@TSSOP8 [(SA026)]
NM93CS06(N)	NM93CS46(M8)@SOIC8 [(SA602A)]
NM93CS46(MT8)@TSSOP8 [(SA026)]	NM93CS46(N)
NM93CS56(M8)@SOIC8 [(SA602A)]	NM93CS56(MT8)@TSSOP8 [(SA026)]
NM93CS56(N)	NM93CS66(M8)@SOIC8 [(SA602A)]
NM93CS66(MT8)@TSSOP8 [(SA026)]	NM93CS66(N)
NMC2732	NMC2732B
NMC2732H	NMC27C010
NMC27C010@PLCC32 [(SA015A1T)]	NMC27C010@TSOP32 [(SA410T)]
NMC27C1024	NMC27C1024@PLCC44 [(SA244)]
NMC27C128B	NMC27C128B@PLCC32 [(SA015A1T)]
NMC27C128BN	NMC27C128BN@PLCC32 [(SA015A1T)]
NMC27C128BQ	NMC27C128BQ@PLCC32 [(SA015A1T)]
NMC27C128CQ	NMC27C128Q
NMC27C16	NMC27C16BQ
NMC27C16BQE	NMC27C16H
NMC27C16HQ	NMC27C16Q
NMC27C210	NMC27C210@PLCC44 [(SA244)]
NMC27C210Q	NMC27C210Q@PLCC44 [(SA244)]
NMC27C256B	NMC27C256B@PLCC32 [(SA015A1T)]
NMC27C256BN	NMC27C256BQE
NMC27C256BQM	NMC27C256Q
NMC27C256Q@PLCC32 [(SA015A1T)]	NMC27C32
NMC27C32B	NMC27C32BQ
NMC27C32E	NMC27C32EH
NMC27C32H	NMC27C512
NMC27C512@PLCC32 [(SA015A1T)]	NMC27C512A
NMC27C512A@PLCC32 [(SA015A1T)]	NMC27C512AN
NMC27C512AN@PLCC32 [(SA015A1T)]	NMC27C64
NMC27C64@PLCC32 [(SA015A1T)]	NMC27C64BN
NMC27C64N	NMC27CP128
NMC27CP256	NMC27CP64
NMC59C11	NMC59C11@SOIC8 [(SA602A)]
NMC87C257Q	NMC87C257Q@PLCC32
NMC87C257V	NMC87C257V@PLCC32
NMC9306	NMC9306@SOIC8 [(SA602A)]
NMC9307	NMC9307@SOIC8 [(SA602A)]
NMC9346	NMC9346@SOIC8 [(SA602A)]
NMC93C56	NMC93C56@SOIC14 [(SA602)]
NMC93C56@SOIC8 [(SA602A)]	NMC93C66
NMC93C66@SOIC14 [(SA602)]	NMC93C86A
NMC93C86A@SOIC14 [(SA602)]	NMC93C86A@SOIC8 [(SA602A)]
NMC93CS06(M14)@SOIC14 [(SA602)]	NMC93CS06(N)
NMC93CS46(M14)@SOIC14 [(SA602)]	NMC93CS46(N)
NMC93CS56(M14)@SOIC14 [(SA602)]	NMC93CS56(N)
NMC93CS66(M14)@SOIC14 [(SA602)]	NMC93CS66(N)
NMC93S06(M14)@SOIC14 [(SA602)]	NMC93S06(N)
NMC9817	NMC9817A
NS2816A	NS9816A

PLD

GAL16V8	GAL16V8@PLCC20 [(SA001A)]
GAL16V8A	GAL16V8A@PLCC20 [(SA001A)]
GAL20V8	GAL20V8@PLCC28 [(SA008A)]
GAL20V8A	GAL20V8A@PLCC28 [(SA008A)]
GAL20V8QS	GAL20V8QS@PLCC28 [(SA008A)]

NTE

E(E) PROM/FRAM/NVRAM

NTE2532	NTE2532A
NTE25L32	

NUMONYX

E(E) PROM/FRAM/NVRAM

M25PX32@SOIC16 [(SA404)]	M25PX32@SOIC8 [(SA023A)]
--------------------------	--------------------------

M25PX32@VFQFPN8 [(SA683)]
 M25PX64@TBGA24 [(SA778)]

M25PX64@SOIC16 [(SA404)]
 M25PX64@VDFPN8 [(SA684)]

NUVOTON

MICROCONTROLLER

N79E342AKG
 N79E342RAKG
 N79E352AEG
 N79E352ALG@TQFP48 [(SA248)]
 N79E8213AKG
 N79E8213RAKG
 W78E051C
 W78E051C@TQFP44 [(SA245A)]
 W78E051DFG@TQFP44 [(SA245A)]
 W78E051DLG@TQFP48 [(SA248A-B005)]
 W78E051DPG@PLCC44 [(SA244)]
 W78E052C@PLCC44 [(SA244)]
 W78E052DDG
 W78E052DLG@TQFP48 [(SA248A-B005)]
 W78E052DPG@PLCC44 [(SA244)]
 W78E054C@PLCC44 [(SA244)]
 W78E054DDG
 W78E054DLG@TQFP48 [(SA248A-B005)]
 W78E054DPG@PLCC44 [(SA244)]
 W78E058DFG@TQFP44 [(SA245A)]
 W78E058DLG@TQFP48 [(SA248A-B005)]
 W78E058DPG@PLCC44 [(SA244)]
 W78E516DFG@TQFP44 [(SA245A)]
 W78E516DLG@TQFP48 [(SA248A-B005)]
 W78E516DPG@PLCC44 [(SA244)]
 W78E51C@PLCC44 [(SA244)]
 W78E52C
 W78E52C@TQFP44 [(SA245A)]
 W78E54C@PLCC44 [(SA244)]
 W78I051DDG
 W78I051DLG@TQFP48 [(SA248A-B005)]
 W78I051DPG@PLCC44 [(SA244)]
 W78I052DFG@TQFP44 [(SA245A)]
 W78I052DLG@TQFP48 [(SA248A-B005)]
 W78I052DPG@PLCC44 [(SA244)]
 W78I054DFG@TQFP44 [(SA245A)]
 W78I054DLG@TQFP48 [(SA248A-B005)]
 W78I054DPG@PLCC44 [(SA244)]
 W78L051C@PLCC44 [(SA244)]
 W78L052C
 W78L052C@TQFP44 [(SA245A)]
 W78L054C@PLCC44 [(SA244)]
 W78LE51C
 W78LE51C@TQFP44 [(SA245A)]
 W78LE52C@PLCC44 [(SA244)]
 W78LE54C
 W78LE54C@TQFP44 [(SA245A)]

N79E342ASG@SOP16 [(SA404)]
 N79E342RASG@SOP16 [(SA404)]
 N79E352AFG@TQFP44 [(SA245)]
 N79E352APG@PLCC44 [(SA244)]
 N79E8213ASG@SOP20 [(SA404)]
 N79E8213RASG@SOP20 [(SA404)]
 W78E051C@PLCC44 [(SA244)]
 W78E051DDG

W78E052C
 W78E052C@TQFP44 [(SA245A)]
 W78E052DFG@TQFP44 [(SA245A)]

W78E054C
 W78E054C@TQFP44 [(SA245A)]
 W78E054DFG@TQFP44 [(SA245A)]

W78E058DDG

W78E516DDG

W78E51C
 W78E51C@TQFP44 [(SA245A)]
 W78E52C@PLCC44 [(SA244)]
 W78E54C
 W78E54C@TQFP44 [(SA245A)]
 W78I051DFG@TQFP44 [(SA245A)]

W78I052DDG

W78I054DDG

W78L051C
 W78L051C@TQFP44 [(SA245A)]
 W78L052C@PLCC44 [(SA244)]
 W78L054C
 W78L054C@TQFP44 [(SA245A)]
 W78LE51C@PLCC44 [(SA244)]
 W78LE52C
 W78LE52C@TQFP44 [(SA245A)]
 W78LE54C@PLCC44 [(SA244)]

NXP

MICROCONTROLLER

P83C660X2@PLCC44 [(SA244)]
 P83C661X2@PLCC44 [(SA244)]
 P87C51
 P87C51@TQFP44 [(SA245A)]
 P87C51FA@PLCC44 [(SA244)]
 P87C51FB
 P87C51FB@TQFP44 [(SA245A)]
 P87C51FC@PLCC44 [(SA244)]
 P87C51MA2@PLCC44 [(SA244)]
 P87C51MC2@PLCC44 [(SA244)]
 P87C51RA+@PLCC44 [(SA244)]
 P87C51RA2
 P87C51RA2@TQFP44 [(SA245A)]
 P87C51RB+@PLCC44 [(SA244)]
 P87C51RB2

P83C660X2@TQFP44 [(SA245A)]
 P83C661X2@TQFP44 [(SA245A)]
 P87C51@PLCC44 [(SA244)]
 P87C51FA
 P87C51FA@TQFP44 [(SA245A)]
 P87C51FB@PLCC44 [(SA244)]
 P87C51FC
 P87C51FC@TQFP44 [(SA245A)]
 P87C51MB2@PLCC44 [(SA244)]
 P87C51RA+
 P87C51RA+@TQFP44 [(SA245A)]
 P87C51RA2@PLCC44 [(SA244)]
 P87C51RB+
 P87C51RB+@TQFP44 [(SA245A)]
 P87C51RB2@PLCC44 [(SA244)]

P87C51RB2@TQFP44 [(SA245A)]	P87C51RC+
P87C51RC+@PLCC44 [(SA244)]	P87C51RC+@TQFP44 [(SA245A)]
P87C51RC2	P87C51RC2@PLCC44 [(SA244)]
P87C51RC2@TQFP44 [(SA245A)]	P87C51RD+
P87C51RD+@PLCC44 [(SA244)]	P87C51RD+@TQFP44 [(SA245A)]
P87C51RD2	P87C51RD2@PLCC44 [(SA244)]
P87C51RD2@TQFP44 [(SA245A)]	P87C51SB
P87C51SB@PLCC44 [(SA244)]	P87C51SB@TQFP44 [(SA245A)]
P87C51SF	P87C51SF@PLCC44 [(SA244)]
P87C51SF@TQFP44 [(SA245A)]	P87C51UB
P87C51UB@PLCC44 [(SA244)]	P87C51UB@TQFP44 [(SA245A)]
P87C51UF	P87C51UF@PLCC44 [(SA244)]
P87C51UF@TQFP44 [(SA245A)]	P87C51X2
P87C51X2@PLCC44 [(SA244)]	P87C51X2@TQFP44 [(SA245A)]
P87C52	P87C52@PLCC44 [(SA244)]
P87C52@TQFP44 [(SA245A)]	P87C524
P87C524@PLCC44 [(SA244)]	P87C524@TQFP44 [(SA245A)]
P87C528	P87C528@PLCC44 [(SA244)]
P87C528@TQFP44 [(SA245A)]	P87C52SB
P87C52SB@PLCC44 [(SA244)]	P87C52SB@TQFP44 [(SA245A)]
P87C52SF	P87C52SF@PLCC44 [(SA244)]
P87C52SF@TQFP44 [(SA675)]	P87C52UB
P87C52UB@PLCC44 [(SA244)]	P87C52UB@TQFP44 [(SA245A)]
P87C52UF	P87C52UF@PLCC44 [(SA244)]
P87C52UF@TQFP44 [(SA245A)]	P87C52X2
P87C52X2@PLCC44 [(SA244)]	P87C52X2@TQFP44 [(SA245A)]
P87C54	P87C54@PLCC44 [(SA244)]
P87C54@TQFP44 [(SA245A)]	P87C54SB
P87C54SB@PLCC44 [(SA244)]	P87C54SB@TQFP44 [(SA245A)]
P87C54SF	P87C54SF@PLCC44 [(SA244)]
P87C54SF@TQFP44 [(SA245A)]	P87C54UB
P87C54UB@PLCC44 [(SA244)]	P87C54UB@TQFP44 [(SA245A)]
P87C54UF	P87C54UF@PLCC44 [(SA244)]
P87C54UF@TQFP44 [(SA245A)]	P87C54X2
P87C54X2@PLCC44 [(SA244)]	P87C54X2@TQFP44 [(SA245A)]
P87C550	P87C550@PLCC44 [(SA244)]
P87C552@PLCC68 (*) [(SA648-B6806)]	
P87C554@PLCC68 (*) [(SA648-B6806)]	
P87C575	P87C575@PLCC44 [(SA244)]
P87C575@TQFP44 [(SA245A)]	P87C576
P87C576@PLCC44 [(SA244)]	P87C576@TQFP44 [(SA245A)]
P87C58	P87C58@PLCC44 [(SA244)]
P87C58@TQFP44 [(SA245A)]	P87C58SB
P87C58SB@PLCC44 [(SA244)]	P87C58SB@TQFP44 [(SA245A)]
P87C58UB	P87C58UB@PLCC44 [(SA244)]
P87C58UB@TQFP44 [(SA245A)]	P87C58X2
P87C58X2@PLCC44 [(SA244)]	P87C58X2@TQFP44 [(SA245A)]
P87C591@PLCC44 [(SA244)]	P87C591@TQFP44 [(SA245A)]
P87C652	P87C652@PLCC44 [(SA244)]
P87C652@TQFP44 [(SA245A)]	P87C654
P87C654@PLCC44 [(SA244)]	P87C654@TQFP44 [(SA245A)]
P87C660X2@PLCC44 [(SA244)]	P87C660X2@TQFP44 [(SA245A)]
P87C661X2@PLCC44 [(SA244)]	P87C661X2@TQFP44 [(SA245A)]
P87C748	P87C748@PLCC28 [(SA008A)]
P87C749	P87C749@PLCC28 [(SA008A)]
P87C750	P87C750@PLCC28 [(SA008A)]
P87C750@SSOP24 [(SA626A)]	P87C751
P87C751@PLCC28 [(SA008A)]	P87C751@SSOP24 [(SA626A)]
P87C752	P87C752@PLCC28 [(SA008A)]
P87C752@SSOP28 [(SA626A)]	P87C754
P87C754@PLCC28 [(SA008A)]	P87C754@SSOP28 [(SA626A)]
P87CL52X2	P87CL52X2@PLCC44 [(SA244)]
P87CL52X2@TQFP44 [(SA245A)]	P87CL54X2
P87CL54X2@PLCC44 [(SA244)]	P87CL54X2@TQFP44 [(SA245A)]
P87L51FA	P87L51FA@PLCC44 [(SA244)]
P87L51FA@TQFP44 [(SA245A)]	P87L51FB
P87L51FB@PLCC44 [(SA244)]	P87L51FB@TQFP44 [(SA245A)]
P87LPC759	P87LPC759 (ISP) [ISP-HEADER01]
P87LPC760	P87LPC760 (ISP) [ISP-HEADER01]
P87LPC760@TSSOP14 [(SA026)]	
P87LPC760@TSSOP14 (ISP) [ISP-HEADER01]	
P87LPC761	P87LPC761 (ISP) [ISP-HEADER01]
P87LPC762	P87LPC762 (ISP) [ISP-HEADER01]
P87LPC762@PLCC44 [(SA244)]	
P87LPC762@PLCC44 (ISP) [ISP-HEADER01]	
P87LPC762@SOIC20 [(SA404)]	
P87LPC762@SOIC20 (ISP) [ISP-HEADER01]	
P87LPC764	P87LPC764 (ISP) [ISP-HEADER01]
P87LPC764@PLCC44 [(SA244)]	
P87LPC764@PLCC44 (ISP) [ISP-HEADER01]	
P87LPC764@SOIC20 [(SA404)]	

```

P87LPC764@SOIC20 (ISP) [ISP-HEADER01]
P87LPC764@TSSOP20 [(SA643)]
P87LPC764@TSSOP20 (ISP) [ISP-HEADER01]
P87LPC767
P87LPC767@PLCC44 [(SA244)]
P87LPC767@PLCC44 (ISP) [ISP-HEADER01]
P87LPC767@SOIC20 [(SA404)]
P87LPC767@SOIC20 (ISP) [ISP-HEADER01]
P87LPC768
P87LPC768@SOIC20 [(SA404)]
P87LPC768@SOIC20 (ISP) [ISP-HEADER01]
P87LPC769
P87LPC769@PLCC44 [(SA244)]
P87LPC769@PLCC44 (ISP) [ISP-HEADER01]
P87LPC769@SOIC20 [(SA404)]
P87LPC769@SOIC20 (ISP) [ISP-HEADER01]
P87LPC778
P87LPC778@TSSOP20 [(SA026)]
P87LPC778@TSSOP20 (ISP) [ISP-HEADER01]
P87LPC779
P87LPC779@TSSOP20 [(SA643)]
P87LPC779@TSSOP20 (ISP) [ISP-HEADER01]
P89C138
P89C138@TQFP44 [(SA245A)]
P89C238@PLCC44 [(SA244)]
P89C51B
P89C51B@TQFP44 [(SA245A)]
P89C51RA+@PLCC44 [(SA244)]
P89C51RA2B
P89C51RA2B@TQFP44 [(SA245A)]
P89C51RB+@PLCC44 [(SA244)]
P89C51RB2B
P89C51RB2B@TQFP44 [(SA245A)]
P89C51RB2H@PLCC44 [(SA244)]
P89C51RC+
P89C51RC+@TQFP44 [(SA245A)]
P89C51RC2B@PLCC44 [(SA244)]
P89C51RC2H
P89C51RC2H@TQFP44 [(SA245A)]
P89C51RD+@PLCC44 [(SA244)]
P89C51RD2B
P89C51RD2B@TQFP44 [(SA245A)]
P89C51RD2H@PLCC44 [(SA244)]
P89C51UB
P89C51UB@TQFP44 [(SA245A)]
P89C51UF@PLCC44 [(SA244)]
P89C51X2
P89C51X2@TQFP44 [(SA245A)]
P89C51X2B@PLCC44 [(SA244)]
P89C51X2F
P89C51X2F@TQFP44 [(SA245A)]
P89C52@PLCC44 [(SA244)]
P89C52B
P89C52B@TQFP44 [(SA245A)]
P89C52UB@PLCC44 [(SA244)]
P89C52UF
P89C52UF@TQFP44 [(SA245A)]
P89C52X2@PLCC44 [(SA244)]
P89C52X2B
P89C52X2B@TQFP44 [(SA245A)]
P89C52X2F@PLCC44 [(SA244)]
P89C52X2F
P89C52X2F@TQFP44 [(SA245A)]
P89C538@PLCC44 [(SA244)]
P89C54
P89C54@TQFP44 [(SA245A)]
P89C54B@PLCC44 [(SA244)]
P89C54UB
P89C54UB@TQFP44 [(SA245A)]
P89C54UF@PLCC44 [(SA244)]
P89C54X2
P89C54X2@TQFP44 [(SA245A)]
P89C54X2B@PLCC44 [(SA244)]
P89C54X2F
P89C54X2F@TQFP44 [(SA245A)]
P89C58@PLCC44 [(SA244)]
P89C58B
P89C58B@TQFP44 [(SA245A)]
P89C58UB@PLCC44 [(SA244)]
P89C58UF
P89C58UF@TQFP44 [(SA245A)]
P89C58X2@PLCC44 [(SA244)]
P89C58X2B
P87LPC767 (ISP) [ISP-HEADER01]
P87LPC768 (ISP) [ISP-HEADER01]
P87LPC769 (ISP) [ISP-HEADER01]
P87LPC778 (ISP) [ISP-HEADER01]
P87LPC779 (ISP) [ISP-HEADER01]
P89C138@PLCC44 [(SA244)]
P89C238
P89C238@TQFP44 [(SA245A)]
P89C51B@PLCC44 [(SA244)]
P89C51RA+
P89C51RA+@TQFP44 [(SA245A)]
P89C51RA2B@PLCC44 [(SA244)]
P89C51RB+
P89C51RB+@TQFP44 [(SA245A)]
P89C51RB2B@PLCC44 [(SA244)]
P89C51RB2H
P89C51RB2H@TQFP44 [(SA245A)]
P89C51RC+@PLCC44 [(SA244)]
P89C51RC2B
P89C51RC2B@TQFP44 [(SA245A)]
P89C51RC2H@PLCC44 [(SA244)]
P89C51RD+
P89C51RD+@TQFP44 [(SA245A)]
P89C51RD2B@PLCC44 [(SA244)]
P89C51RD2H
P89C51RD2H@TQFP44 [(SA245A)]
P89C51UB@PLCC44 [(SA244)]
P89C51UF
P89C51UF@TQFP44 [(SA245A)]
P89C51X2@PLCC44 [(SA244)]
P89C51X2B
P89C51X2B@TQFP44 [(SA245A)]
P89C51X2F@PLCC44 [(SA244)]
P89C52
P89C52@TQFP44 [(SA245A)]
P89C52B@PLCC44 [(SA244)]
P89C52UB
P89C52UB@TQFP44 [(SA245A)]
P89C52UF@PLCC44 [(SA244)]
P89C52X2
P89C52X2@TQFP44 [(SA245A)]
P89C52X2B@PLCC44 [(SA244)]
P89C52X2F
P89C52X2F@TQFP44 [(SA245A)]
P89C538@PLCC44 [(SA244)]
P89C54@PLCC44 [(SA244)]
P89C54B
P89C54B@TQFP44 [(SA245A)]
P89C54UB@PLCC44 [(SA244)]
P89C54UF
P89C54UF@TQFP44 [(SA245A)]
P89C54X2@PLCC44 [(SA244)]
P89C54X2B
P89C54X2B@TQFP44 [(SA245A)]
P89C54X2F@PLCC44 [(SA244)]
P89C58
P89C58@TQFP44 [(SA245A)]
P89C58B@PLCC44 [(SA244)]
P89C58UB
P89C58UB@TQFP44 [(SA245A)]
P89C58UF@PLCC44 [(SA244)]
P89C58X2
P89C58X2@TQFP44 [(SA245A)]
P89C58X2B@PLCC44 [(SA244)]

```

```

P89C58X2B@TQFP44 [(SA245A)]      P89C58X2F
P89C58X2F@PLCC44 [(SA244)]      P89C58X2F@TQFP44 [(SA245A)]
P89C60X2                          P89C60X2@PLCC44 [(SA244)]
P89C60X2@TQFP44 [(SA245A)]      P89C61X2
P89C61X2@PLCC44 [(SA244)]      P89C61X2@TQFP44 [(SA245A)]
P89C660                          P89C660@PLCC44 [(SA244)]
P89C660@TQFP44 [(SA245A)]      P89C662
P89C662@PLCC44 [(SA244)]      P89C662@TQFP44 [(SA245A)]
P89C664                          P89C664@PLCC44 [(SA244)]
P89C664@TQFP44 [(SA245A)]      P89C668
P89C668@PLCC44 [(SA244)]      P89C668@TQFP44 [(SA245A)]
P89C669                          P89C669@LQFP44 [(SA245A)]
P89C669@PLCC44 [(SA244)]      P89C738
P89C738@PLCC44 [(SA244)]      P89C738@TQFP44 [(SA245A)]
P89C838                          P89C838@PLCC44 [(SA244)]
P89C838@TQFP44 [(SA245A)]      P89CV51RB2@PLCC44 [(SA244)]
P89CV51RB2@TQFP44 [(SA245A)]    P89CV51RC2@PLCC44 [(SA244)]
P89CV51RC2@TQFP44 [(SA245A)]    P89CV51RD2@PLCC44 [(SA244)]
P89CV51RD2@TQFP44 [(SA245A)]    P89LPC901(FD) [(SA602A)]
P89LPC901(FD)(ISP) [ISP-HEADER01]
P89LPC901(FN)
P89LPC901(FN)(ISP) [ISP-HEADER01]
P89LPC902(FD) [(SA602A)]
P89LPC902(FD)(ISP) [ISP-HEADER01]
P89LPC902(FN)
P89LPC902(FN)(ISP) [ISP-HEADER01]
P89LPC903(FD) [(SA602A)]
P89LPC903(FD)(ISP) [ISP-HEADER01]
P89LPC904(FD) [(SA605A)]
P89LPC904(FD)(ISP) [ISP-HEADER01]
P89LPC904(FN)
P89LPC904(FN)(ISP) [ISP-HEADER01]
P89LPC906(FD) [(SA605A)]
P89LPC906(FD)(ISP) [ISP-HEADER01]
P89LPC907(FD) [(SA605A)]
P89LPC907(FD)(ISP) [ISP-HEADER01]
P89LPC908(FD) [(SA605A)]
P89LPC908(FD)(ISP) [ISP-HEADER01]
P89LPC9102(FTK)@HVSON10 [(SA695A)]
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9103(FTK)@HVSON10 [(SA695A)]
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9107(FDH)@TSSOP14 [(SA643)]
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC9107(FN)
P89LPC9107(FN)(ISP) [ISP-HEADER01]
P89LPC912(FDH)@TSSOP14 [(SA643)]
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC913(FDH)@TSSOP14 [(SA643)]
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC914(FDH)@TSSOP14 [(SA643)]
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC915(FDH)@TSSOP14 [(SA643)]
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC9151(FDH)@TSSOP14 [(SA643)]
P89LPC9151(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC916(FDH)@TSSOP16 [(SA643)]
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC9161(FDH)@TSSOP16 [(SA643)]
P89LPC9161(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC917(FDH)@TSSOP16 [(SA643)]
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC9171(FDH)@TSSOP16 [(SA643)]
P89LPC9171(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC920(FDH)@TSSOP20 [(SA643)]
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920(FN)
P89LPC920(FN)(ISP) [ISP-HEADER01]
P89LPC9201(FDH)@TSSOP20 [(SA643)]
P89LPC9201(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9201(FN)
P89LPC9201(FN)(ISP) [ISP-HEADER01]
P89LPC920A1(FDH)@TSSOP20 [(SA643)]
P89LPC920A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920A1(FN)
P89LPC920A1(FN)(ISP) [ISP-HEADER01]
P89LPC921(FDH)@TSSOP20 [(SA643)]
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921(FN)
P89LPC921(FN)(ISP) [ISP-HEADER01]
P89LPC9211(FDH)@TSSOP20 [(SA643)]

```


P89LPC9211(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9211(FN)
P89LPC9211(FN)(ISP) [ISP-HEADER01]
P89LPC921A1(FDH)@TSSOP20 [(SA643)]
P89LPC921A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921A1(FN)
P89LPC921A1(FN)(ISP) [ISP-HEADER01]
P89LPC922(FDH)@TSSOP20 [(SA643)]
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922(FN)
P89LPC922(FN)(ISP) [ISP-HEADER01]
P89LPC9221(FDH)@TSSOP20 [(SA643)]
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221(FN)
P89LPC9221(FN)(ISP) [ISP-HEADER01]
P89LPC9221A1(FDH)@TSSOP20 [(SA643)]
P89LPC9221A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221A1(FN)
P89LPC9221A1(FN)(ISP) [ISP-HEADER01]
P89LPC922A1(FDH)@TSSOP20 [(SA643)]
P89LPC922A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922A1(FN)
P89LPC922A1(FN)(ISP) [ISP-HEADER01]
P89LPC924(FDH)@TSSOP20 [(SA643)]
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC924(FN)
P89LPC924(FN)(ISP) [ISP-HEADER01]
P89LPC9241(FDH)@TSSOP20 [(SA643)]
P89LPC9241(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9241(FN)
P89LPC9241(FN)(ISP) [ISP-HEADER01]
P89LPC924A1(FDH)@TSSOP20 [(SA643)]
P89LPC924A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC924A1(FN)
P89LPC924A1(FN)(ISP) [ISP-HEADER01]
P89LPC925(FDH)@TSSOP20 [(SA643)]
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC925(FN)
P89LPC925(FN)(ISP) [ISP-HEADER01]
P89LPC9251(FDH)@TSSOP20 [(SA643)]
P89LPC9251(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9251(FN)
P89LPC9251(FN)(ISP) [ISP-HEADER01]
P89LPC925A1(FDH)@TSSOP20 [(SA643)]
P89LPC925A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC925A1(FN)
P89LPC925A1(FN)(ISP) [ISP-HEADER01]
P89LPC930(BA)@PLCC28 [(SA008A)]
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC930(BDH)@TSSOP28 [(SA643)]
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9301(BA)@PLCC28 [(SA008A)]
P89LPC9301(BDH)@TSSOP28 [(SA643)]
P89LPC931(BA)@PLCC28 [(SA008A)]
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC931(BDH)@TSSOP28 [(SA643)]
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9311(BA)@PLCC28 [(SA008A)]
P89LPC9311(BDH)@TSSOP28 [(SA643)]
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28 [(SA643)]
P89LPC93201(BA)@PLCC28 [(SA008A)]
P89LPC93201(BDH)@TSSOP28 [(SA643)]
P89LPC93201(FA)@PLCC28 [(SA008A)]
P89LPC93201(FDH)@TSSOP28 [(SA643)]
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9321(BA)@PLCC28 [(SA008A)]
P89LPC9321(BDH)@TSSOP28 [(SA643)]
P89LPC9321(FA)@PLCC28 [(SA008A)]
P89LPC9321(FDH)@TSSOP28 [(SA643)]
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(BA)@PLCC28 [(SA008A)]
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC932A1(BDH)@TSSOP28 [(SA643)]
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FDH)@TSSOP28 [(SA643)]
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC933(BDH)@TSSOP28 [(SA643)]
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(FDH)@TSSOP28 [(SA643)]

```

P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(HDH)@TSSOP28 [(SA643)]
P89LPC9331(BDH)@TSSOP28 [(SA643)]
P89LPC9331(FDH)@TSSOP28 [(SA643)]
P89LPC9331(HDH)@TSSOP28 [(SA643)]
P89LPC934(BDH)@TSSOP28 [(SA643)]
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC934(FDH)@TSSOP28 [(SA643)]
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC93401(FDH)@TSSOP28 [(SA643)]
P89LPC93401V
P89LPC9341(BDH)@TSSOP28 [(SA643)]
P89LPC9341(FDH)@TSSOP28 [(SA643)]
P89LPC9341V
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(BDH)@TSSOP28 [(SA643)]
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FA)@PLCC28 [(SA008A)]
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(FDH)@TSSOP28 [(SA643)]
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93501(BA)@PLCC28 [(SA008A)]
P89LPC93501(BDH)@TSSOP28 [(SA643)]
P89LPC93501(FA)@PLCC28 [(SA008A)]
P89LPC93501(FDH)@TSSOP28 [(SA643)]
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9351(BA)@PLCC28 [(SA008A)]
P89LPC9351(BDH)@TSSOP28 [(SA643)]
P89LPC9351(FA)@PLCC28 [(SA008A)]
P89LPC9351(FDH)@TSSOP28 [(SA643)]
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]
P89LPC936(FA)@PLCC28 [(SA008A)]
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC936(FDH)@TSSOP28 [(SA643)]
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9361(FA)@PLCC28 [(SA008A)]
P89LPC9361(FDH)@TSSOP28 [(SA643)]
P89LPC938(FA)@PLCC28 [(SA008A)]
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC938(FDH)@TSSOP28 [(SA643)]
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93801(BA)@PLCC28 [(SA008A)]
P89LPC93801(BDH)@TSSOP28 [(SA643)]
P89LPC93801(FA)@PLCC28 [(SA008A)]
P89LPC93801(FDH)@TSSOP28 [(SA643)]
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9381(BA)@PLCC28 [(SA008A)]
P89LPC9381(BDH)@TSSOP28 [(SA643)]
P89LPC9381(FA)@PLCC28 [(SA008A)]
P89LPC9381(FDH)@TSSOP28 [(SA643)]
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC9402(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC952@LQFP44 [(SA245A)]
P89LPC952@LQFP44(ISP) [ISP-HEADER01]
P89LPC952@LQFP48 [(SA248)]
P89LPC952@LQFP48(ISP) [ISP-HEADER01]
P89LPC952@PLCC44 [(SA244)]
P89LPC952@PLCC44(ISP) [ISP-HEADER01]
P89LPC954@LQFP44 [(SA245A)]
P89LPC954@LQFP44(ISP) [ISP-HEADER01]
P89LPC954@LQFP48 [(SA248)]
P89LPC954@LQFP48(ISP) [ISP-HEADER01]
P89LPC954@PLCC44 [(SA244)]
P89LPC954@PLCC44(ISP) [ISP-HEADER01]
P89LPC970FDH@SSOP20 [(SA643)]
P89LPC971FDH@SSOP20 [(SA643)]
P89LPC972FDH@SSOP20 [(SA643)]
P89LPC980FDH@SSOP28 [(SA643)]
P89LPC983FA@PLCC28 [(SA008A)]
P89LV51RB2
P89LV51RB2@TQFP44 [(SA245A)]
P89LV51RC2@PLCC44 [(SA244)]
P89LV51RD2
P89LV51RD2(new)@PLCC44 [(SA244)]
P89LV51RD2(new)@TQFP44 [(SA245A)]
P89LPC970FN
P89LPC971FN
P89LPC972FN
P89LPC982FDH@SSOP28 [(SA643)]
P89LPC984FA@PLCC28 [(SA008A)]
P89LV51RB2@PLCC44 [(SA244)]
P89LV51RC2
P89LV51RC2@TQFP44 [(SA245A)]
P89LV51RD2(new)

```

P89LV51RD2@PLCC44 [(SA244)]	P89LV51RD2@TQFP44 [(SA245A)]
P89LV51RD2BA(new)@PLCC44 [(SA244)]	
P89LV51RD2BA@PLCC44 [(SA244)]	
P89LV51RD2BBC(new)@TQFP44 [(SA245A)]	
P89LV51RD2BBC@TQFP44 [(SA245A)]	P89LV51RD2BN
P89LV51RD2BN(new)	
P89LV51RD2FA(new)@PLCC44 [(SA244)]	
P89LV51RD2FA@PLCC44 [(SA244)]	
P89LV51RD2FBC(new)@TQFP44 [(SA245A)]	
P89LV51RD2FBC@TQFP44 [(SA245A)]	P89LV51RD2FN
P89LV51RD2FN(new)	P89V51RB2
P89V51RB2@PLCC44 [(SA244)]	P89V51RB2@TQFP44 [(SA245A)]
P89V51RC2	P89V51RC2@PLCC44 [(SA244)]
P89V51RC2@TQFP44 [(SA245A)]	P89V51RD2
P89V51RD2(new)	P89V51RD2(new)@PLCC44 [(SA244)]
P89V51RD2(new)@TQFP44 [(SA245A)]	P89V51RD2@PLCC44 [(SA244)]
P89V51RD2@TQFP44 [(SA245A)]	
P89V51RD2BA(new)@PLCC44 [(SA244)]	
P89V51RD2BA@PLCC44 [(SA244)]	
P89V51RD2BBC(new)@TQFP44 [(SA245A)]	
P89V51RD2BBC@TQFP44 [(SA245A)]	P89V51RD2BN
P89V51RD2BN(new)	
P89V51RD2FA(new)@PLCC44 [(SA244)]	
P89V51RD2FA@PLCC44 [(SA244)]	
P89V51RD2FBC(new)@TQFP44 [(SA245A)]	
P89V51RD2FBC@TQFP44 [(SA245A)]	P89V51RD2FN
P89V51RD2FN(new)	P89V52X2
P89V52X2(ISP) [ISP-HEADER01]	P89V52X2@PLCC44 [(SA244)]
P89V52X2@PLCC44(ISP) [ISP-HEADER01]	
P89V52X2@TQFP44 [(SA245A)]	
P89V52X2@TQFP44(ISP) [ISP-HEADER01]	
P89V660@PLCC44 [(SA244)]	P89V660@TQFP44 [(SA245A)]
P89V662@PLCC44 [(SA244)]	P89V662@TQFP44 [(SA245A)]
P89V664@PLCC44 [(SA244)]	P89V664@TQFP44 [(SA245A)]
PXAC37@PLCC44 [(SA244)]	PXAC37@TQFP44 [(SA245A)]
PXAG17@PLCC44 [(SA244)]	PXAG17@TQFP44 [(SA245A)]
PXAG27@PLCC44 [(SA244)]	PXAG27@TQFP44 [(SA245A)]
PXAG37@PLCC44 [(SA244)]	PXAG37@TQFP44 [(SA245A)]
PXAG39@PLCC44 [(SA244)]	PXAG39@TQFP44 [(SA245A)]
PXAG49@PLCC44 [(SA244)]	PXAG49@TQFP44 [(SA245A)]

OKI

E(E) PROM/FRAM/NVRAM

MSM16812(08bit)	MSM16812(08bit)@SOIC8 [(SA602A)]
MSM271000	MSM271000@PLCC32 [(SA015A1T)]
MSM271000@TSOP32 [(SA410T)]	MSM27128
MSM27128A	MSM27128AS
MSM27128AZB-RS	MSM2716
MSM27256	MSM27256AS
MSM27256ZB-RS	MSM2732
MSM2732A	MSM27512
MSM27512AS	MSM27512ZB-RS
MSM2764	MSM2764A
MSM2764AS	MSM2764AZB-RS
MSM2764RS	MSM27C1024
MSM27C1024AS	MSM27C128
MSM27C128AZB-RS	MSM27C256
MSM27C256A	MSM27C256H
MSM27C256HZB	MSM27C256ZB
MSM27C64AS	MSM27C802CZ
MSM27C802CZ@PSOP44 [(SA638)]	MSM27C802CZ@TSOP44 [(SA645)]
MSM2816A(RS)	MSM28C16A

DRAM & SRAM

MSM51256	MSM51256@SOIC28 [(SA630)]
MSM51257AL	MSM51257AL@SOIC28 [(SA630)]
MSM51257ALL	MSM51257ALL@SOIC28 [(SA630)]
MSM5165AL	MSM5165AL@SOIC28 [(SA630)]
MSM5188	MSM5188@SOJ22 [(SA646)]

ON Semiconductor

E (E) PROM/FRAM/NVRAM

CAT1320	CAT1320@SOIC8 [(SA602A)]
CAT1320@TDFN8	CAT1320@TSSOP8 [(SA026)]
CAT1321	CAT1321@SOIC8 [(SA602A)]
CAT1321@TDFN8	CAT1321@TSSOP8 [(SA026)]
CAT14002@SOIC8 [(SA602A)]	CAT14004@SOIC8 [(SA602A)]
CAT14008@SOIC8 [(SA602A)]	CAT14016@SOIC8 [(SA602A)]
CAT15002@SOIC8 [(SA602A)]	CAT15004@SOIC8 [(SA602A)]
CAT15008@SOIC8 [(SA602A)]	CAT15016@SOIC8 [(SA602A)]
CAT1640	CAT1640@SOIC8 [(SA602A)]
CAT1640@TDFN8	CAT1640@TSSOP8 [(SA026)]
CAT1641	CAT1641@SOIC8 [(SA602A)]
CAT1641@TDFN8	CAT1641@TSSOP8 [(SA026)]

PFLASH(MSTAR)**E (E) PROM/FRAM/NVRAM**

PS25LV010A@SOIC8 [(SA602A)]	PS25LV010A@WSON8 [(SA683)]
PS25LV020@SOIC8 [(SA602A)]	PS25LV020@WSON8 [(SA683)]
PS25LV040@SOIC8 [(SA605A)]	PS25LV040@WSON8 [(SA683)]
PS25LV080@SOIC8 [(SA605A)]	PS25LV080@WSON8 [(SA683)]

PHILIPS**E (E) PROM/FRAM/NVRAM**

27C010	27C010@PLCC32 [(SA015A1T)]
27C010@TSOP32 [(SA410T)]	27C040
27C040@PLCC32 [(SA015A1T)]	27C040@TSOP32 [(SA410T)]
27C210	27C210@PLCC44 [(SA244)]
27C240	27C240@PLCC44 [(SA244)]
27C256	27C256@PLCC32 [(SA015A1T)]
27C32	27C512
27C512@PLCC32 [(SA015A1T)]	27C64
27C64@PLCC32 [(SA015A1T)]	27C64A
27C64A@PLCC32 [(SA015A1T)]	27C64AF
27C64AF@PLCC32 [(SA015A1T)]	27HC641
27HC641@PLCC28 [(SA008A)]	27PC32
PCA24S08@SOIC8 [(SA602A)]	PCA24S08@TSSOP8 [(SA026)]
PCA8574(P)	PCA8574(T)@SOIC16 [(SA404)]
PCA8574(TS)@SSOP20 [(SA026)]	PCA8574A(P)
PCA8574A(T)@SOIC16 [(SA404)]	PCA8574A(TS)@SSOP20 [(SA026)]
PCA8581	PCA8581@SOIC8 [(SA602A)]
PCA8581C	PCA8581C@SOIC8 [(SA602A)]
PCA8582A	PCA8582A@SOIC8 [(SA602A)]
PCA8582B	PCA8582B@SOIC8 [(SA602A)]
PCA8582C	PCA8582C@SOIC8 [(SA602A)]
PCA8582D	PCA8582D@SOIC8 [(SA602A)]
PCA8582E	PCA8582E@SOIC8 [(SA602A)]
PCA9500@HQVFN16	PCA9500@SOIC16 [(SA404)]
PCA9500@TSSOP16 [(SA026)]	PCA9501@HQVFN20
PCA9501@SOIC20 [(SA404)]	PCA9501@TSSOP20 [(SA026)]
PCA9561D@SOP20 [(SA404)]	PCA9561W@TSSOP20 [(SA026)]
PCD8581	PCD8581@SOIC8 [(SA602A)]
PCD8581C	PCD8581C@SOIC8 [(SA602A)]
PCD8582A	PCD8582A@SOIC8 [(SA602A)]
PCD8582B	PCD8582B@SOIC8 [(SA602A)]
PCD8582C	PCD8582C@SOIC8 [(SA602A)]
PCD8582D	PCD8582D@SOIC8 [(SA602A)]
PCD8582E	PCD8582E@SOIC8 [(SA602A)]
PCF85102C	PCF85102C@SOIC8 [(SA602A)]
PCF85103C	PCF85103C@SOIC8 [(SA602A)]
PCF85116	PCF85116@SOIC8 [(SA602A)]
PCF8581	PCF8581@SOIC8 [(SA602A)]
PCF8581C	PCF8581C@SOIC8 [(SA602A)]
PCF8582A	PCF8582A@SOIC8 [(SA602A)]
PCF8582B	PCF8582B@SOIC8 [(SA602A)]
PCF8582C	PCF8582C@SOIC8 [(SA602A)]
PCF8582D	PCF8582D@SOIC8 [(SA602A)]
PCF8582E	PCF8582E@SOIC8 [(SA602A)]
PCF8594	PCF8594@SOIC8 [(SA602A)]

PCF8594C	PCF8594C@SOIC8 [(SA602A)]
PCF8594D	PCF8594D@SOIC8 [(SA602A)]
PCF8594E	PCF8594E@SOIC8 [(SA602A)]
PCF8598	PCF8598@SOIC8 [(SA605A)]
PCF8598C	PCF8598C@SOIC8 [(SA605A)]
PCF8598D	PCF8598D@SOIC8 [(SA605A)]
PCF8598E	PCF8598E@SOIC8 [(SA605A)]

MICROCONTROLLER

P83C660X2@PLCC44 [(SA244)]	P83C660X2@TQFP44 [(SA245A)]
P83C661X2@PLCC44 [(SA244)]	P83C661X2@TQFP44 [(SA245A)]
P87C51	P87C51@PLCC44 [(SA244)]
P87C51@TQFP44 [(SA245A)]	P87C51FA
P87C51FA@PLCC44 [(SA244)]	P87C51FA@TQFP44 [(SA245A)]
P87C51FB	P87C51FB@PLCC44 [(SA244)]
P87C51FB@TQFP44 [(SA245A)]	P87C51FC
P87C51FC@PLCC44 [(SA244)]	P87C51FC@TQFP44 [(SA245A)]
P87C51MA2@PLCC44 [(SA244)]	P87C51MB2@PLCC44 [(SA244)]
P87C51MC2@PLCC44 [(SA244)]	P87C51RA+
P87C51RA+@PLCC44 [(SA244)]	P87C51RA+@TQFP44 [(SA245A)]
P87C51RA2	P87C51RA2@PLCC44 [(SA244)]
P87C51RA2@TQFP44 [(SA245A)]	P87C51RB+
P87C51RB+@PLCC44 [(SA244)]	P87C51RB+@TQFP44 [(SA245A)]
P87C51RB2	P87C51RB2@PLCC44 [(SA244)]
P87C51RB2@TQFP44 [(SA245A)]	P87C51RC+
P87C51RC+@PLCC44 [(SA244)]	P87C51RC+@TQFP44 [(SA245A)]
P87C51RC2	P87C51RC2@PLCC44 [(SA244)]
P87C51RC2@TQFP44 [(SA245A)]	P87C51RD+
P87C51RD+@PLCC44 [(SA244)]	P87C51RD+@TQFP44 [(SA245A)]
P87C51RD2	P87C51RD2@PLCC44 [(SA244)]
P87C51RD2@TQFP44 [(SA245A)]	P87C51SB
P87C51SB@PLCC44 [(SA244)]	P87C51SB@TQFP44 [(SA245A)]
P87C51SF	P87C51SF@PLCC44 [(SA244)]
P87C51SF@TQFP44 [(SA245A)]	P87C51UB
P87C51UB@PLCC44 [(SA244)]	P87C51UB@TQFP44 [(SA245A)]
P87C51UF	P87C51UF@PLCC44 [(SA244)]
P87C51UF@TQFP44 [(SA245A)]	P87C51X2
P87C51X2@PLCC44 [(SA244)]	P87C51X2@TQFP44 [(SA245A)]
P87C52	P87C52@PLCC44 [(SA244)]
P87C52@TQFP44 [(SA245A)]	P87C524
P87C524@PLCC44 [(SA244)]	P87C524@TQFP44 [(SA245A)]
P87C528	P87C528@PLCC44 [(SA244)]
P87C528@TQFP44 [(SA245A)]	P87C52SB
P87C52SB@PLCC44 [(SA244)]	P87C52SB@TQFP44 [(SA245A)]
P87C52SF	P87C52SF@PLCC44 [(SA244)]
P87C52SF@TQFP44 [(SA675)]	P87C52UB
P87C52UB@PLCC44 [(SA244)]	P87C52UB@TQFP44 [(SA245A)]
P87C52UF	P87C52UF@PLCC44 [(SA244)]
P87C52UF@TQFP44 [(SA245A)]	P87C52X2
P87C52X2@PLCC44 [(SA244)]	P87C52X2@TQFP44 [(SA245A)]
P87C54	P87C54@PLCC44 [(SA244)]
P87C54@TQFP44 [(SA245A)]	P87C54SB
P87C54SB@PLCC44 [(SA244)]	P87C54SB@TQFP44 [(SA245A)]
P87C54SF	P87C54SF@PLCC44 [(SA244)]
P87C54SF@TQFP44 [(SA245A)]	P87C54UB
P87C54UB@PLCC44 [(SA244)]	P87C54UB@TQFP44 [(SA245A)]
P87C54UF	P87C54UF@PLCC44 [(SA244)]
P87C54UF@TQFP44 [(SA245A)]	P87C54X2
P87C54X2@PLCC44 [(SA244)]	P87C54X2@TQFP44 [(SA245A)]
P87C550	P87C550@PLCC44 [(SA244)]
P87C552@PLCC68(*) [(SA648-B6806)]	
P87C554@PLCC68(*) [(SA648-B6806)]	
P87C575	P87C575@PLCC44 [(SA244)]
P87C575@TQFP44 [(SA245A)]	P87C576
P87C576@PLCC44 [(SA244)]	P87C576@TQFP44 [(SA245A)]
P87C58	P87C58@PLCC44 [(SA244)]
P87C58@TQFP44 [(SA245A)]	P87C58SB
P87C58SB@PLCC44 [(SA244)]	P87C58SB@TQFP44 [(SA245A)]
P87C58UB	P87C58UB@PLCC44 [(SA244)]
P87C58UB@TQFP44 [(SA245A)]	P87C58X2
P87C58X2@PLCC44 [(SA244)]	P87C58X2@TQFP44 [(SA245A)]
P87C591@PLCC44 [(SA244)]	P87C591@TQFP44 [(SA245A)]
P87C652	P87C652@PLCC44 [(SA244)]
P87C652@TQFP44 [(SA245A)]	P87C654
P87C654@PLCC44 [(SA244)]	P87C654@TQFP44 [(SA245A)]
P87C660X2@PLCC44 [(SA244)]	P87C660X2@TQFP44 [(SA245A)]
P87C661X2@PLCC44 [(SA244)]	P87C661X2@TQFP44 [(SA245A)]
P87C748	P87C748@PLCC28 [(SA008A)]

P87C749	P87C749@PLCC28 [(SA008A)]
P87C750	P87C750@PLCC28 [(SA008A)]
P87C750@SSOP24 [(SA626A)]	P87C751
P87C751@PLCC28 [(SA008A)]	P87C751@SSOP24 [(SA626A)]
P87C752	P87C752@PLCC28 [(SA008A)]
P87C752@SSOP28 [(SA626A)]	P87C754
P87C754@PLCC28 [(SA008A)]	P87C754@SSOP28 [(SA626A)]
P87CL52X2	P87CL52X2@PLCC44 [(SA244)]
P87CL52X2@TQFP44 [(SA245A)]	P87CL54X2
P87CL54X2@PLCC44 [(SA244)]	P87CL54X2@TQFP44 [(SA245A)]
P87L51FA	P87L51FA@PLCC44 [(SA244)]
P87L51FA@TQFP44 [(SA245A)]	P87L51FB
P87L51FB@PLCC44 [(SA244)]	P87L51FB@TQFP44 [(SA245A)]
P87LPC759	P87LPC759(ISP) [ISP-HEADER01]
P87LPC760	P87LPC760(ISP) [ISP-HEADER01]
P87LPC760@TSSOP14 [(SA026)]	
P87LPC760@TSSOP14(ISP) [ISP-HEADER01]	
P87LPC761	P87LPC761(ISP) [ISP-HEADER01]
P87LPC762	P87LPC762(ISP) [ISP-HEADER01]
P87LPC762@PLCC44 [(SA244)]	
P87LPC762@PLCC44(ISP) [ISP-HEADER01]	
P87LPC762@SOIC20 [(SA404)]	
P87LPC762@SOIC20(ISP) [ISP-HEADER01]	
P87LPC764	P87LPC764(ISP) [ISP-HEADER01]
P87LPC764@PLCC44 [(SA244)]	
P87LPC764@PLCC44(ISP) [ISP-HEADER01]	
P87LPC764@SOIC20 [(SA404)]	
P87LPC764@SOIC20(ISP) [ISP-HEADER01]	
P87LPC764@TSSOP20 [(SA643)]	
P87LPC764@TSSOP20(ISP) [ISP-HEADER01]	
P87LPC767	P87LPC767(ISP) [ISP-HEADER01]
P87LPC767@PLCC44 [(SA244)]	
P87LPC767@PLCC44(ISP) [ISP-HEADER01]	
P87LPC767@SOIC20 [(SA404)]	
P87LPC767@SOIC20(ISP) [ISP-HEADER01]	
P87LPC768	P87LPC768(ISP) [ISP-HEADER01]
P87LPC768@SOIC20 [(SA404)]	
P87LPC768@SOIC20(ISP) [ISP-HEADER01]	
P87LPC769	P87LPC769(ISP) [ISP-HEADER01]
P87LPC769@PLCC44 [(SA244)]	
P87LPC769@PLCC44(ISP) [ISP-HEADER01]	
P87LPC769@SOIC20 [(SA404)]	
P87LPC769@SOIC20(ISP) [ISP-HEADER01]	
P87LPC778	P87LPC778(ISP) [ISP-HEADER01]
P87LPC778@TSSOP20 [(SA026)]	
P87LPC778@TSSOP20(ISP) [ISP-HEADER01]	
P87LPC779	P87LPC779(ISP) [ISP-HEADER01]
P87LPC779@TSSOP20 [(SA643)]	
P87LPC779@TSSOP20(ISP) [ISP-HEADER01]	
P89C138	P89C138@PLCC44 [(SA244)]
P89C138@TQFP44 [(SA245A)]	P89C238
P89C238@PLCC44 [(SA244)]	P89C238@TQFP44 [(SA245A)]
P89C51B	P89C51B@PLCC44 [(SA244)]
P89C51B@TQFP44 [(SA245A)]	P89C51RA+
P89C51RA+@PLCC44 [(SA244)]	P89C51RA+@TQFP44 [(SA245A)]
P89C51RA2B	P89C51RA2B@PLCC44 [(SA244)]
P89C51RA2B@TQFP44 [(SA245A)]	P89C51RB+
P89C51RB+@PLCC44 [(SA244)]	P89C51RB+@TQFP44 [(SA245A)]
P89C51RB2B	P89C51RB2B@PLCC44 [(SA244)]
P89C51RB2B@TQFP44 [(SA245A)]	P89C51RB2H
P89C51RB2H@PLCC44 [(SA244)]	P89C51RB2H@TQFP44 [(SA245A)]
P89C51RC+	P89C51RC+@PLCC44 [(SA244)]
P89C51RC+@TQFP44 [(SA245A)]	P89C51RC2B
P89C51RC2B@PLCC44 [(SA244)]	P89C51RC2B@TQFP44 [(SA245A)]
P89C51RC2H	P89C51RC2H@PLCC44 [(SA244)]
P89C51RC2H@TQFP44 [(SA245A)]	P89C51RD+
P89C51RD+@PLCC44 [(SA244)]	P89C51RD+@TQFP44 [(SA245A)]
P89C51RD2B	P89C51RD2B@PLCC44 [(SA244)]
P89C51RD2B@TQFP44 [(SA245A)]	P89C51RD2H
P89C51RD2H@PLCC44 [(SA244)]	P89C51RD2H@TQFP44 [(SA245A)]
P89C51UB	P89C51UB@PLCC44 [(SA244)]
P89C51UB@TQFP44 [(SA245A)]	P89C51UF
P89C51UF@PLCC44 [(SA244)]	P89C51UF@TQFP44 [(SA245A)]
P89C51X2	P89C51X2@PLCC44 [(SA244)]
P89C51X2@TQFP44 [(SA245A)]	P89C51X2B
P89C51X2B@PLCC44 [(SA244)]	P89C51X2B@TQFP44 [(SA245A)]
P89C51X2F	P89C51X2F@PLCC44 [(SA244)]
P89C51X2F@TQFP44 [(SA245A)]	P89C52
P89C52@PLCC44 [(SA244)]	P89C52@TQFP44 [(SA245A)]
P89C52B	P89C52B@PLCC44 [(SA244)]
P89C52B@TQFP44 [(SA245A)]	P89C52UB

```

P89C52UB@PLCC44 [(SA244)]
P89C52UF
P89C52UF@TQFP44 [(SA245A)]
P89C52X2@PLCC44 [(SA244)]
P89C52X2B
P89C52X2B@TQFP44 [(SA245A)]
P89C52X2F@PLCC44 [(SA244)]
P89C536@PLCC44 [(SA244)]
P89C54
P89C54@TQFP44 [(SA245A)]
P89C54B@PLCC44 [(SA244)]
P89C54UB
P89C54UB@TQFP44 [(SA245A)]
P89C54UF@PLCC44 [(SA244)]
P89C54X2
P89C54X2@TQFP44 [(SA245A)]
P89C54X2B@PLCC44 [(SA244)]
P89C54X2F
P89C54X2F@TQFP44 [(SA245A)]
P89C58@PLCC44 [(SA244)]
P89C58B
P89C58B@TQFP44 [(SA245A)]
P89C58UB@PLCC44 [(SA244)]
P89C58UF
P89C58UF@TQFP44 [(SA245A)]
P89C58X2@PLCC44 [(SA244)]
P89C58X2B
P89C58X2B@TQFP44 [(SA245A)]
P89C58X2F@PLCC44 [(SA244)]
P89C60X2
P89C60X2@TQFP44 [(SA245A)]
P89C61X2@PLCC44 [(SA244)]
P89C660
P89C660@TQFP44 [(SA245A)]
P89C662@PLCC44 [(SA244)]
P89C664
P89C664@TQFP44 [(SA245A)]
P89C668@PLCC44 [(SA244)]
P89C669
P89C669@PLCC44 [(SA244)]
P89C738@PLCC44 [(SA244)]
P89C838
P89C838@TQFP44 [(SA245A)]
P89CV51RB2@TQFP44 [(SA245A)]
P89CV51RC2@TQFP44 [(SA245A)]
P89CV51RD2@TQFP44 [(SA245A)]
P89LPC901(FD)(ISP) [ISP-HEADER01]
P89LPC901(FN)
P89LPC901(FN)(ISP) [ISP-HEADER01]
P89LPC902(FD) [(SA602A)]
P89LPC902(FD)(ISP) [ISP-HEADER01]
P89LPC902(FN)
P89LPC902(FN)(ISP) [ISP-HEADER01]
P89LPC903(FD) [(SA602A)]
P89LPC903(FD)(ISP) [ISP-HEADER01]
P89LPC904(FD) [(SA605A)]
P89LPC904(FD)(ISP) [ISP-HEADER01]
P89LPC904(FN)
P89LPC904(FN)(ISP) [ISP-HEADER01]
P89LPC906(FD) [(SA605A)]
P89LPC906(FD)(ISP) [ISP-HEADER01]
P89LPC907(FD) [(SA605A)]
P89LPC907(FD)(ISP) [ISP-HEADER01]
P89LPC908(FD) [(SA605A)]
P89LPC908(FD)(ISP) [ISP-HEADER01]
P89LPC9102(FTK)@HVSON10 [(SA695A)]
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9103(FTK)@HVSON10 [(SA695A)]
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9107(FDH)@TSSOP14 [(SA643)]
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC9107(FN)
P89LPC9107(FN)(ISP) [ISP-HEADER01]
P89LPC912(FDH)@TSSOP14 [(SA643)]
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC913(FDH)@TSSOP14 [(SA643)]
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC914(FDH)@TSSOP14 [(SA643)]
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC915(FDH)@TSSOP14 [(SA643)]
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89C52UB@TQFP44 [(SA245A)]
P89C52UF@PLCC44 [(SA244)]
P89C52X2
P89C52X2@TQFP44 [(SA245A)]
P89C52X2B@PLCC44 [(SA244)]
P89C52X2F
P89C52X2F@TQFP44 [(SA245A)]
P89C538@PLCC44 [(SA244)]
P89C54@PLCC44 [(SA244)]
P89C54B
P89C54B@TQFP44 [(SA245A)]
P89C54UB@PLCC44 [(SA244)]
P89C54UF
P89C54UF@TQFP44 [(SA245A)]
P89C54X2@PLCC44 [(SA244)]
P89C54X2B
P89C54X2B@TQFP44 [(SA245A)]
P89C54X2F@PLCC44 [(SA244)]
P89C58
P89C58@TQFP44 [(SA245A)]
P89C58B@PLCC44 [(SA244)]
P89C58UB
P89C58UB@TQFP44 [(SA245A)]
P89C58UF@PLCC44 [(SA244)]
P89C58X2
P89C58X2@TQFP44 [(SA245A)]
P89C58X2B@PLCC44 [(SA244)]
P89C58X2F
P89C58X2F@TQFP44 [(SA245A)]
P89C60X2@PLCC44 [(SA244)]
P89C61X2
P89C61X2@TQFP44 [(SA245A)]
P89C660@PLCC44 [(SA244)]
P89C662
P89C662@TQFP44 [(SA245A)]
P89C664@PLCC44 [(SA244)]
P89C668
P89C668@TQFP44 [(SA245A)]
P89C669@LQFP44 [(SA245A)]
P89C738
P89C738@TQFP44 [(SA245A)]
P89C838@PLCC44 [(SA244)]
P89CV51RB2@PLCC44 [(SA244)]
P89CV51RC2@PLCC44 [(SA244)]
P89CV51RD2@PLCC44 [(SA244)]
P89LPC901(FD) [(SA602A)]

```

P89LPC9151(FDH)@TSSOP14 [(SA643)]
P89LPC9151(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC916(FDH)@TSSOP16 [(SA643)]
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC9161(FDH)@TSSOP16 [(SA643)]
P89LPC9161(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC917(FDH)@TSSOP16 [(SA643)]
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC9171(FDH)@TSSOP16 [(SA643)]
P89LPC9171(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC920(FDH)@TSSOP20 [(SA643)]
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920(FN)
P89LPC920(FN)(ISP) [ISP-HEADER01]
P89LPC9201(FDH)@TSSOP20 [(SA643)]
P89LPC9201(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9201(FN)
P89LPC9201(FN)(ISP) [ISP-HEADER01]
P89LPC920A1(FDH)@TSSOP20 [(SA643)]
P89LPC920A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920A1(FN)
P89LPC920A1(FN)(ISP) [ISP-HEADER01]
P89LPC921(FDH)@TSSOP20 [(SA643)]
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921(FN)
P89LPC921(FN)(ISP) [ISP-HEADER01]
P89LPC9211(FDH)@TSSOP20 [(SA643)]
P89LPC9211(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9211(FN)
P89LPC9211(FN)(ISP) [ISP-HEADER01]
P89LPC921A1(FDH)@TSSOP20 [(SA643)]
P89LPC921A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921A1(FN)
P89LPC921A1(FN)(ISP) [ISP-HEADER01]
P89LPC922(FDH)@TSSOP20 [(SA643)]
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922(FN)
P89LPC922(FN)(ISP) [ISP-HEADER01]
P89LPC9221(FDH)@TSSOP20 [(SA643)]
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221(FN)
P89LPC9221(FN)(ISP) [ISP-HEADER01]
P89LPC9221A1(FDH)@TSSOP20 [(SA643)]
P89LPC9221A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221A1(FN)
P89LPC9221A1(FN)(ISP) [ISP-HEADER01]
P89LPC922A1(FDH)@TSSOP20 [(SA643)]
P89LPC922A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922A1(FN)
P89LPC922A1(FN)(ISP) [ISP-HEADER01]
P89LPC924(FDH)@TSSOP20 [(SA643)]
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC924(FN)
P89LPC924(FN)(ISP) [ISP-HEADER01]
P89LPC9241(FDH)@TSSOP20 [(SA643)]
P89LPC9241(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9241(FN)
P89LPC9241(FN)(ISP) [ISP-HEADER01]
P89LPC924A1(FDH)@TSSOP20 [(SA643)]
P89LPC924A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC924A1(FN)
P89LPC924A1(FN)(ISP) [ISP-HEADER01]
P89LPC925(FDH)@TSSOP20 [(SA643)]
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC925(FN)
P89LPC925(FN)(ISP) [ISP-HEADER01]
P89LPC9251(FDH)@TSSOP20 [(SA643)]
P89LPC9251(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9251(FN)
P89LPC9251(FN)(ISP) [ISP-HEADER01]
P89LPC925A1(FDH)@TSSOP20 [(SA643)]
P89LPC925A1(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC925A1(FN)
P89LPC925A1(FN)(ISP) [ISP-HEADER01]
P89LPC930(BA)@PLCC28 [(SA008A)]
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC930(BDH)@TSSOP28 [(SA643)]
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9301(BA)@PLCC28 [(SA008A)]
P89LPC9301(BDH)@TSSOP28 [(SA643)]
P89LPC931(BA)@PLCC28 [(SA008A)]

P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC931(BDH)@TSSOP28 [(SA643)]
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9311(BA)@PLCC28 [(SA008A)]
P89LPC9311(BDH)@TSSOP28 [(SA643)]
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28 [(SA643)]
P89LPC93201(BA)@PLCC28 [(SA008A)]
P89LPC93201(BDH)@TSSOP28 [(SA643)]
P89LPC93201(FA)@PLCC28 [(SA008A)]
P89LPC93201(FDH)@TSSOP28 [(SA643)]
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9321(BA)@PLCC28 [(SA008A)]
P89LPC9321(BDH)@TSSOP28 [(SA643)]
P89LPC9321(FA)@PLCC28 [(SA008A)]
P89LPC9321(FDH)@TSSOP28 [(SA643)]
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(BA)@PLCC28 [(SA008A)]
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC932A1(BDH)@TSSOP28 [(SA643)]
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FDH)@TSSOP28 [(SA643)]
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC933(BDH)@TSSOP28 [(SA643)]
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(FDH)@TSSOP28 [(SA643)]
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(HDH)@TSSOP28 [(SA643)]
P89LPC9331(BDH)@TSSOP28 [(SA643)]
P89LPC9331(FDH)@TSSOP28 [(SA643)]
P89LPC9331(HDH)@TSSOP28 [(SA643)]
P89LPC934(BDH)@TSSOP28 [(SA643)]
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC934(FDH)@TSSOP28 [(SA643)]
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC93401(FDH)@TSSOP28 [(SA643)]
P89LPC93401V
P89LPC9341(BDH)@TSSOP28 [(SA643)]
P89LPC9341(FDH)@TSSOP28 [(SA643)]
P89LPC9341V P89LPC935(BA)@PLCC28 [(SA008A)]
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(BDH)@TSSOP28 [(SA643)]
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FA)@PLCC28 [(SA008A)]
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(FDH)@TSSOP28 [(SA643)]
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93501(BA)@PLCC28 [(SA008A)]
P89LPC93501(BDH)@TSSOP28 [(SA643)]
P89LPC93501(FA)@PLCC28 [(SA008A)]
P89LPC93501(FDH)@TSSOP28 [(SA643)]
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9351(BA)@PLCC28 [(SA008A)]
P89LPC9351(BDH)@TSSOP28 [(SA643)]
P89LPC9351(FA)@PLCC28 [(SA008A)]
P89LPC9351(FDH)@TSSOP28 [(SA643)]
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]
P89LPC936(FA)@PLCC28 [(SA008A)]
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC936(FDH)@TSSOP28 [(SA643)]
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC9361(FA)@PLCC28 [(SA008A)]
P89LPC9361(FDH)@TSSOP28 [(SA643)]
P89LPC938(FA)@PLCC28 [(SA008A)]
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC938(FDH)@TSSOP28 [(SA643)]
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93801(BA)@PLCC28 [(SA008A)]
P89LPC93801(BDH)@TSSOP28 [(SA643)]
P89LPC93801(FA)@PLCC28 [(SA008A)]
P89LPC93801(FDH)@TSSOP28 [(SA643)]
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9381(BA)@PLCC28 [(SA008A)]
P89LPC9381(BDH)@TSSOP28 [(SA643)]
P89LPC9381(FA)@PLCC28 [(SA008A)]
P89LPC9381(FDH)@TSSOP28 [(SA643)]

```

P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC9402(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC952@LQFP44 [(SA245A)]
P89LPC952@LQFP44(ISP) [ISP-HEADER01]
P89LPC952@LQFP48 [(SA248)]
P89LPC952@LQFP48(ISP) [ISP-HEADER01]
P89LPC952@PLCC44 [(SA244)]
P89LPC952@PLCC44(ISP) [ISP-HEADER01]
P89LPC954@LQFP44 [(SA245A)]
P89LPC954@LQFP44(ISP) [ISP-HEADER01]
P89LPC954@LQFP48 [(SA248)]
P89LPC954@LQFP48(ISP) [ISP-HEADER01]
P89LPC954@PLCC44 [(SA244)]
P89LPC954@PLCC44(ISP) [ISP-HEADER01]
P89LPC970FDH@SSOP20 [(SA643)] P89LPC970FN
P89LPC971FDH@SSOP20 [(SA643)] P89LPC971FN
P89LPC972FDH@SSOP20 [(SA643)] P89LPC972FN
P89LPC980FDH@SSOP28 [(SA643)] P89LPC982FDH@SSOP28 [(SA643)]
P89LPC983FA@PLCC28 [(SA008A)] P89LPC984FA@PLCC28 [(SA008A)]
P89LV51RB2 P89LV51RB2@PLCC44 [(SA244)]
P89LV51RB2@TQFP44 [(SA245A)] P89LV51RC2
P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44 [(SA245A)]
P89LV51RD2 P89LV51RD2(new)
P89LV51RD2(new)@PLCC44 [(SA244)]
P89LV51RD2(new)@TQFP44 [(SA245A)]
P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44 [(SA245A)]
P89LV51RD2BA(new)@PLCC44 [(SA244)]
P89LV51RD2BA@PLCC44 [(SA244)]
P89LV51RD2BBC(new)@TQFP44 [(SA245A)]
P89LV51RD2BBC@TQFP44 [(SA245A)] P89LV51RD2BN
P89LV51RD2BN(new)
P89LV51RD2FA(new)@PLCC44 [(SA244)]
P89LV51RD2FA@PLCC44 [(SA244)]
P89LV51RD2FBC(new)@TQFP44 [(SA245A)]
P89LV51RD2FBC@TQFP44 [(SA245A)] P89LV51RD2FN
P89LV51RD2FN(new) P89V51RB2
P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44 [(SA245A)]
P89V51RC2 P89V51RC2@PLCC44 [(SA244)]
P89V51RC2@TQFP44 [(SA245A)] P89V51RD2
P89V51RD2(new) P89V51RD2(new)@PLCC44 [(SA244)]
P89V51RD2(new)@TQFP44 [(SA245A)] P89V51RD2@PLCC44 [(SA244)]
P89V51RD2@TQFP44 [(SA245A)]
P89V51RD2BA(new)@PLCC44 [(SA244)]
P89V51RD2BA@PLCC44 [(SA244)]
P89V51RD2BBC(new)@TQFP44 [(SA245A)]
P89V51RD2BBC@TQFP44 [(SA245A)] P89V51RD2BN
P89V51RD2BN(new)
P89V51RD2FA(new)@PLCC44 [(SA244)]
P89V51RD2FA@PLCC44 [(SA244)]
P89V51RD2FBC(new)@TQFP44 [(SA245A)]
P89V51RD2FBC@TQFP44 [(SA245A)] P89V51RD2FN
P89V51RD2FN(new) P89V52X2
P89V52X2(ISP) [ISP-HEADER01] P89V52X2@PLCC44 [(SA244)]
P89V52X2@PLCC44(ISP) [ISP-HEADER01]
P89V52X2@TQFP44 [(SA245A)]
P89V52X2@TQFP44(ISP) [ISP-HEADER01]
P89V660@PLCC44 [(SA244)] P89V660@TQFP44 [(SA245A)]
P89V662@PLCC44 [(SA244)] P89V662@TQFP44 [(SA245A)]
P89V664@PLCC44 [(SA244)] P89V664@TQFP44 [(SA245A)]
PXAC37@PLCC44 [(SA244)] PXAC37@TQFP44 [(SA245A)]
PXAG17@PLCC44 [(SA244)] PXAG17@TQFP44 [(SA245A)]
PXAG27@PLCC44 [(SA244)] PXAG27@TQFP44 [(SA245A)]
PXAG37@PLCC44 [(SA244)] PXAG37@TQFP44 [(SA245A)]
PXAG39@PLCC44 [(SA244)] PXAG39@TQFP44 [(SA245A)]
PXAG49@PLCC44 [(SA244)] PXAG49@TQFP44 [(SA245A)]

```

PJ

E(E) PROM/FRAM/NVRAM

```

PJ24C02 P89V52X2@SOIC8 [(SA602A)]
PJ24C02@TSSOP8 [(SA026)]

```

PMC

E (E) PROM/FRAM/NVRAM

PM24C64	PM24C64@SOIC8 [(SA602A)]
PM24C64@TSOP8 [(SA026)]	PM25LD512(B)@SOIC8 [(SA023A)]
PM25LD512(Q)@WSON8 [(SA683)]	PM25LD512(S)@SOIC8 [(SA602A)]
PM25LV010(B)@SOIC8 [(SA023A)]	PM25LV010(Q)@WSON8 [(SA683)]
PM25LV010(S)@SOIC8 [(SA602A)]	PM25LV010A@SOIC8 [(SA602A)]
PM25LV010A@WSON8 [(SA683)]	PM25LV016@SOIC8 [(SA605A)]
PM25LV016@WSON8 [(SA683)]	PM25LV016A@SOIC8 [(SA605A)]
PM25LV016A@WSON8 [(SA683)]	PM25LV020(B)@SOIC8 [(SA023A)]
PM25LV020(Q)@WSON8 [(SA683)]	PM25LV020(S)@SOIC8 [(SA602A)]
PM25LV040(B)@SOIC8 [(SA023A)]	PM25LV040(Q)@WSON8 [(SA683)]
PM25LV040(S)@SOIC8 [(SA602A)]	PM25LV080@SOIC8 [(SA605A)]
PM25LV080@WSON8 [(SA683)]	PM25LV080A@SOIC8 [(SA605A)]
PM25LV080A@WSON8 [(SA683)]	PM25LV512(B)@SOIC8 [(SA023A)]
PM25LV512(Q)@WSON8 [(SA683)]	PM25LV512(S)@SOIC8 [(SA602A)]
PM25LV512A(B)@SOIC8 [(SA023A)]	PM25LV512A(Q)@WSON8 [(SA683)]
PM25LV512A(S)@SOIC8 [(SA602A)]	PM29F002B
PM29F002B@PLCC32 [(SA015A1T)]	PM29F002T
PM29F002T@PLCC32 [(SA015A1T)]	PM29F004B
PM29F004B@PLCC32 [(SA015A1T)]	PM29F004T
PM29F004T@PLCC32 [(SA015A1T)]	PM29LV002B
PM29LV002B@PLCC32 [(SA015A1T)]	PM29LV002B@VSOP32 [(SA620)]
PM29LV002T	PM29LV002T@PLCC32 [(SA015A1T)]
PM29LV002T@VSOP32 [(SA620)]	PM29LV004B@PLCC32 [(SA015A1T)]
PM29LV004B@VSOP32 [(SA620)]	PM29LV004T@PLCC32 [(SA015A1T)]
PM29LV004T@VSOP32 [(SA620)]	PM29LV104RB@PLCC32 [(SA015A1T)]
PM29LV104RB@VSOP32 [(SA620)]	PM29LV104RT@PLCC32 [(SA015A1T)]
PM29LV104RT@VSOP32 [(SA620)]	PM37LV512
PM37LV512@PLCC32 [(SA015A1T)]	PM37LV512@VSOP32 [(SA620)]
PM39F010	PM39F010@PLCC32 [(SA015A1T)]
PM39F010@VSOP32 [(SA620)]	PM39F020
PM39F020@PLCC32 [(SA015A1T)]	PM39F020@VSOP32 [(SA620)]
PM39F040	PM39F040@PLCC32 [(SA015A1T)]
PM39F040@VSOP32 [(SA620)]	PM39LV010@PLCC32 [(SA015A1T)]
PM39LV010@VSOP32 [(SA620)]	PM39LV010R@PLCC32 [(SA015A1T)]
PM39LV010R@VSOP32 [(SA620)]	PM39LV020@PLCC32 [(SA015A1T)]
PM39LV020@VSOP32 [(SA620)]	PM39LV040@PLCC32 [(SA015A1T)]
PM39LV040@VSOP32 [(SA620)]	PM39LV512@PLCC32 [(SA015A1T)]
PM39LV512@VSOP32 [(SA620)]	PM39LV512R@PLCC32 [(SA015A1T)]
PM39LV512R@VSOP32 [(SA620)]	PM49FL002T@PLCC32 [(SA015A1T)]
PM49FL002T@VSOP32 [(SA620)]	
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]	
PM49FL004T(Low)@VSOP32 [(SA620-B005)]	
PM49FL004T@PLCC32 [(SA015A1T)]	PM49FL004T@VSOP32 [(SA620)]
PM49FL008T@PLCC32 [(SA015A1T)]	PM49FL008T@VSOP32 [(SA620)]
PM49LP002T@PLCC32 [(SA015A1T)]	PM49LP002T@VSOP32 [(SA620)]

PSS

E (E) PROM/FRAM/NVRAM

PS24C256	PS24C256@SOIC8 [(SA602A)]
----------	---------------------------

PTC

E (E) PROM/FRAM/NVRAM

PT28C020	PT28C020@PLCC32 [(SA015A1T)]
PT28C040	PT28C040@PLCC32 [(SA015A1T)]
PT29C020	PT29C020@PLCC32 [(SA015A1T)]
PT29C040	PT29C040@PLCC32 [(SA015A1T)]

MICROCONTROLLER

PT89316	PT89316@PLCC44 [(SA244)]
PT89316@TQFP44 [(SA245A)]	PT8932
PT8932@PLCC44 [(SA244)]	PT8932@TQFP44 [(SA245)]
PT8936	PT8936@PLCC44 [(SA244)]
PT8936@TQFP44 [(SA245A)]	PT8956

PT8956@PLCC44 [(SA244)]

PT8956@TQFP44 [(SA245A)]

QIXIN

MICROCONTROLLER

LS2051

LS2051@SOIC20 [(SA404)]

Quick Pulse

E (E) PROM / FRAM / NVRAM

27010
27040
27210
27512

27011
27128A
27256
2764A

RAMTRON

E (E) PROM / FRAM / NVRAM

FM1208
FM1608
FM1808
FM18L08
FM24164
FM24C04 (P)
FM24C04A (P)
FM24C16 (P)
FM24C16A (P)
FM24C256@SOIC8 [(SA605A)]
FM24C64
FM24CL04
FM24CL16
FM24CL64@SOIC8 [(SA602A)]
FM25040@SOIC8 [(SA602A)]
FM25160@SOIC8 [(SA602A)]
FM25640@SOIC8 [(SA602A)]
FM25C160@SOIC8 [(SA602A)]
FM25CL64
FM25L16
FM25L256
FM25L256@TDFN8 [(BBBB)]
FM25L512@SOIC8 [(SA602A)]
FM30C256@SOIC20 [(SA404)]
FM3116@SOIC14 [(SA602)]
FM3164@SOIC14 [(SA602)]
FM32256S@SOIC14 [(SA602)]
FM3264S@SOIC14 [(SA602)]
FM3808@TSOP32 [(SA620)]

FM1208@SOIC24 [(SA404)]
FM1608@SOIC28 [(SA404)]
FM1808@SOIC28 [(SA404)]
FM18L08@SOIC28 [(SA404)]
FM24164@SOIC8 [(SA602A)]
FM24C04 (S)@SOP8 [(SA602A)]
FM24C04A (S)@SOP8 [(SA602A)]
FM24C16 (S)@SOP8 [(SA602A)]
FM24C16A (S)@SOP8 [(SA602A)]
FM24C512@SOIC8 [(SA602A)]
FM24C64@SOIC8 [(SA602A)]
FM24CL04@SOIC8 [(SA602A)]
FM24CL16@SOIC8 [(SA602A)]
FM25040
FM25160
FM25640
FM25C160
FM25CL04@SOIC8 [(SA602A)]
FM25CL64@SOIC8 [(SA602A)]
FM25L16@SOIC8 [(SA602A)]
FM25L256@SOIC8 [(SA602A)]
FM25L512
FM25W256@SOIC8 [(SA602A)]
FM3104@SOIC14 [(SA602)]
FM31256@SOIC14 [(SA602)]
FM32256G@SOIC14 [(SA602)]
FM3264G@SOIC14 [(SA602)]
FM3808

MICROCONTROLLER

VMX51C900
VMX51C900@TQFP44 [(SA245A)]
VRS1000@PLCC44 [(SA244)]
VRS1100
VRS1100@TQFP44 [(SA245A)]
VRS51C1000@PLCC44 [(SA244)]
VRS51C1100
VRS51C1100@TQFP44 [(SA245A)]
VRS51C540@PLCC44 [(SA244)]
VRS51C550
VRS51C550@TQFP44 [(SA245A)]
VRS51C560@PLCC44 [(SA244)]
VRS51C570
VRS51C570@TQFP44 [(SA245A)]
VRS51C580@PLCC44 [(SA244)]
VRS51C700
VRS51C700@TQFP44 [(SA245A)]

VMX51C900@PLCC44 [(SA244)]
VRS1000
VRS1000@TQFP44 [(SA245A)]
VRS1100@PLCC44 [(SA244)]
VRS51C1000
VRS51C1000@TQFP44 [(SA245A)]
VRS51C1100@PLCC44 [(SA244)]
VRS51C540
VRS51C540@TQFP44 [(SA245A)]
VRS51C550@PLCC44 [(SA244)]
VRS51C560
VRS51C560@TQFP44 [(SA245A)]
VRS51C570@PLCC44 [(SA244)]
VRS51C580
VRS51C580@TQFP44 [(SA245A)]
VRS51C700@PLCC44 [(SA244)]
VRS51L1050

VRS51L1050@PLCC44 [(SA244)]	VRS51L1050@TQFP44 [(SA245A)]
VRS51L540	VRS51L540@PLCC44 [(SA244)]
VRS51L540@TQFP44 [(SA245A)]	VRS51L550
VRS51L550@PLCC44 [(SA244)]	VRS51L550@TQFP44 [(SA245A)]
VRS51L560	VRS51L560@PLCC44 [(SA244)]
VRS51L560@TQFP44 [(SA245A)]	VRS51L570
VRS51L570@PLCC44 [(SA244)]	VRS51L570@TQFP44 [(SA245A)]
VRS51L580	VRS51L580@PLCC44 [(SA244)]
VRS51L580@TQFP44 [(SA245A)]	VRS51X540
VRS51X540@PLCC44 [(SA244)]	VRS51X540@TQFP44 [(SA245A)]
VRS51X550	VRS51X550@PLCC44 [(SA244)]
VRS51X550@TQFP44 [(SA245A)]	VRS51X560
VRS51X560@PLCC44 [(SA244)]	VRS51X560@TQFP44 [(SA245A)]
VRS51X570	VRS51X570@PLCC44 [(SA244)]
VRS51X570@TQFP44 [(SA245A)]	VRS51X580
VRS51X580@PLCC44 [(SA244)]	VRS51X580@TQFP44 [(SA245A)]
VRS540	VRS540@PLCC44 [(SA244)]
VRS540@TQFP44 [(SA245A)]	VRS550
VRS550@PLCC44 [(SA244)]	VRS550@TQFP44 [(SA245A)]
VRS560	VRS560@PLCC44 [(SA244)]
VRS560@TQFP44 [(SA245A)]	VRS570
VRS570@PLCC44 [(SA244)]	VRS570@TQFP44 [(SA245A)]
VRS580	VRS580@PLCC44 [(SA244)]
VRS580@TQFP44 [(SA245A)]	VRS700
VRS700@PLCC44 [(SA244)]	VRS700@TQFP44 [(SA245A)]
VRS900	VRS900@PLCC44 [(SA244)]
VRS900@TQFP44 [(SA245A)]	

RATO

E(E) PROM/FRAM/NVRAM

RT24A02	RT24A02@SOIC8 [(SA602A)]
RT24A02@TSSOP8 [(SA026)]	RT24A04
RT24A04@SOIC8 [(SA602A)]	RT24A04@TSSOP8 [(SA026)]
RT24A08	RT24A08@SOIC8 [(SA602A)]
RT24A08@TSSOP8 [(SA026)]	RT24A16
RT24A16@SOIC8 [(SA602A)]	RT24A16@TSSOP8 [(SA026)]
RT93C46B(16bit)	RT93C46B(16bit)@SOIC8 [(SA602A)]
RT93C46B(16bit)@TSSOP8 [(SA026)]	RT93LC46(08bit)
RT93LC46(08bit)@SOIC8 [(SA602A)]	RT93LC46(08bit)@TSSOP8 [(SA026)]
RT93LC46(16bit)	RT93LC46(16bit)@SOIC8 [(SA602A)]
RT93LC46(16bit)@TSSOP8 [(SA026)]	

RAYDIUM

E(E) PROM/FRAM/NVRAM

RM24C02@SOP8 [(SA602A)]	RM24C04@SOP8 [(SA602A)]
RM24C08@SOP8 [(SA602A)]	RM24C128@SOP8 [(SA602A)]
RM24C16@SOP8 [(SA602A)]	RM24C32@SOP8 [(SA602A)]
RM24C64@SOP8 [(SA602A)]	

RENESAS

E(E) PROM/FRAM/NVRAM

HN58C256A(FP)@SOP28 [(SA630)]	HN58C256A(P)
HN58C256A(T)@TSOP28 [(SA643)]	HN58C257A(T)@TSOP32 [(SA620)]
HN58V24256	HN58V24256@SOIC8 [(SA602A)]
HN58V24256@TSSOP14 [(SA026)]	HN58V24512
HN58V24512@SOIC8 [(SA602A)]	HN58W241000
HN58W241000@SOIC8 [(SA602A)]	HN58X2402
HN58X2402@SOIC8 [(SA602A)]	HN58X2402@TSSOP8 [(SA026)]
HN58X2404	HN58X2404@SOIC8 [(SA602A)]
HN58X2404@TSSOP8 [(SA026)]	HN58X2408
HN58X2408@SOIC8 [(SA602A)]	HN58X2408@TSSOP8 [(SA026)]
HN58X24128	HN58X24128@SOIC8 [(SA602A)]
HN58X2416	HN58X2416@SOIC8 [(SA602A)]
HN58X2416@TSSOP8 [(SA026)]	HN58X24256
HN58X24256@SOIC8 [(SA602A)]	HN58X2432

HN58X2432@SOIC8 [(SA602A)]	HN58X2432@TSSOP8 [(SA026)]
HN58X24512	HN58X24512@SOIC8 [(SA602A)]
HN58X2464	HN58X2464@SOIC8 [(SA602A)]
HN58X2464@TSSOP8 [(SA026)]	HN58X2502@SOIC8 [(SA602A)]
HN58X2502@TSSOP8 [(SA026)]	HN58X2504@SOIC8 [(SA602A)]
HN58X2504@TSSOP8 [(SA026)]	HN58X25128@SOIC8 [(SA602A)]
HN58X25128@TSSOP14 [(SA026)]	HN58X25256@SOIC8 [(SA602A)]
HN58X25256@TSSOP14 [(SA026)]	HN58X2532@SOIC8 [(SA602A)]
HN58X2532@TSSOP8 [(SA026)]	HN58X2564@SOIC8 [(SA602A)]
HN58X2564@TSSOP8 [(SA026)]	M5L2732
M5L2732A	R1EX24002A@SOP8 [(SA602A)]
R1EX24002A@TSSOP8 [(SA026)]	R1EX24004A@SOP8 [(SA602A)]
R1EX24004A@TSSOP8 [(SA026)]	R1EX24008A@SOP8 [(SA602A)]
R1EX24008A@TSSOP8 [(SA026)]	R1EX24016A@SOP8 [(SA602A)]
R1EX24016A@TSSOP8 [(SA026)]	R1EX24032A@SOP8 [(SA602A)]
R1EX24032A@TSSOP8 [(SA026)]	R1EX24064A@SOP8 [(SA602A)]
R1EX24064A@TSSOP8 [(SA026)]	R1EX24128A@SOP8 [(SA602A)]
R1EX24128A@TSSOP8 [(SA026)]	R1EX24256A@SOP8 [(SA602A)]
R1EX24256A@TSSOP8 [(SA026)]	R1EX24512A@SOP8 [(SA602A)]
R1EX24512A@TSSOP8 [(SA026)]	

DRAM & SRAM

R1LV0408C@SOP32 [(SA438T)]	R1LV0408C@STSOP32 [(SA620)]
R1LV0408C@TSOP32 [(SA410T)]	

MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)]	HD4074344@SOIC28 [(SA404)]
HD4074394@SDIP28 [(SA022A)]	HD4074394@SOIC28 [(SA404)]
R5F21102DFP@TQFP32 [(SA663+B005)]	
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21102FP@TQFP32 [(SA663+B005)]	
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21103DFP@TQFP32 [(SA663+B005)]	
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21103FP@TQFP32 [(SA663+B005)]	
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21104DFP@TQFP32 [(SA663+B005)]	
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21104FP@TQFP32 [(SA663+B005)]	
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21112DFP@TQFP32 [(SA663+B005)]	
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21112FP@TQFP32 [(SA663+B005)]	
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21113DFP@TQFP32 [(SA663+B005)]	
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21113FP@TQFP32 [(SA663+B005)]	
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21114DFP@TQFP32 [(SA663+B005)]	
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21114FP@TQFP32 [(SA663+B005)]	
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21122DFP@TQFP32 [(SA663+B005)]	
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21122FP@TQFP32 [(SA663+B005)]	
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21123DFP@TQFP32 [(SA663+B005)]	
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21123FP@TQFP32 [(SA663+B005)]	
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21124DFP@TQFP32 [(SA663+B005)]	
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21124FP@TQFP32 [(SA663+B005)]	
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21132DFP@TQFP32 [(SA663+B005)]	
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21132FP@TQFP32 [(SA663+B005)]	
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21133DFP@TQFP32 [(SA663+B005)]	
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21133FP@TQFP32 [(SA663+B005)]	
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]	
R5F21134DFP@TQFP32 [(SA663+B005)]	
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]	
R5F21134FP@TQFP32 [(SA663+B005)]	
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]	


```
R5F21181DD@SDIP20 [(SA725-B005)]
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(single wire) [(SA725-B005)]
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]
R5F21181DSP@TSSOP20 [(SA026-B001)]
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21181SP@TSSOP20 [(SA026-B001)]
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182DD@SDIP20 [(SA725-B005)]
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(single wire) [(SA725-B005)]
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]
R5F21182DSP@TSSOP20 [(SA026-B001)]
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182NP@QFN28 [(SA697-B006)]
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]
R5F21182NP@QFN28(single wire) [(SA697-B006)]
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21182NP@QFN28(UART mode) [(SA697+B006)]
R5F21182SP@TSSOP20 [(SA026-B001)]
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183DD@SDIP20 [(SA725-B005)]
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(single wire) [(SA725-B005)]
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]
R5F21183DSP@TSSOP20 [(SA026-B001)]
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183NP@QFN28 [(SA697-B006)]
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]
R5F21183NP@QFN28(single wire) [(SA697-B006)]
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21183NP@QFN28(UART mode) [(SA697+B006)]
R5F21183SP@TSSOP20 [(SA026-B001)]
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184DD@SDIP20 [(SA725-B005)]
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(single wire) [(SA725-B005)]
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]
R5F21184DSP@TSSOP20 [(SA026-B001)]
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184NP@QFN28 [(SA697-B006)]
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]
R5F21184NP@QFN28(single wire) [(SA697-B006)]
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21184NP@QFN28(UART mode) [(SA697+B006)]
R5F21184SP@TSSOP20 [(SA026-B001)]
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191DD@SDIP20 [(SA725-B005)]
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(single wire) [(SA725+B005)]
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]
R5F21191DSP@TSSOP20 [(SA026-B001)]
```

```
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191SP@TSSOP20 [(SA026-B001)]
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192DD@SDIP20 [(SA725-B005)]
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(single wire) [(SA725+B005)]
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]
R5F21192DSP@TSSOP20 [(SA026-B001)]
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192NP@QFN28 [(SA697-B006)]
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]
R5F21192NP@QFN28(single wire) [(SA697+B006)]
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21192NP@QFN28(UART mode) [(SA697+B006)]
R5F21192SP@TSSOP20 [(SA026-B001)]
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193DD@SDIP20 [(SA725-B005)]
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(single wire) [(SA725+B005)]
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]
R5F21193DSP@TSSOP20 [(SA026-B001)]
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193NP@QFN28 [(SA697-B006)]
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]
R5F21193NP@QFN28(single wire) [(SA697+B006)]
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21193NP@QFN28(UART mode) [(SA697+B006)]
R5F21193SP@TSSOP20 [(SA026-B001)]
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194DD@SDIP20 [(SA725-B005)]
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(single wire) [(SA725+B005)]
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]
R5F21194DSP@TSSOP20 [(SA026-B001)]
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194NP@QFN28 [(SA697-B006)]
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]
R5F21194NP@QFN28(single wire) [(SA697+B006)]
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21194NP@QFN28(UART mode) [(SA697+B006)]
R5F21194SP@TSSOP20 [(SA026-B001)]
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1DD@SDIP20 [(SA725-B005)]
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(single wire) [(SA725+B005)]
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A1DSP@TSSOP20 [(SA026-B001)]
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1SP@TSSOP20 [(SA026-B001)]
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]
```



```
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2DD@SDIP20 [(SA725-B005)]
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A2DSP@TSSOP20 [(SA026-B001)]
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2NP@QFN28 [(SA697-B006)]
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(single wire) [(SA697-B006)]
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]
R5F211A2SP@TSSOP20 [(SA026-B001)]
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3DD@SDIP20 [(SA725-B005)]
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A3DSP@TSSOP20 [(SA026-B001)]
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3NP@QFN28 [(SA697-B006)]
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(single wire) [(SA697-B006)]
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]
R5F211A3SP@TSSOP20 [(SA026-B001)]
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4DD@SDIP20 [(SA725-B005)]
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A4DSP@TSSOP20 [(SA026-B001)]
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4NP@QFN28 [(SA697-B006)]
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(single wire) [(SA697-B006)]
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]
R5F211A4SP@TSSOP20 [(SA026-B001)]
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1DD@SDIP20 [(SA725-B005)]
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B1DSP@TSSOP20 [(SA026-B001)]
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1SP@TSSOP20 [(SA026-B001)]
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2DD@SDIP20 [(SA725-B005)]
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]
```

```
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B2DSP@TSSOP20 [(SA026-B001)]
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2NP@QFN28 [(SA697-B006)]
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(single wire) [(SA697+B006)]
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]
R5F211B2SP@TSSOP20 [(SA026-B001)]
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3DD@SDIP20 [(SA725-B005)]
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B3DSP@TSSOP20 [(SA026-B001)]
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3NP@QFN28 [(SA697-B006)]
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(single wire) [(SA697+B006)]
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]
R5F211B3SP@TSSOP20 [(SA026-B001)]
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4DD@SDIP20 [(SA725-B005)]
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B4DSP@TSSOP20 [(SA026-B001)]
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4NP@QFN28 [(SA697-B006)]
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(single wire) [(SA697+B006)]
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]
R5F211B4SP@TSSOP20 [(SA026-B001)]
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21206JFP@TQFP48 [(SA248-B005)]
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]
R5F21206KFP@TQFP48 [(SA248-B005)]
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]
R5F21207JFP@TQFP48 [(SA248-B005)]
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]
R5F21207KFP@TQFP48 [(SA248-B005)]
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]
R5F21208JFP@TQFP48 [(SA248-B005)]
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]
R5F21208KFP@TQFP48 [(SA248-B005)]
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AJFP@TQFP48 [(SA248-B005)]
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AKFP@TQFP48 [(SA248-B005)]
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]
```

R5F2120CJFP@TQFP48 [(SA248-B005)]
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CKFP@TQFP48 [(SA248-B005)]
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21216JFP@TQFP48 [(SA248-B005)]
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]
R5F21216KFP@TQFP48 [(SA248-B005)]
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]
R5F21217JFP@TQFP48 [(SA248-B005)]
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]
R5F21217KFP@TQFP48 [(SA248-B005)]
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]
R5F21218JFP@TQFP48 [(SA248-B005)]
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]
R5F21218KFP@TQFP48 [(SA248-B005)]
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AJFP@TQFP48 [(SA248-B005)]
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AKFP@TQFP48 [(SA248-B005)]
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CJFP@TQFP48 [(SA248-B005)]
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CKFP@TQFP48 [(SA248-B005)]
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21226JFP@TQFP48 [(SA248-B005)]
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]
R5F21226KFP@TQFP48 [(SA248-B005)]
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]
R5F21227JFP@TQFP48 [(SA248-B005)]
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]
R5F21227KFP@TQFP48 [(SA248-B005)]
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]
R5F21228JFP@TQFP48 [(SA248-B005)]
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]
R5F21228KFP@TQFP48 [(SA248-B005)]
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AJFP@TQFP48 [(SA248-B005)]
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AKFP@TQFP48 [(SA248-B005)]
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CJFP@TQFP48 [(SA248-B005)]
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CKFP@TQFP48 [(SA248-B005)]
R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21236JFP@TQFP48 [(SA248-B005)]
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]
R5F21236KFP@TQFP48 [(SA248-B005)]
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]
R5F21237JFP@TQFP48 [(SA248-B005)]
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]
R5F21237KFP@TQFP48 [(SA248-B005)]
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]
R5F21238JFP@TQFP48 [(SA248-B005)]
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]

```
R5F21238KFP@TQFP48 [(SA248-B005)]
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AJFP@TQFP48 [(SA248-B005)]
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AKFP@TQFP48 [(SA248-B005)]
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CJFP@TQFP48 [(SA248-B005)]
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CKFP@TQFP48 [(SA248-B005)]
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21245SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]
```

R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]

R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]

R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]

```

R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20 [(SA026-B001)]
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212H1SNSP@TSSOP20 [(SA026-B001)]
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212H2SDSP@TSSOP20 [(SA725-B005)]
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212H2SNSP@TSSOP20 [(SA725-B005)]
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212J0SDSP@TSSOP20 [(SA026-B001)]
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212J0SNSP@TSSOP20 [(SA026-B001)]
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212J1SDSP@TSSOP20 [(SA026-B001)]
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212J1SNSP@TSSOP20 [(SA026-B001)]
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212K2SDFP@QFP32 [(SA663-B005)]
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SDFP@QFP32(single wire [(SA663-B005)])
R5F212K2SNFP@QFP32 [(SA663-B005)]
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SNFP@QFP32(single wire [(SA663-B005)])
R5F212K4SDFP@QFP32 [(SA663-B005)]
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SDFP@QFP32(single wire [(SA663-B005)])
R5F212K4SNFP@QFP32 [(SA663-B005)]
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SNFP@QFP32(single wire [(SA663-B005)])
R5F212L2SDFP@QFP32 [(SA663-B005)]
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SDFP@QFP32(single wire [(SA663+B005)])
R5F212L2SNFP@QFP32 [(SA663-B005)]
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SNFP@QFP32(single wire [(SA663+B005)])
R5F212L4SDFP@QFP32 [(SA663-B005)]
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SDFP@QFP32(single wire [(SA663+B005)])
R5F212L4SNFP@QFP32 [(SA663-B005)]
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SNFP@QFP32(single wire [(SA663+B005)])

```

RICOH

E(E) PROM/FRAM/NVRAM

RD27C256
RD27C64

RD27C32

ROCKWELL**E (E) PROM/FRAM/NVRAM**

R2764	R2764C
R2764P	R27C64
R2816	R5213
R52B13	R52B33

ROHM**E (E) PROM/FRAM/NVRAM**

BR24A01A (F) [(SA602A)]	BR24A01A (FJ) [(SA602A)]
BR24A02 (F) [(SA602A)]	BR24A02 (FJ) [(SA602A)]
BR24A04 (F) [(SA602A)]	BR24A04 (FJ) [(SA602A)]
BR24A08 (F) [(SA602A)]	BR24A08 (FJ) [(SA602A)]
BR24A16 (F) [(SA602A)]	BR24A16 (FJ) [(SA602A)]
BR24A32 (F) [(SA602A)]	BR24A32 (FJ) [(SA602A)]
BR24A64 (F) [(SA602A)]	BR24A64 (FJ) [(SA602A)]
BR24C01@SOP8 [(SA602A)]	BR24C01@TSSOP8 [(SA026)]
BR24C01@TSSOP8 (3*3mm) [(SA666)]	BR24C01A
BR24C01A (F) [(SA602A)]	BR24C01A (FJ) [(SA602A)]
BR24C01A (FV) [(SA026)]	BR24C02
BR24C02 (F) [(SA602A)]	BR24C02 (FJ) [(SA602A)]
BR24C02 (FV) [(SA026)]	BR24C02@SOP8 [(SA602A)]
BR24C02@TSSOP8 [(SA026)]	BR24C02@TSSOP8 (3*3mm) [(SA666)]
BR24C04	BR24C04 (F) [(SA602A)]
BR24C04 (FJ) [(SA602A)]	BR24C04 (FV) [(SA026)]
BR24C04@SOP8 [(SA602A)]	BR24C04@TSSOP8 [(SA026)]
BR24C04@TSSOP8 (3*3mm) [(SA666)]	BR24C08
BR24C08 (F) [(SA602A)]	BR24C08 (FJ) [(SA602A)]
BR24C08 (FV) [(SA026)]	BR24C08@SOP8 [(SA602A)]
BR24C08@TSSOP8 [(SA026)]	BR24C08@TSSOP8 (3*3mm) [(SA666)]
BR24C16	BR24C16 (F) [(SA602A)]
BR24C16 (FJ) [(SA602A)]	BR24C16 (FV) [(SA026)]
BR24C21	BR24C21 (F) [(SA602A)]
BR24C21 (FJ) [(SA602A)]	BR24C21 (FV) [(SA026)]
BR24C32	BR24C32 (F) [(SA602A)]
BR24C64	BR24C64 (F) [(SA602A)]
BR24E16	BR24E16 (F) [(SA602A)]
BR24E16 (FJ) [(SA602A)]	BR24E16 (FV) [(SA026)]
BR24G32	BR24G32 (F) [(SA602A)]
BR24G32 (FJ) [(SA602A)]	BR24G32 (FV) [(SA026)]
BR24G32 (FVT) [(SA026)]	BR24L01A
BR24L01A (F) [(SA602A)]	BR24L01A (FJ) [(SA602A)]
BR24L01A (FV) [(SA026)]	BR24L01A (FVM) [(SA666)]
BR24L02	BR24L02 (F) [(SA602A)]
BR24L02 (FJ) [(SA602A)]	BR24L02 (FV) [(SA026)]
BR24L02 (FVM) [(SA666)]	BR24L04
BR24L04 (F) [(SA602A)]	BR24L04 (FJ) [(SA602A)]
BR24L04 (FV) [(SA026)]	BR24L04 (FVM) [(SA666)]
BR24L08	BR24L08 (F) [(SA602A)]
BR24L08 (FJ) [(SA602A)]	BR24L08 (FV) [(SA026)]
BR24L08 (FVM) [(SA666)]	BR24L16
BR24L16 (F) [(SA602A)]	BR24L16 (FJ) [(SA602A)]
BR24L16 (FV) [(SA026)]	BR24L16 (FVM) [(SA666)]
BR24L32	BR24L32 (F) [(SA602A)]
BR24L32 (FJ) [(SA602A)]	BR24L32 (FV) [(SA026)]
BR24L64	BR24L64 (F) [(SA602A)]
BR24L64 (FJ) [(SA602A)]	BR24L64 (FV) [(SA026)]
BR24S08 (F) [(SA602A)]	BR24S08 (FJ) [(SA602A)]
BR24S08 (FV) [(SA026)]	BR24S08 (FVJ) [(SA026)]
BR24S08 (FVM) [(SA666)]	BR24S08 (FVT) [(SA026)]
BR24S128	BR24S128 (F) [(SA602A)]
BR24S128 (FJ) [(SA602A)]	BR24S128 (FV) [(SA026)]
BR24S128 (NUX) [(SA724)]	BR24S16
BR24S16 (F) [(SA602A)]	BR24S16 (FJ) [(SA602A)]
BR24S16 (FV) [(SA026)]	BR24S16 (FVM) [(SA666)]
BR24S256	BR24S256 (F) [(SA602A)]
BR24S256 (FJ) [(SA602A)]	BR24S256 (FV) [(SA026)]
BR24S256 (NUX) [(SA724)]	BR24S32
BR24S32 (F) [(SA602A)]	BR24S32 (FJ) [(SA602A)]
BR24S32 (FV) [(SA026)]	BR24S32 (NUX) [(SA724)]
BR24S64	BR24S64 (F) [(SA602A)]

BR24S64 (FJ) [(SA602A)]	BR24S64 (FV) [(SA026)]
BR24S64 (NUX) [(SA724)]	BR25010@SOIC8 [(SA602A)]
BR25010@TSSOP8 [(SA026)]	BR25020@SOIC8 [(SA602A)]
BR25020@TSSOP8 [(SA026)]	BR25040@SOIC8 [(SA602A)]
BR25040@TSSOP8 [(SA026)]	BR25080@SOIC8 [(SA602A)]
BR25080@TSSOP8 [(SA026)]	BR25160@SOIC8 [(SA602A)]
BR25160@TSSOP8 [(SA026)]	BR25320@SOIC8 [(SA602A)]
BR25H010 (F) [(SA602A)]	BR25H010 (FJ) [(SA602A)]
BR25H020 (F) [(SA602A)]	BR25H020 (FJ) [(SA602A)]
BR25H040 (F) [(SA602A)]	BR25H040 (FJ) [(SA602A)]
BR25H080 (F) [(SA602A)]	BR25H080 (FJ) [(SA602A)]
BR25H080 (FVT) [(SA026)]	BR25H160 (F) [(SA602A)]
BR25H160 (FJ) [(SA602A)]	BR25H160 (FVT) [(SA026)]
BR25H320 (F) [(SA602A)]	BR25H320 (FJ) [(SA602A)]
BR25H320 (FVT) [(SA026)]	BR25L010
BR25L010 (F) [(SA602A)]	BR25L010 (FJ) [(SA602A)]
BR25L010 (FV) [(SA026)]	BR25L010 (FVM) [(SA666)]
BR25L020	BR25L020 (F) [(SA602A)]
BR25L020 (FJ) [(SA602A)]	BR25L020 (FV) [(SA026)]
BR25L020 (FVM) [(SA666)]	BR25L040
BR25L040 (F) [(SA602A)]	BR25L040 (FJ) [(SA602A)]
BR25L040 (FV) [(SA026)]	BR25L040 (FVM) [(SA666)]
BR25L080	BR25L080 (F) [(SA602A)]
BR25L080 (FJ) [(SA602A)]	BR25L080 (FV) [(SA026)]
BR25L160	BR25L160 (F) [(SA602A)]
BR25L160 (FJ) [(SA602A)]	BR25L160 (FV) [(SA026)]
BR25L320	BR25L320 (F) [(SA602A)]
BR25L320 (FJ) [(SA602A)]	BR25L320 (FV) [(SA026)]
BR25L640	BR25L640 (F) [(SA602A)]
BR25L640 (FJ) [(SA602A)]	BR25L640 (FV) [(SA026)]
BR34C02A [(SA026)]	BR34L02
BR34L02 (F) [(SA602A)]	BR34L02 (FJ) [(SA602A)]
BR34L02 (FV) [(SA026)]	BR34L02 (FVM) [(SA666)]
BR9010	BR9010 (F) [(SA602A)]
BR9010 (FV) [(SA026)]	BR9010 (RFV) [(SA026)]
BR9010 (RFVM) [(SA666)]	BR9016
BR9016 (F) [(SA602A)]	BR9016 (RFV) [(SA026)]
BR9016A (F) [(SA602A)]	BR9016A (RFV) [(SA026)]
BR9016A (RFVM) [(SA666)]	BR9020
BR9020 (F) [(SA602A)]	BR9020 (FV) [(SA026)]
BR9020 (RFV) [(SA026)]	BR9020 (RFVM) [(SA666)]
BR9040	BR9040 (F) [(SA602A)]
BR9040 (FV) [(SA026)]	BR9040 (RFV) [(SA026)]
BR9040 (RFVM) [(SA666)]	BR9080
BR9080 (F) [(SA602A)]	BR9080 (RFV) [(SA026)]
BR9080A	BR9080A (F) [(SA602A)]
BR9080A (FV) [(SA026)]	BR9080A (RFV) [(SA026)]
BR9080A (RFVM) [(SA666)]	BR93A46 (F) [(SA602A)]
BR93A46 (FJ) [(SA602A)]	BR93A46 (RF) [(SA602A)]
BR93A46 (RFJ) [(SA602A)]	BR93A56 (F) [(SA602A)]
BR93A56 (FJ) [(SA602A)]	BR93A56 (RF) [(SA602A)]
BR93A56 (RFJ) [(SA602A)]	BR93A66 (F) [(SA602A)]
BR93A66 (FJ) [(SA602A)]	BR93A66 (RF) [(SA602A)]
BR93A66 (RFJ) [(SA602A)]	BR93A76 (F) [(SA602A)]
BR93A76 (FJ) [(SA602A)]	BR93A76 (RF) [(SA602A)]
BR93A76 (RFJ) [(SA602A)]	BR93A86 (F) [(SA602A)]
BR93A86 (FJ) [(SA602A)]	BR93A86 (RF) [(SA602A)]
BR93A86 (RFJ) [(SA602A)]	BR93C46
BR93C46 (F) [(SA602A)]	BR93C46 (FJ) [(SA602A)]
BR93C46 (FV) [(SA026)]	BR93C46 (RF) [(SA602A)]
BR93C46 (RFJ) [(SA602A)]	BR93C56
BR93C56 (F) [(SA602A)]	BR93C56 (FJ) [(SA602A)]
BR93C56 (FV) [(SA026)]	BR93C56 (RF) [(SA602A)]
BR93C56 (RFJ) [(SA602A)]	BR93C66
BR93C66 (F) [(SA602A)]	BR93C66 (FJ) [(SA602A)]
BR93C66 (FV) [(SA026)]	BR93C66 (RF) [(SA602A)]
BR93C66 (RFJ) [(SA602A)]	BR93H46 (RF) [(SA602A)]
BR93H46 (RFJ) [(SA602A)]	BR93H56 (RF) [(SA602A)]
BR93H56 (RFJ) [(SA602A)]	BR93H66 (RF) [(SA602A)]
BR93H66 (RFJ) [(SA602A)]	BR93H76 (RF) [(SA602A)]
BR93H76 (RFJ) [(SA602A)]	BR93H86 (RF) [(SA602A)]
BR93H86 (RFJ) [(SA602A)]	BR93L46
BR93L46 (F) [(SA602A)]	BR93L46 (FJ) [(SA602A)]
BR93L46 (FV) [(SA026)]	BR93L46 (RF) [(SA602A)]
BR93L46 (RFJ) [(SA602A)]	BR93L56
BR93L56 (F) [(SA602A)]	BR93L56 (FJ) [(SA602A)]
BR93L56 (FV) [(SA026)]	BR93L56 (RF) [(SA602A)]
BR93L56 (RFJ) [(SA602A)]	BR93L66
BR93L66 (F) [(SA602A)]	BR93L66 (FJ) [(SA602A)]
BR93L66 (FV) [(SA026)]	BR93L66 (RF) [(SA602A)]
BR93L66 (RFJ) [(SA602A)]	BR93L76 (F) [(SA602A)]

BR93L76(FJ) [(SA602A)]	BR93L76(RF) [(SA602A)]
BR93L76(RFJ) [(SA602A)]	BR93L76(RFV) [(SA026A)]
BR93L76(RFVJ) [(SA666A)]	BR93L76(RFVM) [(SA666A)]
BR93L76(RFVT) [(SA026A)]	BR93L86(F) [(SA602A)]
BR93L86(FJ) [(SA602A)]	BR93L86(RF) [(SA602A)]
BR93L86(RFJ) [(SA602A)]	BR93L86(RFV) [(SA026A)]
BR93L86(RFVJ) [(SA666A)]	BR93L86(RFVM) [(SA666A)]
BR93L86(RFVT) [(SA026A)]	BR93LC46
BR93LC46(F) [(SA602A)]	BR93LC46(FJ) [(SA602A)]
BR93LC46(FV) [(SA026)]	BR93LC46(RF) [(SA602A)]
BR93LC46(RFJ) [(SA602A)]	BR93LC56
BR93LC56(F) [(SA602A)]	BR93LC56(FJ) [(SA602A)]
BR93LC56(FV) [(SA026)]	BR93LC56(RF) [(SA602A)]
BR93LC56(RFJ) [(SA602A)]	BR93LC66
BR93LC66(F) [(SA602A)]	BR93LC66(FJ) [(SA602A)]
BR93LC66(FV) [(SA026)]	BR93LC66(RF) [(SA602A)]
BR93LC66(RFJ) [(SA602A)]	BR93LL46(F) [(SA602A)]
BR93LL46(FV) [(SA026)]	BR95010(3*3)@TSSOP8 [(SA666)]
BR95010@SO8 [(SA602A)]	BR95010@TSSOP8 [(SA026)]
BR95020(3*3)@TSSOP8 [(SA666)]	BR95020@SO8 [(SA602A)]
BR95020@TSSOP8 [(SA026)]	BR95040(3*3)@TSSOP8 [(SA666)]
BR95040@SO8 [(SA602A)]	BR95040@TSSOP8 [(SA026)]
BR95080@SO8 [(SA602A)]	BR95080@TSSOP8 [(SA026)]
BR95160@SO8 [(SA602A)]	BR95160@TSSOP8 [(SA026)]

SAIFUN

E(E) PROM/FRAM/NVRAM

SA24C1024	SA24C1024@SOIC8 [(SA602A)]
SA24C512	SA24C512@SOIC8 [(SA602A)]
SA24C512@TSSOP8 [(SA026)]	SA25C020
SA25C020@MLF8 [(SA683)]	SA25C020@SOIC8 [(SA602A)]
SA25C040	SA25C040@MLF8 [(SA683)]
SA25C040@SOIC8 [(SA602A)]	SA25C080
SA25C080@MLF8 [(SA683)]	SA25C080@SOIC8 [(SA602A)]
SA25C1024(H)	SA25C1024(H)@CSP8 [(SA683)]
SA25C1024(H)@SOIC8 [(SA602A)]	SA25C1024(L)
SA25C1024(L)@CSP8 [(SA683)]	SA25C1024(L)@SOIC8 [(SA602A)]
SA25C512(H)	SA25C512(H)@CSP8 [(SA683)]
SA25C512(H)@SOIC8 [(SA602A)]	SA25C512(L)
SA25C512(L)@CSP8 [(SA683)]	SA25C512(L)@SOIC8 [(SA602A)]
SA25F005	SA25F005@MLF8 [(SA683)]
SA25F005@SOIC8 [(SA602A)]	SA25F010
SA25F010@MLF8 [(SA683)]	SA25F010@SOIC8 [(SA602A)]
SA25F020	SA25F020@MLF8 [(SA683)]
SA25F020@SOIC8 [(SA602A)]	SA25F040
SA25F040@MLF8 [(SA683)]	SA25F040@SOIC8 [(SA602A)]
SA25F080	SA25F080@MLF8 [(SA683)]
SA25F080@SOIC8 [(SA602A)]	SA25F160
SA25F160(ISP) [ISP-HEADER01]	SA25F160@MLF8 [(SA683)]
SA25F160@MLF8(ISP) [ISP-HEADER01]	
SA25F160@SOIC16 [(SA602)]	
SA25F160@SOIC16(ISP) [ISP-HEADER01]	

SAMSUNG

E(E) PROM/FRAM/NVRAM

KM2816A	KM2816AI
KM2817A	KM2817AI
KM2864A	KM2864AH
KM2865A	KM2865AH
KM28C16	KM28C16@PLCC32 [(SA015A1T)]
KM28C16I	KM28C16I@PLCC32 [(SA015A1T)]
KM28C17	KM28C17@PLCC32 [(SA015A1T)]
KM28C17I	KM28C17I@PLCC32 [(SA015A1T)]
KM28C256	KM28C256@PLCC32 [(SA015A1T)]
KM28C256I	KM28C256I@PLCC32 [(SA015A1T)]
KM28C64	KM28C64@PLCC32 [(SA015A1T)]
KM28C64A	KM28C64A@PLCC32 [(SA015A1T)]
KM28C64B	KM28C64B@PLCC32 [(SA015A1T)]
KM28C64I	KM28C64I@PLCC32 [(SA015A1T)]
KM28C65	KM28C65@PLCC32 [(SA015A1T)]

KM28C65A	KM28C65A@PLCC32 [(SA015A1T)]
KM28C65I	KM28C65I@PLCC32 [(SA015A1T)]
KM93C06(08bit)	KM93C06(16bit)
KM93C06(G)(08bit)@SOIC8 [(SA602A)]	
KM93C06(G)(16bit)@SOIC8 [(SA602A)]	
KM93C06(GD)(08bit)@SOIC8 [(SA602A)]	
KM93C06(GD)(16bit)@SOIC8 [(SA602A)]	
KM93C07(08bit)	KM93C07(16bit)
KM93C07(G)(08bit)@SOIC8 [(SA602A)]	
KM93C07(G)(16bit)@SOIC8 [(SA602A)]	
KM93C07(GD)(08bit)@SOIC8 [(SA602A)]	
KM93C07(GD)(16bit)@SOIC8 [(SA602A)]	
KM93C46V	KM93C46V(G)@SOIC8 [(SA602A)]
KM93C46V(GD)@SOIC8 [(SA602A)]	KM93C47V
KM93C47V(G)@SOIC8 [(SA602A)]	KM93C47V(GD)@SOIC8 [(SA602A)]
KM93C56V	KM93C56V(G)@SOIC8 [(SA602A)]
KM93C56V(GD)@SOIC8 [(SA602A)]	KM93C57V
KM93C57V(G)@SOIC8 [(SA602A)]	KM93C57V(GD)@SOIC8 [(SA602A)]
KM93C66V	KM93C66V(G)@SOIC8 [(SA602A)]
KM93C66V(GD)@SOIC8 [(SA602A)]	KM93C67V
KM93C67V(G)@SOIC8 [(SA602A)]	KM93C67V(GD)@SOIC8 [(SA602A)]
KS24C010	KS24C010@SOIC8 [(SA602A)]
KS24C010@TSSOP8 [(SA026)]	KS24C011
KS24C011@SOIC8 [(SA602A)]	KS24C011@TSSOP8 [(SA026)]
KS24C020	KS24C020@SOIC8 [(SA602A)]
KS24C020@TSSOP8 [(SA026)]	KS24C021
KS24C021@SOIC8 [(SA602A)]	KS24C021@TSSOP8 [(SA026)]
KS24C040	KS24C040@SOIC8 [(SA602A)]
KS24C040@TSSOP8 [(SA026)]	KS24C041
KS24C041@SOIC8 [(SA602A)]	KS24C041@TSSOP8 [(SA026)]
KS24C080	KS24C080@SOIC8 [(SA602A)]
KS24C080@TSSOP8 [(SA026)]	KS24C081
KS24C081@SOIC8 [(SA602A)]	KS24C081@TSSOP8 [(SA026)]
S524A40X10	S524A40X10@SOP8 [(SA602A)]
S524A40X10@TSSOP8 [(SA026)]	S524A40X11
S524A40X11@SOP8 [(SA602A)]	S524A40X11@TSSOP8 [(SA026)]
S524A40X20	S524A40X20@SOP8 [(SA602A)]
S524A40X20@TSSOP8 [(SA026)]	S524A40X21
S524A40X21@SOP8 [(SA602A)]	S524A40X21@TSSOP8 [(SA026)]
S524A40X40	S524A40X40@SOP8 [(SA602A)]
S524A40X40@TSSOP8 [(SA026)]	S524A40X41
S524A40X41@SOP8 [(SA602A)]	S524A40X41@TSSOP8 [(SA026)]
S524A60X51	S524A60X51@SOP8 [(SA602A)]
S524A60X51@TSSOP8 [(SA026)]	S524A60X81
S524A60X81@SOP8 [(SA602A)]	S524A60X81@TSSOP8 [(SA026)]
S524AB0X91	S524AB0X91@SOP8 [(SA602A)]
S524AB0X91@TSSOP8 [(SA026)]	S524AB0XB1
S524AB0XB1@SOP8 [(SA602A)]	S524AB0XB1@TSSOP8 [(SA026)]
S524AD0XD1	S524AD0XD1@SOP8 [(SA602A)]
S524AD0XD1@TSSOP8 [(SA026)]	S524AD0XF1
S524AD0XF1@SOP8 [(SA602A)]	S524AD0XF1@TSSOP8 [(SA026)]
S524C20D11	S524C20D11@SOP8 [(SA602A)]
S524C20D11@TSSOP8 [(SA026)]	S524C20D21
S524C20D21@SOP8 [(SA602A)]	S524C20D21@TSSOP8 [(SA026)]
S524C80D41	S524C80D41@SOP8 [(SA602A)]
S524C80D41@TSSOP8 [(SA026)]	S524C80D81
S524C80D81@SOP8 [(SA602A)]	S524C80D81@TSSOP8 [(SA026)]
S524L50X51	S524L50X51@SOP8 [(SA602A)]
S524L50X51@TSSOP8 [(SA026)]	S524LB0X91
S524LB0X91@SOP8 [(SA602A)]	S524LB0X91@TSSOP8 [(SA026)]
S524LB0XB1	S524LB0XB1@SOP8 [(SA602A)]
S524LB0XB1@TSSOP8 [(SA026)]	

DRAM & SRAM

KM61257	KM61257@SOJ24 [(SA646)]
KM61257L	KM61257L@SOJ24 [(SA646)]
KM6165	KM6165@SOJ24 [(SA646)]
KM6165L	KM6165L@SOJ24 [(SA646)]
KM62256A	KM62256A@SOIC28 [(SA630)]
KM62256AL	KM62256AL@SOIC28 [(SA630)]
KM6264A	KM6264A@SOIC28 [(SA630)]
KM6264AL	KM6264AL@SOIC28 [(SA630)]
KM64257	KM64257@SOJ24 [(SA646)]
KM64257L	KM64257L@SOJ24 [(SA646)]
KM6465LP	KM6465LP@SOJ22 [(SA646)]
KM6465P	KM68257LP
KM68257LP@SOIC28 [(SA630)]	KM68257P
KM68257P@SOIC28 [(SA630)]	KM6865LP

KM6865LP@SOIC28 [(SA630)]
 KM6865P@SOIC28 [(SA630)]

KM6865P

PLD

CPL16L8	CPL16L8@PLCC20 [(SA001A)]
CPL16L8L	CPL16L8L@PLCC20 [(SA001A)]
CPL16R4	CPL16R4@PLCC20 [(SA001A)]
CPL16R4L	CPL16R4L@PLCC20 [(SA001A)]
CPL16R6	CPL16R6@PLCC20 [(SA001A)]
CPL16R6L	CPL16R6L@PLCC20 [(SA001A)]
CPL16R8	CPL16R8@PLCC20 [(SA001A)]
CPL16R8L	CPL16R8L@PLCC20 [(SA001A)]

SANYO

E(E) PROM/FRAM/NVRAM

LE24C041	LE24C041@MFP8 [(SA654)]
LE24C042	LE24C042@MFP8 [(SA654)]
LE24C081	LE24C081@MFP8 [(SA654)]
LE24C082	LE24C082@MFP8 [(SA654)]
LE24C161	LE24C161@MFP8 [(SA654)]
LE24C162	LE24C162@MFP8 [(SA654)]
LE24C322@MFP8 [(SA654)]	LE24C322@WLP6 [(SA698)]
LE24L322@MFP8 [(SA654)]	LE25FU106BMA@MFP8 [(SA654)]
LE25FU106BTT@MSOP8 [(SA654)]	LE25FU406BMA@MFP8 [(SA602A)]
LE25FU406BTT@MSOP8 [(SA654)]	LE25FV055T@MSOP8 [(SA654)]
LE25FV101T@MSOP8 [(SA654)]	LE25FV105T@MSOP8 [(SA654)]
LE25FV201T@MSOP8 [(SA654)]	LE25FV401T@MSOP8 [(SA654)]
LE25FV411T@MSOP8 [(SA654)]	LE25FV451T@VSOP32 [(SA620)]
LE25FW056FN@VSON8 [(SA683)]	LE25FW056MA@MFP8 [(SA602A)]
LE25FW106M@SOP8 [(SA602A)]	LE25FW106T@MSOP8 [(SA654)]
LE25FW1606FN@VSON8 [(SA683)]	LE25FW203ATT@MSOP8 [(SA654)]
LE25FW206M@SOP8 [(SA602A)]	LE25FW206T@MSOP8 [(SA654)]
LE25FW406BMA@MFP8 [(SA602A)]	LE25FW406BTT@MSOP8 [(SA654)]
LE25FW406M@SOP8 [(SA602A)]	LE25FW406T@MSOP8 [(SA654)]
LE25FW806M@SOP8 [(SA602A)]	LE25FW806T@MSOP8 [(SA654)]
LE26CW006@WLP6 [(SA698)]	LE28C1001AM@SOP32 [(SA687)]
LE28C1001AT@TSOP32 [(SA410T)]	LE28C1001ATS@VSOP32 [(SA620)]
LE28C1001DT@TSOP32 [(SA410T)]	LE28C1001DTS@VSOP32 [(SA620)]
LE28CV1001AT@TSOP32 [(SA410T)]	LE28CV1001ATS@VSOP32 [(SA620)]
LE28CV1001DT@TSOP32 [(SA410T)]	LE28CV1001DTS@VSOP32 [(SA620)]
LE28CW1001DT@TSOP32 [(SA410T)]	LE28CW1001DTS@VSOP32 [(SA620)]
LE28F1101T@TSOP40 [(SA623)]	LE28F1601T@TSOP40 [(SA409T)]
LE28F2001ATS@TSOP32 [(SA410T)]	LE28F4001ATS@TSOP32 [(SA410T)]
LE28F4001M@SSOP32 [(SA438T)]	LE28F8001T@TSOP40 [(SA409T)]
LE28FV1101T@TSOP40 [(SA623)]	LE28FV1601T@TSOP40 [(SA409T)]
LE28FV2001ATS@TSOP32 [(SA410T)]	LE28FV4001ATS@TSOP32 [(SA410T)]
LE28FV4001CTS@TSOP32 [(SA410T)]	LE28FV4001M@SSOP32 [(SA438T)]
LE28FV4001T@TSOP40 [(SA409T)]	LE28FV8001T@TSOP40 [(SA409T)]

SEEQ

E(E) PROM/FRAM/NVRAM

27128	27256
2764	27C256
2804	2804A
2816A	2816AH
5213	52B13
52B13H	52B23
52B23H	52B33
52B33H	5516A
5516AH	5517A
5517AH	DE2817A
DE2817A@PLCC32 [(SA015A1T)]	DE2817AH
DE2817AH@PLCC32 [(SA015A1T)]	DQ2817A
DQ2817A@PLCC32 [(SA015A1T)]	DQ2817AH
DQ2817AH@PLCC32 [(SA015A1T)]	DQ2864
DQ2864@PLCC32 [(SA015A1T)]	DQ2864H
DQ2864H@PLCC32 [(SA015A1T)]	DQ28C256
DQ28C256@PLCC32 [(SA015A1T)]	DQ28C64

DQ28C64@PLCC32 [(SA015A1T)]	DQ28C64A
DQ28C64A@PLCC32 [(SA015A1T)]	DQ28C65
DQ28C65@PLCC32 [(SA015A1T)]	DQ52B13
DQ52B13H	E28C64
E28C64@PLCC32 [(SA015A1T)]	E52B13
E52B13H	E52B23
E52B23H	E52B33
E52B33H	M28C64
M28C64@PLCC32 [(SA015A1T)]	M52B13
M52B13H	M52B23
M52B23H	M52B33
M52B33H	PQ2864
PQ2864@PLCC32 [(SA015A1T)]	PQ2864H
PQ2864H@PLCC32 [(SA015A1T)]	PQ28C64
PQ28C64@PLCC32 [(SA015A1T)]	PQ28C65
PQ28C65@PLCC32 [(SA015A1T)]	

SEIKO

E(E) PROM/FRAM/NVRAM

S-22H10	S-22H10@SOP18 [(SA404)]
S-22H12	S-22H12@SOP18 [(SA404)]
S-22S10	S-22S10@SOP18 [(SA404)]
S-22S12	S-22S12@SOP18 [(SA404)]
S-24C01A(DP)	S-24C01A(DPA)
S-24C01A(FJA)@SOIC8 [(SA602A)]	S-24C01B(DP)
S-24C01B(FJ)@SOIC8 [(SA602A)]	S-24C02A(DP)
S-24C02A(DPA)	S-24C02A(FJA)@SOIC8 [(SA602A)]
S-24C02B(DP)	S-24C02B(FJ)@SOIC8 [(SA602A)]
S-24C04A(DP)	S-24C04A(DPA)
S-24C04A(FJA)@SOIC8 [(SA602A)]	S-24C04B(DP)
S-24C04B(FJ)@SOIC8 [(SA602A)]	S-24C08A(DPA)
S-24C08A(FJA)@SOIC8 [(SA602A)]	S-24C16A(DPA)
S-24C16A(FJA)@SOIC8 [(SA602A)]	S-24CS01A(DP)
S-24CS01A(FJ)@SOIC8 [(SA602A)]	S-24CS01A(FT)@TSSOP8 [(SA026)]
S-24CS02A(DP)	S-24CS02A(FJ)@SOIC8 [(SA602A)]
S-24CS02A(FT)@TSSOP8 [(SA026)]	S-24CS04A(DP)
S-24CS04A(FJ)@SOIC8 [(SA602A)]	S-24CS04A(FT)@TSSOP8 [(SA026)]
S-24CS08A(DP)	S-24CS08A(FJ)@SOIC8 [(SA602A)]
S-24CS08A(FT)@TSSOP8 [(SA026)]	S-24CS16A(DP)
S-24CS16A(FJ)@SOIC8 [(SA602A)]	S-24CS16A(FT)@TSSOP8 [(SA026)]
S-24CS64A(FJ)@SOIC8 [(SA602A)]	S-24CS64A(FT)@TSSOP8 [(SA026)]
S-24H45	S-24H45@SOP8 [(SA605A)]
S-24S45	S-24S45@SOP8 [(SA605A)]
S-25A010A@SOP8 [(SA602A)]	S-25A020A@SOP8 [(SA602A)]
S-25A040A@SOP8 [(SA602A)]	S-25A080A@SOP8 [(SA602A)]
S-25A160A@SOP8 [(SA602A)]	S-25A320A@SOP8 [(SA602A)]
S-25A640A@SOP8 [(SA602A)]	S-25C010A@SOP8 [(SA602A)]
S-25C010A@TSSOP8 [(SA026)]	S-25C020A@SOP8 [(SA602A)]
S-25C020A@TSSOP8 [(SA026)]	S-25C040A@SOP8 [(SA602A)]
S-25C040A@TSSOP8 [(SA026)]	S-25C080A@SOP8 [(SA602A)]
S-25C080A@TSSOP8 [(SA026)]	S-25C160A@SOP8 [(SA602A)]
S-25C160A@TSSOP8 [(SA026)]	S-25C320A@SOP8 [(SA602A)]
S-25C320A@TSSOP8 [(SA026)]	S-25C640A@SOP8 [(SA602A)]
S-25C640A@TSSOP8 [(SA026)]	S-2817A@SOP28 [(SA630)]
S-29130A(DFJA)@SOIC8 [(SA602A)]	S-29130A(DPA)
S-29130A(FJA)@SOIC8 [(SA602A)]	S-29131A(DPA)
S-29131A(FJA)@SOIC8 [(SA602A)]	S-29190A(DPA)
S-29190A(FJA)@SOIC8 [(SA602A)]	S-29191A(DPA)
S-29191A(FJA)@SOIC8 [(SA602A)]	S-29194A(DPA)
S-29194A(FJA)@SOIC8 [(SA602A)]	S-29220A(DFJA)@SOIC8 [(SA602A)]
S-29220A(DPA)	S-29220A(FJA)@SOIC8 [(SA602A)]
S-29221A(DPA)	S-29221A(FJA)@SOIC8 [(SA602A)]
S-29230A(DFJA)@SOIC8 [(SA602A)]	S-29230A(DPA)
S-29230A(FJA)@SOIC8 [(SA602A)]	S-29231A(DPA)
S-29231A(FJA)@SOIC8 [(SA602A)]	S-29290A(DPA)
S-29290A(FJA)@SOIC8 [(SA602A)]	S-29291A(DPA)
S-29291A(FJA)@SOIC8 [(SA602A)]	S-29294A(DPA)
S-29294A(FJA)@SOIC8 [(SA602A)]	S-29330A(DFJA)@SOIC8 [(SA602A)]
S-29330A(DPA)	S-29330A(FJA)@SOIC8 [(SA602A)]
S-29331A(DPA)	S-29331A(FJA)@SOIC8 [(SA602A)]
S-29390A(DPA)	S-29390A(FJA)@SOIC8 [(SA602A)]
S-29391A(DPA)	S-29391A(FJA)@SOIC8 [(SA602A)]
S-29394A(DPA)	S-29394A(FJA)@SOIC8 [(SA602A)]
S-29430A	S-29430A@SOIC8 [(SA602A)]
S-29530A	S-29530A@SOIC8 [(SA602A)]


```

S-29630A
S-29L130A(DFE)@SOIC8 [(SA602A)]
S-29L130A(FS)@SSOP8 [(SA026)]
S-29L131A(FS)@SSOP8 [(SA026)]
S-29L194A(FS)@TSSOP8 [(SA026)]
S-29L220A(FE)@SOIC8 [(SA602A)]
S-29L221A(DFE)@SOIC8 [(SA602A)]
S-29L294A(DFE)@SOIC8 [(SA602A)]
S-29L330A(DFE)@SOIC8 [(SA602A)]
S-29L330A(FS)@SSOP8 [(SA026)]
S-29L331A(FS)@SSOP8 [(SA026)]
S-29L394A(FS)@TSSOP8 [(SA026)]
S-29U130A(FS)@SSOP8 [(SA026)]
S-29U131A(FS)@SSOP8 [(SA026)]
S-29U194A(FS)@TSSOP8 [(SA026)]
S-29U220A(FS)@SSOP8 [(SA026)]
S-29U221A(FS)@SSOP8 [(SA026)]
S-29U294A(FS)@TSSOP8 [(SA026)]
S-29U330A(FS)@SSOP8 [(SA026)]
S-29U331A(FS)@SSOP8 [(SA026)]
S-29U394A(FS)@TSSOP8 [(SA026)]
S-29Z330A(FS)@SSOP8 [(SA026)]
S-29Z430A(FS)@SSOP8 [(SA026)]
S-93A56A(D0A)@SOIC8 [(SA602A)]
S-93A66A(FJ)@SOIC8 [(SA602A)]
S-93C46A(DFJ)@SOIC8 [(SA602A)]
S-93C46A(FJ)@SOIC8 [(SA602A)]
S-93C46B(DP)
S-93C46B(FT)@TSSOP8 [(SA026)]
S-93C56A(DP)
S-93C56A(FT)@TSSOP8 [(SA026)]
S-93C56B(FJ)@SOIC8 [(SA602A)]
S-93C66A(DFJ)@SOIC8 [(SA602A)]
S-93C66A(FJ)@SOIC8 [(SA602A)]
S-93C66B(DP)
S-93C66B(FT)@TSSOP8 [(SA026)]
S-93C76A(FJ)@SOIC8 [(SA602A)]
S-93C86A(DP)
S-93C86A(FT)@TSSOP8 [(SA026)]
S-93C86B@TSSOP8 [(SA026)]
S-93L56A(D0I)@SOIC8 [(SA602A)]
S-93L76A(D0I)@SOIC8 [(SA602A)]

S-29630A@SOIC8 [(SA602A)]
S-29L130A(FE)@SOIC8 [(SA602A)]
S-29L131A(DFE)@SOIC8 [(SA602A)]
S-29L194A(DFE)@SOIC8 [(SA602A)]
S-29L220A(DFE)@SOIC8 [(SA602A)]
S-29L220A(FS)@SSOP8 [(SA026)]
S-29L221A(FS)@SSOP8 [(SA026)]
S-29L294A(FS)@TSSOP8 [(SA026)]
S-29L330A(FE)@SOIC8 [(SA602A)]
S-29L331A(DFE)@SOIC8 [(SA602A)]
S-29L394A(DFE)@SOIC8 [(SA602A)]
S-29U130A(DFE)@SOIC8 [(SA602A)]
S-29U131A(DFE)@SOIC8 [(SA602A)]
S-29U194A(DFE)@SOIC8 [(SA602A)]
S-29U220A(DFE)@SOIC8 [(SA602A)]
S-29U221A(DFE)@SOIC8 [(SA602A)]
S-29U294A(DFE)@SOIC8 [(SA602A)]
S-29U330A(DFE)@SOIC8 [(SA602A)]
S-29U331A(DFE)@SOIC8 [(SA602A)]
S-29U394A(DFE)@SOIC8 [(SA602A)]
S-29Z330A(DFJA)@SOIC8 [(SA602A)]
S-29Z430A(DFJA)@SOIC8 [(SA602A)]
S-93A46A(D0A)@SOIC8 [(SA602A)]
S-93A66A(D0A)@SOIC8 [(SA602A)]
S-93A86A@SOIC8 [(SA602A)]
S-93C46A(DP)
S-93C46A(FT)@TSSOP8 [(SA026)]
S-93C46B(FJ)@SOIC8 [(SA602A)]
S-93C56A(DFJ)@SOIC8 [(SA602A)]
S-93C56A(FJ)@SOIC8 [(SA602A)]
S-93C56B(DP)
S-93C56B(FT)@TSSOP8 [(SA026)]
S-93C66A(DP)
S-93C66A(FT)@TSSOP8 [(SA026)]
S-93C66B(FJ)@SOIC8 [(SA602A)]
S-93C76A(DP)
S-93C76A(FT)@TSSOP8 [(SA026)]
S-93C86A(FJ)@SOIC8 [(SA602A)]
S-93C86B@SOIC8 [(SA602A)]
S-93L46A(D0I)@SOIC8 [(SA602A)]
S-93L66A(D0I)@SOIC8 [(SA602A)]

```

SGS-THOMSON

E(E) PROM/FRAM/NVRAM

```

ET2716
ETC2732
M24128@SOIC8 [(SA602A)]
M24164@SOIC8 [(SA602A)]
M24256[3.9]@SOIC8 [(SA602A)]
M24512
M24512@TSOP8 [(SA026)]
M24C04@SOIC8 [(SA602A)]
M24C08@SOIC8 [(SA602A)]
M24C08W@SOIC8 [(SA602A)]
M24C64(BN)
M24C64(DW)@TSSOP8 [(SA602A)]
M24C64(MW)@SOIC8 [(SA602A)]
M2716
M27256A
M27512
M2764A
M27C1000@PLCC32 [(SA015A1T)]
M27C1001
M27C1001@TSOP32 [(SA410T)]
M27C1024@PLCC44 [(SA244)]
M27C160@PLCC44 [(SA244)]
M27C2001
M27C2001@TSOP32 [(SA410T)]
M27C202@PLCC44 [(SA244)]
M27C256B
M27C400
M27C4001@PLCC32 [(SA015A1T)]
M27C4002
M27C405

ETC2716
M24128
M24164
M24256
M24256[5.5]@SOIC8 [(SA605A)]
M24512@SOIC8 [(SA605A)]
M24C04
M24C08
M24C08W
M24C08W@TSOP8 [(SA026)]
M24C64(DL)@TSSOP14 [(SA026)]
M24C64(MN)@SOIC8 [(SA605A)]
M27128A
M27256
M2732A
M2764
M27C1000
M27C1000@TSOP32 [(SA410T)]
M27C1001@PLCC32 [(SA015A1T)]
M27C1024
M27C160
M27C160@PSOP44 [(SA638)]
M27C2001@PLCC32 [(SA015A1T)]
M27C202
M27C202@TSOP40 [(SA409T)]
M27C256B@PLCC32 [(SA015A1T)]
M27C4001
M27C4001@TSOP32 [(SA410T)]
M27C4002@PLCC44 [(SA244)]
M27C405@PLCC32 [(SA015A1T)]

```

M27C405@TSOP32 [(SA410T)]	M27C512
M27C512@PLCC32 [(SA015A1T)]	M27C516
M27C516@PLCC44 [(SA244)]	M27C64A
M27C64A@PLCC32 [(SA015A1T)]	M27C800
M27C800@PLCC44 [(SA244)]	M27C800@PSOP44 [(SA638)]
M27C801	M27C801@PLCC32 [(SA015A1T)]
M27C801@TSOP32 [(SA410T)]	M27HC641
M27HC641@PLCC28 [(SA008A)]	M27HC642
M27HC642@PLCC28 [(SA008A)]	M27V101
M27V101@PLCC32 [(SA015A1T)]	M27V101@TSOP32 [(SA410T)]
M27V201	M27V201@PLCC32 [(SA015A1T)]
M27V201@TSOP32 [(SA410T)]	M27V401
M27V401@PLCC32 [(SA015A1T)]	M27V401@TSOP32 [(SA410T)]
M27V402	M27V402@PLCC44 [(SA244)]
M27V402@TSOP40 [(SA409T)]	M27V512
M27V512@PLCC32 [(SA015A1T)]	M27V512@TSOP28 [(SA430T)]
M27V800	M27V800@PLCC44 [(SA244)]
M27V801	M27V801@PLCC32 [(SA015A1T)]
M27V801@TSOP32 [(SA410T)]	M27W201
M27W201@PLCC32 [(SA015A1T)]	M27W201@TSOP32 [(SA410T)]
M28010	M28010@PLCC32 [(SA015A1T)]
M28010@TSOP32 [(SA410T)]	M28C16@PLCC32 [(SA015A1T)]
M28C64C	M28C64C@PLCC32 [(SA015A1T)]
M28C64C@SOIC28 [(SA404)]	M28C64C@TSOP28 [(SA430T)]
M28F101	M28F101@PLCC32 [(SA015A1T)]
M28F101@TSOP32 [(SA410T)]	M28F102
M28F102@PLCC44 [(SA244)]	M28F102@TSOP40 [(SA409T)]
M28F201	M28F201@PLCC32 [(SA015A1T)]
M28F201@TSOP32 [(SA410T)]	M28F211@TSOP40 [(SA409T)]
M28F256	M28F256@PLCC32 [(SA015A1T)]
M28F256@TSOP32 [(SA410T)]	M28F411@TSOP40 [(SA409T)]
M28F512	M28F512@PLCC32 [(SA015A1T)]
M28F512@TSOP32 [(SA410T)]	M29F002B
M29F002B@PLCC32 [(SA015A1T)]	M29F002B@TSOP32 [(SA410T)]
M29F002T	M29F002T@PLCC32 [(SA015A1T)]
M29F002T@TSOP32 [(SA410T)]	M29F040
M29F040@PLCC32 [(SA015A1T)]	M29F040@TSOP32 [(SA410T)]
M29F040B	M29F040B@PLCC32 [(SA015A1T)]
M29F040B@TSOP32 [(SA410T)]	M29F100B@PSOP44 [(SA638-B006)]
M29F100B@TSOP48 [(SA247-B005)]	M29F100T@PSOP44 [(SA638-B006)]
M29F100T@TSOP48 [(SA247-B005)]	M29F102B@PLCC44 [(SA244)]
M29F102B@TSOP40 [(SA623)]	M29F102BB@PLCC44 [(SA244)]
M29F102BB@TSOP40 [(SA623)]	M29F200B@PSOP44 [(SA638-B006)]
M29F200B@TSOP48 [(SA247-B005)]	M29F200T@PSOP44 [(SA638-B006)]
M29F200T@TSOP48 [(SA247-B005)]	M29F400B@PSOP44 [(SA638-B006)]
M29F400B@TSOP48 [(SA247-B005)]	M29F400T@PSOP44 [(SA638-B006)]
M29F400T@TSOP48 [(SA247-B005)]	M29V040@PLCC32 [(SA015A1T)]
M29V040@TSOP32 [(SA410T)]	M29W008B@TSOP40 [(SA409T)]
M29W008T@TSOP40 [(SA409T)]	M29W040@PLCC32 [(SA015A1T)]
M29W040@TSOP32 [(SA410T)]	M29W512B@PLCC32 [(SA015A1T)]
M29W512B@TSOP32 [(SA620)]	M48T35
M48T35@SOIC28 [(SA404)]	M48T35Y
M48T35Y@SOIC28 [(SA404)]	M48T59
M48T59@SOIC28 [(SA404)]	M48T59Y
M48T59Y@SOIC28 [(SA404)]	M48Z128
M48Z128Y	M48Z30
M48Z30Y	M48Z32
M48Z32Y	M50FW080@PLCC32 [(SA015A1T)]
M50FW080@TSOP40 [(SA409T)]	M50FW080@VSOP32 [(SA620)]
M87C257	M87C257@PLCC32 [(SA015A1T)]
M93C06(08bit)	M93C06(08bit)@SOIC8 [(SA602A)]
M93C06(16bit)	M93C06(16bit)@SOIC8 [(SA602A)]
M93S46	M93S46@SOIC8 [(SA602A)]
M93S46@TSSOP8 [(SA026)]	M95P02
M95P02@SOIC8 [(SA602A)]	M95P04
M95P04@SOIC8 [(SA602A)]	M95P08
M95P08@SOIC8 [(SA602A)]	MK48C02
MK48C02B	MK48C12
MK48C12B	MK48T02
MK48T02B	MK48T08
MK48T12	MK48T12B
MK48T18	MK48Z02
MK48Z02B	MK48Z08
MK48Z12	MK48Z12B
MK48Z18	MKI48Z02
MKI48Z02B	MKI48Z12
MKI48Z12B	MKI48Z18
ST24C01	ST24C01@SOIC8 [(SA602A)]
ST24C02A	ST24C02A@SOIC8 [(SA602A)]
ST24C16	ST24C16@SOIC8 [(SA602A)]
ST24W01	ST24W01@SOIC8 [(SA602A)]

ST24W02	ST24W02@SOIC8 [(SA602A)]
ST24W04C	ST24W04C@SOIC8 [(SA602A)]
ST27128A	ST27256
ST2764A	ST27C256
ST93C06(08bit)	ST93C06(08bit)@SOIC8 [(SA602A)]
ST93C06(16bit)	ST93C06(16bit)@SOIC8 [(SA602A)]
ST93CS46	ST93CS46@SOIC8 [(SA602A)]
TS27C256	TS27C64
TS27C64@PLCC32 [(SA015A1T)]	TS27C64A
TS27C64A@PLCC32 [(SA015A1T)]	TS28C16A
TS28C17A	

PLD

GAL16V8	GAL16V8A
GAL20V8	GAL20V8A

SHARP**E(E) PROM/FRAM/NVRAM**

LH28F002SCHN@PSOP44 [(SA638)]	LH28F002SCHT@TSOP40 [(SA409T)]
LH28F002SCN@PSOP44 [(SA638)]	LH28F002SCT@TSOP40 [(SA409T)]
LH28F004BVE(BT)@TSOP40 [(SA409T)]	
LH28F004BVE(TT)@TSOP40 [(SA409T)]	
LH28F004BVHS(BT)@VSOP40 [(SA623)]	
LH28F004BVHS(TT)@VSOP40 [(SA623)]	
LH28F004BVT(BT)@TSOP40 [(SA409T)]	
LH28F004BVT(TT)@TSOP40 [(SA409T)]	
LH28F004SCHN@PSOP44 [(SA638)]	LH28F004SCHS@VSOP40 [(SA623)]
LH28F004SCHT@TSOP40 [(SA409T)]	LH28F004SCN@PSOP44 [(SA638)]
LH28F004SCS@VSOP40 [(SA623)]	LH28F004SCT@TSOP40 [(SA409T)]
LH28F008BJT(BTLZ1)@TSOP40 [(SA409T)]	
LH28F008BJT(TB)@TSOP40 [(SA409T)]	
LH28F008BJT(TT)@TSOP40 [(SA409T)]	
LH28F008BJT(TTLZ2)@TSOP40 [(SA409T)]	
LH28F008BVT(BT)@TSOP40 [(SA409T)]	
LH28F008BVT(TT)@TSOP40 [(SA409T)]	
LH28F008SAN@PSOP44 [(SA638)]	LH28F008SAR@RTSOP40 [(SA409T)]
LH28F008SAT@TSOP40 [(SA409T)]	
LH28F008SCH(L85)@RTSOP40 [(SA409T)]	
LH28F008SCH-L@TSOP40 [(SA409T)]	LH28F008SCHN@PSOP44 [(SA638)]
LH28F008SCH-V@TSOP40 [(SA409T)]	
LH28F008SCH-ZU-120@TSOP40 [(SA409T)]	
LH28F008SCN@PSOP44 [(SA638)]	LH28F008SCN-L@PSOP44 [(SA638)]
LH28F008SCT@TSOP40 [(SA409T)]	LH28F008SCT-L@TSOP40 [(SA409T)]
LH28F008SCT-V@TSOP40 [(SA409T)]	LH28F008SCV@TSOP40 [(SA409T)]
LH28F016SC@PSOP44 [(SA638)]	
LH28F016SCR(L95)@RTSOP40 [(SA409T)]	
LH28F016SCT-L95@TSOP40 [(SA409T)]	
LHF00L03@PLCC32 [(SA015A1T)]	LHF00L04@TSOP40 [(SA409T)]
LHF00L06@TSOP40 [(SA409T)]	LHF00L07@PLCC32 [(SA015A1T)]

SIEMENS**E(E) PROM/FRAM/NVRAM**

SDA2526	SDA2526@SOIC8 [(SA602A)]
SDA2546	SDA2546@SOIC8 [(SA602A)]
SDA25X26	SDA25X26@SOIC8 [(SA602A)]
SDA25X46	SDA25X46@SOIC8 [(SA602A)]
SDE2526	SDE2526@SOIC8 [(SA602A)]
SDE2546	SDE2546@SOIC8 [(SA602A)]
SDE25X26	SDE25X26@SOIC8 [(SA602A)]
SDE25X46	SDE25X46@SOIC8 [(SA602A)]
SLA24C01	SLA24C01@SOIC8 [(SA602A)]
SLA24C02	SLA24C02@SOIC8 [(SA602A)]
SLA24C04	SLA24C04@SOIC8 [(SA602A)]
SLA24C08	SLA24C08@SOIC8 [(SA602A)]
SLA24C16	SLA24C16@SOIC8 [(SA602A)]
SLA24C164	SLA24C164@SOIC8 [(SA602A)]
SLA24C32	SLA24C32@SOIC8 [(SA602A)]
SLA24C64	SLA24C64@SOIC8 [(SA602A)]

SLA25010	SLA25010@SOIC8 [(SA602A)]
SLA25020	SLA25020@SOIC8 [(SA602A)]
SLA25040	SLA25040@SOIC8 [(SA602A)]
SLA25080	SLA25080@SOIC8 [(SA602A)]
SLA25160	SLA25160@SOIC8 [(SA602A)]
SLE24C01	SLE24C01@SOIC8 [(SA602A)]
SLE24C02	SLE24C02@SOIC8 [(SA602A)]
SLE24C04	SLE24C04@SOIC8 [(SA602A)]
SLE24C08	SLE24C08@SOIC8 [(SA602A)]
SLE24C16	SLE24C16@SOIC8 [(SA602A)]
SLE24C164	SLE24C164@SOIC8 [(SA602A)]
SLE24C32	SLE24C32@SOIC8 [(SA602A)]
SLE24C64	SLE24C64@SOIC8 [(SA602A)]
SLE25010	SLE25010@SOIC8 [(SA602A)]
SLE25020	SLE25020@SOIC8 [(SA602A)]
SLE25040	SLE25040@SOIC8 [(SA602A)]
SLE25080	SLE25080@SOIC8 [(SA602A)]
SLE25160	SLE25160@SOIC8 [(SA602A)]

SIGNETICS

E(E) PROM/FRAM/NVRAM

27C010	27C010@PLCC32 [(SA015A1T)]
27C010@TSOP32 [(SA410T)]	27C040
27C040@PLCC32 [(SA015A1T)]	27C040@TSOP32 [(SA410T)]
27C210	27C210@PLCC44 [(SA244)]
27C240	27C240@PLCC44 [(SA244)]
27C256	27C256@PLCC32 [(SA015A1T)]
27C512	27C512@PLCC32 [(SA015A1T)]
27C64A	27C64A@PLCC32 [(SA015A1T)]
27HC641	27HC641@PLCC28 [(SA008A)]
27HC642	27HC642@PLCC28 [(SA008A)]
PCA8582A	PCA8582A@SOIC8 [(SA602A)]
PCA8582B	PCA8582B@SOIC8 [(SA602A)]
PCA8582C	PCA8582C@SOIC8 [(SA602A)]
PCA8582D	PCA8582D@SOIC8 [(SA602A)]
PCA8582E	PCA8582E@SOIC8 [(SA602A)]
PCD8582A	PCD8582A@SOIC8 [(SA602A)]
PCD8582B	PCD8582B@SOIC8 [(SA602A)]
PCD8582C	PCD8582C@SOIC8 [(SA602A)]
PCD8582D	PCD8582D@SOIC8 [(SA602A)]
PCD8582E	PCD8582E@SOIC8 [(SA602A)]
PCF8582A	PCF8582A@SOIC8 [(SA602A)]
PCF8582B	PCF8582B@SOIC8 [(SA602A)]
PCF8582C	PCF8582C@SOIC8 [(SA602A)]
PCF8582D	PCF8582D@SOIC8 [(SA602A)]
PCF8582E	PCF8582E@SOIC8 [(SA602A)]
PCF8594	PCF8594@SOIC8 [(SA602A)]
PCF8594C	PCF8594C@SOIC8 [(SA602A)]
PCF8594D	PCF8594D@SOIC8 [(SA602A)]
PCF8594E	PCF8594E@SOIC8 [(SA602A)]
PCF8598	PCF8598@SOIC8 [(SA605A)]
PCF8598C	PCF8598C@SOIC8 [(SA605A)]
PCF8598D	PCF8598D@SOIC8 [(SA605A)]
PCF8598E	PCF8598E@SOIC8 [(SA605A)]

MICROCONTROLLER

S87C51	S87C51@PLCC44 [(SA244)]
S87C51@TQFP44 [(SA245A)]	S87C51FA
S87C51FA@PLCC44 [(SA244)]	S87C51FA@TQFP44 [(SA245A)]
S87C51FB	S87C51FB@PLCC44 [(SA244)]
S87C51FB@TQFP44 [(SA245A)]	S87C51FC
S87C51FC@PLCC44 [(SA244)]	S87C51FC@TQFP44 [(SA245A)]
S87C52	S87C52@PLCC44 [(SA244)]
S87C52@TQFP44 [(SA245A)]	S87C524
S87C524@PLCC44 [(SA244)]	S87C524@TQFP44 [(SA245A)]
S87C528	S87C528@PLCC44 [(SA244)]
S87C528@TQFP44 [(SA245A)]	S87C54
S87C54@PLCC44 [(SA244)]	S87C54@TQFP44 [(SA245A)]
S87C550	S87C550@PLCC44 [(SA244)]
S87C552@PLCC68(*) [(SA648-B6806)]	
S87C554@PLCC68(*) [(SA648-B6806)]	
S87C575	S87C575@PLCC44 [(SA244)]
S87C575@TQFP44 [(SA245A)]	S87C576

S87C576@PLCC44 [(SA244)]	S87C576@TQFP44 [(SA245A)]
S87C58	S87C58@PLCC44 [(SA244)]
S87C58@TQFP44 [(SA245A)]	S87C591@PLCC44 [(SA244)]
S87C591@TQFP44 [(SA245A)]	S87C652
S87C652@PLCC44 [(SA244)]	S87C652@TQFP44 [(SA245A)]
S87C654	S87C654@PLCC44 [(SA244)]
S87C654@TQFP44 [(SA245A)]	S87C748
S87C748@PLCC28 [(SA008A)]	S87C749
S87C749@PLCC28 [(SA008A)]	S87C750
S87C750@PLCC28 [(SA008A)]	S87C750@SSOP24 [(SA626A)]
S87C751	S87C751@PLCC28 [(SA008A)]
S87C751@SSOP24 [(SA626A)]	S87C752
S87C752@PLCC28 [(SA008A)]	S87C752@SSOP28 [(SA626A)]
S87C754	S87C754@PLCC28 [(SA008A)]
S87C754@SSOP28 [(SA626A)]	S87L51FA
S87L51FA@PLCC44 [(SA244)]	S87L51FA@TQFP44 [(SA245A)]
S87L51FB	S87L51FB@PLCC44 [(SA244)]
S87L51FB@TQFP44 [(SA245A)]	

Silicon Laboratories

MICROCONTROLLER

C8051F000@TQFP64(ISP) [(PEP+S616)]	C8051F001@TQFP48(ISP) [(SA248)]
C8051F001@TQFP48 [(SA248)]	C8051F002@TQFP32(ISP) [(SA663)]
C8051F002@TQFP32 [(SA663)]	C8051F005@TQFP64(ISP) [(PEP+S616)]
C8051F005@TQFP64(ISP) [(PEP+S616)]	C8051F006@TQFP48(ISP) [(SA248)]
C8051F006@TQFP48 [(SA248)]	C8051F007@TQFP32(ISP) [(SA663)]
C8051F007@TQFP32 [(SA663)]	C8051F010@TQFP64(ISP) [(PEP+S616)]
C8051F010@TQFP64(ISP) [(PEP+S616)]	C8051F011@TQFP48(ISP) [(SA248)]
C8051F011@TQFP48 [(SA248)]	C8051F012@TQFP32(ISP) [(SA663)]
C8051F012@TQFP32 [(SA663)]	C8051F015@TQFP64(ISP) [(PEP+S616)]
C8051F015@TQFP64(ISP) [(PEP+S616)]	C8051F016@TQFP48(ISP) [(SA248)]
C8051F016@TQFP48 [(SA248)]	C8051F017@TQFP32(ISP) [(SA663)]
C8051F017@TQFP32 [(SA663)]	C8051F018@TQFP64(ISP) [(PEP+S616)]
C8051F018@TQFP64(ISP) [(PEP+S616)]	C8051F019@TQFP48(ISP) [(SA248)]
C8051F019@TQFP48 [(SA248)]	C8051F020@TQFP100(ISP) [ISP-HEADER01]
C8051F020@TQFP100(ISP) [ISP-HEADER01]	C8051F021@TQFP64(ISP) [ISP-HEADER01]
C8051F021@TQFP64(ISP) [ISP-HEADER01]	C8051F022@TQFP100(ISP) [ISP-HEADER01]
C8051F022@TQFP100(ISP) [ISP-HEADER01]	C8051F023@TQFP64(ISP) [ISP-HEADER01]
C8051F023@TQFP64(ISP) [ISP-HEADER01]	C8051F040@TQFP100(ISP) [ISP-HEADER01]
C8051F040@TQFP100(ISP) [ISP-HEADER01]	C8051F041@TQFP64(ISP) [ISP-HEADER01]
C8051F041@TQFP64(ISP) [ISP-HEADER01]	C8051F042@TQFP100(ISP) [ISP-HEADER01]
C8051F042@TQFP100(ISP) [ISP-HEADER01]	C8051F043@TQFP64(ISP) [ISP-HEADER01]
C8051F043@TQFP64(ISP) [ISP-HEADER01]	C8051F044@TQFP100(ISP) [ISP-HEADER01]
C8051F044@TQFP100(ISP) [ISP-HEADER01]	C8051F045@TQFP64(ISP) [ISP-HEADER01]
C8051F045@TQFP64(ISP) [ISP-HEADER01]	C8051F046@TQFP100(ISP) [ISP-HEADER01]
C8051F046@TQFP100(ISP) [ISP-HEADER01]	C8051F047@TQFP64(ISP) [ISP-HEADER01]
C8051F047@TQFP64(ISP) [ISP-HEADER01]	C8051F220@TQFP48 [(SA248)]
C8051F206@TQFP48 [(SA248)]	C8051F226@TQFP48 [(SA248)]
C8051F221@TQFP32 [(SA663)]	C8051F231@TQFP32 [(SA663)]
C8051F222@TQFP32 [(SA663)]	C8051F300 [(SA695A)]
C8051F230@TQFP48 [(SA248)]	C8051F302 [(SA695A)]
C8051F236@TQFP48 [(SA248)]	C8051F304 [(SA695A)]
C8051F301 [(SA695A)]	C8051F310@TQFP32 [(SA663)]
C8051F303 [(SA695A)]	C8051F311@QFN28 [(SA697-B006)]
C8051F305 [(SA695A)]	C8051F312-GQ@TQFP32 [(SA663)]
C8051F310-GQ@TQFP32 [(SA663)]	C8051F314-GQ@TQFP32 [(SA663)]
C8051F311-GM@QFN28 [(SA697-B006)]	C8051F315@QFN28 [(SA697-B006)]
C8051F312@TQFP32 [(SA663)]	C8051F315-GM@QFN28 [(SA697-B006)]
C8051F313@QFN28 [(SA697-B006)]	C8051F316-GM@QFN24 [(SA710-B006)]
C8051F313-GM@QFN28 [(SA697-B006)]	C8051F317-GM@QFN24 [(SA710-B006)]
C8051F314@TQFP32 [(SA663)]	C8051F320@TQFP32 [(SA663)]
C8051F315@QFN28 [(SA697-B006)]	C8051F321@QFN28 [(SA697-B006)]
C8051F315-GM@QFN28 [(SA697-B006)]	C8051F326@QFN28 [(SA697-B006)]
C8051F316-GM@QFN24 [(SA710-B006)]	C8051F326-GQ@QFN28 [(SA697-B006)]
C8051F317-GM@QFN24 [(SA710-B006)]	C8051F327@QFN28 [(SA697-B006)]
C8051F320@TQFP32 [(SA663)]	C8051F327-GQ@QFN28 [(SA697-B006)]
C8051F326@QFN28 [(SA697-B006)]	C8051F330@MLP20 [(SA692)]
C8051F326-GQ@QFN28 [(SA697-B006)]	C8051F331@MLP20 [(SA692)]
C8051F327@QFN28 [(SA697-B006)]	C8051F333-GM@MLP20 [(SA692)]
C8051F327-GQ@QFN28 [(SA697-B006)]	C8051F335-GM@MLP20 [(SA692)]
C8051F330@MLP20 [(SA692)]	C8051F337-GM@QFN20 [(SA692)]
C8051F331@MLP20 [(SA692)]	C8051F339-GM@QFN24 [(SA710)]
C8051F333-GM@MLP20 [(SA692)]	C8051F330D
C8051F335-GM@MLP20 [(SA692)]	C8051F332-GM@MLP20 [(SA692)]
C8051F337-GM@QFN20 [(SA692)]	C8051F334-GM@MLP20 [(SA692)]
C8051F339-GM@QFN24 [(SA710)]	C8051F336-GM@QFN20 [(SA692)]
	C8051F338-GM@QFN24 [(SA710)]
	C8051F340-GQ@TQFP48 [(SA248)]

C8051F341-GQ@TQFP48 [(SA248)]	C8051F342-GQ@LQFP32 [(SA663)]
C8051F343-GQ@LQFP32 [(SA663)]	C8051F344-GQ@TQFP48 [(SA248)]
C8051F345-GQ@TQFP48 [(SA248)]	C8051F346-GQ@LQFP32 [(SA663)]
C8051F347-GQ@LQFP32 [(SA663)]	C8051F350-GQ@LQFP32 [(SA663)]
C8051F351-GM@QFN28 [(SA697-B006)]	
C8051F352-GQ@LQFP32 [(SA663)]	
C8051F353-GM@QFN28 [(SA697-B006)]	
C8051F410-GQ@LQFP32 [(SA663)]	C8051F411-GM@QFN28 [(SA697)]
C8051F412-GQ@LQFP32 [(SA663)]	C8051F413-GM@QFN28 [(SA697)]
C8051F520-IM@QFN10 [(SA695A)]	C8051F521-IM@QFN10 [(SA695A)]
C8051F523-IM@QFN10 [(SA695A)]	C8051F524-IM@QFN10 [(SA695A)]
C8051F526-IM@QFN10 [(SA695A)]	C8051F527-IM@QFN10 [(SA695A)]
C8051F530-IM@QFN20 [(SA692)]	C8051F530-IT@TSSOP20 [(SA026)]
C8051F531-IM@QFN20 [(SA692)]	C8051F531-IT@TSSOP20 [(SA026)]
C8051F533-IM@QFN20 [(SA692)]	C8051F533-IT@TSSOP20 [(SA026)]
C8051F534-IM@QFN20 [(SA692)]	C8051F534-IT@TSSOP20 [(SA026)]
C8051F536-IM@QFN20 [(SA692)]	C8051F536-IT@TSSOP20 [(SA026)]
C8051F537-IM@QFN20 [(SA692)]	C8051F537-IT@TSSOP20 [(SA026)]
C8051F610-GQ@QFP32 [(SA663)]	
C8051F611-GM@QFN28 [(SA697-B006)]	
C8051F612-GQ@QFP32 [(SA663)]	
C8051F613-GM@QFN28 [(SA697-B006)]	
C8051F614-GQ@QFP32 [(SA663)]	
C8051F615-GM@QFN28 [(SA697-B006)]	
C8051F616-GM@QFN24 [(SA710-B006)]	
C8051F617-GM@QFN24 [(SA710-B006)]	
C8051T600@QFN11 [(SA695A)]	C8051T600@SOIC14 [(SA602)]
C8051T601@QFN11 [(SA695A)]	C8051T601@SOIC14 [(SA602)]
C8051T602@QFN11 [(SA695A)]	C8051T602@SOIC14 [(SA602)]
C8051T603@QFN11 [(SA695A)]	C8051T603@SOIC14 [(SA602)]
C8051T604@QFN11 [(SA695A)]	C8051T604@SOIC14 [(SA602)]
C8051T605@QFN11 [(SA695A)]	C8051T605@SOIC14 [(SA602)]
SI8250@LQFP32 [(SA663)]	SI8250@QFN28 [(SA697)]
SI8251@LQFP32 [(SA663)]	SI8251@QFN28 [(SA697)]
SI8252@LQFP32 [(SA663)]	SI8252@QFN28 [(SA697)]

SIMTEK

E(E) PROM/FRAM/NVRAM

STK10C48	
STK10C48@SOIC28(300 mil) [(SA404)]	
STK10C48@SOIC28(350 mil) [(SA630)]	
STK10C68	STK10C68@PLCC28 [(SA008A)]
STK10C68@SOIC28(350 mil) [(SA630)]	
STK11C48	
STK11C48@SOIC28(300 mil) [(SA404)]	
STK11C48@SOIC28(350 mil) [(SA630)]	
STK11C68	STK11C68@PLCC28 [(SA008A)]
STK11C68@SOIC28(350 mil) [(SA630)]	
STK11C88	STK11C88(3V)
STK11C88(3V)@SOIC28(300 mil) [(SA404)]	
STK11C88(3V)@SOIC28(350 mil) [(SA630)]	
STK11C88@SOIC28(300 mil) [(SA404)]	
STK11C88@SOIC28(350 mil) [(SA630)]	
STK12C68	STK12C68@PLCC28 [(SA008A)]
STK12C68@SOIC28(350 mil) [(SA630)]	
STK14C88	STK14C88(3V)
STK14C88(3V)@PLCC32 [(SA015A1T)]	
STK14C88(3V)@SOIC32(300 mil) [(SA715)]	
STK14C88(3V)@SOIC32(350 mil) [(SA630)]	
STK14C88@PLCC32 [(SA015A1T)]	
STK14C88@SOIC32(300 mil) [(SA715)]	
STK14C88@SOIC32(350 mil) [(SA630)]	
STK14CA8	STK14CA8@SOIC32 [(SA715)]
STK14CA8@SSOP48 [(SA669)]	STK14D88@SOIC32 [(SA715)]
STK14D88@SSOP48 [(SA669)]	STK15C68
STK15C68@SOIC28(350 mil) [(SA630)]	
STK15C88	
STK15C88@SOIC28(300 mil) [(SA404)]	
STK15C88@SOIC28(350 mil) [(SA630)]	
STK16C68	STK16C88
STK16C88(3V)	STK16CA8
STK20C04	STK22C48
STK22C48@SOIC28(300 mil) [(SA404)]	
STK22C48@SOIC28(350 mil) [(SA630)]	
STK25C48	

SMOS

E(E) PROM/FRAM/NVRAM

SPM27128	SPM27128C
SPM27C256	SPM27C64
SPM27C64H	

SONY

E(E) PROM/FRAM/NVRAM

CXK1011M@SOIC8 [(SA602A)]	CXK1011P
CXK1012P	CXK1013P
CXK1023P	CXK27C4001

DRAM & SRAM

CXK581000	CXK581000@SOIC32 [(SA630)]
-----------	----------------------------

SPACE ELECTRONICS[SEi]

E(E) PROM/FRAM/NVRAM

28C010	28C010@PLCC32 [(SA015A1T)]
28C010@TSOP32 [(SA410T)]	28C010T
28C010T@PLCC32 [(SA015A1T)]	28C010T@TSOP32 [(SA410T)]
28C011	28C011@PLCC32 [(SA015A1T)]
28C011@TSOP32 [(SA410T)]	28C011T
28C011T@PLCC32 [(SA015A1T)]	28C011T@TSOP32 [(SA410T)]

SPANSION

E(E) PROM/FRAM/NVRAM

AM29DL400BB@PSOP44 [(SA638-B006)]	
AM29DL400BB@TSOP48 [(SA247-B005)]	
AM29DL400BT@PLCC44 [(SA638-B006)]	
AM29DL400BT@TSOP48 [(SA247-B005)]	
AM29DL800B@PSOP44 [(SA638-B006)]	AM29DL800B@TSOP48 [(SA247-B005)]
AM29DL800BB@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29DL800BB@PSOP44 [(SA638)]	
AM29DL800BB@TSOP48 [(SA247-B005)]	
AM29DL800BT@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29DL800BT@PSOP44 [(SA638)]	
AM29DL800BT@TSOP48 [(SA247-B005)]	
AM29DL800T@PSOP44 [(SA638-B006)]	AM29DL800T@TSOP48 [(SA247-B005)]
AM29F002B	AM29F002B@PLCC32 [(SA015A1T)]
AM29F002B@TSOP32 [(SA410T)]	AM29F002BB
AM29F002BB@PLCC32 [(SA015A1T)]	AM29F002BB@TSOP32 [(SA410T)]
AM29F002BT	AM29F002BT@PLCC32 [(SA015A1T)]
AM29F002BT@TSOP32 [(SA410T)]	AM29F002NB
AM29F002NB@PLCC32 [(SA015A1T)]	AM29F002NB@TSOP32 [(SA410T)]
AM29F002NBB	AM29F002NBB@PLCC32 [(SA015A1T)]
AM29F002NBB@TSOP32 [(SA410T)]	AM29F002NBT
AM29F002NBT@PLCC32 [(SA015A1T)]	AM29F002NBT@TSOP32 [(SA410T)]
AM29F002NT	AM29F002NT@PLCC32 [(SA015A1T)]
AM29F002NT@TSOP32 [(SA410T)]	AM29F002T
AM29F002T@PLCC32 [(SA015A1T)]	AM29F002T@TSOP32 [(SA410T)]
AM29F004BB@PLCC32 [(SA015A1T)]	AM29F004BB@TSOP32 [(SA410T)]
AM29F004BT@PLCC32 [(SA015A1T)]	AM29F004BT@TSOP32 [(SA410T)]
AM29F010	AM29F010@PLCC32 [(SA015A1T)]
AM29F010@TSOP32 [(SA410T)]	AM29F010A
AM29F010A@PLCC32 [(SA015A1T)]	AM29F010A@TSOP32 [(SA410T)]
AM29F010B	AM29F010B@PLCC32 [(SA015A1T)]
AM29F010B@TSOP32 [(SA410T)]	AM29F016@PSOP44 [(SA638)]

AM29F016@TSOP40 [(SA409T)]	AM29F016@TSOP48 [(SA247-B005)]
AM29F016B@PSOP44 [(SA638)]	AM29F016B@TSOP40 [(SA409T)]
AM29F016B@TSOP48 [(SA247-B005)]	
AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016D@PSOP44 [(SA638)]	AM29F016D@TSOP40 [(SA409T)]
AM29F016D@TSOP48 [(SA247-B005)]	AM29F017B@TSOP48 [(SA247-B005)]
AM29F017D@TSOP40 [(SA409T)]	AM29F017D@TSOP48 [(SA247-B005)]
AM29F032B@PSOP44 [(SA638)]	AM29F032B@TSOP40 [(SA409T)]
AM29F040	AM29F040@PLCC32 [(SA015A1T)]
AM29F040@TSOP32 [(SA410T)]	AM29F040A
AM29F040A@PLCC32 [(SA015A1T)]	AM29F040A@TSOP32 [(SA410T)]
AM29F040B	
AM29F040B(Reverse)@TSOP32 [(SA410T)]	
AM29F040B@PLCC32 [(SA015A1T)]	AM29F040B@TSOP32 [(SA410T)]
AM29F080@PSOP44 [(SA638)]	AM29F080@TSOP40 [(SA409T)]
AM29F080B@PSOP44 [(SA638)]	AM29F080B@TSOP40 [(SA409T)]
AM29F100BE@PSOP44 [(SA638-B006)]	AM29F100BE@TSOP48 [(SA247-B005)]
AM29F100BS@PSOP44 [(SA638-B006)]	AM29F100BS@TSOP48 [(SA247-B005)]
AM29F100TE@PSOP44 [(SA638-B006)]	AM29F100TE@TSOP48 [(SA247-B005)]
AM29F100TS@PSOP44 [(SA638-B006)]	AM29F100TS@TSOP48 [(SA247-B005)]
AM29F160DB@TSOP48 [(SA247-B005)]	AM29F160DT@TSOP48 [(SA247-B005)]
AM29F200AB@PSOP44 [(SA638-B006)]	AM29F200AB@TSOP48 [(SA247-B005)]
AM29F200AT@PSOP44 [(SA638-B006)]	AM29F200AT@TSOP48 [(SA247-B005)]
AM29F200BB@PSOP44 [(SA638-B006)]	AM29F200BB@TSOP48 [(SA247-B005)]
AM29F200BE@PSOP44 [(SA638-B006)]	AM29F200BE@TSOP48 [(SA247-B005)]
AM29F200BS@PSOP44 [(SA638-B006)]	AM29F200BS@TSOP48 [(SA247-B005)]
AM29F200BT@PSOP44 [(SA638-B006)]	AM29F200BT@TSOP48 [(SA247-B005)]
AM29F200TE@PSOP44 [(SA638-B006)]	AM29F200TE@TSOP48 [(SA247-B005)]
AM29F200TS@PSOP44 [(SA638-B006)]	AM29F200TS@TSOP48 [(SA247-B005)]
AM29F400AB@PSOP44 [(SA638-B006)]	AM29F400AB@TSOP48 [(SA247-B005)]
AM29F400AT@PSOP44 [(SA638-B006)]	AM29F400AT@TSOP48 [(SA247-B005)]
AM29F400BB@PSOP44 [(SA638-B006)]	AM29F400BB@TSOP48 [(SA247-B005)]
AM29F400BBE@PSOP44 [(SA638-B006)]	
AM29F400BBE@TSOP48 [(SA247-B005)]	
AM29F400BBF@PSOP44 [(SA638-B006)]	
AM29F400BBF@TSOP48 [(SA247-B005)]	
AM29F400BBS@PSOP44 [(SA638-B006)]	
AM29F400BBS@TSOP48 [(SA247-B005)]	
AM29F400BE@PSOP44 [(SA638-B006)]	AM29F400BE@TSOP48 [(SA247-B005)]
AM29F400BF@PSOP44 [(SA638-B006)]	AM29F400BF@TSOP48 [(SA247-B005)]
AM29F400BS@PSOP44 [(SA638-B006)]	AM29F400BS@TSOP48 [(SA247-B005)]
AM29F400BT@PSOP44 [(SA638-B006)]	AM29F400BT@TSOP48 [(SA247-B005)]
AM29F400BTE@PSOP44 [(SA638-B006)]	
AM29F400BTE@TSOP48 [(SA247-B005)]	
AM29F400BTF@PSOP44 [(SA638-B006)]	
AM29F400BTF@TSOP48 [(SA247-B005)]	
AM29F400BTS@PSOP44 [(SA638-B006)]	
AM29F400BTS@TSOP48 [(SA247-B005)]	
AM29F800B@PSOP44 [(SA638-B006)]	AM29F800B@TSOP48 [(SA247-B005)]
AM29F800BB@PSOP44 [(SA638-B006)]	AM29F800BB@TSOP48 [(SA247-B005)]
AM29F800BBF@PSOP44 [(SA638-B006)]	
AM29F800BBF@TSOP48 [(SA247-B005)]	
AM29F800BF@PSOP44 [(SA638-B006)]	AM29F800BF@TSOP48 [(SA247-B005)]
AM29F800BT@PSOP44 [(SA638-B006)]	AM29F800BT@TSOP48 [(SA247-B005)]
AM29F800BTF@PSOP44 [(SA638-B006)]	
AM29F800BTF@TSOP48 [(SA247-B005)]	
AM29F800T@PSOP44 [(SA638-B006)]	AM29F800T@TSOP48 [(SA247-B005)]
AM29F800TB@PSOP44 [(SA638-B006)]	AM29F800TB@TSOP48 [(SA247-B005)]
AM29F800TF@PSOP44 [(SA638-B006)]	AM29F800TF@TSOP48 [(SA247-B005)]
AM29LL800B@TSOP48 [(SA247-B005)]	
AM29LL800BB@TSOP48 [(SA247-B005)]	
AM29LL800BT@TSOP48 [(SA247-B005)]	
AM29LL800T@TSOP48 [(SA247-B005)]	
AM29LV001BB@PLCC32 [(SA015A1T)]	AM29LV001BB@PLCC32 [(SA015A1T)]
AM29LV001BT@PLCC32 [(SA410T)]	AM29LV002@TSOP40 [(SA409T)]
AM29LV001BT@TSOP32 [(SA410T)]	AM29LV002BB@TSOP40 [(SA409T)]
AM29LV002B@TSOP40 [(SA409T)]	AM29LV004B@PSOP44 [(SA638)]
AM29LV002BT@TSOP40 [(SA409T)]	AM29LV004BB@TSOP40 [(SA409T)]
AM29LV004B@TSOP40 [(SA409T)]	AM29LV004T@PSOP44 [(SA638)]
AM29LV004BT@TSOP40 [(SA409T)]	AM29LV008B@PSOP44 [(SA638)]
AM29LV004T@TSOP40 [(SA409T)]	AM29LV008BB@TSOP40 [(SA409T)]
AM29LV008B@TSOP40 [(SA409T)]	AM29LV008T@PSOP44 [(SA638)]
AM29LV008BT@TSOP40 [(SA409T)]	AM29LV010B@PLCC32 [(SA015A1T)]
AM29LV008T@TSOP40 [(SA409T)]	AM29LV017B@TSOP40 [(SA409T)]
AM29LV010B@TSOP32 [(SA410T)]	AM29LV020B@TSOP32 [(SA410T)]
AM29LV020B@PLCC32 [(SA015A1T)]	AM29LV033MU@TSOP40 [(SA409T)]
AM29LV033C@TSOP40 [(SA409T)]	AM29LV040B@TSOP32 [(SA410T)]
AM29LV040B@PLCC32 [(SA015A1T)]	AM29LV040E@TSOP32 [(SA410T)]
AM29LV040E@PLCC32 [(SA015A1T)]	AM29LV040J@TSOP32 [(SA410T)]
AM29LV040J@PLCC32 [(SA015A1T)]	AM29LV081B@TSOP40 [(SA409T)]
AM29LV081@TSOP40 [(SA409T)]	AM29LV116BT@TSOP40 [(SA409T)]
AM29LV116BB@TSOP40 [(SA409T)]	

AM29LV116DB@TSOP40 [(SA409T)]	AM29LV116DT@TSOP40 [(SA409T)]
AM29LV200B@PSOP44 [(SA638-B006)]	AM29LV200B@TSOP48 [(SA247-B005)]
AM29LV200BB@PSOP44 [(SA638-B006)]	
AM29LV200BB@TSOP48 [(SA247-B005)]	
AM29LV200BE@PSOP44 [(SA638-B006)]	
AM29LV200BE@TSOP48 [(SA247-B005)]	
AM29LV200BF@PSOP44 [(SA638-B006)]	
AM29LV200BF@TSOP48 [(SA247-B005)]	
AM29LV200BS@PSOP44 [(SA638-B006)]	
AM29LV200BS@TSOP48 [(SA247-B005)]	
AM29LV200BT@PSOP44 [(SA638-B006)]	
AM29LV200BT@TSOP48 [(SA247-B005)]	
AM29LV200T@PSOP44 [(SA638-B006)]	AM29LV200T@TSOP48 [(SA247-B005)]
AM29LV200TE@PSOP44 [(SA638-B006)]	
AM29LV200TE@TSOP48 [(SA247-B005)]	
AM29LV200TF@PSOP44 [(SA638-B006)]	
AM29LV200TF@TSOP48 [(SA247-B005)]	
AM29LV200TS@PSOP44 [(SA638-B006)]	
AM29LV200TS@TSOP48 [(SA247-B005)]	
AM29LV400B@PSOP44 [(SA638-B006)]	AM29LV400B@TSOP48 [(SA247-B005)]
AM29LV400BB@FBGA48 [(SA642G-B026A-T048F001Y)]	
AM29LV400BB@PSOP44 [(SA638-B006)]	
AM29LV400BB@TSOP48 [(SA247-B005)]	
AM29LV400BT@FBGA48 [(SA642G-B026A-T048F001Y)]	
AM29LV400BT@PSOP44 [(SA638-B006)]	
AM29LV400BT@TSOP48 [(SA247-B005)]	
AM29LV400T@PSOP44 [(SA638-B006)]	AM29LV400T@TSOP48 [(SA247-B005)]
AM29LV800B@PSOP44 [(SA638-B006)]	AM29LV800B@TSOP48 [(SA247-B005)]
AM29LV800BB@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29LV800BB@PSOP44 [(SA638-B006)]	
AM29LV800BB@TSOP48 [(SA247-B005)]	
AM29LV800BT@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29LV800BT@PSOP44 [(SA638-B006)]	
AM29LV800BT@TSOP48 [(SA247-B005)]	
AM29LV800DB(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29LV800DB(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]	
AM29LV800DB@PSOP44 [(SA638)]	
AM29LV800DB@TSOP48 [(SA247-B005)]	
AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]	
AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]	
AM29LV800DT@PSOP44 [(SA638)]	
AM29LV800DT@TSOP48 [(SA247-B005)]	
AM29LV800T@PSOP44 [(SA638-B006)]	AM29LV800T@TSOP48 [(SA247-B005)]
MBM29F001B	MBM29F001B@PLCC32 [(SA015A1T)]
MBM29F001B@TSOP32 [(SA410T)]	MBM29F001T
MBM29F001T@PLCC32 [(SA015A1T)]	MBM29F001T@TSOP32 [(SA410T)]
MBM29F002B	MBM29F002B@PLCC32 [(SA015A1T)]
MBM29F002B@TSOP32 [(SA410T)]	MBM29F002NB
MBM29F002NB@PLCC32 [(SA015A1T)]	MBM29F002NB@TSOP32 [(SA410T)]
MBM29F002NT	MBM29F002NT@PLCC32 [(SA015A1T)]
MBM29F002NT@TSOP32 [(SA410T)]	MBM29F002T
MBM29F002T@PLCC32 [(SA015A1T)]	MBM29F002T@TSOP32 [(SA410T)]
MBM29F010	MBM29F010@PLCC32 [(SA015A1T)]
MBM29F010@TSOP32 [(SA410T)]	MBM29F010A
MBM29F010A@PLCC32 [(SA015A1T)]	MBM29F010A@TSOP32 [(SA410T)]
MBM29F016@PSOP44 [(SA638)]	MBM29F016@TSOP40 [(SA409T)]
MBM29F016@TSOP48 [(SA247-B005)]	MBM29F016A@PSOP44 [(SA638)]
MBM29F016A@TSOP40 [(SA409T)]	MBM29F016A@TSOP48 [(SA247-B005)]
MBM29F016B@PSOP44 [(SA638)]	MBM29F016B@TSOP40 [(SA409T)]
MBM29F016B@TSOP48 [(SA247-B005)]	MBM29F017B@TSOP48 [(SA247-B005)]
MBM29F017D@TSOP40 [(SA409T)]	MBM29F017D@TSOP48 [(SA247-B005)]
MBM29F032B@PSOP44 [(SA638)]	MBM29F032B@TSOP40 [(SA409T)]
MBM29F033C@TSOP40 [(SA409T)]	MBM29F040
MBM29F040@PLCC32 [(SA015A1T)]	MBM29F040@TSOP32 [(SA410T)]
MBM29F040B	MBM29F040B@PLCC32 [(SA015A1T)]
MBM29F040B@TSOP32 [(SA410T)]	MBM29F040C@PLCC32 [(SA015A1T)]
MBM29F040C@TSOP32 [(SA410T)]	MBM29F080@PSOP44 [(SA638)]
MBM29F080@TSOP48 [(SA409T)]	MBM29F080A@TSOP48 [(SA247-B005)]
MBM29F080B@PSOP44 [(SA638)]	MBM29F080B@TSOP40 [(SA409T)]
MBM29F100B@PSOP44 [(SA638-B006)]	MBM29F100B@TSOP48 [(SA247-B005)]
MBM29F100T@PSOP44 [(SA638-B006)]	MBM29F100T@TSOP48 [(SA247-B005)]
MBM29F160BE@TSOP48 [(SA247-B005)]	
MBM29F160TE@TSOP48 [(SA247-B005)]	
MBM29F200AB@PSOP44 [(SA638-B006)]	
MBM29F200AB@TSOP48 [(SA247-B005)]	
MBM29F200AT@PSOP44 [(SA638-B006)]	
MBM29F200AT@TSOP48 [(SA247-B005)]	
MBM29F200B@PSOP44 [(SA638-B006)]	MBM29F200B@TSOP48 [(SA247-B005)]
MBM29F200T@PSOP44 [(SA638-B006)]	MBM29F200T@TSOP48 [(SA247-B005)]
MBM29F400AB@PSOP44 [(SA638-B006)]	
MBM29F400AB@TSOP48 [(SA247-B005)]	

```

MBM29F400AT@PSOP44 [(SA638-B006)]
MBM29F400AT@TSOP48 [(SA247-B005)]
MBM29F400B@PSOP44 [(SA638-B006)] MBM29F400B@TSOP48 [(SA247-B005)]
MBM29F400BB@PSOP44 [(SA638-B006)]
MBM29F400BB@TSOP48 [(SA247-B005)]
MBM29F400BT@PSOP44 [(SA638-B006)]
MBM29F400BT@TSOP48 [(SA247-B005)]
MBM29F400T@PSOP44 [(SA638-B006)] MBM29F400T@TSOP48 [(SA247-B005)]
MBM29F800B@PSOP44 [(SA638-B006)] MBM29F800B@TSOP48 [(SA247-B005)]
MBM29F800BB@PSOP44 [(SA638-B006)]
MBM29F800BB@TSOP48 [(SA247-B005)]
MBM29F800BT@PSOP44 [(SA638-B006)]
MBM29F800BT@TSOP48 [(SA247-B005)]
MBM29F800T@PSOP44 [(SA638-B006)] MBM29F800T@TSOP48 [(SA247-B005)]
MBM29LL800B@TSOP48 [(SA247-B005)]
MBM29LL800BB@TSOP48 [(SA247-B005)]
MBM29LL800BT@TSOP48 [(SA247-B005)]
MBM29LL800T@TSOP48 [(SA247-B005)]
MBM29LV001B@PLCC32 [(SA015A1T)] MBM29LV001B@PLCC32 [(SA015A1T)]
MBM29LV001BB@TSOP32 [(SA410T)] MBM29LV001BC@PLCC32 [(SA015A1T)]
MBM29LV001BC@TSOP32 [(SA410T)] MBM29LV001BT@PLCC32 [(SA015A1T)]
MBM29LV001BT@TSOP32 [(SA410T)] MBM29LV001T@TSOP32 [(SA410T)]
MBM29LV001TC@PLCC32 [(SA015A1T)] MBM29LV001TC@TSOP32 [(SA410T)]
MBM29LV002B@TSOP40 [(SA409T)] MBM29LV002T@TSOP40 [(SA409T)]
MBM29LV004B@PSOP44 [(SA638)] MBM29LV004B@TSOP40 [(SA409T)]
MBM29LV004BB@TSOP40 [(SA409T)] MBM29LV004BT@TSOP40 [(SA409T)]
MBM29LV004T@PSOP44 [(SA638)] MBM29LV004T@TSOP40 [(SA409T)]
MBM29LV008B@PSOP44 [(SA638)] MBM29LV008B@TSOP40 [(SA409T)]
MBM29LV008BB@TSOP40 [(SA409T)] MBM29LV008BT@TSOP40 [(SA409T)]
MBM29LV008T@PSOP44 [(SA638)] MBM29LV008T@TSOP40 [(SA409T)]
MBM29LV016/B@TSOP40 [(SA409T)] MBM29LV016/T@TSOP40 [(SA409T)]
MBM29LV016B@TSOP40 [(SA409T)] MBM29LV017B@TSOP40 [(SA409T)]
MBM29LV017E@TSOP40 [(SA409T)] MBM29LV033C@TSOP40 [(SA409T)]
MBM29LV080@TSOP40 [(SA409T)] MBM29LV081@TSOP40 [(SA409T)]
MBM29LV081B@TSOP40 [(SA409T)] MBM29LV116B@TSOP40 [(SA409T)]
MBM29LV200B@PSOP44 [(SA638-B006)]
MBM29LV200B@TSOP48 [(SA247-B005)]
MBM29LV200BB@PSOP44 [(SA638-B006)]
MBM29LV200BB@TSOP48 [(SA247-B005)]
MBM29LV200BC@PSOP44 [(SA638)]
MBM29LV200BC@TSOP48 [(SA247-B005)]
MBM29LV200BT@PSOP44 [(SA638-B006)]
MBM29LV200BT@TSOP48 [(SA247-B005)]
MBM29LV200T@PSOP44 [(SA638-B006)]
MBM29LV200T@TSOP48 [(SA247-B005)]
MBM29LV200TC@PSOP44 [(SA638)]
MBM29LV200TC@TSOP48 [(SA247-B005)]
MBM29LV400B@PSOP44 [(SA638-B006)]
MBM29LV400B@TSOP48 [(SA247-B005)]
MBM29LV400BB@PSOP44 [(SA638-B006)]
MBM29LV400BB@TSOP48 [(SA247-B005)]
MBM29LV400BT@PSOP44 [(SA638-B006)]
MBM29LV400BT@TSOP48 [(SA247-B005)]
MBM29LV400T@PSOP44 [(SA638-B006)]
MBM29LV400T@TSOP48 [(SA247-B005)]
MBM29LV800B@PSOP44 [(SA638-B006)]
MBM29LV800B@SON46 [(SA631)]
MBM29LV800B@TSOP48 [(SA247-B005)]
MBM29LV800BB@PSOP44 [(SA638-B006)]
MBM29LV800BB@TSOP48 [(SA247-B005)]
MBM29LV800BT@PSOP44 [(SA638-B006)]
MBM29LV800BT@TSOP48 [(SA247-B005)]
MBM29LV800T@PSOP44 [(SA638-B006)]
MBM29LV800T@SON46 [(SA631)]
MBM29LV800T@TSOP48 [(SA247-B005)]
S25FL001D@SOIC8 [(SA602A)] S25FL001D@USON8 [(SA683)]
S25FL002A@SOIC8 [(SA605A)] S25FL002A@USON8 [(SA683)]
S25FL002D@SOIC8 [(SA602A)] S25FL002D@USON8 [(SA683)]
S25FL004A@SOIC8 [(SA605A)] S25FL004A@USON8 [(SA683)]
S25FL004D@SOIC8 [(SA602A)] S25FL004D@USON8 [(SA683)]
S25FL008A@SOIC8 [(SA605A)] S25FL008A@USON8 [(SA683)]
S25FL008D@SOIC8 [(SA602A)] S25FL008D@USON8 [(SA683)]
S25FL016A@SOIC16 [(SA404)]
S25FL016A@SOIC16(ISP) [ISP-HEADER01]
S25FL016A@SOIC8 [(SA605A)]
S25FL016A@SOIC8(ISP) [ISP-HEADER01]
S25FL016A@WSON8 [(SA684)]
S25FL016A@WSON8(ISP) [ISP-HEADER01]
S25FL016P@SOIC16 [(SA404)] S25FL016P@SOIC8 [(SA605A)]
S25FL016P@WSON8 [(SA684)] S25FL020A@SOIC8(4.0) [(SA602A)]
S25FL020A@SOIC8(5.4) [(SA605A)] S25FL020A@USON8 [(SA683)]

```


S25FL032A@SOIC16 [(SA404)]
 S25FL032A@SOIC16(ISP) [ISP-HEADER01]
 S25FL032A@WSON8 [(SA684)]
 S25FL032A@WSON8(ISP) [ISP-HEADER01]
 S25FL032P@WSON8 [(SA684)] S25FL03PA@SOIC16 [(SA404)]
 S25FL040A(Bottom Boot)@SOP8(4.0) [(SA602A)]
 S25FL040A(Bottom Boot)@SOP8(5.4) [(SA605A)]
 S25FL040A(Bottom Boot)@USON8 [(SA683)]
 S25FL040A(Top Boot)@SOP8(4.0) [(SA602A)]
 S25FL040A(Top Boot)@SOP8(5.4) [(SA605A)]
 S25FL040A(Top Boot)@USON8 [(SA683)]
 S25FL040A@SOP8(4.0) [(SA602A)] S25FL040A@SOP8(5.4) [(SA605A)]
 S25FL040A@USON8 [(SA683)] S25FL064A@SOIC16 [(SA404)]
 S25FL064A@SOIC16(ISP) [ISP-HEADER01]
 S25FL064A@WSON8 [(SA684)]
 S25FL064A@WSON8(ISP) [ISP-HEADER01]
 S25FL064P@SOIC16 [(SA404)] S25FL064P@WSON8 [(SA684)]
 S25FL080A@SOIC8(4.0) [(SA602A)] S25FL080A@SOIC8(5.4) [(SA605A)]
 S25FL080A@USON8 [(SA683)]
 S25FL128P(256 KB)@SOIC16 [(SA404)]
 S25FL128P(256 KB)@SOIC16(ISP) [ISP-HEADER01]
 S25FL128P(256 KB)@WSON8 [(SA684)]
 S25FL128P(256 KB)@WSON8(ISP) [ISP-HEADER01]
 S25FL128P(64 KB)@SOIC16 [(SA404)]
 S25FL128P(64 KB)@SOIC16(ISP) [ISP-HEADER01]
 S25FL128P(64 KB)@WSON8 [(SA684)]
 S25FL128P(64 KB)@WSON8(ISP) [ISP-HEADER01]
 S25FLK05D@SOIC8 [(SA602A)] S25FLK05D@USON8 [(SA683)]

SSSC

MICROCONTROLLER

SSU7301 SSU7301@PLCC44 [(SA244)]
 SSU7301@TQFP44 [(SA245A)]

SST

E(E) PROM/FRAM/NVRAM

SST25LF010@SOIC8(4.0) [(SA602A)] SST25LF010@SOIC8(5.4) [(SA605B)]
 SST25LF010@WSON8 [(SA683)]
 SST25LF010A@SOIC8(4.0) [(SA602A)]
 SST25LF010A@SOIC8(5.4) [(SA605B)]
 SST25LF010A@WSON8 [(SA683)]
 SST25LF016A@SOIC8(4.0) [(SA602A)]
 SST25LF016A@SOIC8(5.4) [(SA605A)]
 SST25LF016A@WSON8 [(SA683)]
 SST25LF016B@SOIC8(4.0) [(SA602A)]
 SST25LF016B@SOIC8(5.4) [(SA605A)]
 SST25LF016B@WSON8 [(SA683)] SST25LF020@SOIC8(4.0) [(SA602A)]
 SST25LF020@SOIC8(5.4) [(SA605B)] SST25LF020@WSON8 [(SA683)]
 SST25LF020A@SOIC8(4.0) [(SA602A)]
 SST25LF020A@SOIC8(5.4) [(SA605B)]
 SST25LF020A@WSON8 [(SA683)] SST25LF040@SOIC8(4.0) [(SA602A)]
 SST25LF040@SOIC8(5.4) [(SA605B)] SST25LF040@WSON8 [(SA683)]
 SST25LF040A@SOIC8(4.0) [(SA602A)]
 SST25LF040A@SOIC8(5.4) [(SA605B)]
 SST25LF040A@WSON8 [(SA683)] SST25LF080@SOIC8(4.0) [(SA602A)]
 SST25LF080@SOIC8(5.4) [(SA605B)] SST25LF080@WSON8 [(SA683)]
 SST25LF080A@SOIC8(4.0) [(SA602A)]
 SST25LF080A@SOIC8(5.4) [(SA605B)]
 SST25LF080A@WSON8 [(SA683)] SST25VF010@SOIC8(4.0) [(SA602A)]
 SST25VF010@SOIC8(5.4) [(SA605B)] SST25VF010@WSON8 [(SA683)]
 SST25VF010A@SOIC8(4.0) [(SA602A)]
 SST25VF010A@SOIC8(5.4) [(SA605B)]
 SST25VF010A@WSON8 [(SA683)]
 SST25VF016B@SOIC8(4.0) [(SA602A)]
 SST25VF016B@SOIC8(5.4) [(SA605A)]
 SST25VF016B@WSON8 [(SA683)] SST25VF020@SOIC8(4.0) [(SA602A)]
 SST25VF020@SOIC8(5.4) [(SA605B)] SST25VF020@WSON8 [(SA683)]
 SST25VF032B@SOIC8(4.0) [(SA602A)]
 SST25VF032B@SOIC8(5.4) [(SA605A)]
 SST25VF032B@WSON8 [(SA683)] SST25VF040@SOIC8(4.0) [(SA602A)]

```

SST25VF040@SOIC8(5.4) [(SA605B)]      SST25VF040@WSON8 [(SA683)]
SST25VF040B@SOIC8(4.0) [(SA602A)]
SST25VF040B@SOIC8(5.4) [(SA605A)]
SST25VF040B@WSON8 [(SA683)]          SST25VF064C@SOIC16 [(SA404)]
SST25VF064C@WSON8 [(SA684)]          SST25VF080@SOIC8(4.0) [(SA602A)]
SST25VF080@SOIC8(5.4) [(SA605B)]    SST25VF080@WSON8 [(SA683)]
SST25VF080B@SOIC8(4.0) [(SA602A)]
SST25VF080B@SOIC8(5.4) [(SA605A)]
SST25VF080B@WSON8 [(SA683)]
SST25VF512@SOIC8(5.4) [(SA605B)]    SST25VF512@SOIC8(4.0) [(SA602A)]
SST25VF512A@SOIC8(4.0) [(SA602A)]  SST25VF512@WSON8 [(SA683)]
SST25VF512A@SOIC8(5.4) [(SA605B)]
SST25VF512A@WSON8 [(SA683)]
SST25WF020@SOIC8 [(SA602A)]
SST25WF080@SOIC8 [(SA602A)]
SST27SF010
SST27SF010@TSOP32 [(SA410T)]
SST27SF020@PLCC32 [(SA015A1T)]
SST27SF256
SST27SF256@VSOP32 [(SA620)]
SST27SF512@PLCC32 [(SA015A1T)]
SST27VF010
SST27VF010@TSOP32 [(SA410T)]
SST27VF020@PLCC32 [(SA015A1T)]
SST27VF040
SST27VF040@TSOP32 [(SA410T)]
SST27VF256@PLCC32 [(SA015A1T)]
SST27VF512
SST27VF512@VSOP32 [(SA620)]
SST28EE011@PLCC32 [(SA015A1T)]
SST28LE011
SST28LE011@TSOP32 [(SA410T)]
SST28LF040@PLCC32 [(SA015A1T)]
SST28SF040
SST28SF040@TSOP32 [(SA410T)]
SST28SF040A@PLCC32 [(SA015A1T)]
SST28VE011
SST28VE011@TSOP32 [(SA410T)]
SST28VF040@PLCC32 [(SA015A1T)]
SST28VF040A
SST28VF040A@TSOP32 [(SA410T)]
SST29EE010@PLCC32 [(SA015A1T)]
SST29EE020
SST29EE020@TSOP32 [(SA410T)]
SST29EE512@PLCC32 [(SA015A1T)]
SST29LE010
SST29LE010@TSOP32 [(SA410T)]
SST29LE020@PLCC32 [(SA015A1T)]
SST29LE512
SST29LE512@TSOP32 [(SA410T)]
SST29SF010@PLCC32 [(SA015A1T)]
SST29SF020
SST29SF020@VSOP32 [(SA620)]
SST29SF040@PLCC32 [(SA015A1T)]
SST29SF512
SST29SF512@VSOP32 [(SA620)]
SST29VE010@PLCC32 [(SA015A1T)]
SST29VE020
SST29VE020@TSOP32 [(SA410T)]
SST29VE512@PLCC32 [(SA015A1T)]
SST29VF010
SST29VF010@VSOP32 [(SA620)]
SST29VF020@PLCC32 [(SA015A1T)]
SST29VF040
SST29VF040@VSOP32 [(SA620)]
SST29VF512@PLCC32 [(SA015A1T)]
SST31LF021@VSOP32 [(SA620)]
SST31LF041A@VSOP32 [(SA620)]
SST31LF043A@VSOP32 [(SA620)]
SST37VF010@PLCC32 [(SA015A1T)]
SST37VF020
SST37VF020@VSOP32 [(SA620)]
SST37VF040@PLCC32 [(SA015A1T)]
SST37VF512
SST37VF512@VSOP32 [(SA620)]
SST39LF010@VSOP32 [(SA620)]
SST39LF020@PLCC32 [(SA015A1T)]
SST39LF040@PLCC32 [(SA015A1T)]
SST39LF080@TSOP40 [(SA409T)]
SST39LF512@PLCC32 [(SA015A1T)]
SST39LH010
SST25VF040@WSON8 [(SA683)]
SST25VF064C@SOIC16 [(SA404)]
SST25VF080@SOIC8(4.0) [(SA602A)]
SST25VF080@WSON8 [(SA683)]
SST25VF512@SOIC8(4.0) [(SA602A)]
SST25VF512@WSON8 [(SA683)]
SST25WF010@SOIC8 [(SA602A)]
SST25WF040@SOIC8 [(SA602A)]
SST25WF512@SOIC8 [(SA602A)]
SST27SF010@PLCC32 [(SA015A1T)]
SST27SF020
SST27SF020@TSOP32 [(SA410T)]
SST27SF256@PLCC32 [(SA015A1T)]
SST27SF512
SST27SF512@VSOP32 [(SA620)]
SST27VF010@PLCC32 [(SA015A1T)]
SST27VF020
SST27VF020@TSOP32 [(SA410T)]
SST27VF040@PLCC32 [(SA015A1T)]
SST27VF256
SST27VF256@VSOP32 [(SA620)]
SST27VF512@PLCC32 [(SA015A1T)]
SST28EE011
SST28EE011@TSOP32 [(SA410T)]
SST28LE011@PLCC32 [(SA015A1T)]
SST28LF040
SST28LF040@TSOP32 [(SA410T)]
SST28SF040@PLCC32 [(SA015A1T)]
SST28SF040A
SST28SF040A@TSOP32 [(SA410T)]
SST28VE011@PLCC32 [(SA015A1T)]
SST28VF040
SST28VF040@TSOP32 [(SA410T)]
SST28VF040A@PLCC32 [(SA015A1T)]
SST29EE010
SST29EE010@TSOP32 [(SA410T)]
SST29EE020@PLCC32 [(SA015A1T)]
SST29EE512
SST29EE512@TSOP32 [(SA410T)]
SST29LE010@PLCC32 [(SA015A1T)]
SST29LE020
SST29LE020@TSOP32 [(SA410T)]
SST29LE512@PLCC32 [(SA015A1T)]
SST29SF010
SST29SF010@VSOP32 [(SA620)]
SST29SF020@PLCC32 [(SA015A1T)]
SST29SF040
SST29SF040@VSOP32 [(SA620)]
SST29SF512@PLCC32 [(SA015A1T)]
SST29VE010
SST29VE010@TSOP32 [(SA410T)]
SST29VE020@PLCC32 [(SA015A1T)]
SST29VE512
SST29VE512@TSOP32 [(SA410T)]
SST29VF010@PLCC32 [(SA015A1T)]
SST29VF020
SST29VF020@VSOP32 [(SA620)]
SST29VF040@PLCC32 [(SA015A1T)]
SST29VF512
SST29VF512@VSOP32 [(SA620)]
SST31LF041@VSOP40 [(SA623)]
SST31LF043@VSOP40 [(SA623)]
SST37VF010
SST37VF010@VSOP32 [(SA620)]
SST37VF020@PLCC32 [(SA015A1T)]
SST37VF040
SST37VF040@VSOP32 [(SA620)]
SST37VF512@PLCC32 [(SA015A1T)]
SST39LF010@PLCC32 [(SA015A1T)]
SST39LF016@TSOP40 [(SA409T)]
SST39LF020@VSOP32 [(SA620)]
SST39LF040@VSOP32 [(SA620)]
SST39LF080Q@TSOP40 [(SA409T)]
SST39LF512@VSOP32 [(SA620)]
SST39LH010@PLCC32 [(SA015A1T)]

```

SST39LH010@TSOP32 [(SA410T)]	SST39LH040
SST39LH040@PLCC32 [(SA015A1T)]	SST39LH040@TSOP32 [(SA410T)]
SST39LH512	SST39LH512@PLCC32 [(SA015A1T)]
SST39LH512@TSOP32 [(SA410T)]	SST39SF010
SST39SF010@PLCC32 [(SA015A1T)]	SST39SF010@VSOP32 [(SA620)]
SST39SF010A	SST39SF010A@PLCC32 [(SA015A1T)]
SST39SF010A@VSOP32 [(SA620)]	SST39SF020
SST39SF020@PLCC32 [(SA015A1T)]	SST39SF020@VSOP32 [(SA620)]
SST39SF020A	SST39SF020A@PLCC32 [(SA015A1T)]
SST39SF020A@VSOP32 [(SA620)]	SST39SF020P
SST39SF020P@PLCC32 [(SA015A1T)]	SST39SF020P@VSOP32 [(SA620)]
SST39SF040	SST39SF040@PLCC32 [(SA015A1T)]
SST39SF040@VSOP32 [(SA620)]	SST39SF040P
SST39SF040P@PLCC32 [(SA015A1T)]	SST39SF040P@VSOP32 [(SA620)]
SST39SF512	SST39SF512@PLCC32 [(SA015A1T)]
SST39SF512@VSOP32 [(SA620)]	SST39SF512A
SST39SF512A@PLCC32 [(SA015A1T)]	SST39SF512A@VSOP32 [(SA620)]
SST39VF010	SST39VF010@PLCC32 [(SA015A1T)]
SST39VF010@VSOP32 [(SA620)]	SST39VF016@TSOP40 [(SA409T)]
SST39VF016Q@TSOP40 [(SA409T)]	SST39VF020
SST39VF020@PLCC32 [(SA015A1T)]	SST39VF020@VSOP32 [(SA620)]
SST39VF020P	SST39VF020P@PLCC32 [(SA015A1T)]
SST39VF020P@VSOP32 [(SA620)]	SST39VF040
SST39VF040@PLCC32 [(SA015A1T)]	SST39VF040@VSOP32 [(SA620)]
SST39VF040P	SST39VF040P@PLCC32 [(SA015A1T)]
SST39VF040P@VSOP32 [(SA620)]	SST39VF080@TSOP40 [(SA409T)]
SST39VF080Q@TSOP40 [(SA409T)]	SST39VF512
SST39VF512@PLCC32 [(SA015A1T)]	SST39VF512@VSOP32 [(SA620)]
SST45LF010@SOIC8 [(SA602A)]	SST45LF010@WSON8 [(SA683)]
SST45VF010@SOIC8 [(SA602A)]	SST45VF020@SOIC8 [(SA602A)]
SST45VF512@SOIC8 [(SA602A)]	SST49LF002@PLCC32 [(SA015A1T)]
SST49LF002@VSOP32 [(SA620)]	SST49LF002A@PLCC32 [(SA015A1T)]
SST49LF002A@VSOP32 [(SA620)]	SST49LF002B@PLCC32 [(SA015A1T)]
SST49LF003A@PLCC32 [(SA015A1T)]	SST49LF003A@VSOP32 [(SA620)]
SST49LF003B@PLCC32 [(SA015A1T)]	SST49LF004@PLCC32 [(SA015A1T)]
SST49LF004@VSOP32 [(SA620)]	SST49LF004A@PLCC32 [(SA015A1T)]
SST49LF004A@VSOP32 [(SA620)]	SST49LF004B@PLCC32 [(SA015A1T)]
SST49LF004B@VSOP32 [(SA620)]	SST49LF004B@VSOP40 [(SA409T)]
SST49LF004C@PLCC32 [(SA015A1T)]	SST49LF004C@VSOP32 [(SA620)]
SST49LF008@PLCC32 [(SA015A1T)]	SST49LF008@VSOP32 [(SA620)]
SST49LF008A@PLCC32 [(SA015A1T)]	SST49LF008A@TSOP40 [(SA409T)]
SST49LF008A@VSOP32 [(SA620)]	SST49LF008C@PLCC32 [(SA015A1T)]
SST49LF008C@VSOP32 [(SA620)]	SST49LF016C@PLCC32 [(SA015A1T)]
SST49LF016C@TSOP40 [(SA409T)]	SST49LF016C@VSOP32 [(SA620)]
SST49LF020@PLCC32 [(SA015A1T)]	SST49LF020@VSOP32 [(SA620)]
SST49LF020A@PLCC32 [(SA015A1T)]	SST49LF020A@VSOP32 [(SA620)]
SST49LF030A@PLCC32 [(SA015A1T)]	SST49LF030A@VSOP32 [(SA620)]
SST49LF040@PLCC32 [(SA015A1T)]	SST49LF040@VSOP32 [(SA620)]
SST49LF040A@PLCC32 [(SA015A1T)]	SST49LF040A@VSOP32 [(SA620)]
SST49LF040B@PLCC32 [(SA015A1T)]	SST49LF040B@TSOP40 [(SA409T)]
SST49LF040B@VSOP32 [(SA620)]	SST49LF080A@PLCC32 [(SA015A1T)]
SST49LF080A@VSOP32 [(SA620)]	SST49LF160C@PLCC32 [(SA015A1T)]
SST49LF160C@TSOP32 [(SA620)]	

MICROCONTROLLER

SST65P542R@SOIC28 [(SA404)]	SST89C54
SST89C54@PLCC44 [(SA244)]	SST89C54@TQFP44 [(SA245A)]
SST89C58	SST89C58@PLCC44 [(SA244)]
SST89C58@TQFP44 [(SA245A)]	SST89C58RC@PLCC44 [(SA244)]
SST89C58RC@TQFP44 [(SA245A)]	SST89C58RC@WQFN40 [(SA245A)]
SST89E516RD	SST89E516RD@PLCC44 [(SA244)]
SST89E516RD@TQFP44 [(SA245A)]	SST89E516RD2
SST89E516RD2@PLCC44 [(SA244)]	SST89E516RD2@TQFP44 [(SA245A)]
SST89E52RC	SST89E52RC@PLCC44 [(SA244)]
SST89E52RC@TQFP44 [(SA245A)]	SST89E52RD
SST89E52RD@PLCC44 [(SA244)]	SST89E52RD@TQFP44 [(SA245A)]
SST89E52RD2	SST89E52RD2@PLCC44 [(SA244)]
SST89E52RD2@TQFP44 [(SA245A)]	SST89E54RC
SST89E54RC@PLCC44 [(SA244)]	SST89E54RC@TQFP44 [(SA245A)]
SST89E54RD	SST89E54RD@PLCC44 [(SA244)]
SST89E54RD@TQFP44 [(SA245A)]	SST89E54RD2
SST89E54RD2@PLCC44 [(SA244)]	SST89E54RD2@TQFP44 [(SA245A)]
SST89E554RC	SST89E554RC@PLCC44 [(SA244)]
SST89E554RC@TQFP44 [(SA245A)]	SST89E564RD
SST89E564RD@PLCC44 [(SA244)]	SST89E564RD@TQFP44 [(SA245A)]
SST89E58RD	SST89E58RD@PLCC44 [(SA244)]
SST89E58RD@TQFP44 [(SA245A)]	SST89E58RD2
SST89E58RD2@PLCC44 [(SA244)]	SST89E58RD2@TQFP44 [(SA245A)]

SST89V516RD	SST89V516RD@PLCC44 [(SA244)]
SST89V516RD@TQFP44 [(SA245A)]	SST89V516RD2
SST89V516RD2@PLCC44 [(SA244)]	SST89V516RD2@TQFP44 [(SA245A)]
SST89V52RD	SST89V52RD@PLCC44 [(SA244)]
SST89V52RD@TQFP44 [(SA245A)]	SST89V52RD2
SST89V52RD2@PLCC44 [(SA244)]	SST89V52RD2@TQFP44 [(SA245A)]
SST89V54RD2	SST89V54RD2@PLCC44 [(SA244)]
SST89V54RD2@TQFP44 [(SA245A)]	SST89V54RC
SST89V554RC@PLCC44 [(SA244)]	SST89V554RC@TQFP44 [(SA245A)]
SST89V564RD	SST89V564RD@PLCC44 [(SA244)]
SST89V564RD@TQFP44 [(SA245A)]	SST89V58RD2
SST89V58RD2@PLCC44 [(SA244)]	SST89V58RD2@TQFP44 [(SA245A)]

ST

E(E) PROM/FRAM/NVRAM

ET2716	ETC2716
ETC2732	M24128
M24128@MLP8 [(SA724)]	M24128@SOIC8 [(SA602A)]
M24128@TSOP8 [(SA026)]	M24164
M24164@SOIC8 [(SA602A)]	M24256
M24256@MLP8 [(SA724)]	M24256@TSOP8 [(SA026)]
M24256[3.9]@SOIC8 [(SA602A)]	M24256[5.5]@SOIC8 [(SA605A)]
M24512	M24512@SOIC8 [(SA605A)]
M24512@TSOP8 [(SA026)]	M24C01
M24C01@MLP8 [(SA724)]	M24C01@SOIC8 [(SA602A)]
M24C01R	M24C01R@MLP8 [(SA724)]
M24C01R@SOIC8 [(SA602A)]	M24C01R@TSOP8 [(SA026)]
M24C01W	M24C01W@MLP8 [(SA724)]
M24C01W@SOIC8 [(SA602A)]	M24C01W@TSOP8 [(SA026)]
M24C02	M24C02@MLP8 [(SA724)]
M24C02@SOIC8 [(SA602A)]	M24C02R
M24C02R@MLP8 [(SA724)]	M24C02R@SOIC8 [(SA602A)]
M24C02R@TSOP8 [(SA026)]	M24C02W
M24C02W@MLP8 [(SA724)]	M24C02W@SOIC8 [(SA602A)]
M24C02W@TSOP8 [(SA026)]	M24C04
M24C04@MLP8 [(SA724)]	M24C04@SOIC8 [(SA602A)]
M24C04R	M24C04R@MLP8 [(SA724)]
M24C04R@SOIC8 [(SA602A)]	M24C04R@TSOP8 [(SA026)]
M24C04W	M24C04W@MLP8 [(SA724)]
M24C04W@SOIC8 [(SA602A)]	M24C04W@TSOP8 [(SA026)]
M24C08	M24C08@MLP8 [(SA724)]
M24C08@MSOP8 [(SA695A)]	M24C08@SOIC8 [(SA602A)]
M24C08@TSOP8 [(SA026)]	M24C08R
M24C08R@MLP8 [(SA724)]	M24C08R@MSOP8 [(SA695A)]
M24C08R@SOIC8 [(SA602A)]	M24C08R@TSOP8 [(SA026)]
M24C08W	M24C08W@MLP8 [(SA724)]
M24C08W@MSOP8 [(SA695A)]	M24C08W@SOIC8 [(SA602A)]
M24C08W@TSOP8 [(SA026)]	M24C128(BN)
M24C128(MN)@SOIC8 [(SA605A)]	M24C128(MW)@SOIC8 [(SA602A)]
M24C128@MLP8 [(SA724)]	M24C128B(BN)
M24C128B(MN)@SOIC8 [(SA605A)]	M24C128B(MW)@SOIC8 [(SA602A)]
M24C128B@MLP8 [(SA724)]	M24C16
M24C16@MLP8 [(SA724)]	M24C16@SOIC8 [(SA602A)]
M24C16R	M24C16R@MLP8 [(SA724)]
M24C16R@SOIC8 [(SA602A)]	M24C16R@TSOP8 [(SA026)]
M24C16W	M24C16W@MLP8 [(SA724)]
M24C16W@SOIC8 [(SA602A)]	M24C16W@TSOP8 [(SA026)]
M24C256(BN)	M24C256(MN)@SOIC8 [(SA605A)]
M24C256(MW)@SOIC8 [(SA602A)]	M24C256@MLP8 [(SA724)]
M24C256A(BN)	M24C256A(MN)@SOIC8 [(SA605A)]
M24C256A(MW)@SOIC8 [(SA602A)]	M24C256A@MLP8 [(SA724)]
M24C256B(BN)	M24C256B(MN)@SOIC8 [(SA605A)]
M24C256B(MW)@SOIC8 [(SA602A)]	M24C256B@MLP8 [(SA724)]
M24C256W(BN)	M24C256W(MN)@SOIC8 [(SA605A)]
M24C256W(MW)@SOIC8 [(SA602A)]	M24C256W@MLP8 [(SA724)]
M24C32(BN)	M24C32(DL)@TSSOP14 [(SA026)]
M24C32(DW)@TSSOP8 [(SA602A)]	M24C32(MN)@SOIC8 [(SA605A)]
M24C32(MW)@SOIC8 [(SA602A)]	M24C32@MLP8 [(SA724)]
M24C32W(BN)	M24C32W(DL)@TSSOP14 [(SA026)]
M24C32W(DW)@TSSOP8 [(SA602A)]	M24C32W(MN)@SOIC8 [(SA605A)]
M24C32W(MW)@SOIC8 [(SA602A)]	M24C32W@MLP8 [(SA724)]
M24C64(BN)	M24C64(DL)@TSSOP14 [(SA026)]
M24C64(DW)@TSSOP8 [(SA602A)]	M24C64(MN)@SOIC8 [(SA605A)]
M24C64(MW)@SOIC8 [(SA602A)]	M24C64@MLP8 [(SA724)]
M24C64W(BN)	M24C64W(DL)@TSSOP14 [(SA026)]

M24C64W(DW)@TSSOP8 [(SA602A)]	M24C64W(MN)@SOIC8 [(SA605A)]
M24C64W(MW)@SOIC8 [(SA602A)]	M24C64W@MLP8 [(SA724)]
M24CL04B	M24CL04B@MLP8 [(SA724)]
M24CL04B@SOIC8 [(SA602A)]	M24CL04B@TSOP8 [(SA026)]
M24E16	M24E32(BN)
M24E32(DW)@TSSOP8 [(SA602A)]	M24E32(MN)@SOIC8 [(SA605A)]
M24E32(MW)@SOIC8 [(SA602A)]	M24M01@LGA8 [(SA684)]
M24M01@SOIC8 [(SA023A)]	M24W01
M24W01@SOIC8 [(SA602A)]	M24W02
M24W02@SOIC8 [(SA602A)]	M24W04
M24W04@SOIC8 [(SA602A)]	M24W08
M24W08@SOIC8 [(SA602A)]	M24W16
M24W16@SOIC8 [(SA602A)]	M25C01
M25C02	M25C04
M25C08	M25C16
M25E16	M25P05@SOIC8 [(SA602A)]
M25P05@VQFPN8 [(SA683)]	M25P05-A@SOIC8 [(SA602A)]
M25P05-A@TSSOP8 [(SA605A)]	M25P05-A@VDFPN8 [(SA684)]
M25P10@SOIC8 [(SA602A)]	M25P10@VQFPN8 [(SA683)]
M25P10-A@SOIC8 [(SA602A)]	M25P10-A@VFQFPN8 [(SA684)]
M25P128@SOIC16 [(SA404)]	
M25P128@SOIC16(ISP) [ISP-HEADER01]	
M25P128@VDFPN8 [(SA684)]	
M25P128@VDFPN8(ISP) [ISP-HEADER01]	
M25P16@SOIC16 [(SA404)]	
M25P16@SOIC16(ISP) [ISP-HEADER01]	
M25P16@SOIC8(150mil) [(SA602A)]	
M25P16@SOIC8(150mil)(ISP) [ISP-HEADER01]	
M25P16@SOIC8(200mil) [(SA605A)]	
M25P16@SOIC8(200mil)(ISP) [ISP-HEADER01]	
M25P16@VDFPN8 [(SA684)]	
M25P16@VDFPN8(ISP) [ISP-HEADER01]	
M25P16@VFQFPN8 [(SA683)]	
M25P16@VFQFPN8(ISP) [ISP-HEADER01]	
M25P20@SOIC8 [(SA602A)]	M25P20@SOIC8(ISP) [ISP-HEADER01]
M25P20@VFQFPN8 [(SA683)]	
M25P20@VFQFPN8(ISP) [ISP-HEADER01]	
M25P32(Fast Mode)@SOIC16 [(SA404)]	
M25P32(Fast Mode)@VQFPN8 [(SA684)]	
M25P32@SOIC16 [(SA404)]	
M25P32@SOIC16(ISP) [ISP-HEADER01]	
M25P32@SOIC8 [(SA605A)]	M25P32@SOIC8(ISP) [ISP-HEADER01]
M25P32@VDFPN8 [(SA684)]	
M25P32@VDFPN8(ISP) [ISP-HEADER01]	
M25P32@VFQFPN8 [(SA683)]	
M25P32@VFQFPN8(ISP) [ISP-HEADER01]	
M25P40@SOIC8 [(SA602A)]	M25P40@SOIC8(ISP) [ISP-HEADER01]
M25P40@VFQFPN8 [(SA683)]	
M25P40@VFQFPN8(ISP) [ISP-HEADER01]	
M25P64(Fast Mode)@SOIC16 [(SA404)]	
M25P64(Fast Mode)@VDFPN8 [(SA684)]	
M25P64@SOIC16 [(SA404)]	
M25P64@SOIC16(ISP) [ISP-HEADER01]	
M25P64@VDFPN8 [(SA684)]	
M25P64@VDFPN8(ISP) [ISP-HEADER01]	
M25P80@SOIC16 [(SA404)]	
M25P80@SOIC16(ISP) [ISP-HEADER01]	
M25P80@SOIC8 [(SA605A)]	M25P80@SOIC8(ISP) [ISP-HEADER01]
M25P80@VFQFPN8 [(SA683)]	
M25P80@VFQFPN8(ISP) [ISP-HEADER01]	
M25PE10@SOIC8 [(SA602A)]	
M25PE10@SOIC8(ISP) [ISP-HEADER01]	
M25PE10@VQFPN8 [(SA683)]	
M25PE10@VQFPN8(ISP) [ISP-HEADER01]	
M25PE16@SOIC8 [(SA023A)]	M25PE16@VQFPN8 [(SA683)]
M25PE20@SOIC8 [(SA602A)]	
M25PE20@SOIC8(ISP) [ISP-HEADER01]	
M25PE20@VQFPN8 [(SA683)]	
M25PE20@VQFPN8(ISP) [ISP-HEADER01]	
M25PE40@SOIC8 [(SA023A)]	
M25PE40@SOIC8(ISP) [ISP-HEADER01]	
M25PE40@VQFPN8 [(SA683)]	
M25PE40@VQFPN8(ISP) [ISP-HEADER01]	
M25PE80@SOIC8 [(SA023A)]	
M25PE80@SOIC8(ISP) [ISP-HEADER01]	
M25PE80@VQFPN8 [(SA683)]	
M25PE80@VQFPN8(ISP) [ISP-HEADER01]	
M25PX32@SOIC16 [(SA404)]	M25PX32@SOIC8 [(SA023A)]
M25PX32@VFQFPN8 [(SA683)]	M25PX64@SOIC16 [(SA404)]
M25PX64@TBGA24 [(SA778)]	M25PX64@VDFPN8 [(SA684)]
M25W01	M25W02

M25W04		M25W08	
M25W16		M25W166	
M27128A		M2716	
M2716F1		M27256	
M27256A		M2732A	
M27512		M2764	
M2764A		M27C1000	
M27C1000@PLCC32 [(SA015A1T)]		M27C1000@TSOP32 [(SA410T)]	
M27C1001		M27C1001@PLCC32 [(SA015A1T)]	
M27C1001@TSOP32 [(SA410T)]		M27C1024	
M27C1024@PLCC44 [(SA244)]		M27C128B	
M27C16		M27C160	
M27C160@PLCC44 [(SA244)]		M27C160@PSOP44 [(SA638)]	
M27C160K		M27C160K@PLCC44 [(SA244)]	
M27C160K@PSOP44 [(SA638)]		M27C2001	
M27C2001@PLCC32 [(SA015A1T)]		M27C2001@TSOP32 [(SA410T)]	
M27C202		M27C202@PLCC44 [(SA244)]	
M27C202@TSOP40 [(SA409T)]		M27C256B	
M27C256B@PLCC32 [(SA015A1T)]		M27C32	
M27C322		M27C322@SDIP42 [(SA028)]	
M27C400		M27C4001	
M27C4001@PLCC32 [(SA015A1T)]		M27C4001@TSOP32 [(SA410T)]	
M27C4002		M27C4002@PLCC44 [(SA244)]	
M27C405		M27C405@PLCC32 [(SA015A1T)]	
M27C405@TSOP32 [(SA410T)]		M27C512	
M27C512@PLCC32 [(SA015A1T)]		M27C513	
M27C516		M27C516@PLCC44 [(SA244)]	
M27C64A		M27C64A@PLCC32 [(SA015A1T)]	
M27C800		M27C800@PLCC44 [(SA244)]	
M27C800@PSOP44 [(SA638)]		M27C801	
M27C801@PLCC32 [(SA015A1T)]		M27C801@TSOP32 [(SA410T)]	
M27HC641		M27HC641@PLCC28 [(SA008A)]	
M27HC642		M27HC642@PLCC28 [(SA008A)]	
M27V101		M27V101@PLCC32 [(SA015A1T)]	
M27V101@TSOP32 [(SA410T)]		M27V102	
M27V102@PLCC44 [(SA244)]		M27V160	
M27V160@PLCC44 [(SA244)]		M27V160@PSOP44 [(SA638)]	
M27V160K		M27V160K@PLCC44 [(SA244)]	
M27V160K@PSOP44 [(SA638)]		M27V201	
M27V201@PLCC32 [(SA015A1T)]		M27V201@TSOP32 [(SA410T)]	
M27V256		M27V322	
M27V322@SDIP42 [(SA028)]		M27V401	
M27V401@PLCC32 [(SA015A1T)]		M27V401@TSOP32 [(SA410T)]	
M27V402		M27V402@PLCC44 [(SA244)]	
M27V402@TSOP40 [(SA409T)]		M27V405	
M27V405@PLCC32 [(SA015A1T)]		M27V405@TSOP32 [(SA410T)]	
M27V512		M27V512@PLCC32 [(SA015A1T)]	
M27V512@TSOP28 [(SA430T)]		M27V800	
M27V800@PLCC44 [(SA244)]		M27V801	
M27V801@PLCC32 [(SA015A1T)]		M27V801@TSOP32 [(SA410T)]	
M27W101		M27W101@PLCC32 [(SA015A1T)]	
M27W101@TSOP32 [(SA410T)]		M27W102	
M27W102@PLCC44 [(SA244)]		M27W160	
M27W160@PLCC44 [(SA244)]		M27W160@PSOP44 [(SA638)]	
M27W201		M27W201@PLCC32 [(SA015A1T)]	
M27W201@TSOP32 [(SA410T)]		M27W202	
M27W202@PLCC44 [(SA244)]		M27W202@TSOP40 [(SA409T)]	
M27W400		M27W400@PLCC44 [(SA244)]	
M27W401		M27W401@PLCC32 [(SA015A1T)]	
M27W401@TSOP32 [(SA410T)]		M27W402	
M27W402@PLCC44 [(SA244)]		M27W402@TSOP40 [(SA409T)]	
M27W512		M27W512@PLCC32 [(SA015A1T)]	
M27W512@TSOP28 [(SA430T)]		M27W800	
M27W800@PLCC44 [(SA244)]		M27W801	
M27W801@PLCC32 [(SA015A1T)]		M27W801@TSOP32 [(SA410T)]	
M28010		M28010@PLCC32 [(SA015A1T)]	
M28010@TSOP32 [(SA410T)]		M28010R	
M28010R@PLCC32 [(SA015A1T)]		M28010R@TSOP32 [(SA410T)]	
M28010W		M28010W@PLCC32 [(SA015A1T)]	
M28010W@TSOP32 [(SA410T)]		M28256	
M28256@PLCC32 [(SA015A1T)]		M28256@TSOP28 [(SA430T)]	
M28C010		M28C010@PLCC32 [(SA015A1T)]	
M28C010@TSOP32 [(SA410T)]		M28C010R	
M28C010R@PLCC32 [(SA015A1T)]		M28C010R@TSOP32 [(SA410T)]	
M28C010W		M28C010W@PLCC32 [(SA015A1T)]	
M28C010W@TSOP32 [(SA410T)]		M28C16@PLCC32 [(SA015A1T)]	
M28C17@SOIC28 [(SA404)]		M28C64	
M28C64@PLCC32 [(SA015A1T)]		M28C64@TSOP28 [(SA430T)]	
M28C64C		M28C64C@PLCC32 [(SA015A1T)]	
M28C64C@SOIC28 [(SA404)]		M28C64C@TSOP28 [(SA430T)]	
M28C64X		M28C64X@PLCC32 [(SA015A1T)]	

M28C64X@TSOP28 [(SA430T)]	M28F101
M28F101@PLCC32 [(SA015A1T)]	M28F101@TSOP32 [(SA410T)]
M28F102	M28F102@PLCC44 [(SA244)]
M28F102@TSOP40 [(SA409T)]	M28F151
M28F151@PLCC32 [(SA015A1T)]	M28F151@TSOP32 [(SA410T)]
M28F201	M28F201@PLCC32 [(SA015A1T)]
M28F201@TSOP32 [(SA410T)]	M28F211@TSOP40 [(SA409T)]
M28F221@TSOP40 [(SA409T)]	M28F256
M28F256@PLCC32 [(SA015A1T)]	M28F256@TSOP32 [(SA410T)]
M28F411@TSOP40 [(SA409T)]	M28F421@TSOP40 [(SA409T)]
M28F512	M28F512@PLCC32 [(SA015A1T)]
M28F512@TSOP32 [(SA410T)]	M28LV64
M28LV64@PLCC32 [(SA015A1T)]	M28LV64@TSOP28 [(SA430T)]
M28V411@TSOP40 [(SA409T)]	M28V421@TSOP40 [(SA409T)]
M29F002B	M29F002B@PLCC32 [(SA015A1T)]
M29F002B@TSOP32 [(SA410T)]	M29F002BB
M29F002BB@PLCC32 [(SA015A1T)]	M29F002BB@TSOP32 [(SA410T)]
M29F002BNT	M29F002BNT@PLCC32 [(SA015A1T)]
M29F002BNT@TSOP32 [(SA410T)]	M29F002BT
M29F002BT@PLCC32 [(SA015A1T)]	M29F002BT@TSOP32 [(SA410T)]
M29F002T	M29F002T@PLCC32 [(SA015A1T)]
M29F002T@TSOP32 [(SA410T)]	M29F010B
M29F010B@PLCC32 [(SA015A1T)]	M29F010B@TSOP32 [(SA410T)]
M29F016B@PSOP44 [(SA638)]	M29F016B@TSOP40 [(SA409T)]
M29F016D@PSOP44 [(SA638)]	M29F016D@TSOP40 [(SA409T)]
M29F032D@TSOP40 [(SA409T)]	M29F040
M29F040@PLCC32 [(SA015A1T)]	M29F040@TSOP32 [(SA410T)]
M29F040B	M29F040B@PLCC32 [(SA015A1T)]
M29F040B@TSOP32 [(SA410T)]	M29F080A@PSOP44 [(SA638)]
M29F080A@TSOP40 [(SA409T)]	M29F080D@PSOP44 [(SA638)]
M29F080D@TSOP40 [(SA409T)]	M29F100B@PSOP44 [(SA638-B006)]
M29F100B@TSOP48 [(SA247-B005)]	M29F100T@PSOP44 [(SA638-B006)]
M29F100T@TSOP48 [(SA247-B005)]	M29F102B@PLCC44 [(SA244)]
M29F102B@TSOP40 [(SA623)]	M29F102BB@PLCC44 [(SA244)]
M29F102BB@TSOP40 [(SA623)]	M29F160BB@TSOP48 [(SA247-B005)]
M29F160BT@TSOP48 [(SA247-B005)]	M29F200B@PSOP44 [(SA638-B006)]
M29F200B@TSOP48 [(SA247-B005)]	M29F200BB@PSOP44 [(SA638-B006)]
M29F200BB@TSOP48 [(SA247-B005)]	M29F200BT@PSOP44 [(SA638-B006)]
M29F200BT@TSOP48 [(SA247-B005)]	M29F200T@PSOP44 [(SA638-B006)]
M29F200T@TSOP48 [(SA247-B005)]	M29F400B@PSOP44 [(SA638-B006)]
M29F400B@TSOP48 [(SA247-B005)]	M29F400BB@PSOP44 [(SA638-B006)]
M29F400BB@TSOP48 [(SA247-B005)]	M29F400BT@PSOP44 [(SA638-B006)]
M29F400BT@TSOP48 [(SA247-B005)]	M29F400T@PSOP44 [(SA638-B006)]
M29F400T@TSOP48 [(SA247-B005)]	M29F512B@PLCC32 [(SA015A1T)]
M29F512B@TSOP32 [(SA620)]	M29F800AB@PSOP44 [(SA638-B006)]
M29F800AB@TSOP48 [(SA247-B005)]	M29F800AT@PSOP44 [(SA638-B006)]
M29F800AT@TSOP48 [(SA247-B005)]	M29F800DB@PSOP44 [(SA638)]
M29F800DB@TSOP48 [(SA247-B005)]	M29F800DT@PSOP44 [(SA638)]
M29F800DT@TSOP48 [(SA247-B005)]	M29V040@PLCC32 [(SA015A1T)]
M29V040@TSOP32 [(SA410T)]	M29W004B@TSOP40 [(SA409T)]
M29W004BB@TSOP40 [(SA409T)]	M29W004BT@TSOP40 [(SA409T)]
M29W004T@TSOP40 [(SA409T)]	M29W008AB@TSOP40 [(SA409T)]
M29W008AT@TSOP40 [(SA409T)]	M29W008B@TSOP40 [(SA409T)]
M29W008T@TSOP40 [(SA409T)]	M29W010B@PLCC32 [(SA015A1T)]
M29W010B@TSOP32 [(SA410T)]	M29W022BB
M29W022BB@PLCC32 [(SA015A1T)]	M29W022BB@TSOP32 [(SA410T)]
M29W022BT	M29W022BT@PLCC32 [(SA015A1T)]
M29W022BT@TSOP32 [(SA410T)]	M29W040@PLCC32 [(SA015A1T)]
M29W040@TSOP32 [(SA410T)]	M29W040B@PLCC32 [(SA015A1T)]
M29W040B@TSOP32 [(SA410T)]	M29W102BB@TSOP40 [(SA623)]
M29W102BT@TSOP40 [(SA623)]	M29W116BB@TSOP40 [(SA409T)]
M29W116BT@TSOP40 [(SA409T)]	M29W200BB@PSOP44 [(SA638)]
M29W200BB@TSOP48 [(SA247-B005)]	M29W200BT@PSOP44 [(SA638)]
M29W200BT@TSOP48 [(SA247-B005)]	M29W512B@PLCC32 [(SA015A1T)]
M29W512B@TSOP32 [(SA620)]	M34C02
M34C02@MSOP8 [(SA666)]	M34C02@SOIC8 [(SA602A)]
M34C02@TSOP8 [(SA026)]	M34D32
M34D32@SOIC8 [(SA602A)]	M34D32@TSSOP8 [(SA026)]
M34D64	M34D64@SOIC8 [(SA602A)]
M34D64@TSSOP8 [(SA026)]	M34E02
M34E02@MSOP8 [(SA666)]	M34E02@SOIC8 [(SA602A)]
M34E02@TSOP8 [(SA026)]	M35080
M35080@SOIC8 [(SA602A)]	M45PE10@SOIC8 [(SA602A)]
M45PE10@VQFPN8 [(SA683)]	M45PE16@SOIC8 [(SA023A)]
M45PE16@VQFPN8 [(SA683)]	M45PE20@SOIC8 [(SA602A)]
M45PE20@SOIC8(ISP) [ISP-HEADER01]	
M45PE20@VQFPN8 [(SA683)]	
M45PE20@VQFPN8(ISP) [ISP-HEADER01]	
M45PE40@SOIC8 [(SA023A)]	
M45PE40@SOIC8(ISP) [ISP-HEADER01]	
M45PE40@VQFPN8 [(SA683)]	

M45PE40@VQFPN8 (ISP) [ISP-HEADER01]	
M45PE80@SOIC16 [(SA023A)]	
M45PE80@SOIC16 (ISP) [ISP-HEADER01]	
M45PE80@SOIC8 [(SA023A)]	
M45PE80@SOIC8 (ISP) [ISP-HEADER01]	
M45PE80@VQFPN8 [(SA683)]	
M45PE80@VQFPN8 (ISP) [ISP-HEADER01]	
M48C02	M48C02B
M48C12	M48C12B
M48T02	M48T02B
M48T08	M48T12
M48T128V	M48T128Y
M48T129V	M48T129Y
M48T12B	M48T18
M48T30	M48T30Y
M48T32	M48T32Y
M48T35	M48T35@SOIC28 [(SA404)]
M48T35AV	M48T35AV@SOIC28 [(SA630)]
M48T35AY	M48T35AY@SOIC28 [(SA630)]
M48T35Y	M48T35Y@SOIC28 [(SA404)]
M48T512AV	M48T512AY
M48T512V	M48T512Y
M48T513V	M48T513Y
M48T559	M48T559@SOIC28 [(SA630)]
M48T559Y	M48T559Y@SOIC28 [(SA630)]
M48T58	M48T58@SOIC28 [(SA404)]
M48T58Y	M48T58Y@SOIC28 [(SA404)]
M48T59	M48T59@SOIC28 [(SA404)]
M48T59V	M48T59V@SOIC28 [(SA404)]
M48T59Y	M48T59Y@SOIC28 [(SA404)]
M48Z02	M48Z02B
M48Z08	M48Z09
M48Z12	M48Z128
M48Z128V	M48Z128Y
M48Z129V	M48Z129Y
M48Z12B	M48Z18
M48Z19	M48Z30
M48Z30Y	M48Z32
M48Z32Y	M48Z35
M48Z35@SOIC28 [(SA630)]	M48Z35Y
M48Z35Y@SOIC28 [(SA630)]	M48Z512AV
M48Z512AY	M48Z512V
M48Z512Y	M48Z513V
M48Z513Y	M48Z58
M48Z58@SOIC28 [(SA404)]	M48Z58Y
M48Z58Y@SOIC28 [(SA404)]	M48Z59
M48Z59@SOIC28 [(SA404)]	M48Z59W
M48Z59W@SOIC28 [(SA404)]	M48Z59Y
M48Z59Y@SOIC28 [(SA404)]	M50FLW040A@PLCC32 [(SA015A1T)]
M50FLW040A@TSOP40 [(SA409T)]	M50FLW040A@VSOP32 [(SA620)]
M50FLW040B@PLCC32 [(SA015A1T)]	M50FLW040B@TSOP40 [(SA409T)]
M50FLW040B@VSOP32 [(SA620)]	M50FLW080A@PLCC32 [(SA015A1T)]
M50FLW080A@TSOP40 [(SA409T)]	M50FLW080A@VSOP32 [(SA620)]
M50FLW080B@PLCC32 [(SA015A1T)]	M50FLW080B@TSOP40 [(SA409T)]
M50FLW080B@VSOP32 [(SA620)]	M50FW002@PLCC32 [(SA015A1T)]
M50FW016@TSOP40 [(SA409T)]	M50FW020@PLCC32 [(SA015A1T)]
M50FW040@PLCC32 [(SA015A1T)]	M50FW040@TSOP40 [(SA409T)]
M50FW080@PLCC32 [(SA015A1T)]	M50FW080@TSOP40 [(SA409T)]
M50FW080@VSOP32 [(SA620)]	M50LPW002@PLCC32 [(SA015A1T)]
M50LPW012@PLCC32 [(SA015A1T)]	M50LPW020@PLCC32 [(SA015A1T)]
M50LPW040@PLCC32 [(SA015A1T)]	M50LPW040@TSOP40 [(SA409T)]
M50LPW041@PLCC32 [(SA015A1T)]	M50LPW041@TSOP40 [(SA409T)]
M50LPW080@PLCC32 [(SA015A1T)]	M50LPW080@TSOP40 [(SA409T)]
M50LPW116@TSOP40 [(SA409T)]	M87C257
M87C257@PLCC32 [(SA015A1T)]	M93C06(08bit)
M93C06(08bit)@SOIC8 [(SA602A)]	M93C06(16bit)
M93C06(16bit)@SOIC8 [(SA602A)]	M93C46(08bit)
M93C46(08bit)@MLP8 [(SA694)]	M93C46(08bit)@MSOP8 [(SA666)]
M93C46(08bit)@SOIC8 [(SA602A)]	M93C46(08bit)@TSSOP8 [(SA026)]
M93C46(16bit)	M93C46(16bit)@MLP8 [(SA694)]
M93C46(16bit)@MSOP8 [(SA666)]	M93C46(16bit)@SOIC8 [(SA602A)]
M93C46(16bit)@TSSOP8 [(SA026)]	M93C46R(08bit)
M93C46R(08bit)@MLP8 [(SA694)]	M93C46R(08bit)@MSOP8 [(SA666)]
M93C46R(08bit)@SOIC8 [(SA602A)]	M93C46R(08bit)@TSSOP8 [(SA026)]
M93C46R(16bit)	M93C46R(16bit)@MLP8 [(SA694)]
M93C46R(16bit)@MSOP8 [(SA666)]	M93C46R(16bit)@SOIC8 [(SA602A)]
M93C46R(16bit)@TSSOP8 [(SA026)]	M93C46W(08bit)
M93C46W(08bit)@MLP8 [(SA694)]	M93C46W(08bit)@MSOP8 [(SA666)]
M93C46W(08bit)@SOIC8 [(SA602A)]	M93C46W(08bit)@TSSOP8 [(SA026)]
M93C46W(16bit)	M93C46W(16bit)@MLP8 [(SA694)]
M93C46W(16bit)@MSOP8 [(SA666)]	M93C46W(16bit)@SOIC8 [(SA602A)]


```

M93C46W(16bit)@TSSOP8 [(SA026)]
M93C56(08bit)@MLP8 [(SA694)]
M93C56(08bit)@SOIC8 [(SA602A)]
M93C56(16bit)
M93C56(16bit)@MSOP8 [(SA666)]
M93C56(16bit)@TSSOP8 [(SA026)]
M93C56R(08bit)@MLP8 [(SA694)]
M93C56R(08bit)@SOIC8 [(SA602A)]
M93C56R(16bit)
M93C56R(16bit)@MSOP8 [(SA666)]
M93C56R(16bit)@TSSOP8 [(SA026)]
M93C56W(08bit)@MLP8 [(SA694)]
M93C56W(08bit)@SOIC8 [(SA602A)]
M93C56W(16bit)
M93C56W(16bit)@MSOP8 [(SA666)]
M93C56W(16bit)@TSSOP8 [(SA026)]
M93C66(08bit)@MLP8 [(SA694)]
M93C66(08bit)@SOIC8 [(SA602A)]
M93C66(16bit)
M93C66(16bit)@MSOP8 [(SA666)]
M93C66(16bit)@TSSOP8 [(SA026)]
M93C66R(08bit)@MLP8 [(SA694)]
M93C66R(08bit)@SOIC8 [(SA602A)]
M93C66R(16bit)
M93C66R(16bit)@MSOP8 [(SA666)]
M93C66R(16bit)@TSSOP8 [(SA026)]
M93C66W(08bit)@MLP8 [(SA694)]
M93C66W(08bit)@SOIC8 [(SA602A)]
M93C66W(16bit)
M93C66W(16bit)@MSOP8 [(SA666)]
M93C66W(16bit)@TSSOP8 [(SA026)]
M93C76(08bit)@MLP8 [(SA694)]
M93C76(08bit)@SOIC8 [(SA602A)]
M93C76(16bit)
M93C76(16bit)@MSOP8 [(SA666)]
M93C76(16bit)@TSSOP8 [(SA026)]
M93C76R(08bit)@MLP8 [(SA694)]
M93C76R(08bit)@SOIC8 [(SA602A)]
M93C76R(16bit)
M93C76R(16bit)@MSOP8 [(SA666)]
M93C76R(16bit)@TSSOP8 [(SA026)]
M93C76W(08bit)@MLP8 [(SA694)]
M93C76W(08bit)@SOIC8 [(SA602A)]
M93C76W(16bit)
M93C76W(16bit)@MSOP8 [(SA666)]
M93C76W(16bit)@TSSOP8 [(SA026)]
M93C86(08bit)@MLP8 [(SA694)]
M93C86(08bit)@SOIC8 [(SA602A)]
M93C86(16bit)
M93C86(16bit)@MSOP8 [(SA666)]
M93C86(16bit)@TSSOP8 [(SA026)]
M93C86R(08bit)@MLP8 [(SA694)]
M93C86R(08bit)@SOIC8 [(SA602A)]
M93C86R(16bit)
M93C86R(16bit)@MSOP8 [(SA666)]
M93C86R(16bit)@TSSOP8 [(SA026)]
M93C86W(08bit)@MLP8 [(SA694)]
M93C86W(08bit)@SOIC8 [(SA602A)]
M93C86W(16bit)
M93C86W(16bit)@MSOP8 [(SA666)]
M93C86W(16bit)@TSSOP8 [(SA026)]
M93CS566@SOIC8 [(SA602A)]
M93S46@SOIC8 [(SA602A)]
M93S46R
M93S46R@TSSOP8 [(SA026)]
M93S46W@SOIC8 [(SA602A)]
M93S56
M93S56@TSSOP8 [(SA026)]
M93S56R@SOIC8 [(SA602A)]
M93S56W
M93S56W@TSSOP8 [(SA026)]
M93S66@SOIC8 [(SA602A)]
M93S66R
M93S66R@TSSOP8 [(SA026)]
M93S66W@SOIC8 [(SA602A)]
M95010
M95010@SOIC8 [(SA602A)]
M95010@TSSOP8 [(SA026)]
M95010@TSSOP8(ISP) [ISP-HEADER01]
M95020
M95020@SOIC8 [(SA602A)]
M93C56(08bit)
M93C56(08bit)@MSOP8 [(SA666)]
M93C56(08bit)@TSSOP8 [(SA026)]
M93C56(16bit)@MLP8 [(SA694)]
M93C56(16bit)@SOIC8 [(SA602A)]
M93C56R(08bit)
M93C56R(08bit)@MSOP8 [(SA666)]
M93C56R(08bit)@TSSOP8 [(SA026)]
M93C56R(16bit)@MLP8 [(SA694)]
M93C56R(16bit)@SOIC8 [(SA602A)]
M93C56W(08bit)
M93C56W(08bit)@MSOP8 [(SA666)]
M93C56W(08bit)@TSSOP8 [(SA026)]
M93C56W(16bit)@MLP8 [(SA694)]
M93C56W(16bit)@SOIC8 [(SA602A)]
M93C66(08bit)
M93C66(08bit)@MSOP8 [(SA666)]
M93C66(08bit)@TSSOP8 [(SA026)]
M93C66(16bit)@MLP8 [(SA694)]
M93C66(16bit)@SOIC8 [(SA602A)]
M93C66R(08bit)
M93C66R(08bit)@MSOP8 [(SA666)]
M93C66R(08bit)@TSSOP8 [(SA026)]
M93C66R(16bit)@MLP8 [(SA694)]
M93C66R(16bit)@SOIC8 [(SA602A)]
M93C66W(08bit)
M93C66W(08bit)@MSOP8 [(SA666)]
M93C66W(08bit)@TSSOP8 [(SA026)]
M93C66W(16bit)@MLP8 [(SA694)]
M93C66W(16bit)@SOIC8 [(SA602A)]
M93C76(08bit)
M93C76(08bit)@MSOP8 [(SA666)]
M93C76(08bit)@TSSOP8 [(SA026)]
M93C76(16bit)@MLP8 [(SA694)]
M93C76(16bit)@SOIC8 [(SA602A)]
M93C76R(08bit)
M93C76R(08bit)@MSOP8 [(SA666)]
M93C76R(08bit)@TSSOP8 [(SA026)]
M93C76R(16bit)@MLP8 [(SA694)]
M93C76R(16bit)@SOIC8 [(SA602A)]
M93C76W(08bit)
M93C76W(08bit)@MSOP8 [(SA666)]
M93C76W(08bit)@TSSOP8 [(SA026)]
M93C76W(16bit)@MLP8 [(SA694)]
M93C76W(16bit)@SOIC8 [(SA602A)]
M93C86(08bit)
M93C86(08bit)@MSOP8 [(SA666)]
M93C86(08bit)@TSSOP8 [(SA026)]
M93C86(16bit)@MLP8 [(SA694)]
M93C86(16bit)@SOIC8 [(SA602A)]
M93C86R(08bit)
M93C86R(08bit)@MSOP8 [(SA666)]
M93C86R(08bit)@TSSOP8 [(SA026)]
M93C86R(16bit)@MLP8 [(SA694)]
M93C86R(16bit)@SOIC8 [(SA602A)]
M93C86W(08bit)
M93C86W(08bit)@MSOP8 [(SA666)]
M93C86W(08bit)@TSSOP8 [(SA026)]
M93C86W(16bit)@MLP8 [(SA694)]
M93C86W(16bit)@SOIC8 [(SA602A)]
M93CS566
M93S46
M93S46@TSSOP8 [(SA026)]
M93S46R@SOIC8 [(SA602A)]
M93S46W
M93S46W@TSSOP8 [(SA026)]
M93S56@SOIC8 [(SA602A)]
M93S56R
M93S56R@TSSOP8 [(SA026)]
M93S56W@SOIC8 [(SA602A)]
M93S66
M93S66@TSSOP8 [(SA026)]
M93S66R@SOIC8 [(SA602A)]
M93S66W
M93S66W@TSSOP8 [(SA026)]
M95010(ISP) [ISP-HEADER01]
M95010@SOIC8(ISP) [ISP-HEADER01]
M95020(ISP) [ISP-HEADER01]
M95020@SOIC8(ISP) [ISP-HEADER01]

```

```

M95020@TSSOP8 [(SA026)]
M95020@TSSOP8(ISP) [ISP-HEADER01]
M95040
M95040@SOIC8 [(SA602A)]
M95040@TSSOP8 [(SA026)]
M95040@TSSOP8(ISP) [ISP-HEADER01]
M95080
M95080@SOIC8 [(SA602A)]
M95080@TSSOP14 [(SA026)]
M95080@TSSOP14(ISP) [ISP-HEADER01]
M95080@TSSOP8 [(SA026)]
M95080@TSSOP8(ISP) [ISP-HEADER01]
M95128
M95128@TSSOP14 [(SA026)]
M95128@TSSOP14(ISP) [ISP-HEADER01]
M95128@TSSOP8 [(SA026)]
M95128@TSSOP8(ISP) [ISP-HEADER01]
M95128[150mil]@SOIC8 [(SA602A)]
M95128[150mil]@SOIC8(ISP) [ISP-HEADER01]
M95128[200mil]@SOIC8 [(SA023A)]
M95128[200mil]@SOIC8(ISP) [ISP-HEADER01]
M95160
M95160@SOIC8 [(SA602A)]
M95160@TSSOP14 [(SA026)]
M95160@TSSOP14(ISP) [ISP-HEADER01]
M95160@TSSOP8 [(SA026)]
M95160@TSSOP8(ISP) [ISP-HEADER01]
M95256
M95256@TSSOP14 [(SA026)]
M95256@TSSOP14(ISP) [ISP-HEADER01]
M95256@TSSOP8 [(SA026)]
M95256@TSSOP8(ISP) [ISP-HEADER01]
M95256[150mil]@SOIC8 [(SA602A)]
M95256[150mil]@SOIC8(ISP) [ISP-HEADER01]
M95256[200mil]@SOIC8 [(SA023A)]
M95256[200mil]@SOIC8(ISP) [ISP-HEADER01]
M95320
M95320@SOIC8 [(SA602A)]
M95320@TSSOP14 [(SA026)]
M95320@TSSOP14(ISP) [ISP-HEADER01]
M95320@TSSOP8 [(SA026)]
M95320@TSSOP8(ISP) [ISP-HEADER01]
M95512@SOIC8 [(SA602A)]
M95512@TSSOP8 [(SA026)]
M95512@TSSOP8(ISP) [ISP-HEADER01]
M95640
M95640@SOIC8 [(SA602A)]
M95640@TSSOP14 [(SA026)]
M95640@TSSOP14(ISP) [ISP-HEADER01]
M95640@TSSOP8 [(SA026)]
M95640@TSSOP8(ISP) [ISP-HEADER01]
M95M01[150mil]@SOIC8 [(SA602A)]
M95P02@SOIC8 [(SA602A)]
M95P04@SOIC8 [(SA602A)]
M95P08@SOIC8 [(SA602A)]
M95P08@SOIC8 [(SA602A)]
MK48C02B
MK48C12B
MK48T02B
MK48T12
MK48T18
MK48T32Y
MK48T35@SOIC28 [(SA630)]
MK48T35Y@SOIC28 [(SA630)]
MK48T512Y
MK48Z02B
MK48Z12
MK48Z18
MK48Z32Y
MK48Z35@SOIC28 [(SA630)]
MK48Z35Y@SOIC28 [(SA630)]
MK48Z512Y
MKI48Z02B
MKI48Z12B
ST24C01
ST24C02A
ST24C16
ST24FC21
ST24FW21
ST24LC21B
ST24LW21
ST24W01

M95040(ISP) [ISP-HEADER01]
M95040@SOIC8(ISP) [ISP-HEADER01]

M95080(ISP) [ISP-HEADER01]
M95080@SOIC8(ISP) [ISP-HEADER01]

M95128(ISP) [ISP-HEADER01]

M95160(ISP) [ISP-HEADER01]
M95160@SOIC8(ISP) [ISP-HEADER01]

M95256(ISP) [ISP-HEADER01]

M95320(ISP) [ISP-HEADER01]
M95320@SOIC8(ISP) [ISP-HEADER01]

M95512@SOIC8(ISP) [ISP-HEADER01]

M95640(ISP) [ISP-HEADER01]
M95640@SOIC8(ISP) [ISP-HEADER01]

M95P02
M95P04
M95P08
MK48C02
MK48C12
MK48T02
MK48T08
MK48T12B
MK48T32
MK48T35
MK48T35Y
MK48T512V
MK48Z02
MK48Z08
MK48Z12B
MK48Z32
MK48Z35
MK48Z35Y
MK48Z512V
MKI48Z02
MKI48Z12
MKI48Z18
ST24C01@SOIC8 [(SA602A)]
ST24C02A@SOIC8 [(SA602A)]
ST24C16@SOIC8 [(SA602A)]
ST24FC21@SOIC8 [(SA602A)]
ST24FW21@SOIC8 [(SA602A)]
ST24LC21B@SOIC8 [(SA602A)]
ST24LW21@SOIC8 [(SA602A)]
ST24W01@SOIC8 [(SA602A)]

```

ST24W02	ST24W02@SOIC8 [(SA602A)]
ST24W04C	ST24W04C@SOIC8 [(SA602A)]
ST26C201	ST26C201@PLCC32 [(SA015A1T)]
ST26C201@TSOP32 [(SA410T)]	ST27128A
ST27256	ST2764A
ST27C256	ST93C06(08bit)
ST93C06(08bit)@SOIC8 [(SA602A)]	ST93C06(16bit)
ST93C06(16bit)@SOIC8 [(SA602A)]	ST93C46(08bit)
ST93C46(08bit)@SOIC8 [(SA602A)]	ST93C46(16bit)
ST93C46(16bit)@SOIC8 [(SA602A)]	ST93C46A(08bit)
ST93C46A(08bit)@SOIC8 [(SA602A)]	ST93C46A(16bit)
ST93C46A(16bit)@SOIC8 [(SA602A)]	ST93C46C(08bit)
ST93C46C(08bit)@SOIC8 [(SA602A)]	ST93C46C(16bit)
ST93C46C(16bit)@SOIC8 [(SA602A)]	ST93C46T(08bit)
ST93C46T(08bit)@SOIC8 [(SA602A)]	ST93C46T(16bit)
ST93C46T(16bit)@SOIC8 [(SA602A)]	ST93C47C(08bit)
ST93C47C(08bit)@SOIC8 [(SA602A)]	ST93C47C(16bit)
ST93C47C(16bit)@SOIC8 [(SA602A)]	ST93C47T(08bit)
ST93C47T(08bit)@SOIC8 [(SA602A)]	ST93C47T(16bit)
ST93C47T(16bit)@SOIC8 [(SA602A)]	ST93C56(08bit)
ST93C56(08bit)@SOIC8 [(SA602A)]	ST93C56(16bit)
ST93C56(16bit)@SOIC8 [(SA602A)]	ST93C56B(08bit)
ST93C56B(08bit)@SOIC8 [(SA602A)]	ST93C56B(16bit)
ST93C56B(16bit)@SOIC8 [(SA602A)]	ST93C56C(08bit)
ST93C56C(08bit)@SOIC8 [(SA602A)]	ST93C56C(16bit)
ST93C56C(16bit)@SOIC8 [(SA602A)]	ST93C57C(08bit)
ST93C57C(08bit)@SOIC8 [(SA602A)]	ST93C57C(16bit)
ST93C57C(16bit)@SOIC8 [(SA602A)]	ST93C66(08bit)
ST93C66(08bit)@SOIC8 [(SA602A)]	ST93C66(16bit)
ST93C66(16bit)@SOIC8 [(SA602A)]	ST93C67(08bit)
ST93C67(08bit)@SOIC8 [(SA602A)]	ST93C67(16bit)
ST93C67(16bit)@SOIC8 [(SA602A)]	ST93C76(08bit)
ST93C76(08bit)@SOIC8 [(SA602A)]	ST93C76(16bit)
ST93C76(16bit)@SOIC8 [(SA602A)]	ST93C86(08bit)
ST93C86(08bit)@SOIC8 [(SA602A)]	ST93C86(16bit)
ST93C86(16bit)@SOIC8 [(SA602A)]	ST93CS46
ST93CS46@SOIC8 [(SA602A)]	ST93CS47
ST93CS47@SOIC8 [(SA602A)]	ST93CS56
ST93CS56@SOIC8 [(SA602A)]	ST93CS566
ST93CS566@SOIC8 [(SA602A)]	ST93CS57
ST93CS57@SOIC8 [(SA602A)]	ST93CS66
ST93CS66@SOIC14 [(SA602)]	ST93CS67
ST93CS67@SOIC14 [(SA602)]	TS27C256
TS27C64	TS27C64@PLCC32 [(SA015A1T)]
TS27C64A	TS27C64A@PLCC32 [(SA015A1T)]
TS28C16A	TS28C17A

MICROCONTROLLER

ST62T60C6

ST72F324J2B5@SDIP42(ISP) [ISP-HEADER01]

ST72F324J2T6@TQFP44(ISP) [ISP-HEADER01]

ST72F324J2TA@TQFP44(ISP) [ISP-HEADER01]

ST72F324J4B5@SDIP42(ISP) [ISP-HEADER01]

ST72F324J4T6@TQFP44(ISP) [ISP-HEADER01]

ST72F324J4TA@TQFP44(ISP) [ISP-HEADER01]

ST72F324J6B5@SDIP42(ISP) [ISP-HEADER01]

ST72F324J6T5@TQFP44(ISP) [ISP-HEADER01]

ST72F324J6T6@TQFP44(ISP) [ISP-HEADER01]

ST72F324J6TA@TQFP44(ISP) [ISP-HEADER01]

ST72F324J6TC@TQFP44(ISP) [ISP-HEADER01]

ST72F324K2B5@SDIP32(ISP) [ISP-HEADER01]

ST72F324K2B6@SDIP32(ISP) [ISP-HEADER01]

ST72F324K2T6@TQFP32(ISP) [ISP-HEADER01]

ST72F324K2TA@TQFP32(ISP) [ISP-HEADER01]

ST72F324K4B5@SDIP32(ISP) [ISP-HEADER01]

ST72F324K4B6@SDIP32(ISP) [ISP-HEADER01]

ST72F324K4T6@TQFP32(ISP) [ISP-HEADER01]

ST72F324K4TA@TQFP32(ISP) [ISP-HEADER01]

ST72F324K6B5@SDIP32(ISP) [ISP-HEADER01]

ST72F324K6B6@SDIP32(ISP) [ISP-HEADER01]

ST72F324K6T5@TQFP32(ISP) [ISP-HEADER01]

ST72F324K6T6@TQFP32(ISP) [ISP-HEADER01]

ST72F324K6TA@TQFP32(ISP) [ISP-HEADER01]

ST72F324K6TC@TQFP32(ISP) [ISP-HEADER01]

STC

MICROCONTROLLER

STC89C516RD	STC89C516RD@PLCC44 [(SA244)]
STC89C516RD@TQFP44 [(SA245A)]	STC89C58RD
STC89C58RD@PLCC44 [(SA244)]	STC89C58RD@TQFP44 [(SA245A)]
STC89LE516AD	STC89LE516AD@PLCC44 [(SA244)]
STC89LE516AD@TQFP44 [(SA245A)]	STC89LE516X2
STC89LE516X2@PLCC44 [(SA244)]	STC89LE516X2@TQFP44 [(SA245A)]
STC89LE52AD	STC89LE52AD@PLCC44 [(SA244)]
STC89LE52AD@TQFP44 [(SA675)]	STC89LE54AD
STC89LE54AD@PLCC44 [(SA244)]	STC89LE54AD@TQFP44 [(SA675)]
STC89LE556AD	STC89LE556AD@PLCC44 [(SA244)]
STC89LE556AD@TQFP44 [(SA245A)]	STC89LE556X2
STC89LE556X2@PLCC44 [(SA244)]	STC89LE556X2@TQFP44 [(SA245A)]
STC89LE58AD	STC89LE58AD@PLCC44 [(SA244)]
STC89LE58AD@TQFP44 [(SA675)]	STC89LV516RD
STC89LV516RD@PLCC44 [(SA244)]	STC89LV516RD@TQFP44 [(SA245A)]
STC89LV58RD	STC89LV58RD@PLCC44 [(SA244)]
STC89LV58RD@TQFP44 [(SA245A)]	

SUMMIT**E(E) PROM/FRAM/NVRAM**

S24022	S24022@SOIC8 [(SA602A)]
S24023	S24023@SOIC8 [(SA602A)]
S24042	S24042@SOIC8 [(SA602A)]
S24043	S24043@SOIC8 [(SA602A)]
S24162	S24162@SOIC8 [(SA602A)]
S24VP02	S24VP02@SOIC8 [(SA602A)]
S24VP04	S24VP04@SOIC8 [(SA602A)]
S24VP08	S24VP08@SOIC8 [(SA602A)]
S24VP16	S24VP16@SOIC8 [(SA602A)]
S93462(08bit)	S93462(08bit)@SOIC8 [(SA602A)]
S93462(16bit)	S93462(16bit)@SOIC8 [(SA602A)]
S93463(08bit)	S93463(08bit)@SOIC8 [(SA602A)]
S93463(16bit)	S93463(16bit)@SOIC8 [(SA602A)]
S93662(08bit)	S93662(08bit)@SOIC8 [(SA602A)]
S93662(16bit)	S93662(16bit)@SOIC8 [(SA602A)]
S93663(08bit)	S93663(08bit)@SOIC8 [(SA602A)]
S93663(16bit)	S93663(16bit)@SOIC8 [(SA602A)]
S93WD462(08bit)	S93WD462(08bit)@SOIC8 [(SA602A)]
S93WD462(16bit)	S93WD462(16bit)@SOIC8 [(SA602A)]
S93WD463(08bit)	S93WD463(08bit)@SOIC8 [(SA602A)]
S93WD463(16bit)	S93WD463(16bit)@SOIC8 [(SA602A)]
S93WD662(08bit)	S93WD662(08bit)@SOIC8 [(SA602A)]
S93WD662(16bit)	S93WD662(16bit)@SOIC8 [(SA602A)]
S93WD663(08bit)	S93WD663(08bit)@SOIC8 [(SA602A)]
S93WD663(16bit)	S93WD663(16bit)@SOIC8 [(SA602A)]

SUNPLUS**E(E) PROM/FRAM/NVRAM**

SPHE6400A	SPHE6400A@SOIC8 [(SA602A)]
-----------	----------------------------

MICROCONTROLLER

SPMC65P2102A(dip18)	
SPMC65P2102A(dip18)(ISP) [ISP-HEADER01]	
SPMC65P2102A@SOP18 [(SA404)]	
SPMC65P2102A@SOP18(ISP) [ISP-HEADER01]	
SPMC65P2104A(dip18)	
SPMC65P2104A(dip18)(ISP) [ISP-HEADER01]	
SPMC65P2104A@SOP18 [(SA404)]	
SPMC65P2104A@SOP18(ISP) [ISP-HEADER01]	
SPMC65P2202A(dip16)	
SPMC65P2202A(dip16)(ISP) [ISP-HEADER01]	
SPMC65P2202A(dip20)	
SPMC65P2202A(dip20)(ISP) [ISP-HEADER01]	
SPMC65P2202A@SOP16 [(SA404)]	
SPMC65P2202A@SOP16(ISP) [ISP-HEADER01]	

SPMC65P2202A@SOP20 [(SA404)]
 SPMC65P2202A@SOP20 (ISP) [ISP-HEADER01]
 SPMC65P2204A(dip16)
 SPMC65P2204A(dip16) (ISP) [ISP-HEADER01]
 SPMC65P2204A(dip20)
 SPMC65P2204A(dip20) (ISP) [ISP-HEADER01]
 SPMC65P2204A@SOP16 [(SA404)]
 SPMC65P2204A@SOP16 (ISP) [ISP-HEADER01]
 SPMC65P2204A@SOP20 [(SA404)]
 SPMC65P2204A@SOP20 (ISP) [ISP-HEADER01]
 SPMC65P2404A(dip20)
 SPMC65P2404A(dip20) (ISP) [ISP-HEADER01]
 SPMC65P2404A(dip28)
 SPMC65P2404A(dip28) (ISP) [ISP-HEADER01]
 SPMC65P2404A@SOP20 [(SA404)]
 SPMC65P2404A@SOP20 (ISP) [ISP-HEADER01]
 SPMC65P2404A@SOP28 [(SA404)]
 SPMC65P2404A@SOP28 (ISP) [ISP-HEADER01]
 SPMC65P2408A(dip28)
 SPMC65P2408A(dip28) (ISP) [ISP-HEADER01]
 SPMC65P2408A(dip32)
 SPMC65P2408A(dip32) (ISP) [ISP-HEADER01]
 SPMC65P2408A@SOP28 [(SA404)]
 SPMC65P2408A@SOP28 (ISP) [ISP-HEADER01]
 SPMC65P2408A@SOP32 [(SA603)]
 SPMC65P2408A@SOP32 (ISP) [ISP-HEADER01]

SYNCMOS

E (E) PROM / FRAM / NVRAM

F29C31004B	F29C31004B@PLCC32 [(SA015A1T)]
F29C31004B@TSOP32 [(SA410T)]	F29C31004T
F29C31004T@PLCC32 [(SA015A1T)]	F29C31004T@TSOP32 [(SA410T)]
F29C51000B	F29C51000B@PLCC32 [(SA015A1T)]
F29C51000T	F29C51000T@PLCC32 [(SA015A1T)]
F29C51001B	F29C51001B@PLCC32 [(SA015A1T)]
F29C51001B@TSOP32 [(SA410T)]	F29C51001T
F29C51001T@PLCC32 [(SA015A1T)]	F29C51001T@TSOP32 [(SA410T)]
F29C51002B	F29C51002B@PLCC32 [(SA015A1T)]
F29C51002B@TSOP32 [(SA410T)]	F29C51002T
F29C51002T@PLCC32 [(SA015A1T)]	F29C51002T@TSOP32 [(SA410T)]
F29C51004B	F29C51004B@PLCC32 [(SA015A1T)]
F29C51004B@TSOP32 [(SA410T)]	F29C51004T
F29C51004T@PLCC32 [(SA015A1T)]	F29C51004T@TSOP32 [(SA410T)]
F29LC51000	F29LC51000@PLCC32 [(SA015A1T)]
F29LC51001	F29LC51001@PLCC32 [(SA015A1T)]
F29LC51002	F29LC51002@PLCC32 [(SA015A1T)]
S29C31001B	S29C31001B@PLCC32 [(SA015A1T)]
S29C31001B@TSOP32 [(SA410T)]	S29C31001T
S29C31001T@PLCC32 [(SA015A1T)]	S29C31001T@TSOP32 [(SA410T)]
S29C31002B	S29C31002B@PLCC32 [(SA015A1T)]
S29C31002B@TSOP32 [(SA410T)]	S29C31002T
S29C31002T@PLCC32 [(SA015A1T)]	S29C31002T@TSOP32 [(SA410T)]
S29C31004B	S29C31004B@PLCC32 [(SA015A1T)]
S29C31004B@TSOP32 [(SA410T)]	S29C31004T
S29C31004T@PLCC32 [(SA015A1T)]	S29C31004T@TSOP32 [(SA410T)]
S29C51001B	S29C51001B@PLCC32 [(SA015A1T)]
S29C51001B@TSOP32 [(SA410T)]	S29C51001T
S29C51001T@PLCC32 [(SA015A1T)]	S29C51001T@TSOP32 [(SA410T)]
S29C51002B	S29C51002B@PLCC32 [(SA015A1T)]
S29C51002B@TSOP32 [(SA410T)]	S29C51002T
S29C51002T@PLCC32 [(SA015A1T)]	S29C51002T@TSOP32 [(SA410T)]
S29C51004B	S29C51004B@PLCC32 [(SA015A1T)]
S29C51004B@TSOP32 [(SA410T)]	S29C51004T
S29C51004T@PLCC32 [(SA015A1T)]	S29C51004T@TSOP32 [(SA410T)]

MICROCONTROLLER

MSU1958	MSU1958@PLCC44 [(SA244)]
MSU1958@TQFP44 [(SA245A)]	MSU2952
MSU2952@PLCC44 [(SA244)]	MSU2952@TQFP44 [(SA245A)]
MSU2964	MSU2964@PLCC44 [(SA244)]
MSU2964@TQFP44 [(SA245A)]	SM2958
SM2958@PLCC44 [(SA244)]	SM2958@TQFP44 [(SA245A)]
SM2965	SM2965@PLCC44 [(SA244)]

SM2965@TQFP44 [(SA245A)]	SM59064
SM59064@PLCC44 [(SA244)]	SM59064@TQFP44 [(SA245A)]
SM59128C	SM59128C@PLCC44 [(SA244)]
SM59128C@TQFP44 [(SA245A)]	SM59128L
SM59128L@PLCC44 [(SA244)]	SM59128L@TQFP44 [(SA245A)]
SM5912C	SM5912C(ISP) [ISP-HEADER01]
SM5912C@PLCC44 [(SA244-B002)]	
SM5912C@PLCC44(ISP) [ISP-HEADER01]	
SM5912C@TQFP44 [(SA675-B005)]	
SM5912C@TQFP44(ISP) [ISP-HEADER01]	
SM5912L	SM5912L(ISP) [ISP-HEADER01]
SM5912L@PLCC44 [(SA244-B002)]	
SM5912L@PLCC44(ISP) [ISP-HEADER01]	
SM5912L@TQFP44 [(SA675-B005)]	
SM5912L@TQFP44(ISP) [ISP-HEADER01]	
SM59164	SM59164@PLCC44 [(SA244)]
SM59164@TQFP44 [(SA245A)]	SM5916C
SM5916C(ISP) [ISP-HEADER01]	SM5916C@PLCC44 [(SA244-B002)]
SM5916C@PLCC44(ISP) [ISP-HEADER01]	
SM5916C@TQFP44 [(SA675-B005)]	
SM5916C@TQFP44(ISP) [ISP-HEADER01]	
SM5916L	SM5916L(ISP) [ISP-HEADER01]
SM5916L@PLCC44 [(SA244-B002)]	
SM5916L@PLCC44(ISP) [ISP-HEADER01]	
SM5916L@TQFP44 [(SA675-B005)]	
SM5916L@TQFP44(ISP) [ISP-HEADER01]	
SM59264	SM59264@PLCC44 [(SA244)]
SM59264@TQFP44 [(SA245A)]	SM5964
SM5964@PLCC44 [(SA244)]	SM5964@TQFP44 [(SA245A)]
SM5964A	SM5964A@PLCC44 [(SA244)]
SM5964A@TQFP44 [(SA245A)]	SM5964AC
SM5964AC@PLCC44 [(SA244)]	SM5964AC@TQFP44 [(SA245A)]
SM5964AL	SM5964AL@PLCC44 [(SA244)]
SM5964AL@TQFP44 [(SA245A)]	SM5964C
SM5964C@PLCC44 [(SA244)]	SM5964C@TQFP44 [(SA245A)]
SM5964D0	SM5964D0@PLCC44 [(SA244)]
SM5964D0@TQFP44 [(SA245A)]	SM5964D0A
SM5964D0A@PLCC44 [(SA244)]	SM5964D0A@TQFP44 [(SA245A)]
SM5964D1A	SM5964D1A@PLCC44 [(SA244)]
SM5964D1A@TQFP44 [(SA245A)]	SM59D02G2C
SM59D02G2C(ISP) [ISP-HEADER01]	SM59D02G2C@LQFP44 [(SA675-B005)]
SM59D02G2C@LQFP44(ISP) [ISP-HEADER01]	
SM59D02G2C@PLCC44 [(SA244-B002)]	
SM59D02G2C@PLCC44(ISP) [ISP-HEADER01]	
SM59D02G2L	SM59D02G2L(ISP) [ISP-HEADER01]
SM59D02G2L@LQFP44 [(SA675-B005)]	
SM59D02G2L@LQFP44(ISP) [ISP-HEADER01]	
SM59D02G2L@PLCC44 [(SA244-B002)]	
SM59D02G2L@PLCC44(ISP) [ISP-HEADER01]	
SM59D03G2C	SM59D03G2C(ISP) [ISP-HEADER01]
SM59D03G2C@LQFP44 [(SA675-B005)]	
SM59D03G2C@LQFP44(ISP) [ISP-HEADER01]	
SM59D03G2C@PLCC44 [(SA244-B002)]	
SM59D03G2C@PLCC44(ISP) [ISP-HEADER01]	
SM59D03G2L	SM59D03G2L(ISP) [ISP-HEADER01]
SM59D03G2L@LQFP44 [(SA675-B005)]	
SM59D03G2L@LQFP44(ISP) [ISP-HEADER01]	
SM59D03G2L@PLCC44 [(SA244-B002)]	
SM59D03G2L@PLCC44(ISP) [ISP-HEADER01]	
SM59D04G2C	SM59D04G2C(ISP) [ISP-HEADER01]
SM59D04G2C@LQFP44 [(SA675-B005)]	
SM59D04G2C@LQFP44(ISP) [ISP-HEADER01]	
SM59D04G2C@PLCC44 [(SA244-B002)]	
SM59D04G2C@PLCC44(ISP) [ISP-HEADER01]	
SM59D04G2L	SM59D04G2L(ISP) [ISP-HEADER01]
SM59D04G2L@LQFP44 [(SA675-B005)]	
SM59D04G2L@LQFP44(ISP) [ISP-HEADER01]	
SM59D04G2L@PLCC44 [(SA244-B002)]	
SM59D04G2L@PLCC44(ISP) [ISP-HEADER01]	
SM59R08A2@TQFP64(*) [(SA732-B292)]	
SM59R16A2@TQFP64(*) [(SA732-B292)]	
SM7908	SM7908@PLCC44 [(SA244)]
SM7908@TQFP44 [(SA245A)]	SM79108
SM79108@PLCC44 [(SA244)]	SM79108@TQFP44 [(SA245A)]
SM79164	SM79164@PLCC44 [(SA244)]
SM79164@TQFP44 [(SA245A)]	SM79164L
SM79164L@PLCC44 [(SA244)]	SM79164L@TQFP44 [(SA245A)]
SM79164V	SM79164V@PLCC44 [(SA244)]
SM79164V@TQFP44 [(SA245A)]	SM7932
SM7932@PLCC44 [(SA244)]	SM7932@TQFP44 [(SA245A)]
SM7964	SM7964@PLCC44 [(SA244)]

SM7964@TQFP44 [(SA245A)]	SM894051
SM894051@SOIC20 [(SA023A)]	SM8951
SM8951@PLCC44 [(SA244)]	SM8951@TQFP44 [(SA245A)]
SM89516	SM89516@PLCC44 [(SA244)]
SM89516@TQFP44 [(SA245A)]	SM89516A
SM89516A@PLCC44 [(SA244)]	SM89516A@TQFP44 [(SA245A)]
SM89516AL	SM89516AL@PLCC44 [(SA244)]
SM89516AL@TQFP44 [(SA245A)]	SM89516B
SM89516B@PLCC44 [(SA244)]	SM89516B@TQFP44 [(SA245A)]
SM89516BL	SM89516BL@PLCC44 [(SA244)]
SM89516BL@TQFP44 [(SA245A)]	SM89516L
SM89516L@PLCC44 [(SA244)]	SM89516L@TQFP44 [(SA245A)]
SM8951A	SM8951A@PLCC44 [(SA244)]
SM8951A@TQFP44 [(SA245A)]	SM8951AL
SM8951AL@PLCC44 [(SA244)]	SM8951AL@TQFP44 [(SA245A)]
SM8951B	SM8951B@PLCC44 [(SA244)]
SM8951B@TQFP44 [(SA245A)]	SM8951BL
SM8951BL@PLCC44 [(SA244)]	SM8951BL@TQFP44 [(SA245A)]
SM8951L	SM8951L@PLCC44 [(SA244)]
SM8951L@TQFP44 [(SA245A)]	SM8952
SM8952@PLCC44 [(SA244)]	SM8952@TQFP44 [(SA245A)]
SM8952A	SM8952A@PLCC44 [(SA244)]
SM8952A@TQFP44 [(SA245A)]	SM8952AL
SM8952AL@PLCC44 [(SA244)]	SM8952AL@TQFP44 [(SA245A)]
SM8952B	SM8952B@PLCC44 [(SA244)]
SM8952B@TQFP44 [(SA245A)]	SM8952BL
SM8952BL@PLCC44 [(SA244)]	SM8952BL@TQFP44 [(SA245A)]
SM8952L	SM8952L@PLCC44 [(SA244)]
SM8952L@TQFP44 [(SA245A)]	SM8954
SM8954@PLCC44 [(SA244)]	SM8954@TQFP44 [(SA245A)]
SM8954A	SM8954A@PLCC44 [(SA244)]
SM8954A@TQFP44 [(SA245A)]	SM8954AL
SM8954AL@PLCC44 [(SA244)]	SM8954AL@TQFP44 [(SA245A)]
SM8954B	SM8954B@PLCC44 [(SA244)]
SM8954B@TQFP44 [(SA245A)]	SM8954BL
SM8954BL@PLCC44 [(SA244)]	SM8954BL@TQFP44 [(SA245A)]
SM8954L	SM8954L@PLCC44 [(SA244)]
SM8954L@TQFP44 [(SA245A)]	SM8958
SM8958@PLCC44 [(SA244)]	SM8958@TQFP44 [(SA245A)]
SM8958A	SM8958A@PLCC44 [(SA244)]
SM8958A@TQFP44 [(SA245A)]	SM8958AL
SM8958AL@PLCC44 [(SA244)]	SM8958AL@TQFP44 [(SA245A)]
SM8958B	SM8958B@PLCC44 [(SA244)]
SM8958B@TQFP44 [(SA245A)]	SM8958BL
SM8958BL@PLCC44 [(SA244)]	SM8958BL@TQFP44 [(SA245A)]
SM8958L	SM8958L@PLCC44 [(SA244)]
SM8958L@TQFP44 [(SA245A)]	SM89S16R1C
SM89S16R1C@PLCC44 [(SA244)]	SM89S16R1C@TQFP44 [(SA245A)]
SM89T04R1C	SM89T04R1C@PLCC44 [(SA244)]
SM89T04R1C@TQFP44 [(SA245A)]	SM89T04R1L
SM89T04R1L@PLCC44 [(SA244)]	SM89T04R1L@TQFP44 [(SA245A)]
SM89T08R1C	SM89T08R1C@PLCC44 [(SA244)]
SM89T08R1C@TQFP44 [(SA245A)]	SM89T08R1L
SM89T08R1L@PLCC44 [(SA244)]	SM89T08R1L@TQFP44 [(SA245A)]
SM89T16R1C	SM89T16R1C@PLCC44 [(SA244)]
SM89T16R1C@TQFP44 [(SA245A)]	SM89T16R1L
SM89T16R1L@PLCC44 [(SA244)]	SM89T16R1L@TQFP44 [(SA245A)]

SYNERTEK

E(E) PROM/FRAM/NVRAM

SY2716

SYNTEK

MICROCONTROLLER

STK6011BP1-3V@PLCC44 [(SA244)]	STK6011BP21-5V@PLCC44 [(SA244)]
STK6011BP5-3V@TQFP44 [(SA245A)]	STK6011P10-5V@LQFP48 [(SA248)]
STK6011P1-3V@PLCC44 [(SA244)]	STK6011P2-5V@PLCC44 [(SA244)]
STK6011P3-3V@SDIP42 [(SA028)]	STK6011P4-5V@SDIP42 [(SA028)]
STK6011P5-3V@PQFP44 [(SA245A)]	STK6011P6-5V@PQFP44 [(SA245A)]
STK6011P7-3V	STK6011P8-5V

STK6011P9-3V@LQFP48 [(SA248)]	STK6012BP1-3V@PLCC44 [(SA244)]
STK6012BP22-5V@PLCC44 [(SA244)]	STK6012BP5-3V@TQFP44 [(SA245A)]
STK6012P10-5V@LQFP48 [(SA248)]	STK6012P1-3V@PLCC44 [(SA244)]
STK6012P2-5V@PLCC44 [(SA244)]	STK6012P3-3V@SDIP42 [(SA028)]
STK6012P4-5V@SDIP42 [(SA028)]	STK6012P5-3V@PQFP44 [(SA245A)]
STK6012P6-5V@PQFP44 [(SA245A)]	STK6012P7-3V
STK6012P8-5V	STK6012P9-3V@LQFP48 [(SA248)]
STK6031@LQFP48 [(SA248)]	STK6031@PLCC44 [(SA244)]
STK6031@QFP44 [(SA245A)]	STK6032
STK6032@LQFP48 [(SA248)]	STK6032@PLCC44 [(SA244)]
STK6032@QFP44 [(SA245A)]	STK6033
STK6033@LQFP48 [(SA248)]	STK6033@PLCC44 [(SA244)]
STK6033@QFP44 [(SA245A)]	

TECHCODE

MICROCONTROLLER

T89C516	T89C516@PLCC44 [(SA244)]
T89C516@TQFP44 [(SA245A)]	T89C52
T89C52@PLCC44 [(SA244)]	T89C52@TQFP44 [(SA245A)]
T89C58	T89C58@PLCC44 [(SA244)]
T89C58@TQFP44 [(SA245A)]	

TEKMOS

E(E) PROM/FRAM/NVRAM

TK17LV040@PLCC20 [(SA001A)]

TEMIC

MICROCONTROLLER

T89C51RD2	T89C51RD2@PLCC44 [(SA244)]
T89C51RD2@TQFP44 [(SA245A)]	T89F64
T89F64@PLCC44 [(SA244)]	T89F64@TQFP44 [(SA245A)]
TS87C51RB2	TS87C51RB2@PLCC44 [(SA244)]
TS87C51RB2@TQFP44 [(SA245A)]	TS87C51RC2
TS87C51RC2@PLCC44 [(SA244)]	TS87C51RC2@TQFP44 [(SA245A)]
TS87C51RD2	TS87C51RD2@PLCC44 [(SA244)]
TS87C51RD2@TQFP44 [(SA245A)]	TS87C51U2
TS87C51U2@PLCC44 [(SA244)]	TS87C51U2@TQFP44 [(SA245A)]
TS87C52X2	TS87C52X2@PLCC44 [(SA244)]
TS87C52X2@TQFP44 [(SA245A)]	TS87C54X2
TS87C54X2@PLCC44 [(SA244)]	TS87C54X2@TQFP44 [(SA245A)]
TS87C58X2	TS87C58X2@PLCC44 [(SA244)]
TS87C58X2@TQFP44 [(SA245A)]	TSC71RBX2
TSC71RBX2@PLCC44 [(SA244)]	TSC71RBX2@TQFP44 [(SA245A)]
TSC71RCX2	TSC71RCX2@PLCC44 [(SA244)]
TSC71RCX2@TQFP44 [(SA245A)]	TSC71RDX2
TSC71RDX2@PLCC44 [(SA244)]	TSC71RDX2@TQFP44 [(SA245A)]
TSC87251A1@PLCC44 [(SA244)]	TSC87251G1
TSC87251G1@PLCC44 [(SA244)]	TSC87251G1A
TSC87251G1A@PLCC44 [(SA244)]	TSC87251G2D
TSC87251G2D@PLCC44 [(SA244)]	TSC87251G2D@TQFP44 [(SA245A)]
TSC87C51	TSC87C51@PLCC44 [(SA244)]
TSC87C51@TQFP44 [(SA245A)]	TSC87C52
TSC87C52@PLCC44 [(SA244)]	TSC87C52@TQFP44 [(SA245A)]
TSC87C54	TSC87C54@PLCC44 [(SA244)]
TSC87C54@TQFP44 [(SA245A)]	TSC87C58
TSC87C58@PLCC44 [(SA244)]	TSC87C58@TQFP44 [(SA245A)]

Terra Semiconductor

E(E) PROM/FRAM/NVRAM

TS25L16AP	TS25L16AP@SOP8 [(SA023A)]
-----------	---------------------------

TS25L80AP

TS25L80AP@SOP8 [(SA023A)]

TI**E(E) PROM/FRAM/NVRAM**

BQ4010	BQ4010Y
BQ4011	BQ4011Y
BQ4013	BQ4013Y
BQ4014	BQ4014Y
BQ4015	BQ4015Y
SMJ2516	SMJ2532
SMJ2532A	SMJ2564
SMJ2564@PLCC32 [(SA015A1T)]	SMJ2716
SMJ27C256	SMJ27C256@PLCC32 [(SA015A1T)]
SMJ27C512	SMJ27C512@PLCC32 [(SA015A1T)]
TMS2516	TMS2516JLW
TMS2532	TMS2532A
TMS2564	TMS2564@PLCC32 [(SA015A1T)]
TMS25L32	TMS27128
TMS27128A	TMS2716
TMS2732	TMS2732A
TMS2764	TMS27C010
TMS27C010@PLCC32 [(SA015A1T)]	TMS27C010@TSOP32 [(SA410T)]
TMS27C010A	TMS27C010A@PLCC32 [(SA015A1T)]
TMS27C010A@TSOP32 [(SA410T)]	TMS27C020
TMS27C020@PLCC32 [(SA015A1T)]	TMS27C020@TSOP32 [(SA410T)]
TMS27C040	TMS27C040@PLCC32 [(SA015A1T)]
TMS27C040@TSOP32 [(SA410T)]	TMS27C128
TMS27C128@PLCC32 [(SA015A1T)]	TMS27C2001
TMS27C2001@PLCC32 [(SA015A1T)]	TMS27C2001@TSOP32 [(SA410T)]
TMS27C210	TMS27C210@PLCC44 [(SA244)]
TMS27C210A	TMS27C210A@PLCC44 [(SA244)]
TMS27C240	TMS27C240@PLCC44 [(SA244)]
TMS27C256	TMS27C256@PLCC32 [(SA015A1T)]
TMS27C291	TMS27C291@PLCC28 [(SA008A)]
TMS27C292	TMS27C292@PLCC28 [(SA008A)]
TMS27C32	TMS27C512
TMS27C512@PLCC32 [(SA015A1T)]	TMS27C64
TMS27LV010A	TMS27LV010A@PLCC32 [(SA015A1T)]
TMS27LV010A@TSOP32 [(SA410T)]	TMS27P32A
TMS27P64	TMS27PC010
TMS27PC010@PLCC32 [(SA015A1T)]	TMS27PC010@TSOP32 [(SA410T)]
TMS27PC010A	TMS27PC010A@PLCC32 [(SA015A1T)]
TMS27PC010A@TSOP32 [(SA410T)]	TMS27PC020
TMS27PC020@PLCC32 [(SA015A1T)]	TMS27PC020@TSOP32 [(SA410T)]
TMS27PC040	TMS27PC040@PLCC32 [(SA015A1T)]
TMS27PC040@TSOP32 [(SA410T)]	TMS27PC128
TMS27PC128@PLCC32 [(SA015A1T)]	TMS27PC210
TMS27PC210@PLCC44 [(SA244)]	TMS27PC210A
TMS27PC210A@PLCC44 [(SA244)]	TMS27PC240
TMS27PC240@PLCC44 [(SA244)]	TMS27PC256
TMS27PC256@PLCC32 [(SA015A1T)]	TMS27PC291
TMS27PC291@PLCC28 [(SA008A)]	TMS27PC32
TMS27PC32A	TMS27PC512
TMS27PC512@PLCC32 [(SA015A1T)]	TMS27PC64
TMS28F010	TMS28F010@PLCC32 [(SA015A1T)]
TMS28F010@TSOP32 [(SA410T)]	TMS28F020
TMS28F020@PLCC32 [(SA015A1T)]	TMS28F020@TSOP32 [(SA410T)]
TMS28F210	TMS28F210@PLCC44 [(SA244)]
TMS28F210@TSOP40 [(SA409T)]	TMS28F512
TMS28F512@PLCC32 [(SA015A1T)]	TMS28F512@TSOP32 [(SA410T)]
TMS29F040	TMS29F040@PLCC32 [(SA015A1T)]
TMS29F040@TSOP32 [(SA410T)]	TMS29F259
TMS29F259@PLCC32 [(SA015A1T)]	TMS29F259@TSOP32 [(SA410T)]
TMS29F512	TMS29F512@PLCC32 [(SA015A1T)]
TMS29F512@TSOP32 [(SA410T)]	TMS87C257
TMS87C257@PLCC32 [(SA015A1T)]	

PLD

EP330	EP330@PLCC20 [(SA001A)]
EP910	EP910-P44 [(SA244)]

MICROCONTROLLER

```

MSP430F1122@SOIC20 (ISP) [ISP-HEADER01]
MSP430F1122@TSSOP20 (ISP) [ISP-HEADER01]
MSP430F1132@SOIC20 (ISP) [ISP-HEADER01]
MSP430F1132@TSSOP20 (ISP) [ISP-HEADER01]
MSP430F1222@SOIC28 (ISP) [ISP-HEADER01]
MSP430F1222@TSSOP28 (ISP) [ISP-HEADER01]
MSP430F1232@SOIC28 (ISP) [ISP-HEADER01]
MSP430F1232@TSSOP28 (ISP) [ISP-HEADER01]
MSP430F133@QFN64 (ISP) [ISP-HEADER01]
MSP430F133@TQFP64 (ISP) [ISP-HEADER01]
MSP430F135@QFN64 (ISP) [ISP-HEADER01]
MSP430F135@TQFP64 (ISP) [ISP-HEADER01]
MSP430F147@QFN64 (ISP) [ISP-HEADER01]
MSP430F147@TQFP64 (ISP) [ISP-HEADER01]
MSP430F1471@QFN64 (ISP) [ISP-HEADER01]
MSP430F1471@TQFP64 (ISP) [ISP-HEADER01]
MSP430F148@QFN64 (ISP) [ISP-HEADER01]
MSP430F148@TQFP64 (ISP) [ISP-HEADER01]
MSP430F1481@QFN64 (ISP) [ISP-HEADER01]
MSP430F1481@TQFP64 (ISP) [ISP-HEADER01]
MSP430F149@QFN64 (ISP) [ISP-HEADER01]
MSP430F149@TQFP64 (ISP) [ISP-HEADER01]
MSP430F1491@QFN64 (ISP) [ISP-HEADER01]
MSP430F1491@TQFP64 (ISP) [ISP-HEADER01]
MSP430F155@QFN64 (ISP) [ISP-HEADER01]
MSP430F155@TQFP64 (ISP) [ISP-HEADER01]
MSP430F156@QFN64 (ISP) [ISP-HEADER01]
MSP430F156@TQFP64 (ISP) [ISP-HEADER01]
MSP430F157@QFN64 (ISP) [ISP-HEADER01]
MSP430F157@TQFP64 (ISP) [ISP-HEADER01]
MSP430F1610@QFN64 (ISP) [ISP-HEADER01]
MSP430F1610@TQFP64 (ISP) [ISP-HEADER01]
MSP430F1611@QFN64 (ISP) [ISP-HEADER01]
MSP430F1611@TQFP64 (ISP) [ISP-HEADER01]
MSP430F1612@QFN64 (ISP) [ISP-HEADER01]
MSP430F1612@TQFP64 (ISP) [ISP-HEADER01]
MSP430F167@QFN64 (ISP) [ISP-HEADER01]
MSP430F167@TQFP64 (ISP) [ISP-HEADER01]
MSP430F168@QFN64 (ISP) [ISP-HEADER01]
MSP430F168@TQFP64 (ISP) [ISP-HEADER01]
MSP430F169@QFN64 (ISP) [ISP-HEADER01]
MSP430F169@TQFP64 (ISP) [ISP-HEADER01]
MSP430F412@QFN64 (ISP) [ISP-HEADER01]
MSP430F412@TQFP64 (ISP) [ISP-HEADER01]
MSP430F413@QFN64 (ISP) [ISP-HEADER01]
MSP430F413@TQFP64 (ISP) [ISP-HEADER01]
MSP430F435@TQFP100 (ISP) [ISP-HEADER01]
MSP430F435@TQFP80 (ISP) [ISP-HEADER01]
MSP430F4351@TQFP100 (ISP) [ISP-HEADER01]
MSP430F4351@TQFP80 (ISP) [ISP-HEADER01]
MSP430F436@TQFP100 (ISP) [ISP-HEADER01]
MSP430F436@TQFP80 (ISP) [ISP-HEADER01]
MSP430F4361@TQFP100 (ISP) [ISP-HEADER01]
MSP430F4361@TQFP80 (ISP) [ISP-HEADER01]
MSP430F437@TQFP100 (ISP) [ISP-HEADER01]
MSP430F437@TQFP80 (ISP) [ISP-HEADER01]
MSP430F4371@TQFP100 (ISP) [ISP-HEADER01]
MSP430F4371@TQFP80 (ISP) [ISP-HEADER01]
MSP430F447@TQFP100 (ISP) [ISP-HEADER01]
MSP430F448@TQFP100 (ISP) [ISP-HEADER01]
MSP430F449@TQFP100 (ISP) [ISP-HEADER01]
MSP430FG4250@QFN48 (ISP) [ISP-HEADER01]
MSP430FG4260@QFN48 (ISP) [ISP-HEADER01]
MSP430FG4270@QFN48 (ISP) [ISP-HEADER01]
MSP430FG437@TQFP100 (ISP) [ISP-HEADER01]
MSP430FG437@TQFP80 (ISP) [ISP-HEADER01]
MSP430FG438@TQFP100 (ISP) [ISP-HEADER01]
MSP430FG438@TQFP80 (ISP) [ISP-HEADER01]
MSP430FG439@TQFP100 (ISP) [ISP-HEADER01]
MSP430FG439@TQFP80 (ISP) [ISP-HEADER01]

```

TMC

E (E) PROM / FRAM / NVRAM

```

24A01                                     24A01@SOIC8 [ (SA602A) ]
24A01@TSSOP8 [ (SA026) ]                24A02

```

24A02@SOIC8 [(SA602A)]	24A02@TSSOP8 [(SA026)]
24A04	24A04@SOIC8 [(SA602A)]
24A04@TSSOP8 [(SA026)]	24A08
24A08@SOIC8 [(SA602A)]	24A08@TSSOP8 [(SA026)]
24A16	24A16@SOIC8 [(SA602A)]
24A16@TSSOP8 [(SA026)]	93LC46(08bit)
93LC46(08bit)@SOIC8 [(SA602A)]	93LC46(08bit)@TSSOP8 [(SA026)]
93LC46(16bit)	93LC46(16bit)@SOIC8 [(SA602A)]
93LC46(16bit)@TSSOP8 [(SA026)]	93LC56(08bit)
93LC56(08bit)@SOIC8 [(SA602A)]	93LC56(08bit)@TSSOP8 [(SA026)]
93LC56(16bit)	93LC56(16bit)@SOIC8 [(SA602A)]
93LC56(16bit)@TSSOP8 [(SA026)]	93LC57
93LC57@SOIC8 [(SA602A)]	93LC57@TSSOP8 [(SA026)]
93LC66(08bit)	93LC66(08bit)@SOIC8 [(SA602A)]
93LC66(08bit)@TSSOP8 [(SA026)]	93LC66(16bit)
93LC66(16bit)@SOIC8 [(SA602A)]	93LC66(16bit)@TSSOP8 [(SA026)]
93LC86(08bit)	93LC86(08bit)@SOIC8 [(SA602A)]
93LC86(08bit)@TSSOP8 [(SA026)]	93LC86(16bit)
93LC86(16bit)@SOIC8 [(SA602A)]	93LC86(16bit)@TSSOP8 [(SA026)]

TOPRO

MICROCONTROLLER

TP2804H	TP2804H@PLCC44 [(SA244)]
TP2804H@TQFP44 [(SA245A)]	TP2804L
TP2804L@PLCC44 [(SA244)]	TP2804L@TQFP44 [(SA245A)]
TP2808H	TP2808H@PLCC44 [(SA244)]
TP2808H@TQFP44 [(SA245A)]	TP2808L
TP2808L@PLCC44 [(SA244)]	TP2808L@TQFP44 [(SA245A)]
TP2851	TP2851@PLCC44 [(SA244)]
TP2851@TQFP44 [(SA245A)]	TP2852
TP2852@PLCC44 [(SA244)]	TP2852@TQFP44 [(SA245A)]

TOSHIBA

E(E) PROM/FRAM/NVRAM

TC541000AF@PLCC32 [(SA015A1T)]	TC541000AP
TC541001AF@PLCC32 [(SA015A1T)]	TC541001AP
TC54256AF	TC54256AF@SOIC28 [(SA404)]
TC54256AP	TC54256AP@SOIC28 [(SA404)]
TC544000P	TC54512AF
TC54512AP	TC571000
TC571000AD	TC571000D
TC571001AD	TC571001D
TC571024D	TC57256
TC57256A	TC57256AD
TC57256ADI	TC57256D
TC574000D	TC574096D
TC574200D	TC57512
TC57512AD	TC578200D
TC57H1000AD	TC57H1001AD
TC57H256D	TC89101(08bit)
TC89101(16bit)	TC89102(08bit)
TC89102(16bit)	TC89121
TC89121@SOIC8 [(SA602A)]	TC89122
TC89122@SOIC8 [(SA602A)]	TC97101
TC9WMA1FK@US8 [(BBBB)]	TC9WMA2FK@US8 [(BBBB)]
TC9WMB1AFK@US8 [(BBBB)]	TC9WMB1AFU@SM8 [(SA666)]
TC9WMB1FK@US8 [(BBBB)]	TC9WMB2AFK@US8 [(BBBB)]
TC9WMB2AFU@SM8 [(SA666)]	TC9WMB2FK@US8 [(BBBB)]
TC9WMB4FU@SM8 [(SA666)]	TC9WMB8FU@SM8 [(SA666)]
TC9WMC1FK@US8 [(BBBB)]	TC9WMC1FU@SM8 [(SA666)]
TC9WMC2FK@US8 [(BBBB)]	TC9WMC2FU@SM8 [(SA666)]
TC9WMC4FK@US8 [(BBBB)]	TC9WMC4FU@SM8 [(SA602A)]
TMM24128	TMM24128A
TMM24128AP	TMM24256
TMM24256A	TMM24256AP
TMM24256B	TMM24512
TMM24512A	TMM24512P
TMM2464AP	TMM27128
TMM27128A	TMM27128ADI
TMM27128AP	TMM27256

TMM27256A	TMM27256AD
TMM27256ADI	TMM27256BD
TMM27256BDI	TMM27256D
TMM27256DI	TMM2732
TMM2732A	TMM2732D
TMM27512	TMM27512AD
TMM27512ADI	TMM27512D
TMM27512DI	TMM2764
TMM2764AD	TMM2764ADI
TMM2764AP	TMM2764D
TMM2764DI	

DRAM & SRAM

TC518128	TC518128@SOIC32 [(SA630)]
TC518129	TC518129@SOIC32 [(SA630)]
TC51832	TC51832@SOIC28 [(SA630)]
TC518512	TC518512@SOIC32 [(SA630)]
TC551001FL	TC551001FL@SOIC32 [(SA630)]
TC551001PL	TC551001PL@SOIC32 [(SA630)]
TC55257	TC55257@SOIC28 [(SA630)]
TC55257L	TC55257L@SOIC28 [(SA630)]
TC55258	TC55258@SOIC28 [(SA630)]
TC55258L	TC55258L@SOIC28 [(SA630)]
TC55328	TC55328@SOIC28 [(SA630)]
TC5561P	TC5561P@SOJ24 [(SA646)]
TC5562P	TC5562P@SOJ24 [(SA646)]
TC5563APL	TC5563APL@SOIC28 [(SA630)]
TC5564APL	TC5564APL@SOIC28 [(SA630)]
TC5565AFL	TC5565AFL@SOIC28 [(SA630)]
TC5565APL	TC5565APL@SOIC28 [(SA630)]
TC5588	TC5588@SOIC28 [(SA630)]
TC55B88	TC55B88@SOIC28 [(SA630)]
TMM2018	TMM2018@PLCC32 [(SA015A1T)]
TMM2063	TMM2063@SOIC28 [(SA630)]

MICROCONTROLLER

TMP87P808LM@SOP28 (Toshiba) [(BM11116)]
TMP87P808LN@SDIP28 (Toshiba) [(BM11122)]
TMP87P808M@SOP28 (Toshiba) [(BM11116)]
TMP87P808N@SDIP28 (Toshiba) [(BM11122)]
TMP87P844N@SDIP42 (Toshiba) [(BM11108)]
TMP87P844NG@SDIP42 (Toshiba) [(BM11108)]
TMP87PH00DF@QFP64 (Toshiba) [(BM1173)]
TMP87PH00F@QFP64 (Toshiba) [(BM1137)]
TMP87PH00LF@QFP64 (Toshiba) [(BM1173)]
TMP87PH00N@SDIP64 (Toshiba) [(BM1136)]
TMP87PH20F@QFP80 (Toshiba) [(BM1138)]
TMP87PH40AF@PQFP64 (Toshiba) [(BM1137)]
TMP87PH40AN@SDIP64 (Toshiba) [(BM1136)]
TMP87PH46N@SDIP42 (Toshiba) [(BM1193)]
TMP87PH47LU@QFP44 (Toshiba) [(BM1194C)]
TMP87PH47U@QFP44 (Toshiba) [(BM1194C)]
TMP87PM14F@QFP64 (Toshiba) [(BM1199)]
TMP87PM14N@SDIP64 (Toshiba) [(BM1198)]
TMP87PM20F@QFP80 (Toshiba) [(BM1138)]
TMP87PM29U@LQFP64 (Toshiba) [(BM11117)]
TMP87PM34AN@SDIP42 (Toshiba) [(BM1183A)]
TMP87PM36N@SDIP42 (Toshiba) [(BM1183A)]
TMP87PM40AF@PQFP64 (Toshiba) [(BM1137)]
TMP87PM40AN@SDIP64 (Toshiba) [(BM1136)]
TMP87PM41F@QFP64 (Toshiba) [(BM1137)]
TMP87PM41N@SDIP64 (Toshiba) [(BM1136)]
TMP87PM41U@LQFP64 (Toshiba) [(BM1121)]
TMP87PM43N@SDIP42 (Toshiba) [(BM1163)]
TMP87PM70F@QFP80 (Toshiba) [(BM1150B)]
TMP87PM74F@QFP80 (Toshiba) [(BM11120)]
TMP87PM75F@QFP100 (Toshiba) [(BM11124)]
TMP87PM78F@QFP100 (Toshiba) [(BM1188)]
TMP87PP21DF@LQFP80 (Toshiba) [(BM11105)]
TMP87PP21F@QFP80 (Toshiba) [(BM11104)]
TMP87PP23F@QFP100 (Toshiba) [(BM1185A)]
TMP87PP24F@LQFP100 (Toshiba) [(BM11127)]
TMP87PP71F@QFP80 (Toshiba) [(BM11107)]
TMP87PS38F@QFP44 (Toshiba) [(BM11136)]
TMP87PS38N@SDIP42 (Toshiba) [(BM11112)]
TMP87PS39F@QFP64 (Toshiba) [(BM11138)]

TMP87PS39N@SDIP64(Toshiba) [(BM11118)]
 TMP87PS64F@QFP100(Toshiba) [(BM1185A)]
 TMP87PS71F@QFP80(Toshiba) [(BM11107)]

TURBO IC

E(E) PROM/FRAM/NVRAM

TU24C01	TU24C01@SOIC8 [(SA602A)]
TU24C02	TU24C02@SOIC8 [(SA602A)]
TU24C04	TU24C04@SOIC8 [(SA602A)]
TU24C08	TU24C08@SOIC8 [(SA602A)]
TU24C128	TU24C128@SOIC8 [(SA602A)]
TU24C16	TU24C16@SOIC8 [(SA602A)]
TU24C16@TSSOP8 [(SA026)]	TU24C256
TU24C256@SOIC8 [(SA602A)]	TU24C32
TU24C32@SOIC8 [(SA602A)]	TU24C64
TU24C64@SOIC8 [(SA602A)]	

UMC

E(E) PROM/FRAM/NVRAM

2732	2764
------	------

DRAM & SRAM

UM6116	UM6116@PLCC32 [(SA015A1T)]
UM6116A	UM6116A@PLCC32 [(SA015A1T)]
UM61256	UM61256@SOIC28 [(SA630)]
UM61257	UM61512
UM61512@SOIC32 [(SA630)]	UM6164
UM6164@SOIC28 [(SA630)]	UM6167
UM621024	UM621024@SOIC32 [(SA630)]
UM62256	UM62256@SOIC28 [(SA630)]
UM62256A	UM62256A@SOIC28 [(SA630)]
UM6264	UM6264@SOIC28 [(SA630)]
UM6264A	UM6264A@SOIC28 [(SA630)]

UTRON

E(E) PROM/FRAM/NVRAM

UT61256C	UT61256C@SOIC28 [(SA630)]
UT61256C@TSOP28 [(SA430T)]	UT6164C@SOIC28 [(SA630)]
UT6164C@TSOP28 [(SA430T)]	UT61L256C
UT61L256C@SOIC28 [(SA630)]	UT61L256C@TSOP28 [(SA430T)]
UT62256C	UT62256C@SOIC28 [(SA630)]
UT62256C@TSOP28 [(SA430T)]	UT62256CE
UT62256CE@SOIC28 [(SA630)]	UT62256CE@TSOP28 [(SA430T)]
UT62257C	UT62257C@SOIC28 [(SA630)]
UT62257C@TSOP28 [(SA430T)]	UT6264C
UT6264C@SOIC28 [(SA630)]	UT62L256C
UT62L256C@SOIC28 [(SA630)]	UT62L256C@TSOP28 [(SA430T)]
UT62L64C	UT62L64C@SOIC28 [(SA630)]
UT62W256C	UT62W256C@SOIC28 [(SA630)]
UT62W256C@TSOP28 [(SA430T)]	UT62W64C
UT62W64C@SOIC28 [(SA630)]	

VLSI

E(E) PROM/FRAM/NVRAM

VT27C128	VT27C256
VT27C512	VT27C64
VT28H64	VT28HC64

PLD

GAL16V8

WELTREND**MICROCONTROLLER**

WT6703F@SOP20 [(SA404)]	WT6703F@SOP24 [(SA404)]
WT6703F@SOP28 [(SA404)]	WT6703F@SSOP20 [(SA674)]
WT6703F@SSOP24 [(SA674)]	WT6703FS161@SSOP16 [(SA602)]
WT6703FS163@SSOP16 [(SA602)]	

WHITE ELECTRONIC DESIGNS**E (E) PROM/FRAM/NVRAM**

WE128K8	WE256K8
WE512K8	WF256K8
WF256K8@CLCC32 [(SA015A1T)]	WF256K8@CSOJ32 [(SA661)]
WF512K8	WF512K8@CLCC32 [(SA015A1T)]
WF512K8@CSOJ32 [(SA661)]	WME128K8
WME128K8@CLCC32 [(SA015A1T)]	WME128K8@CSOJ32 [(SA661)]
WMF128K8	WMF128K8@CLCC32 [(SA015A1T)]
WMF128K8@CSOJ32 [(SA661)]	WMF256K8
WMF256K8@CLCC32 [(SA015A1T)]	WMF256K8@CSOJ32 [(SA661)]
WMF512K8	WMF512K8@CLCC32 [(SA015A1T)]
WMF512K8@CSOJ32 [(SA661)]	WMS128K8
WMS128K8@CLCC32 [(SA015A1T)]	WMS128K8@CSOJ32 [(SA661)]
WMS256K8	WMS256K8@CLCC32 [(SA015A1T)]
WMS256K8@CSOJ32 [(SA661)]	WMS512K8
WMS512K8@CLCC32 [(SA015A1T)]	WMS512K8@CSOJ32 [(SA661)]

WINBOND**E (E) PROM/FRAM/NVRAM**

W15B020L	W15B020L@SOIC8 [(SA602A)]
W15B020M	W15B020M@SOIC8 [(SA602A)]
W15B040L	W15B040L@SOIC8 [(SA602A)]
W15B040M	W15B040M@SOIC8 [(SA602A)]
W25B40 (Bottom Boot)@SOIC8 [(SA602A)]	
W25B40 (Bottom Boot)@WSON8 [(SA683)]	
W25B40 (Top Boot)@SOIC8 [(SA602A)]	
W25B40 (Top Boot)@WSON8 [(SA683)]	
W25B40A (Bottom Boot)@SOIC8 [(SA602A)]	
W25B40A (Bottom Boot)@WSON8 [(SA683)]	
W25B40A (Top Boot)@SOIC8 [(SA602A)]	
W25B40A (Top Boot)@WSON8 [(SA683)]	
W25D10	W25D10 (SN)@SOIC8 [(SA602A)]
W25D10 (SS)@SOIC8 [(SA023A)]	W25D10 (ZP)@WSON8 [(SA683)]
W25D20	W25D20 (SN)@SOIC8 [(SA602A)]
W25D20 (SS)@SOIC8 [(SA023A)]	W25D20 (ZP)@WSON8 [(SA683)]
W25D40	W25D40 (SN)@SOIC8 [(SA602A)]
W25D40 (SS)@SOIC8 [(SA023A)]	W25D40 (ZP)@WSON8 [(SA683)]
W25D80	W25D80 (SN)@SOIC8 [(SA602A)]
W25D80 (SS)@SOIC8 [(SA023A)]	W25D80 (ZP)@WSON8 [(SA683)]
W25P10@SOIC8 [(SA602A)]	W25P10@WSON8 [(SA683)]
W25P16@SOIC16 [(SA404)]	
W25P16@SOIC16 (ISP) [ISP-HEADER01]	
W25P16@SOIC8 [(SA023A)]	W25P16@SOIC8 (ISP) [ISP-HEADER01]
W25P16@WSON8 [(SA683)]	W25P16@WSON8 (ISP) [ISP-HEADER01]
W25P20@SOIC8 [(SA602A)]	W25P20@WSON8 [(SA683)]
W25P32@SOIC16 [(SA404)]	
W25P32@SOIC16 (ISP) [ISP-HEADER01]	
W25P32@WSON8 [(SA683)]	W25P32@WSON8 (ISP) [ISP-HEADER01]
W25P40@SOIC8 [(SA602A)]	W25P40@WSON8 [(SA683)]
W25P64@SOIC16 [(SA404)]	
W25P64@SOIC16 (ISP) [ISP-HEADER01]	
W25P64@WSON8 [(SA683)]	W25P64@WSON8 (ISP) [ISP-HEADER01]
W25P80@SOIC8 [(SA602A)]	W25P80@WSON8 [(SA683)]

W25Q128BV@SOIC16 [(SA404)]	W25Q128BV@WSON8 [(SA684)]
W25Q16@SOIC16 [(SA404)]	
W25Q16@SOIC16 (ISP) [ISP-HEADER01]	
W25Q16@SOIC8 [(SA023A)]	W25Q16@SOIC8 (ISP) [ISP-HEADER01]
W25Q16@WSON8 [(SA683)]	W25Q16@WSON8 (ISP) [ISP-HEADER01]
W25Q16BV@SOIC16 [(SA404)]	W25Q16BV@SOIC8 [(SA023A)]
W25Q16BV@WSON8 [(SA683)]	W25Q16V@SOIC16 [(SA404)]
W25Q16V@SOIC8 [(SA023A)]	W25Q16V@WSON8 [(SA683)]
W25Q32@SOIC16 [(SA404)]	
W25Q32@SOIC16 (ISP) [ISP-HEADER01]	
W25Q32@SOIC8 [(SA023A)]	W25Q32@WSON8 [(SA683)]
W25Q32@WSON8 (ISP) [ISP-HEADER01]	W25Q32BV@SOIC16 [(SA404)]
W25Q32BV@SOIC8 [(SA023A)]	W25Q32BV@WSON8 [(SA683)]
W25Q32V@SOIC16 [(SA404)]	W25Q32V@SOIC8 [(SA023A)]
W25Q32V@WSON8 [(SA683)]	W25Q64BV@SOIC16 [(SA404)]
W25Q64BV@SOIC8 [(SA023A)]	W25Q80@SOIC8 [(SA602A)]
W25Q80@WSON8 [(SA683)]	W25Q80BV
W25Q80BV@SOIC16 [(SA602A)]	W25Q80BV@SOIC8[4.0] [(SA602A)]
W25Q80BV@SOIC8[5.4] [(SA605A)]	W25Q80BV@WSON8 [(SA683)]
W25X10	W25X10(SN)@SOIC8 [(SA602A)]
W25X10(SS)@SOIC8 [(SA023A)]	W25X10(ZP)@WSON8 [(SA683)]
W25X10AV	W25X10AV(SN)@SOIC8 [(SA602A)]
W25X10AV(SS)@SOIC8 [(SA023A)]	W25X10AV(ZP)@WSON8 [(SA683)]
W25X10BV	W25X10BV(SN)@SOIC8 [(SA602A)]
W25X10BV(SS)@SOIC8 [(SA023A)]	W25X10BV(ZP)@WSON8 [(SA683)]
W25X10L	W25X10L(SN)@SOIC8 [(SA602A)]
W25X10L(ZP)@WSON8 [(SA683)]	W25X10V
W25X10V(SN)@SOIC8 [(SA602A)]	W25X10V(SS)@SOIC8 [(SA023A)]
W25X10V(ZP)@WSON8 [(SA683)]	W25X16@SOIC16 [(SA404)]
W25X16@SOIC16 (ISP) [ISP-HEADER01]	
W25X16@SOIC8 [(SA023A)]	W25X16@SOIC8 (ISP) [ISP-HEADER01]
W25X20	W25X20(SN)@SOIC8 [(SA602A)]
W25X20(SS)@SOIC8 [(SA023A)]	W25X20(ZP)@WSON8 [(SA683)]
W25X20AV	W25X20AV(SN)@SOIC8 [(SA602A)]
W25X20AV(SS)@SOIC8 [(SA023A)]	W25X20AV(ZP)@WSON8 [(SA683)]
W25X20BV	W25X20BV(SN)@SOIC8 [(SA602A)]
W25X20BV(SS)@SOIC8 [(SA023A)]	W25X20BV(ZP)@WSON8 [(SA683)]
W25X20L	W25X20L(SN)@SOIC8 [(SA602A)]
W25X20L(ZP)@WSON8 [(SA683)]	W25X20V
W25X20V(SN)@SOIC8 [(SA602A)]	W25X20V(SS)@SOIC8 [(SA023A)]
W25X20V(ZP)@WSON8 [(SA683)]	W25X32@SOIC16 [(SA404)]
W25X32@SOIC16 (ISP) [ISP-HEADER01]	
W25X32@SOIC8 [(SA023A)]	W25X32@SOIC8 (ISP) [ISP-HEADER01]
W25X40	W25X40(SN)@SOIC8 [(SA602A)]
W25X40(SS)@SOIC8 [(SA023A)]	W25X40(ZP)@WSON8 [(SA683)]
W25X40AV	W25X40AV(SN)@SOIC8 [(SA602A)]
W25X40AV(SS)@SOIC8 [(SA023A)]	W25X40AV(ZP)@WSON8 [(SA683)]
W25X40BV	W25X40BV(SN)@SOIC8 [(SA602A)]
W25X40BV(SS)@SOIC8 [(SA023A)]	W25X40BV(ZP)@WSON8 [(SA683)]
W25X40L	W25X40L(SN)@SOIC8 [(SA602A)]
W25X40L(SS)@SOIC8 [(SA023A)]	W25X40L(ZP)@WSON8 [(SA683)]
W25X40V	W25X40V(SN)@SOIC8 [(SA602A)]
W25X40V(SS)@SOIC8 [(SA023A)]	W25X40V(ZP)@WSON8 [(SA683)]
W25X64@SOIC16 [(SA404)]	
W25X64@SOIC16 (ISP) [ISP-HEADER01]	
W25X64@SOIC8 [(SA023A)]	W25X64@SOIC8 (ISP) [ISP-HEADER01]
W25X80	W25X80(SN)@SOIC8 [(SA602A)]
W25X80(SS)@SOIC8 [(SA023A)]	W25X80(ZP)@WSON8 [(SA683)]
W25X80AV	W25X80AV(SN)@SOIC8 [(SA602A)]
W25X80AV(SS)@SOIC8 [(SA023A)]	W25X80AV(ZP)@WSON8 [(SA683)]
W25X80L	W25X80L(SS)@SOIC8 [(SA023A)]
W25X80L(ZP)@WSON8 [(SA683)]	W25X80V
W25X80V(SN)@SOIC8 [(SA602A)]	W25X80V(SS)@SOIC8 [(SA023A)]
W25X80V(ZP)@WSON8 [(SA683)]	W27C01
W27C01@PLCC32 [(SA015A1T)]	W27C01@VSOP32 [(SA620)]
W27C010	W27C010@PLCC32 [(SA015A1T)]
W27C010@SOIC32 [(SA438T)]	W27C02
W27C02@PLCC32 [(SA015A1T)]	W27C02@VSOP32 [(SA620)]
W27C020	W27C020@PLCC32 [(SA015A1T)]
W27C020M	W27C020M@PLCC32 [(SA015A1T)]
W27C257	W27C257@PLCC32 [(SA015A1T)]
W27C4096	W27C4096@PLCC44 [(SA244)]
W27C4096@TSOP40 [(SA409T)]	W27C512
W27C512@PLCC32 [(SA015A1T)]	W27C512@TSOP28 [(SA430T)]
W27C520@SOIC20 [(SA404)]	W27C520@TSSOP20 [(SA026)]
W27E01	W27E01@PLCC32 [(SA015A1T)]
W27E01@VSOP32 [(SA620)]	W27E010
W27E010@PLCC32 [(SA015A1T)]	W27E010@SOIC32 [(SA438T)]
W27E02	W27E02@PLCC32 [(SA015A1T)]
W27E02@VSOP32 [(SA620)]	W27E020
W27E020@PLCC32 [(SA015A1T)]	W27E040

W27E040@PLCC32 [(SA015A1T)]	W27E040@SOIC32 [(SA438T)]
W27E257	W27E257@PLCC32 [(SA015A1T)]
W27E4096	W27E4096@PLCC44 [(SA244)]
W27E4096@TSOP40 [(SA409T)]	W27E512
W27E512@PLCC32 [(SA015A1T)]	W27E512@TSOP28 [(SA430T)]
W27E520@SOIC20 [(SA404)]	W27E520@TSSOP20 [(SA026)]
W27L01	W27L01@PLCC32 [(SA015A1T)]
W27L01@VSOP32 [(SA620)]	W27L010
W27L010@PLCC32 [(SA015A1T)]	W27L02
W27L02@PLCC32 [(SA015A1T)]	W27L02@VSOP32 [(SA620)]
W27L520@SOIC20 [(SA404)]	W27L520@TSSOP20 [(SA026)]
W29C010	W29C010@PLCC32 [(SA015A1T)]
W29C011A	W29C011A@PLCC32 [(SA015A1T)]
W29C020	W29C020@PLCC32 [(SA015A1T)]
W29C020@SOIC32 [(SA438T)]	W29C020@TSOP32 [(SA410T)]
W29C020C	
W29C020C@PLCC32 [(SA015A1T-B001)]	W29C020C@VSOP32 [(SA620-B005)]
W29C020C@TSOP32 [(SA410T-B003)]	W29C040@PLCC32 [(SA015A1T-B001)]
W29C040	W29C040@VSOP32 [(SA620-B005)]
W29C040@TSOP32 [(SA410T-B003)]	W29C101@PLCC44 [(SA244)]
W29C101	W29C102
W29C101@TSOP40 [(SA409T)]	W29C102@TSOP40 [(SA409T)]
W29C102@PLCC44 [(SA244)]	W29EE010@PLCC32 [(SA015A1T)]
W29EE010	W29EE010@TSOP32 [(SA410T)]
W29EE010@SOIC32 [(SA438T)]	W29EE011@PLCC32 [(SA015A1T)]
W29EE011	W29EE012
W29EE011@SOIC32 [(SA438T)]	W29EE012@SOIC32 [(SA438T)]
W29EE012@PLCC32 [(SA015A1T)]	W29EE512@PLCC32 [(SA015A1T)]
W29EE512	W29EE512@TSOP32 [(SA410T)]
W29EE512@SOIC32 [(SA438T)]	W29F040@PLCC32 [(SA015A1T)]
W29F040	W39F010
W29F040@TSOP32 [(SA410T)]	
W39F010@PLCC32 [(SA015A1T-B001)]	
W39F010@TSOP32[12.4mm] [(SA620-B005)]	
W39F010@TSOP32[18.4mm] [(SA410T-B003)]	
W39L010@PLCC32 [(SA015A1T-B001)]	W39L010@TSOP32 [(SA620-B005)]
W39L020@PLCC32 [(SA015A1T-B001)]	
W39L020@TSOP32[12.4mm] [(SA620-B005)]	
W39L020@TSOP32[18.4mm] [(SA410T-B003)]	
W39L040@PLCC32 [(SA015A1T-B001)]	
W39L040@TSOP32[12.4mm] [(SA620-B005)]	
W39L040@TSOP32[18.4mm] [(SA410T-B003)]	
W39L040A	W39L040A@PLCC32 [(SA015A1T)]
W39L040A@TSOP32 [(SA410T)]	W39L040A@VSOP32 [(SA620)]
W39L512@PLCC32 [(SA015A1T-B001)]	W39L512@TSOP32 [(SA620-B005)]
W39V040AP@PLCC32 [(SA015A1T)]	W39V040AQ@VSOP32 [(SA620)]
W39V040B(P)@PLCC32 [(SA015A1T)]	W39V040B(Q)@VSOP32 [(SA620)]
W39V040CP@PLCC32 [(SA015A1T)]	W39V040CPZ@PLCC32 [(SA015A1T)]
W39V040CQ@VSOP32 [(SA620)]	W39V040CQZ@VSOP32 [(SA620)]
W39V040FAP@PLCC32 [(SA015A1T)]	W39V040FAQ@VSOP32 [(SA620)]
W39V040FAT@TSOP40 [(SA409T)]	W39V040FB(P)@PLCC32 [(SA015A1T)]
W39V040FB(Q)@VSOP32 [(SA620)]	W39V040FCP@PLCC32 [(SA015A1T)]
W39V040FCPZ@PLCC32 [(SA015A1T)]	W39V040FCQ@VSOP32 [(SA620)]
W39V040FCQZ@VSOP32 [(SA620)]	W39V080A(P)@PLCC32 [(SA015A1T)]
W39V080A(Q)@VSOP32 [(SA620)]	W39V080A(T)@TSOP40 [(SA409T)]
W39V080FA(P)@PLCC32 [(SA015A1T)]	W39V080FA(Q)@VSOP32 [(SA620)]
W39V080FA(T)@TSOP40 [(SA409T)]	W45B012@PLCC32 [(SA015A1T)]
W45B012@SON8 [(SA683)]	W45B512@PLCC32 [(SA015A1T)]
W45B512@SON8 [(SA683)]	W49F002
W49F002@PLCC32 [(SA015A1T-B001)]	W49F002@TSOP32 [(SA410T-B003)]
W49F002B	
W49F002B@PLCC32 [(SA015A1T-B001)]	
W49F002B@TSOP32 [(SA410T-B003)]	W49F002N
W49F002N@PLCC32 [(SA015A1T-B001)]	
W49F002N@TSOP32 [(SA410T-B003)]	W49F002U
W49F002U@PLCC32 [(SA015A1T-B001)]	
W49F002U@TSOP32 [(SA410T-B003)]	
W49F020@PLCC32 [(SA015A1T)]	W49F020
W49F102@PLCC44 [(SA244)]	W49F020@TSOP32 [(SA410T)]
W49F201@PSOP44 [(SA638)]	W49F102@TSOP40 [(SA623)]
W49L102@PLCC44 [(SA244)]	W49F201@TSOP48 [(SA247-B005)]
W49L201@PSOP44 [(SA638)]	W49L102@TSOP40 [(SA623)]
W49L401@PSOP44 [(SA638)]	W49L201@TSOP48 [(SA247-B005)]
W49L401T@PSOP44 [(SA638)]	W49L401@TSOP48 [(SA247-B005)]
W49V002A@PLCC32 [(SA015A1T)]	W49L401T@TSOP48 [(SA247-B005)]
W49V002FA@PLCC32 [(SA015A1T)]	W49V002A@VSOP32 [(SA620)]
W49V002FP@PLCC32 [(SA015A1T)]	W49V002FA@VSOP32 [(SA620)]
W49V002P@PLCC32 [(SA015A1T)]	W49V002FP@VSOP32 [(SA620)]
W55F05	W49V002P@VSOP32 [(SA620)]
W55F20	W55F10A

MICROCONTROLLER

N79E342AKG	N79E342ASG@SOP16 [(SA404)]
N79E342RAKG	N79E342RASG@SOP16 [(SA404)]
N79E352AEG	N79E352AFG@TQFP44 [(SA245)]
N79E352ALG@TQFP48 [(SA248)]	N79E352APG@PLCC44 [(SA244)]
N79E8213AKG	N79E8213ASG@SOP20 [(SA404)]
N79E8213RAKG	N79E8213RASG@SOP20 [(SA404)]
W77E058	W77E058@PLCC44 [(SA244)]
W77E058@TQFP44 [(SA245A)]	W77E516
W77E516@PLCC44 [(SA244)]	W77E516@TQFP44 [(SA245A)]
W77E532	W77E532@PLCC44 [(SA244)]
W77E532@TQFP44 [(SA245A)]	W77E532A
W77E532A@PLCC44 [(SA244)]	W77E532A@TQFP44 [(SA245A)]
W77E58	W77E58@PLCC44 [(SA244)]
W77E58@TQFP44 [(SA245A)]	W77E58A
W77E58A@PLCC44 [(SA244)]	W77E58A@TQFP44 [(SA245A)]
W77IE58	W77IE58@PLCC44 [(SA244)]
W77IE58@TQFP44 [(SA245A)]	W77L058
W77L058@PLCC44 [(SA244)]	W77L058@TQFP44 [(SA245A)]
W77L516A	W77L516A@PLCC44 [(SA244)]
W77L516A@TQFP44 [(SA245A)]	W77L532A
W77L532A@PLCC44 [(SA244)]	W77L532A@TQFP44 [(SA245A)]
W77LE516	W77LE516@PLCC44 [(SA244)]
W77LE516@TQFP44 [(SA245A)]	W77LE532
W77LE532@PLCC44 [(SA244)]	W77LE532@TQFP44 [(SA245A)]
W77LE58	W77LE58@PLCC44 [(SA244)]
W77LE58@TQFP44 [(SA245A)]	W78E051B
W78E051B@PLCC44 [(SA244)]	W78E051B@TQFP44 [(SA245A)]
W78E051C	W78E051C@PLCC44 [(SA244)]
W78E051C@TQFP44 [(SA245A)]	W78E051DDG
W78E051DFG@TQFP44 [(SA245A)]	
W78E051DLG@TQFP48 [(SA248A-B005)]	
W78E051DPG@PLCC44 [(SA244)]	W78E052B
W78E052B@PLCC44 [(SA244)]	W78E052B@TQFP44 [(SA245A)]
W78E052C	W78E052C@PLCC44 [(SA244)]
W78E052C@TQFP44 [(SA245A)]	W78E052DDG
W78E052DFG@TQFP44 [(SA245A)]	
W78E052DLG@TQFP48 [(SA248A-B005)]	
W78E052DPG@PLCC44 [(SA244)]	W78E054B
W78E054B@PLCC44 [(SA244)]	W78E054B@TQFP44 [(SA245A)]
W78E054C	W78E054C@PLCC44 [(SA244)]
W78E054C@TQFP44 [(SA245A)]	W78E054DDG
W78E054DFG@TQFP44 [(SA245A)]	
W78E054DLG@TQFP48 [(SA248A-B005)]	
W78E054DPG@PLCC44 [(SA244)]	W78E058B
W78E058B@PLCC44 [(SA244)]	W78E058B@TQFP44 [(SA245A)]
W78E058DDG	W78E058DFG@TQFP44 [(SA245A)]
W78E058DLG@TQFP48 [(SA248A-B005)]	
W78E058DPG@PLCC44 [(SA244)]	W78E065
W78E065@PLCC44 [(SA244)]	W78E065@TQFP44 [(SA245A)]
W78E354 (dip40)	W78E365
W78E365@PLCC44 [(SA244)]	W78E365@TQFP44 [(SA245A)]
W78E374B	W78E378
W78E378E	W78E378P@PLCC44 [(SA244)]
W78E51	W78E51@PLCC44 [(SA244)]
W78E51@TQFP44 [(SA245A)]	W78E516
W78E516@PLCC44 [(SA244)]	W78E516@TQFP44 [(SA245A)]
W78E516B	W78E516B@PLCC44 [(SA244)]
W78E516B@TQFP44 [(SA245A)]	W78E516DDG
W78E516DFG@TQFP44 [(SA245A)]	
W78E516DLG@TQFP48 [(SA248A-B005)]	
W78E516DPG@PLCC44 [(SA244)]	W78E51B
W78E51B@PLCC44 [(SA244)]	W78E51B@TQFP44 [(SA245A)]
W78E51C	W78E51C@PLCC44 [(SA244)]
W78E51C@TQFP44 [(SA245A)]	W78E52
W78E52@PLCC44 [(SA244)]	W78E52@TQFP44 [(SA245A)]
W78E52B	W78E52B@PLCC44 [(SA244)]
W78E52B@TQFP44 [(SA245A)]	W78E52C
W78E52C@PLCC44 [(SA244)]	W78E52C@TQFP44 [(SA245A)]
W78E54	W78E54@PLCC44 [(SA244)]
W78E54@TQFP44 [(SA245A)]	W78E54B
W78E54B@PLCC44 [(SA244)]	W78E54B@TQFP44 [(SA245A)]
W78E54C	W78E54C@PLCC44 [(SA244)]
W78E54C@TQFP44 [(SA245A)]	W78E58
W78E58@PLCC44 [(SA244)]	W78E58@TQFP44 [(SA245A)]
W78E58B	W78E58B@PLCC44 [(SA244)]
W78E58B@TQFP44 [(SA245A)]	W78E62B
W78E62B@PLCC44 [(SA244)]	W78E62B@TQFP44 [(SA245A)]

W78E65	W78E65@PLCC44 [(SA244)]
W78E65@TQFP44 [(SA245A)]	W78E858
W78E858@PLCC44 [(SA244)]	W78E858@TQFP44 [(SA245A)]
W78ERD2	W78ERD2@PLCC44 [(SA244)]
W78ERD2@TQFP44 [(SA245A)]	W78I051DDG
W78I051DFG@TQFP44 [(SA245A)]	
W78I051DLG@TQFP48 [(SA248A-B005)]	W78I052
W78I051DPG@PLCC44 [(SA244)]	W78I052DDG
W78I052@PLCC44 [(SA244)]	
W78I052DFG@TQFP44 [(SA245A)]	W78I054
W78I052DLG@TQFP48 [(SA248A-B005)]	W78I054DDG
W78I052DPG@PLCC44 [(SA244)]	
W78I054@PLCC44 [(SA244)]	W78IE52
W78I054DFG@TQFP44 [(SA245A)]	W78IE54
W78I054DLG@TQFP48 [(SA248A-B005)]	W78IRD2
W78I054DPG@PLCC44 [(SA244)]	W78IRD2@TQFP44 [(SA245A)]
W78IE52@PLCC44 [(SA244)]	W78L051@PLCC44 [(SA244)]
W78IE54@PLCC44 [(SA244)]	W78L051C
W78IRD2@PLCC44 [(SA244)]	W78L051C@TQFP44 [(SA245A)]
W78L051	W78L052@PLCC44 [(SA244)]
W78L051@TQFP44 [(SA245A)]	W78L052C
W78L051C@PLCC44 [(SA244)]	W78L052C@TQFP44 [(SA245A)]
W78L052	W78L054@PLCC44 [(SA244)]
W78L052@TQFP44 [(SA245A)]	W78L054C
W78L052C@PLCC44 [(SA244)]	W78L054C@TQFP44 [(SA245A)]
W78L054	W78L058@PLCC44 [(SA244)]
W78L054@TQFP44 [(SA245A)]	W78L365
W78L054C@PLCC44 [(SA244)]	W78L365@TQFP44 [(SA245A)]
W78L058	W78L365@PLCC44 [(SA244)]
W78L058@TQFP44 [(SA245A)]	W78L365@TQFP48 [(SA248A-B005)]
W78L365@PLCC44 [(SA244)]	W78L516
W78L365@TQFP48 [(SA248A-B005)]	W78L516@TQFP44 [(SA245A)]
W78L516@PLCC44 [(SA244)]	W78L516A@PLCC44 [(SA244)]
W78L516A	W78L812
W78L516A@TQFP44 [(SA245A)]	W78L812@TQFP44 [(SA245A)]
W78L812@PLCC44 [(SA244)]	W78LE365@PLCC44 [(SA244)]
W78LE365	W78LE365@TQFP48 [(SA248A-B005)]
W78LE365@TQFP44 [(SA245A)]	W78LE51@PLCC44 [(SA244)]
W78LE51	W78LE516
W78LE51@TQFP44 [(SA245A)]	W78LE516@TQFP44 [(SA245A)]
W78LE516@PLCC44 [(SA244)]	W78LE51C@PLCC44 [(SA244)]
W78LE51C	W78LE52
W78LE51C@TQFP44 [(SA245A)]	W78LE52@TQFP44 [(SA245A)]
W78LE52@PLCC44 [(SA244)]	W78LE52C@PLCC44 [(SA244)]
W78LE52C	W78LE54
W78LE52C@TQFP44 [(SA245A)]	W78LE54@TQFP44 [(SA245A)]
W78LE54@PLCC44 [(SA244)]	W78LE54C@PLCC44 [(SA244)]
W78LE54C	W78LE58
W78LE54C@TQFP44 [(SA245A)]	W78LE58@TQFP44 [(SA245A)]
W78LE58@PLCC44 [(SA244)]	W78LE812@PLCC44 [(SA244)]
W78LE812	W79E201
W78LE812@TQFP44 [(SA245A)]	W79E201@TQFP44 [(SA245A)]
W79E201@PLCC44 [(SA244)]	W79E2051(dip16)
W79E2051(dip14)	W79E2051@SOP20 [(SA404A)]
W79E2051(dip20)	W79E2051@SSOP16 [(SA626A)]
W79E2051@SSOP14 [(SA626A)]	W79E2051R(dip20)
W79E2051@SSOP20 [(SA626A)]	W79E225A@LQFP48 [(SA248)]
W79E2051R@SOP20 [(SA404A)]	W79E226A@LQFP48 [(SA248)]
W79E225A@PLCC44 [(SA244)]	W79E227A@LQFP48 [(SA248)]
W79E226A@PLCC44 [(SA244)]	W79E4051(dip14)
W79E227A@PLCC44 [(SA244)]	W79E4051(dip20)
W79E4051(dip16)	W79E4051@SSOP14 [(SA626A)]
W79E4051@SOP20 [(SA404A)]	W79E4051@SSOP20 [(SA626A)]
W79E4051@SSOP16 [(SA626A)]	W79E4051R@SOP20 [(SA404A)]
W79E4051R@SOP20 [(SA404A)]	W79E532@PLCC44 [(SA244)]
W79E532	W79E532A
W79E532@TQFP44 [(SA245A)]	W79E532A@TQFP44 [(SA245A)]
W79E532A@PLCC44 [(SA244)]	W79E632@PLCC44 [(SA244)]
W79E632	W79E633@PLCC44 [(SA244)]
W79E632@TQFP44 [(SA245A)]	
W79E648A@PLCC68(*) [(SA648-B6809)]	W79E801A@SOIC20 [(SA404)]
W79E649A@PLCC68(*) [(SA648-B6809)]	W79E802A@SOIC20 [(SA404)]
W79E659A@PQFP100(*) [(SA741-B233)]	W79E803A@SOIC20 [(SA404)]
W79E801A	W79E804A@SOIC20 [(SA404)]
W79E802A	W79E821A@SOIC20 [(SA404)]
W79E803A	W79E822A@SOIC20 [(SA404)]
W79E804A	W79E822B@SOIC20 [(SA404)]
W79E821A	W79E822B@SOIC20 [(SA404)]
W79E822A	W79E823A@SOIC20 [(SA404)]
W79E822B	
W79E823A	

W79E823B	W79E823B@SOIC20 [(SA404)]
W79E824A	W79E824A@SOIC20 [(SA404)]
W79E825A	W79E825A@SOIC20 [(SA404)]
W79E831A	W79E831A@SOIC28 [(SA404)]
W79E832A	W79E832A@SOIC28 [(SA404)]
W79E833A	W79E833A@SOIC28 [(SA404)]
W79E834A	W79E834A@SOIC28 [(SA404)]
W79L532	W79L532@PLCC44 [(SA244)]
W79L532@TQFP44 [(SA245A)]	W79L632
W79L632@PLCC44 [(SA244)]	W79L632@TQFP44 [(SA245A)]
W79L633@PLCC44 [(SA244)]	
W79L648A@PLCC68(*) [(SA648-B6809)]	
W79L649A@PLCC68(*) [(SA648-B6809)]	
W79L659A@PQFP100(*) [(SA741-B233)]	
W925EP01@PQFP100(*) [(TA041-B006)]	
W99100DG@TQFP48 [(SA248A-B005)]	

WSI

E(E) PROM/FRAM/NVRAM

WS27C010L	WS27C010L@PLCC32 [(SA015A1T)]
WS27C010L@TSOP32 [(SA410T)]	WS27C010R
WS27C010R@PLCC32 [(SA015A1T)]	WS27C010R@TSOP32 [(SA410T)]
WS27C040L	WS27C040L@PLCC32 [(SA015A1T)]
WS27C040L@TSOP32 [(SA410T)]	WS27C128F
WS27C128F@PLCC32 [(SA015A1T)]	WS27C128L
WS27C128L@PLCC32 [(SA015A1T)]	WS27C210L
WS27C210L@PLCC44 [(SA244)]	WS27C256F
WS27C256F@PLCC32 [(SA015A1T)]	WS27C256L
WS27C256L@PLCC32 [(SA015A1T)]	WS27C512F
WS27C512F@PLCC32 [(SA015A1T)]	WS27C512L
WS27C512L@PLCC32 [(SA015A1T)]	WS27C64
WS27C64@PLCC32 [(SA015A1T)]	WS27C64F
WS27C64F@PLCC32 [(SA015A1T)]	WS27C64L
WS27C64L@PLCC32 [(SA015A1T)]	WS57C128
WS57C128@PLCC32 [(SA015A1T)]	WS57C128F
WS57C128F@PLCC32 [(SA015A1T)]	WS57C128FB
WS57C128FB@PLCC32 [(SA015A1T)]	WS57C191
WS57C191@PLCC28 [(SA008A)]	WS57C191B
WS57C191B@PLCC28 [(SA008A)]	WS57C191C
WS57C191C@PLCC28 [(SA008A)]	WS57C256F
WS57C256F@PLCC32 [(SA015A1T)]	WS57C256FB
WS57C256FB@PLCC32 [(SA015A1T)]	WS57C257
WS57C257@PLCC44 [(SA244)]	WS57C291
WS57C291@PLCC28 [(SA008A)]	WS57C291B
WS57C291B@PLCC28 [(SA008A)]	WS57C291C
WS57C291C@PLCC28 [(SA008A)]	WS57C43
WS57C43@PLCC28 [(SA008A)]	WS57C43B
WS57C43B@PLCC28 [(SA008A)]	WS57C43C
WS57C43C@PLCC28 [(SA008A)]	WS57C45
WS57C45@PLCC28 [(SA008A)]	WS57C49
WS57C49@PLCC28 [(SA008A)]	WS57C49B
WS57C49B@PLCC28 [(SA008A)]	WS57C49C
WS57C49C@PLCC28 [(SA008A)]	WS57C51
WS57C51@PLCC32 [(SA015A1T)]	WS57C51B
WS57C51B@PLCC32 [(SA015A1T)]	WS57C51C
WS57C51C@PLCC32 [(SA015A1T)]	WS57C64F
WS57C64F@PLCC32 [(SA015A1T)]	WS57C71C
WS57C71C@PLCC32 [(SA015A1T)]	WS57LV191C
WS57LV191C@PLCC28 [(SA008A)]	WS57LV291C
WS57LV291C@PLCC28 [(SA008A)]	

XELTEK

MICROCONTROLLER

#####11111111111111111111	#####2222222222222222
#####33333333333333333333	#####44444444444444444444
#####99999999999999999999	ATMEGA168@TQFP32 [(SA636)]
ATMEGA48@TQFP32 [(SA636)]	ATMEGA88@TQFP32 [(SA636)]
ATMEGA8L(fast)@TQFP32 [(SA636)]	ATMEGA8L@TQFP32 [(SA636)]

XICOR**E(E) PROM/FRAM/NVRAM**

X2004	X2004@PLCC32 [(SA015A1T)]
X2004D	X2004D@PLCC32 [(SA015A1T)]
X2004I	X2004I@PLCC32 [(SA015A1T)]
X2210	X2210@SOIC16 [(SA404)]
X2210A	X2210A@SOIC16 [(SA404)]
X2210I	X2210I@SOIC16 [(SA404)]
X2212	X2212@SOIC20 [(SA404)]
X2212A	X2212A@SOIC20 [(SA404)]
X2212I	X2212I@SOIC20 [(SA404)]
X22C10	X22C10@SOIC16 [(SA404)]
X22C10I	X22C10I@SOIC16 [(SA404)]
X22C12	X22C12@SOIC20 [(SA404)]
X22C12I	X22C12I@SOIC20 [(SA404)]
X24012	X24012@SOIC8 [(SA602A)]
X24022	X24022@SOIC8 [(SA602A)]
X24026	X24026@SOIC8 [(SA602A)]
X24042	X24042@SOIC8 [(SA602A)]
X24164	X24164@SOIC8 [(SA602A)]
X24165	X24165@SOIC8 [(SA602A)]
X24325	X24325@SOIC8 [(SA602A)]
X24645	X24645@SOIC8 [(SA602A)]
X24C01	X24C01@MSOP8 [(SA666)]
X24C01@SOIC8 [(SA602A)]	X24C01A
X24C01A@SOIC8 [(SA602A)]	X24C01I
X24C01I@SOIC8 [(SA602A)]	X24C02
X24C02@SOIC8 [(SA602A)]	X24C02I
X24C02I@SOIC8 [(SA602A)]	X24C04
X24C04@SOIC14 [(SA602)]	X24C04@SOIC8 [(SA602A)]
X24C04I	X24C04I@SOIC14 [(SA602)]
X24C04I@SOIC8 [(SA602A)]	X24C08
X24C08@SOIC14 [(SA602)]	X24C08@SOIC8 [(SA602A)]
X24C08I	X24C08I@SOIC14 [(SA602)]
X24C08I@SOIC8 [(SA602A)]	X24C16
X24C16@SOIC14 [(SA602)]	X24C16@SOIC8 [(SA602A)]
X24C16I	X24C16I@SOIC14 [(SA602)]
X24C16I@SOIC8 [(SA602A)]	X24C44
X24C44@SOIC8 [(SA602A)]	X24C44I
X24C44I@SOIC8 [(SA602A)]	X24C45
X24C45@SOIC8 [(SA602A)]	X24C45I
X24C45I@SOIC8 [(SA602A)]	X24F008(3V)
X24F008(3V)@SOIC8 [(SA602A)]	X24F008(3V)@TSSOP14 [(SA602)]
X24F008(5V)	X24F008(5V)@SOIC8 [(SA602A)]
X24F008(5V)@TSSOP14 [(SA602)]	X24F016(3V)
X24F016(3V)@SOIC8 [(SA602A)]	X24F016(3V)@TSSOP14 [(SA602)]
X24F016(5V)	X24F016(5V)@SOIC8 [(SA602A)]
X24F016(5V)@TSSOP14 [(SA602)]	X24F032(3V)
X24F032(3V)@SOIC8 [(SA602A)]	X24F032(3V)@TSSOP14 [(SA602)]
X24F032(5V)	X24F032(5V)@SOIC8 [(SA602A)]
X24F032(5V)@TSSOP14 [(SA602)]	X24F064(3V)
X24F064(3V)@SOIC8 [(SA602A)]	X24F064(3V)@TSSOP20 [(SA404)]
X24F064(5V)	X24F064(5V)@SOIC8 [(SA602A)]
X24F064(5V)@TSSOP20 [(SA404)]	X25020
X25020@SOIC8 [(SA602A)]	X25021
X25021@SOIC8 [(SA602A)]	X25040
X25040@SOIC8 [(SA602A)]	X25041
X25041@SOIC8 [(SA602A)]	X25043
X25043@MSOP8 [(SA666)]	X25043@SOIC8 [(SA602A)]
X25043@TSSOP14 [(SA026)]	X25045
X25045@MSOP8 [(SA666)]	X25045@SOIC8 [(SA602A)]
X25045@TSSOP14 [(SA026)]	X25057@MSOP8 [(SA666)]
X25057@TSSOP8 [(SA026)]	X25080
X25080@SOIC8 [(SA602A)]	X25080@TSSOP14 [(SA026)]
X25097@MSOP8 [(SA666)]	X25097@SOIC8 [(SA602A)]
X25097@TSSOP8 [(SA026)]	X25128
X25128@SOIC16 [(SA602)]	X25138
X25138@SOIC14 [(SA602)]	X25138@SOIC16 [(SA602)]
X25138@SOIC8 [(SA602A)]	X25138@TSSOP8 [(SA026)]
X25160	X25160@SOIC8 [(SA602A)]
X25160@TSSOP14 [(SA026)]	X25163
X25163@SOIC8 [(SA602A)]	X25163@TSSOP14 [(SA026)]
X25164	X25164@SOIC8 [(SA602A)]
X25164@TSSOP14 [(SA026)]	X25165
X25165@SOIC8 [(SA602A)]	X25165@TSSOP14 [(SA026)]
X25166	X25166@SOIC8 [(SA602A)]
X25166@TSSOP14 [(SA026)]	X25168

X25168@SOIC8 [(SA602A)]	X25168@TSSOP14 [(SA026)]
X25169	X25169@SOIC8 [(SA602A)]
X25169@TSSOP14 [(SA026)]	X25256
X25256@SOIC8 [(SA602A)]	X25256@TSSOP20 [(SA026)]
X25320	X25320@SOIC8 [(SA602A)]
X25323@SOIC8 [(SA602A)]	X25323@TSSOP14 [(SA026)]
X25324@SOIC8 [(SA602A)]	X25324@TSSOP14 [(SA026)]
X25325@SOIC8 [(SA602A)]	X25325@TSSOP14 [(SA026)]
X25326@SOIC8 [(SA602A)]	X25328@SOIC8 [(SA602A)]
X25328@TSSOP14 [(SA026)]	X25329@SOIC8 [(SA602A)]
X25329@TSSOP14 [(SA026)]	X25330@SOIC8 [(SA602A)]
X25330@TSSOP14 [(SA026)]	X25401
X25401@SOIC8 [(SA602A)]	X25640
X25640@SOIC14 [(SA602)]	X25642
X25642@SOIC14 [(SA602)]	X25642@SOIC8 [(SA602A)]
X25642@TSSOP20 [(SA026)]	X25643@SOIC14 [(SA602)]
X25644@SOIC14 [(SA602)]	X25645
X25645@SOIC14 [(SA602)]	X25645@SOIC8 [(SA602A)]
X25645@TSSOP20 [(SA026)]	X25648@SOIC14 [(SA602)]
X25649@SOIC14 [(SA602)]	X25650
X25650@SOIC14 [(SA602)]	X25650@SOIC8 [(SA602A)]
X25650@TSSOP20 [(SA026)]	X25C02
X25C02@SOIC8 [(SA602A)]	X25C02@TSSOP8 [(SA026)]
X25F008(3V)	X25F008(3V)@SOIC8 [(SA602A)]
X25F008(3V)@TSSOP14 [(SA602)]	X25F008(3V)@TSSOP20 [(SA404)]
X25F008(5V)	X25F008(5V)@SOIC8 [(SA602A)]
X25F008(5V)@TSSOP14 [(SA602)]	X25F008(5V)@TSSOP20 [(SA404)]
X25F016(3V)	X25F016(3V)@SOIC8 [(SA602A)]
X25F016(3V)@TSSOP14 [(SA602)]	X25F016(3V)@TSSOP20 [(SA404)]
X25F016(5V)	X25F016(5V)@SOIC8 [(SA602A)]
X25F016(5V)@TSSOP14 [(SA602)]	X25F016(5V)@TSSOP20 [(SA404)]
X25F032(3V)	X25F032(3V)@SOIC8 [(SA602A)]
X25F032(3V)@TSSOP14 [(SA602)]	X25F032(3V)@TSSOP20 [(SA404)]
X25F032(5V)	X25F032(5V)@SOIC8 [(SA602A)]
X25F032(5V)@TSSOP14 [(SA602)]	X25F032(5V)@TSSOP20 [(SA404)]
X25F047(3V)	X25F047(3V)@MSOP8 [(SA666)]
X25F047(3V)@SOIC8 [(SA602A)]	X25F047(3V)@TSSOP8 [(SA026)]
X25F047(5V)	X25F047(5V)@MSOP8 [(SA666)]
X25F047(5V)@SOIC8 [(SA602A)]	X25F047(5V)@TSSOP8 [(SA026)]
X25F064(3V)	X25F064(3V)@SOIC8 [(SA602A)]
X25F064(3V)@TSSOP14 [(SA602)]	X25F064(3V)@TSSOP20 [(SA404)]
X25F064(5V)	X25F064(5V)@SOIC8 [(SA602A)]
X25F064(5V)@TSSOP14 [(SA602)]	X25F064(5V)@TSSOP20 [(SA404)]
X25F087(3V)	X25F087(3V)@MSOP8 [(SA666)]
X25F087(3V)@SOIC8 [(SA602A)]	X25F087(3V)@TSSOP8 [(SA026)]
X25F087(5V)	X25F087(5V)@MSOP8 [(SA666)]
X25F087(5V)@SOIC8 [(SA602A)]	X25F087(5V)@TSSOP8 [(SA026)]
X25F128(3V)	X25F128(3V)@SOIC16 [(SA602)]
X25F128(5V)	X25F128(5V)@SOIC16 [(SA602)]
X28010	X28010@PLCC32 [(SA015A1T)]
X28010@TSOP32 [(SA410T)]	X2804A
X2804A(I)	X2804A(MB)
X2816A	X2816A@PLCC32 [(SA015A1T)]
X2816B	X2816B@PLCC32 [(SA015A1T)]
X2816BI	X2816BI@PLCC32 [(SA015A1T)]
X2816BMB	X2816C
X2816C@PLCC32 [(SA015A1T)]	X28256
X28256@PLCC32 [(SA015A1T)]	X28256I
X28256I@PLCC32 [(SA015A1T)]	X2864A
X2864A(I)	X2864A(I)@PLCC32 [(SA015A1T)]
X2864A(M)	X2864A(M)@PLCC32 [(SA015A1T)]
X2864A(MB)	X2864A(MB)@PLCC32 [(SA015A1T)]
X2864A(T)	X2864A(T)@PLCC32 [(SA015A1T)]
X2864A@PLCC32 [(SA015A1T)]	X2864B
X2864B(I)	X2864B(I)@PLCC32 [(SA015A1T)]
X2864B(M)	X2864B(M)@PLCC32 [(SA015A1T)]
X2864B@PLCC32 [(SA015A1T)]	X2864H
X2864H(I)	X2864H(I)@PLCC32 [(SA015A1T)]
X2864H@PLCC32 [(SA015A1T)]	X28C010
X28C010@PLCC32 [(SA015A1T)]	X28C16A
X28C16A@PLCC32 [(SA015A1T)]	X28C16B
X28C16B@PLCC32 [(SA015A1T)]	X28C16C
X28C16C@PLCC32 [(SA015A1T)]	X28C256
X28C256@PLCC32 [(SA015A1T)]	X28C256@TSOP28 [(SA430T)]
X28C512	X28C512@PLCC32 [(SA015A1T)]
X28C513	X28C513@PLCC32 [(SA015A1T)]
X28C64	X28C64@PLCC32 [(SA015A1T)]
X28C64@SOIC28 [(SA404)]	X28C64@TSOP28 [(SA430T)]
X28HC16	X28HC16@PLCC32 [(SA015A1T)]
X28HC16@SOIC24 [(SA404)]	X28HC256
X28HC256@PLCC32 [(SA015A1T)]	X28HC256@TSOP28 [(SA430T)]

X28HC64	X28HC64@PLCC32 [(SA015A1T)]
X28HC64@SOIC28 [(SA404)]	X28HC64@TSOP28 [(SA430T)]
X28LC512	X28LC512@PLCC32 [(SA015A1T)]
X28LC513	X28LC513@PLCC32 [(SA015A1T)]
X28VC256	X28VC256@PLCC32 [(SA015A1T)]
X28VC256@TSOP28 [(SA430T)]	X40231@SOIC16 [(SA404)]
X40233@SOIC16 [(SA404)]	X40235@SOIC16 [(SA404)]
X40237@SOIC16 [(SA404)]	X40239@SOIC16 [(SA404)]
X40430@SOIC14 [(SA404)]	X40430@TSSOP14 [(SA026)]
X40431@SOIC14 [(SA404)]	X40431@TSSOP14 [(SA026)]
X40434@SOIC14 [(SA404)]	X40434@TSSOP14 [(SA026)]
X40435@SOIC14 [(SA404)]	X40435@TSSOP14 [(SA026)]
X4C105@TSSOP20 [(SA026)]	X5043
X5043@MSOP8 [(SA666)]	X5043@SOIC8 [(SA602A)]
X5043@TSSOP14 [(SA026)]	X5045
X5045@MSOP8 [(SA666)]	X5045@SOIC8 [(SA602A)]
X5045@TSSOP14 [(SA026)]	X5083
X5083@SOIC8 [(SA602A)]	X5083@TSSOP8 [(SA026)]
X5163	X5163@SOIC8 [(SA602A)]
X5163@TSSOP14 [(SA026)]	X51638
X51638@SOIC8 [(SA602A)]	X51638@TSSOP14 [(SA026)]
X5165	X5165@SOIC8 [(SA602A)]
X5165@TSSOP14 [(SA026)]	X5168
X5168@SOIC8 [(SA602A)]	X5168@TSSOP14 [(SA026)]
X5169	X5169@SOIC8 [(SA602A)]
X5169@TSSOP14 [(SA026)]	X5323
X5323@SOIC8 [(SA602A)]	X5323@TSSOP14 [(SA026)]
X5325	X5325@SOIC8 [(SA602A)]
X5325@TSSOP14 [(SA026)]	X5328
X5328@SOIC8 [(SA602A)]	X5328@TSSOP14 [(SA026)]
X5329	X5329@SOIC8 [(SA602A)]
X5329@TSSOP14 [(SA026)]	X5643
X5643@SOIC14 [(SA602)]	X5643@SOIC8 [(SA602A)]
X5643@TSSOP20 [(SA026)]	X5645
X5645@SOIC14 [(SA602)]	X5645@SOIC8 [(SA602A)]
X5645@TSSOP20 [(SA026)]	X5648
X5648@SOIC14 [(SA602)]	X5649
X5649@SOIC14 [(SA602)]	X76F041
X76F041(3)	X76F041(3)@SOIC8 [(SA605)]
X76F041@SOIC8 [(SA605)]	X76F101
X76F101@SOIC8 [(SA602A)]	X76F400@SOIC8 [(SA602A)]
X76F400@TSSOP8 [(SA026)]	XD2210
XD2210@SOIC16 [(SA404)]	XM28C010
XM28C020	XM28C040

XILINX

E(E) PROM/FRAM/NVRAM

XC1701	XC1701@PLCC20 [(SA001A)]
XC1701@SOIC20 [(SA404)]	XC1701L
XC1701L@PLCC20 [(SA001A)]	XC1701L@PLCC44 [(SA244)]
XC1701L@SOIC20 [(SA404)]	XC1702L@PLCC44 [(SA244)]
XC1702L@TQFP44 [(SA245A)]	XC1704L@PLCC44 [(SA244)]
XC1704L@TQFP44 [(SA245A)]	XC17128
XC17128@SOIC8 [(SA602A)]	XC17128D
XC17128D@PLCC20 [(SA001A)]	XC17128D@SOIC8 [(SA602A)]
XC17128D@VOIC8 [(SA602A)]	XC17128E
XC17128E@PLCC20 [(SA001A)]	XC17128E@VOIC8 [(SA602A)]
XC17128EL	XC17128EL@PLCC20 [(SA001A)]
XC17128EL@VOIC8 [(SA602A)]	XC17128L
XC17128L@PLCC20 [(SA001A)]	XC17128L@SOIC8 [(SA602A)]
XC17128L@VOIC8 [(SA602A)]	XC17128X
XC17128X@PLCC20 [(SA001A)]	XC17128X@SOIC8 [(SA602A)]
XC17128X@VOIC8 [(SA602A)]	XC1718D
XC1718D@PLCC20 [(SA001A)]	XC1718D@SOIC8 [(SA602A)]
XC1718D@VOIC8 [(SA602A)]	XC1718L
XC1718L@PLCC20 [(SA001A)]	XC1718L@SOIC8 [(SA602A)]
XC1718L@VOIC8 [(SA602A)]	XC17256D
XC17256D@PLCC20 [(SA001A)]	XC17256D@SOIC8 [(SA602A)]
XC17256D@VOIC8 [(SA602A)]	XC17256E
XC17256E@PLCC20 [(SA001A)]	XC17256E@VOIC8 [(SA602A)]
XC17256EL	XC17256EL@PLCC20 [(SA001A)]
XC17256EL@VOIC8 [(SA602A)]	XC17256L
XC17256L@PLCC20 [(SA001A)]	XC17256L@SOIC8 [(SA602A)]
XC17256L@VOIC8 [(SA602A)]	XC17256X
XC17256X@PLCC20 [(SA001A)]	XC17256X@SOIC8 [(SA602A)]
XC17256X@VOIC8 [(SA602A)]	XC1736

XC1736@SOIC8 [(SA602A)]	XC1736A
XC1736A@SOIC8 [(SA602A)]	XC1736D
XC1736D@PLCC20 [(SA001A)]	XC1736D@SOIC8 [(SA602A)]
XC1736D@VOIC8 [(SA602A)]	XC1736E
XC1736E@PLCC20 [(SA001A)]	XC1736E@SOIC8 [(SA602A)]
XC1736E@VOIC8 [(SA602A)]	XC17512L
XC17512L@PLCC20 [(SA001A)]	XC17512L@PLCC44 [(SA244)]
XC17512L@SOIC20 [(SA404)]	XC1765
XC1765@SOIC8 [(SA602A)]	XC1765D
XC1765D@PLCC20 [(SA001A)]	XC1765D@SOIC8 [(SA602A)]
XC1765D@VOIC8 [(SA602A)]	XC1765E
XC1765E@PLCC20 [(SA001A)]	XC1765E@SOIC8 [(SA602A)]
XC1765E@VOIC8 [(SA602A)]	XC1765EL
XC1765EL@PLCC20 [(SA001A)]	XC1765EL@SOIC8 [(SA602A)]
XC1765EL@VOIC8 [(SA602A)]	XC1765L
XC1765L@PLCC20 [(SA001A)]	XC1765L@SOIC8 [(SA602A)]
XC1765L@VOIC8 [(SA602A)]	XC1765X
XC1765X@PLCC20 [(SA001A)]	XC1765X@SOIC8 [(SA602A)]
XC1765X@VOIC8 [(SA602A)]	XC17S05
XC17S05@SOIC8 [(SA602A)]	XC17S05XL(L)
XC17S05XL(L)@SOIC8 [(SA602A)]	XC17S10
XC17S10@SOIC8 [(SA602A)]	XC17S100A
XC17S100A@SOIC20 [(SA404)]	XC17S100A@SOIC8 [(SA602A)]
XC17S100XL(L)	XC17S100XL(L)@SOIC20 [(SA404)]
XC17S10XL(L)	XC17S10XL(L)@SOIC8 [(SA602A)]
XC17S150A	XC17S150A@SOIC20 [(SA404)]
XC17S150A@SOIC8 [(SA602A)]	XC17S150XL(L)
XC17S150XL(L)@SOIC20 [(SA404)]	XC17S15A
XC17S15A@SOIC20 [(SA404)]	XC17S15A@SOIC8 [(SA602A)]
XC17S20	XC17S20@SOIC8 [(SA602A)]
XC17S200A	XC17S200A@SOIC8 [(SA602A)]
XC17S200A@TQFP44 [(SA245A)]	XC17S20XL(L)
XC17S20XL(L)@SOIC8 [(SA602A)]	XC17S30
XC17S30@SOIC8 [(SA602A)]	XC17S300A@TQFP44 [(SA245A)]
XC17S30A	XC17S30A@SOIC20 [(SA404)]
XC17S30A@SOIC8 [(SA602A)]	XC17S30XL(L)
XC17S30XL(L)@SOIC8 [(SA602A)]	XC17S40
XC17S40@SOIC20 [(SA404)]	XC17S40XL(L)
XC17S40XL(L)@SOIC20 [(SA404)]	XC17S50A
XC17S50A@SOIC20 [(SA404)]	XC17S50A@SOIC8 [(SA602A)]
XC17S50XL(L)	XC17S50XL(L)@SOIC20 [(SA404)]
XC17V01@PLCC20 [(SA001A)]	XC17V01@SOIC20 [(SA404)]
XC17V01@SOIC8 [(SA602A)]	XC17V02@PLCC20 [(SA001A)]
XC17V02@PLCC44 [(SA244)]	XC17V02@TQFP44 [(SA245A)]
XC17V04@PLCC20 [(SA001A)]	XC17V04@PLCC44 [(SA244)]
XC17V04@TQFP44 [(SA245A)]	XC17V08@PLCC44 [(SA244)]
XC17V08@TQFP44 [(SA245A)]	XC17V16@PLCC44 [(SA244)]
XC17V16@TQFP44 [(SA245A)]	

XILINX-CUSTOMER

E(E) PROM/FRAM/NVRAM

XC17S100A	XC17S100A@SOIC20 [(SA404)]
XC17S100A@SOIC8 [(SA602A)]	XC17S150A
XC17S150A@SOIC20 [(SA404)]	XC17S150A@SOIC8 [(SA602A)]
XC17S15A	XC17S15A@SOIC20 [(SA404)]
XC17S15A@SOIC8 [(SA602A)]	XC17S200A
XC17S200A@SOIC8 [(SA602A)]	XC17S200A@TQFP44 [(SA245A)]
XC17S300A@TQFP44 [(SA245A)]	XC17S30A
XC17S30A@SOIC20 [(SA404)]	XC17S30A@SOIC8 [(SA602A)]
XC17S50A	XC17S50A@SOIC20 [(SA404)]
XC17S50A@SOIC8 [(SA602A)]	XC17V01@PLCC20 [(SA001A)]
XC17V01@SOIC20 [(SA404)]	XC17V01@SOIC8 [(SA602A)]
XC17V02@PLCC20 [(SA001A)]	XC17V02@PLCC44 [(SA244)]
XC17V02@TQFP44 [(SA245A)]	XC17V04@PLCC20 [(SA001A)]
XC17V04@PLCC44 [(SA244)]	XC17V04@TQFP44 [(SA245A)]
XC17V08@PLCC44 [(SA244)]	XC17V08@TQFP44 [(SA245A)]
XC17V16@PLCC44 [(SA244)]	XC17V16@TQFP44 [(SA245A)]

YMC

E(E) PROM/FRAM/NVRAM

Y24LC01	Y24LC01@SOIC8 [(SA602A)]
Y24LC01@TSSOP8 [(SA026)]	Y24LC02
Y24LC02@SOIC8 [(SA602A)]	Y24LC02@TSSOP8 [(SA026)]
Y24LC02A	Y24LC02A@SOIC8 [(SA602A)]
Y24LC02A@TSSOP8 [(SA026)]	Y24LC04
Y24LC04@SOIC8 [(SA602A)]	Y24LC04@TSSOP8 [(SA026)]
Y24LC08	Y24LC08@SOIC8 [(SA602A)]
Y24LC08@TSSOP8 [(SA026)]	Y24LC16
Y24LC16@SOIC8 [(SA602A)]	Y24LC16@TSSOP8 [(SA026)]
Y24LC32	Y24LC32@SOIC8 [(SA602A)]
Y24LC32@TSSOP8 [(SA026)]	Y24LC64
Y24LC64@SOIC8 [(SA602A)]	Y24LC64@TSSOP8 [(SA026)]
Y54LC64	Y54LC64@SOIC8 [(SA602A)]
Y54LC64@TSSOP8 [(SA026)]	Y93LC46(08bit)
Y93LC46(08bit)@SOIC8 [(SA602A)]	Y93LC46(08bit)@TSSOP8 [(SA026)]
Y93LC46(16bit)	Y93LC46(16bit)@SOIC8 [(SA602A)]
Y93LC46(16bit)@TSSOP8 [(SA026)]	Y93LC66(08bit)
Y93LC66(08bit)@SOIC8 [(SA602A)]	Y93LC66(08bit)@TSSOP8 [(SA026)]
Y93LC66(16bit)	Y93LC66(16bit)@SOIC8 [(SA602A)]
Y93LC66(16bit)@TSSOP8 [(SA026)]	Y93LC86(08bit)
Y93LC86(08bit)@SOIC8 [(SA602A)]	Y93LC86(08bit)@TSSOP8 [(SA026)]
Y93LC86(16bit)	Y93LC86(16bit)@SOIC8 [(SA602A)]
Y93LC86(16bit)@TSSOP8 [(SA026)]	

YSS

E(E) PROM/FRAM/NVRAM

Y25F05@SOP8 [(SA602A)]	Y25F05@VQFN8 [(SA683)]
Y25F10@SOP8 [(SA602A)]	Y25F10@VQFN8 [(SA683)]

ZILOG

MICROCONTROLLER

Z86733	Z86733@PLCC28 [(SA008A)]
Z86733@SOIC28 [(SA404)]	Z86743
Z86743@PLCC44 [(SA244)]	Z86C0208PEC
Z86C0208PSC	Z86C0208SEC@SOIC18 [(SA404)]
Z86C0208SSC@SOIC18 [(SA404)]	Z86E02
Z86E02@SOIC18 [(SA404)]	Z86E03
Z86E03@SOIC18 [(SA404)]	Z86E04
Z86E04@SOIC18 [(SA404)]	Z86E0412PEC
Z86E0412PEC1903	Z86E0412PSC1866
Z86E0412PSC1903	Z86E0412SEC [(SA404)]
Z86E0412SEC1903 [(SA404)]	Z86E0412SSC1866 [(SA404)]
Z86E0412SSC1903 [(SA404)]	Z86E06
Z86E06@SOIC18 [(SA404)]	Z86E07
Z86E07@SOIC18 [(SA404)]	Z86E08
Z86E08@SOIC18 [(SA404)]	Z86E0812PEC
Z86E0812PEC1903	Z86E0812PSC1866
Z86E0812PSC1903	Z86E0812SEC [(SA404)]
Z86E0812SEC1903 [(SA404)]	Z86E0812SSC1866 [(SA404)]
Z86E0812SSC1903 [(SA404)]	Z86E122
Z86E122@SOIC20 [(SA404)]	Z86E123
Z86E123@SOIC20 [(SA404)]	Z86E124
Z86E124@SOIC20 [(SA404)]	Z86E125
Z86E125@SOIC20 [(SA404)]	Z86E126
Z86E126@SOIC20 [(SA404)]	Z86E132
Z86E132@SOIC28 [(SA404)]	Z86E133
Z86E133@SOIC28 [(SA404)]	Z86E134
Z86E134@SOIC28 [(SA404)]	Z86E135
Z86E135@SOIC28 [(SA404)]	Z86E136
Z86E136@SOIC28 [(SA404)]	Z86E142
Z86E142@TQFP44 [(SA245A)]	Z86E143
Z86E143@TQFP44 [(SA245A)]	Z86E144
Z86E144@TQFP44 [(SA245A)]	Z86E145
Z86E145@TQFP44 [(SA245A)]	Z86E146
Z86E146@TQFP44 [(SA245A)]	Z86E15
Z86E21	Z86E21@PLCC44 [(SA244)]
Z86E21@TQFP44 [(SA245A)]	Z86E2112
Z86E2112@PLCC44 [(SA244)]	Z86E2112@TQFP44 [(SA245A)]
Z86E2116	Z86E2116@PLCC44 [(SA244)]
Z86E2116@TQFP44 [(SA245A)]	Z86E23

Z86E23@PLCC44 [(SA244)]	Z86E23@TQFP44 [(SA245A)]
Z86E2312	Z86E2312@PLCC44 [(SA244)]
Z86E2312@TQFP44 [(SA245A)]	Z86E2316
Z86E2316@PLCC44 [(SA244)]	Z86E2316@TQFP44 [(SA245A)]
Z86E33	Z86E33@PLCC28 [(SA008A)]
Z86E33@SOIC28 [(SA404)]	Z86E34
Z86E34@PLCC28 [(SA008A)]	Z86E34@SOIC28 [(SA404)]
Z86E43	Z86E43@PLCC44 [(SA244)]
Z86E43@TQFP44 [(SA245A)]	Z86E44
Z86E44@PLCC44 [(SA244)]	Z86E44@TQFP44 [(SA245A)]
Z86E6116ASG@TQFP44 [(SA245A)]	Z86E6116PSC
Z86E6116VSC@PLCC44 [(SA244)]	Z86E6120ASG@TQFP44 [(SA245A)]
Z86E6120PSC	Z86E6120VSC@PLCC44 [(SA244)]
Z86E61FSC@TQFP44 [(SA245A)]	Z86E61PSC
Z86E61VSC@PLCC44 [(SA244)]	Z86E6316ASG@TQFP44 [(SA245A)]
Z86E6316PSC	Z86E6316VSC@PLCC44 [(SA244)]
Z86E6320ASG@TQFP44 [(SA245A)]	Z86E6320PSC
Z86E6320VSC@PLCC44 [(SA244)]	Z86E63FSC@TQFP44 [(SA245A)]
Z86E63PSC	Z86E63VSC@PLCC44 [(SA244)]
Z86E72	Z86E72@PLCC44 [(SA244)]
Z86E72@TQFP44 [(SA245A)]	Z86E73
Z86E73@PLCC44 [(SA244)]	Z86E73@TQFP44 [(SA245A)]
Z86E83	Z86E83@PLCC28 [(SA008A)]
Z86E83@SOIC28 [(SA404)]	Z86L0208PEC
Z86L0208PSC	Z86L0208SEC@SOIC18 [(SA404)]
Z86L0208SSC@SOIC18 [(SA404)]	Z89371
Z89371@PLCC44 [(SA244)]	Z89371@TQFP44 [(SA245A)]
Z89371B	Z89371B@PLCC44 [(SA244)]
Z89371B@TQFP44 [(SA245A)]	Z8F0113PB005EC
Z8F0113PB005EG	Z8F0113PB005SC
Z8F0113PB005SG	Z8F0113QB005EC@QFN8 [(SA683)]
Z8F0113QB005EG@QFN8 [(SA683)]	Z8F0113QB005SC@QFN8 [(SA683)]
Z8F0113QB005SG@QFN8 [(SA683)]	Z8F0113SB005EC@SOIC8 [(SA602A)]
Z8F0113SB005EG@SOIC8 [(SA602A)]	Z8F0113SB005SC@SOIC8 [(SA602A)]
Z8F0113SB005SG@SOIC8 [(SA602A)]	Z8F011APB020EC
Z8F011APB020EG	Z8F011APB020SC
Z8F011APB020SG	Z8F011AQB020EC@QFN8 [(SA683)]
Z8F011AQB020EG@QFN8 [(SA683)]	Z8F011AQB020SC@QFN8 [(SA683)]
Z8F011AQB020SG@QFN8 [(SA683)]	Z8F011ASB020EC@SOIC8 [(SA602A)]
Z8F011ASB020EG@SOIC8 [(SA602A)]	Z8F011ASB020SC@SOIC8 [(SA602A)]
Z8F011ASB020SG@SOIC8 [(SA602A)]	Z8F0123PB005EC
Z8F0123PB005EG	Z8F0123PB005SC
Z8F0123PB005SG	Z8F0123QB005EC@QFN8 [(SA683)]
Z8F0123QB005EG@QFN8 [(SA683)]	Z8F0123QB005SC@QFN8 [(SA683)]
Z8F0123QB005SG@QFN8 [(SA683)]	Z8F0123SB005EC@SOIC8 [(SA602A)]
Z8F0123SB005EG@SOIC8 [(SA602A)]	Z8F0123SB005SC@SOIC8 [(SA602A)]
Z8F0123SB005SG@SOIC8 [(SA602A)]	Z8F012APB020EC
Z8F012APB020EG	Z8F012APB020SC
Z8F012APB020SG	Z8F012AQB020EC@QFN8 [(SA683)]
Z8F012AQB020EG@QFN8 [(SA683)]	Z8F012AQB020SC@QFN8 [(SA683)]
Z8F012AQB020SG@QFN8 [(SA683)]	Z8F012ASB020EC@SOIC8 [(SA602A)]
Z8F012ASB020EG@SOIC8 [(SA602A)]	Z8F012ASB020SC@SOIC8 [(SA602A)]
Z8F012ASB020SG@SOIC8 [(SA602A)]	Z8F0213PB005EC
Z8F0213PB005EG	Z8F0213PB005SC
Z8F0213PB005SG	Z8F0213QB005EC@QFN8 [(SA683)]
Z8F0213QB005EG@QFN8 [(SA683)]	Z8F0213QB005SC@QFN8 [(SA683)]
Z8F0213QB005SG@QFN8 [(SA683)]	Z8F0213SB005EC@SOIC8 [(SA602A)]
Z8F0213SB005EG@SOIC8 [(SA602A)]	Z8F0213SB005SC@SOIC8 [(SA602A)]
Z8F0213SB005SG@SOIC8 [(SA602A)]	Z8F021APB020EC
Z8F021APB020EG	Z8F021APB020SC
Z8F021APB020SG	Z8F021AQB020EC@QFN8 [(SA683)]
Z8F021AQB020EG@QFN8 [(SA683)]	Z8F021AQB020SC@QFN8 [(SA683)]
Z8F021AQB020SG@QFN8 [(SA683)]	Z8F021ASB020EC@SOIC8 [(SA602A)]
Z8F021ASB020EG@SOIC8 [(SA602A)]	Z8F021ASB020SC@SOIC8 [(SA602A)]
Z8F021ASB020SG@SOIC8 [(SA602A)]	Z8F0223PB005EC
Z8F0223PB005EG	Z8F0223PB005SC
Z8F0223PB005SG	Z8F0223QB005EC@QFN8 [(SA683)]
Z8F0223QB005EG@QFN8 [(SA683)]	Z8F0223QB005SC@QFN8 [(SA683)]
Z8F0223QB005SG@QFN8 [(SA683)]	Z8F0223SB005EC@SOIC8 [(SA602A)]
Z8F0223SB005EG@SOIC8 [(SA602A)]	Z8F0223SB005SC@SOIC8 [(SA602A)]
Z8F0223SB005SG@SOIC8 [(SA602A)]	Z8F022APB020EC
Z8F022APB020EG	Z8F022APB020SC
Z8F022APB020SG	Z8F022AQB020EC@QFN8 [(SA683)]
Z8F022AQB020EG@QFN8 [(SA683)]	Z8F022AQB020SC@QFN8 [(SA683)]
Z8F022AQB020SG@QFN8 [(SA683)]	Z8F022ASB020EC@SOIC8 [(SA602A)]
Z8F022ASB020EG@SOIC8 [(SA602A)]	Z8F022ASB020SC@SOIC8 [(SA602A)]
Z8F022ASB020SG@SOIC8 [(SA602A)]	Z8F0413PB005EC
Z8F0413PB005EG	Z8F0413PB005SC
Z8F0413PB005SG	Z8F0413QB005EC@QFN8 [(SA683)]
Z8F0413QB005EG@QFN8 [(SA683)]	Z8F0413QB005SC@QFN8 [(SA683)]
Z8F0413QB005SG@QFN8 [(SA683)]	Z8F0413SB005EC@SOIC8 [(SA602A)]

Z8F0413SB005EG@SOIC8 [(SA602A)]	Z8F0413SB005SC@SOIC8 [(SA602A)]
Z8F0413SB005SG@SOIC8 [(SA602A)]	Z8F041APB020EC
Z8F041APB020EG	Z8F041APB020SC
Z8F041APB020SG	Z8F041AQB020EC@QFN8 [(SA683)]
Z8F041AQB020EG@QFN8 [(SA683)]	Z8F041AQB020SC@QFN8 [(SA683)]
Z8F041AQB020SG@QFN8 [(SA683)]	Z8F041ASB020EC@SOIC8 [(SA602A)]
Z8F041ASB020EG@SOIC8 [(SA602A)]	Z8F041ASB020SC@SOIC8 [(SA602A)]
Z8F041ASB020SG@SOIC8 [(SA602A)]	Z8F0423PB005EC
Z8F0423PB005EG	Z8F0423PB005SC
Z8F0423PB005SG	Z8F0423QB005EC@QFN8 [(SA683)]
Z8F0423QB005EG@QFN8 [(SA683)]	Z8F0423QB005SC@QFN8 [(SA683)]
Z8F0423QB005SG@QFN8 [(SA683)]	Z8F0423SB005EC@SOIC8 [(SA602A)]
Z8F0423SB005EG@SOIC8 [(SA602A)]	Z8F0423SB005SC@SOIC8 [(SA602A)]
Z8F0423SB005SG@SOIC8 [(SA602A)]	Z8F042APB020EC
Z8F042APB020EG	Z8F042APB020SC
Z8F042APB020SG	Z8F042AQB020EC@QFN8 [(SA683)]
Z8F042AQB020EG@QFN8 [(SA683)]	Z8F042AQB020SC@QFN8 [(SA683)]
Z8F042AQB020SG@QFN8 [(SA683)]	Z8F042ASB020EC@SOIC8 [(SA602A)]
Z8F042ASB020EG@SOIC8 [(SA602A)]	Z8F042ASB020SC@SOIC8 [(SA602A)]
Z8F042ASB020SG@SOIC8 [(SA602A)]	Z8F0813PB005EC
Z8F0813PB005EG	Z8F0813PB005SC
Z8F0813PB005SG	Z8F0813QB005EC@QFN8 [(SA683)]
Z8F0813QB005EG@QFN8 [(SA683)]	Z8F0813QB005SC@QFN8 [(SA683)]
Z8F0813QB005SG@QFN8 [(SA683)]	Z8F0813SB005EC@SOIC8 [(SA602A)]
Z8F0813SB005EG@SOIC8 [(SA602A)]	Z8F0813SB005SC@SOIC8 [(SA602A)]
Z8F0813SB005SG@SOIC8 [(SA602A)]	Z8F081APB020EC
Z8F081APB020EG	Z8F081APB020SC
Z8F081APB020SG	Z8F081AQB020EC@QFN8 [(SA683)]
Z8F081AQB020EG@QFN8 [(SA683)]	Z8F081AQB020SC@QFN8 [(SA683)]
Z8F081AQB020SG@QFN8 [(SA683)]	Z8F081ASB020EC@SOIC8 [(SA602A)]
Z8F081ASB020EG@SOIC8 [(SA602A)]	Z8F081ASB020SC@SOIC8 [(SA602A)]
Z8F081ASB020SG@SOIC8 [(SA602A)]	Z8F0823PB005EC
Z8F0823PB005EG	Z8F0823PB005SC
Z8F0823PB005SG	Z8F0823QB005EC@QFN8 [(SA683)]
Z8F0823QB005EG@QFN8 [(SA683)]	Z8F0823QB005SC@QFN8 [(SA683)]
Z8F0823QB005SG@QFN8 [(SA683)]	Z8F0823SB005EC@SOIC8 [(SA602A)]
Z8F0823SB005EG@SOIC8 [(SA602A)]	Z8F0823SB005SC@SOIC8 [(SA602A)]
Z8F0823SB005SG@SOIC8 [(SA602A)]	Z8F082APB020EC
Z8F082APB020EG	Z8F082APB020SC
Z8F082APB020SG	Z8F082AQB020EC@QFN8 [(SA683)]
Z8F082AQB020EG@QFN8 [(SA683)]	Z8F082AQB020SC@QFN8 [(SA683)]
Z8F082AQB020SG@QFN8 [(SA683)]	Z8F082ASB020EC@SOIC8 [(SA602A)]
Z8F082ASB020EG@SOIC8 [(SA602A)]	Z8F082ASB020SC@SOIC8 [(SA602A)]
Z8F082ASB020SG@SOIC8 [(SA602A)]	

ZMD

E (E) PROM / FRAM / NVRAM

U62256	U6264
U6264@SOIC28 [(SA630)]	U6264A
U6264A@SOIC28 [(SA630)]	U62H256A@SOIC28 [(SA630)]
U62H256S@SOIC28 [(SA630)]	U62H64SA@SOIC28 [(SA630)]
U630H16	U630H16@SOIC28 [(SA630)]
U630H64	U630H64@SOIC28 [(SA630)]
U631H16	U631H16@SOIC24 [(SA404)]
U631H16@SOIC28 [(SA630)]	U631H256
U631H256@SOIC28 [(SA630)]	U631H64
U631H64@SOIC28 [(SA630)]	U632H16
U632H16@SOIC28 [(SA630)]	U632H64
U632H64@SOIC28 [(SA630)]	U634H256
U634H256@SOIC32 [(SA630)]	U635H16
U635H16@SOIC24 [(SA404)]	U635H256
U635H256@SOIC28 [(SA630)]	U635H64
U635H64@SOIC28 [(SA630)]	U63716
U637256	U63764
U637H256	UL62H256A@SOIC28 [(SA630)]
UL631H256@SOIC28 [(SA630)]	UL631H256@TSOP32 [(SA410T)]
UL634H256@SOIC32 [(SA630)]	UL634H256@TSOP32 [(SA410T)]
UL635H256@SOIC28 [(SA630)]	UL635H256@TSOP32 [(SA410T)]